Form Number 3350-634

LAWN-BOY®

Gold Series® Lawnmower

Model No. 10656 - 240000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© Lawn-Boy Inc. - 2004
All Rights Reserved

Contents

Description	Page
Deck, Side Chute, and Rear Door Assembly	3
RWD Front Axle Assembly	4
RWD Rear Axle and Transmission Assembly	5
Transmission Assembly 106-3956	6
Engine and Blade Assembly	7
P2P Handle Assembly	8
Electric Start Assembly	9
Rear Bag Assembly	10
Cylinder Barrel Assembly Honda Model No. GCV160AR3A1	11
Oil Pan Assembly Honda Model No. GCV160AR3A1	12
Crankshaft Assembly Honda Model No. GCV160AR3A1	13
Piston and Connecting Rod Assembly Honda Model No. GCV160AR3A1	14
Camshaft Assembly Honda Model No. GCV160AR3A1	15
Recoil Starter Assembly Honda Model No. GCV160AR3A1	16
Fan Cover Assembly Honda Model No. GCV160AR3A1	17
Carburetor Assembly Honda Model No. GCV160AR3A1	18
Air Cleaner Assembly Honda Model No. GCV160AR3A1	19
Muffler Assembly Honda Model No. GCV160AR3A1	20
Flywheel Assembly Honda Model No. GCV160AR3A1	21
Starter Motor Assembly Honda Model No. GCV160AR3A1	22
Control Assembly Honda Model No. GCV160AR3A1	23
Choke Base Assembly Honda Model No. GCV160AR3A1	24
Top Cover Assembly Honda Model No. GCV160AR3A1	25
Label Assembly Honda Model No. GCV160AR3A1	26

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR	as required
ASM	assembly
CARR	carriage
DEG	degrees
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HHFTF	hex head flange thread forming
HJ	hex jam
HLH	hex lag head
HOC	height-of-cut
HS	hex
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming
HYD	hydraulic
INC	incorporated
LH	left hand
NI	nylon insert
PPH	phillips pan head
PTH	phillips truss head
PTO	power take off
RH	right hand
SFH	slotted fillister head
SHH	slotted hex head
SHWH	slotted hex washer head
SPH	slotted pan head
SQH	square head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	torx truss head
WH	wing head

Footnotes

❶ Not illustrated

❷ Not serviced separately


❸ Obtain parts from your local Honda dealer.



Deck, Side Chute, and Rear Door Assembly


Ref	Part No.	Qty.	Description
1	322-3	4	Screw-HH
2	105-1808-03	2	Plate-Hoc, Front
3	104-8694-03	1	Baffle-Front
4	3296-29	8	Nut-Lock, NI
5	106-8343	1	Housing ASM
5:1	105-6838	1	Decal-Danger
7	32128-32	2	Nut-HHF
8	3229-11	2	Screw-CARR
9	99-5293	1	Spring-Torsion
10	99-5292	1	Bracket-Cover
11	99-5291	1	Rod-Cover
12	105-3028	1	Chute-Side Discharge
13	106-8394	1	Discharge Door ASM
13:2	107-0795	1	Latch-Door
13:3	107-7456	1	Cap-Door
13:4	107-7461	1	Screw-Plastite
15	32112-6	1	Pushnut
16	107-0790	1	RH Rear HOC Plate ASM
18	105-3032	1	Spring-Door, Rear
19	106-8389	1	Door ASM-Service
19:1	106-8388	1	Decal-Warning, Door
22	46-6810	1	Screw And Washer ASM
23	46-8091	2	Screw-HWH
24	105-1842	1	Plug-Discharge, Rear

Ref	Part No.	Qty.	Description
25	105-1827	1	Rod-Pivot, Rear Door
27	104-9369	1	Plug-Dome
28	107-0783	1	LH Rear HOC Plate ASM
29	105-3006	4	Washer-Stepped
30	105-1834	1	Baffle-Rear



RWD Front Axle Assembly


Ref	Part No.	Qty.	Description
1	614650	2	Bolt-Shoulder
2	107-1916	2	8in Wheel ASM
3	322-6	2	Screw-HH
4	40-1940	2	Washer
5	105-3048	2	Washer-Flat
6	105-1807	2	Arm-Pivot, Front
7	105-1809	2	Arm-Spring
8	107-1904	2	Knob-Lever, HOC
9	105-1818	2	Bushing-Mount, HOC
10	3296-29	2	Nut-Lock, NI
11	46-8091	1	Screw-HWH
13	105-3005	1	Cover-Belt Opening
15	105-6849	3	Screw-Thread Forming
16	107-1908	1	Bumper-Wpm
17	105-6828	2	Screw
18	107-3764	1	Decal-Housing
19	107-3763	1	Decal-Housing



RWD Rear Axle and Transmission Assembly


Ref	Part No.	Qty.	Description
1	614650	2	Bolt-Shoulder
2	107-1918	2	Wheel Gear Asm, 8-Inch
2:3:1	27-6250	2	Bushing
3	65-2720	4	Klipring-Locking
4	105-3040	2	Gear-Pinion, 15t
5	614426	2	Washer-Stepped
6	105-6840	6	Washer-Thrust
7	107-1919	2	Cover-Wheel
8	32151-36	2	Ring-Retaining
9	105-1819	2	Arm-Pivot, Rear
10	105-1809	2	Arm-Spring
11	107-1904	2	Knob-Lever, HOC
12	104-8698	2	Retainer-Bearing, HOC
13	104-8699	2	Bearing-Ball
14	39-9650	2	Spring-Compression
15	612066	2	Key
16	106-3956	1	Transmission ASM
17	105-6814	1	Washer-Shield
18	105-1832-03	1	Bracket-Pivot
19	32144-4	2	Screw-HWH
20	92-5791	1	Spacer
21	100-1176	2	Pulley-Half
22	91-2258	1	V-Belt
23	3256-24	1	Washer-Flat

Ref	Part No.	Qty.	Description
24	3296-5	1	Nut-Lock, NI
25	105-1811	1	Brace-HOC Plate
26	105-1843	1	Shield-Trailing
28	322-6	4	Screw-HH
29	3229-11	2	Screw-CARR
30	3296-16	2	Nut-Lock, NI
31	36-4780	1	Washer




Transmission Assembly 106-3956

Ref	Part No.	Qty.	Description
1	32144-4	4	Screw-HWH
2	3285-19	1	Pin-Groove
3	36-4780	1	Washer
4	92-5790	1	Pinion
5	100-1048	1	Bearing-Ball
6	104-8671	1	Gear-Bevel, 37t
7	106-3957	1	Shaft-Output
8	104-8673	2	Bushing-Shaft, Output
9	104-8674	1	Gearcase-Upper
10	104-8675-03	1	Cover-Gearcase
11	105-6839	1	Gasket-Gearcase



Engine and Blade Assembly


Ref	Part No.	Qty.	Description
1	105-8579	1	Bolt-Blade
❷2		1	Engine-Gcv 160, Es Honda Model No. Gcv160ar3a1
3	105-3029-03	1	Support-Blade
4	104-8697-03	1	Blade-22 Inch
5	106-3987	1	Blade Driver ASM
6	95-1726	3	Screw-Taptite
7	106-3999	1	Spacer-Driver
8	105-3030-03	1	Guide-Belt
9	105-1835	1	Cover-Belt, Rear
10	46-8091	3	Screw-HWH
12	92-1701	1	Stop-Rope
20	107-3760	1	Decal-Recoil



P2P Handle Assembly


Ref	Part No.	Qty.	Description
1	107-1902	1	Cable-Brake
2	92-2260	2	Screw-Handle
3	106-4161	2	Knob-Handle
4	3296-73	2	Nut-Lock, NI
5	106-8331	1	Anchor-Cable
6	107-1935	1	Guide-Rope
7	105-6841	2	Guide-RH
8	104-8680-05	1	Handle-Upper
9	104-8690	1	Spring-Torsion
10	106-8337	1	Handle-Control, Gray
11	106-8390	1	Decal-Handle
12	104-8679-03	1	Bail-Brake
13	99-1588	1	Bar-Control, Traction
14	99-1589	1	Lever-Traction
15	105-6842	2	Guide-LH
16	321-50	1	Screw-HH
17	92-7729	1	Anchor-Cable, Upper
18	3256-1	2	Washer-Flat
19	107-0784-05	1	Handle-Lower
20	105-1844	1	Cable-Traction
21	106-6805	2	Guide-Cable
22	614249	1	Strap-Tie
24	107-0768	1	Release Lever ASM
25	106-8345	1	Handle-Recoil

Ref	Part No.	Qty.	Description
26	107-7472	1	Spring-Torsion




Electric Start Assembly

Ref	Part No.	Qty.	Description
1	107-3757	1	Box-Battery
2	104-7648	2	Screw-Tek
3	107-3758	1	Cover-Battery
4	700918	1	Key
5	46-5780	1	Switch-Starter
5:1	3254-5	1	Washer-Tooth
5:2	218-461	1	Nut-HH
6	104-8692	1	Mount-Switch
7	106-8395	1	Harness-Wire
8	104-7401	1	Charger-12 Volt
11	104-7953	1	Decal-Harness
12	614249	2	Strap-Tie
15	106-8397	1	Battery-12 Volt
16	107-3774	1	Foam-Battery, Top
❶19	99-6124	2	Fuse-40 Amp
❶99	3256-51	1	Washer-Flat
❶99	47-2830	1	Metric Screw



Rear Bag Assembly


Ref	Part No.	Qty.	Description
1	106-8392	1	Grass Bag ASM
2	105-6831-03	1	Brace-Bag Frame ASM
3	107-1905	1	Handle-Bag, Top
4	107-1906	1	Handle-Bag, Bottom
5	32144-111	2	Screw-PPH



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Cylinder Barrel Assembly
Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
❸1	12000-Z0L-405	1	Cylinder Asm.
❸3	12311-ZL8-000	1	Cover, Head
❸4	12355-ZL8-000	1	Cover, Breather (Breather Valve Asm.)
❸5	90013-883-000	4	Bolt-Flange
❸6	90014-952-000	1	Bolt, Flange (6x14)
❸7	91201-ZL8-003	1	Oil Seal (25.4x62x6)
❸8	98079-56846	1	Spark Plug (Bpr6es) (Ngk)




PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Oil Pan Assembly
Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
❸1	11300-ZM0-811	1	Pan Asm., Oil
❸2	15650-Z0L-820	1	Gauge Asm., Oil Level
❸4	15625-ZE6-000	1	Gasket, Oil Filler Cap
❸5	15631-Z0L-820	1	Extension, Oil Filler
❸6	15639-ZM0-000	1	Washer, Extension Lock
❸8	16508-ZM0-010	1	Shaft, Governor Holder
❸9	16510-ZM0-010	1	Governor Asm.
❸10	16511-ZL8-000	2	Weight, Governor
❸11	16512-ZM0-000	1	Holder, Governor Weight
❸12	16513-ZE1-000	2	Pin, Governor Weight
❸13	16531-ZE1-000	1	Slider, Governor
❸14	16541-ZM0-000	1	Shaft, Governor Arm
❸15	90014-952-000	1	Bolt, Flange (6x14)


Ref	Part No.	Qty.	Description
❸16	90121-952-000	8	Bolt, Flange (6x25)
❸17	90451-ZE1-000	1	Washer, Thrust (6mm)
❸18	90602-ZE1-000	1	Clip-Governor Holder
❸19	91202-ZL8-003	1	Oil Seal (28x41.25x6)
❸21	94101-06800	1	Washer
❸22	94251-08000	1	Pin, Lock (8mm)
❸23	94301-08200	2	Pin, Dowel (8x20)



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Crankshaft Assembly
Honda Model No. GCV160AR3A1


Ref	Part No.	Qty.	Description
❸5	90402-ZL8-000	1	Washer, Thrust
❸9	13310-Z0L-V70	1	Crankshaft



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Piston and Connecting Rod Assembly
Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
❸1	13101-ZL8-000	1	Piston
❸2	13111-ZE0-000	1	Pin, Piston
❸3	13200-ZL8-000	1	Rod Asm., Connecting
❸4	90001-ZE1-000	2	Bolt, Connecting Rod
❸5	90551-ZE0-000	2	Clip, Piston Pin (13mm)
❸6	13010-ZL8-003	1	Ring Set, Piston (Riken)
❸	13010-ZL8-024	1	Ring Set, Piston (Teikoku)





PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Camshaft Assembly
Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
❸1	14320-ZL8-010	1	Pulley, Camshaft
❸2	14324-ZL8-000	1	Shaft, Cam Pulley
❸3	14400-Z0J-014	1	Belt, Timing (84hu7 G-
❸4	14431-Z0J-000	1	Arm, In. Valve Rocker
❸5	14441-Z0J-000	1	Arm, Ex. Valve Rocker
❸6	14461-ZL8-000	2	Shaft, Rocker Arm
❸7	14711-ZL8-000	1	Valve, In.
❸8	14721-ZL8-000	1	Valve, Ex.
❸9	14751-ZL8-000	2	Spring, Valve
❸10	14771-Z0J-000	2	Retainer, Valve Spring
❸11	90012-333-000	2	Screw, Tappet Adj.
❸12	90206-001-000	2	Nut, Tappet Adj.
❸13	91301-ZM0-V31	1	O-Ring (6.8x1.9)

Ref	Part No.	Qty.	Description
❸14	12209-ZM0-003	1	Seal, Valve Stem






PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Recoil Starter Assembly
Honda Model No. GCV160AR3A1


Ref	Part No.	Qty.	Description
❸9	28462-Z0L-V71	1	Rope, Recoil Starter
❸11	90201-ZM0-000	3	Nut, Flange (6mm)
❸13	28400-Z0L-V70	1	Starter Asm., Recoil
❸15	66871-KY2-700	3	Nut, Cowl (Upper)
❸16	28461-Z0L-V71	1	Knob, Recoil Starter



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Fan Cover Assembly
Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
❸1	16854-ZH8-000	1	Rubber-Supporter (107mm)
❸2	16950-ZG9-M03	1	Petcock Asm.
❸3	16956-ZG9-M00	1	Bracket, Petcock
❸4	17620-ZL8-013	1	Cap Asm., Fuel Tank
❸5	17702-ZM0-000	1	Tube, Fuel
❸6	19610-Z0L-830ZA	1	Cover, Fan *nh1* (Black)
❸8	91501-Z0L-800	1	Collar, Fuel Petcock
❸9	90043-ZL8-000	3	Bolt, Stud
❸10	93891-05010-08	1	Screw-Washer (5x10)
❸11	17701-Z0L-000	1	Tube, Fuel Tank
❸12	95002-02080	1	Clip-Tube (B8)
❸13	95002-02100	2	Clip, Tube (B10)
❸14	95002-50000	1	Clip, Tube (C9)




PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Carburetor Assembly
Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
❸1	16010-883-015	1	Gasket Set
❸2	16013-ZL1-003	1	Float Set
❸3	16015-887-782	1	Chamber Set, Float
❸5	16028-ZE0-005	1	Screw Set B
❸7	16100-Z0L-801	1	Carburetor Asm. (Bb62g A)
❸8	16155-ZM0-003	1	Valve, Float
❸9	16166-ZM0-003	1	Nozzle, Main
❸10	16211-ZL8-000	1	Insulator, Carburetor
❸11	16212-ZL8-000	1	Gasket, Insulator
❸12	16221-883-800	2	Gasket, Carburetor
❸13	16228-ZL8-000	1	Gasket, Carburetor (Choke Side)
❸14	19650-ZM0-000	1	Guide, Air
❸15	93500-05006-0H	1	Screw, Pan (5x6)


Ref	Part No.	Qty.	Description
❸16	99101-124-0600	1	Jet, Main (#60)
❸	99101-124-0620	1	Jet, Main (#62)
❸	99101-124-0650	1	Jet, Main (#65)
❸17	16024-ZE1-811	1	Screw Set-Drain



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Air Cleaner Assembly
Honda Model No. GCV160AR3A1


Ref	Part No.	Qty.	Description
❸1	15721-ZM0-000	1	Tube, Breather
❸2	17211-ZL8-013	1	Element, Air Cleaner
❸3	17220-ZM0-000	1	Case Asm., Air Cleaner
❸5	17228-ZM0-000	1	Gasket, Air Cleaner
❸6	17231-Z0L-020	1	Cover, Air Cleaner
❸7	90003-ZM0-000	2	Bolt, Flange (6x86) (Ct200)
❸8	95701-06014-08	1	Bolt, Flange (6x14)



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIS, MAY NOT APPLY TO THIS MODEL.

Muffler Assembly
Honda Model No. GCV160AR3A1


Ref	Part No.	Qty.	Description
❸1	18310-ZM0-000	1	Muffler
❸2	18321-Z0L-J00	1	Protector, Muffler (Cbu)
❸3	90004-ZL8-000	2	Bolt, Flange (6x79) (Ct200)
❸4	90013-883-000	3	Bolt-Flange
❸5	18381-ZL8-305	1	Gasket, Muffler
❸9	18350-ZL8-000	1	Arrester, Spark
❸10	18356-ZL8-000	1	Plate, Arrester Number
❸11	90055-ZE1-000	1	Screw-Tapping (4x6)



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Flywheel Assembly
Honda Model No. GCV160AR3A1


Ref	Part No.	Qty.	Description
❸1	13331-357-000	1	Key, Special Woodruff (25x18)
❸3	30500-Z0J-003	1	Coil Asm., Ignition
❸5	32195-Z0L-820	1	Wire, Stop Switch
❸8	75113-ZM0-000	1	Spring, Brake Lever
❸10	90014-952-000	1	Bolt, Flange (6x14)
❸11	90002-Z0L-820	1	Bolt, Flange (6x23) (Ct200)
❸12	90022-888-010	1	Bolt, Flange (6x20) (Ct200)
❸13	90201-878-003	1	Nut, Special (14mm)
❸14	90681-959-003	1	Clip, Cable (A)
❸22	31105-Z0L-820	1	Flywheel Asm.
❸23	75110-Z0L-820	1	Brake Sub-Asm.



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Starter Motor Assembly
Honda Model No. GCV160AR3A1


Ref	Part No.	Qty.	Description
❸1	22534-Z0L-820	1	Holder, Wire
❸2	30549-Z0L-820	1	Clamp, Wire
❸3	31200-Z0L-821	1	Motor Asm., Starter
❸4	32222-Z0L-820	1	Wire, Terminal Ground
❸5	90001-Z0L-820	2	Bolt, Special (6mm)
❸6	90013-883-000	2	Bolt-Flange
❸7	93500-05008-0A	1	Screw, Pan (5x8)



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Control Assembly
Honda Model No. GCV160AR3A1


Ref	Part No.	Qty.	Description
❸1	16551-ZM0-010	1	Arm, Governor
❸2	16555-Z0L-800	1	Rod, Governor
❸3	16561-Z0L-000	1	Spring, Governor
❸4	16562-ZM0-000	1	Spring, Throttle Return
❸6	16580-Z0L-810	1	Base, Control
❸12	90015-ZE5-010	1	Bolt-Governor Arm
❸13	90016-ZE8-000	1	Bolt, Flange (6x45)
❸15	94050-06000	1	Nut-Flange (6mm)



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Choke Base Assembly
Honda Model No. GCV160AR3A1


Ref	Part No.	Qty.	Description
❸1	16251-Z0L-800	1	Seal, Choke Lever
❸2	16592-ZJ1-000	1	Spring, Cable Return
❸3	16612-Z0L-800	1	Lever, Choke
❸4	16613-Z0L-800	1	Base, Choke
❸5	16614-Z0L-800	1	Spring, Choke Lever
❸6	16616-Z0L-800	1	Hook, Choke Spring
❸7	16619-Z0L-800	1	Plate, Choke
❸8	16632-Z0L-800	1	Rod, Stop
❸9	90029-888-000	1	Bolt, Flange (6x16)
❸10	90102-SP1-003	1	Screw, Tapping (4x8) (Po)
❸11	90141-KT8-000	1	Screw, Pan (5x19)
❸12	93500-04008-0H	1	Screw, Pan (4x8)
❸13	94050-05000	1	Nut, Flange (5mm)



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLE TO THIS MODEL.

Top Cover Assembly
Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
❸1	16613-883-610	2	Grommet, Choke Rod
❸2	19721-Z0L-000ZA	1	Cover, Top *nh1* (Black)
❸3	90137-SH3-000	3	Screw, Tapping (4x16)



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Label Assembly
Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
❸1	87101-ZM0-010	1	Emblem (Gcv160 5.5)
❸9	87528-Z0L-800	1	Mark, Choke Indication
❸15	87601-Z0L-E70	1	Mark, Type (R3a1)

NOTES

LAWN-BOY®