

LAWN-BOY®

Gold Series® Lawnmower

Model No. 10656 - 240000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Deck, Side Chute, and Rear Door Assembly 3	Carburetor Assembly Honda Model No. GCV160AR3A1 18
RWD Front Axle Assembly 4	Air Cleaner Assembly Honda Model No. GCV160AR3A1 19
RWD Rear Axle and Transmission Assembly 5	Muffler Assembly Honda Model No. GCV160AR3A1 20
Transmission Assembly 106-3956 6	Flywheel Assembly Honda Model No. GCV160AR3A1 21
Engine and Blade Assembly 7	Starter Motor Assembly Honda Model No. GCV160AR3A1 22
P2P Handle Assembly 8	Control Assembly Honda Model No. GCV160AR3A1 23
Electric Start Assembly 9	Choke Base Assembly Honda Model No. GCV160AR3A1 24
Rear Bag Assembly 10	Top Cover Assembly Honda Model No. GCV160AR3A1 25
Cylinder Barrel Assembly Honda Model No. GCV160AR3A1 11	Label Assembly Honda Model No. GCV160AR3A1 26
Oil Pan Assembly Honda Model No. GCV160AR3A1 12		
Crankshaft Assembly Honda Model No. GCV160AR3A1 13		
Piston and Connecting Rod Assembly Honda Model No. GCV160AR3A1 14		
Camshaft Assembly Honda Model No. GCV160AR3A1 15		
Recoil Starter Assembly Honda Model No. GCV160AR3A1 16		
Fan Cover Assembly Honda Model No. GCV160AR3A1 17		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	INC. incorporated
ASM. assembly	LH. left hand
CARR. carriage	NI. nylon insert
DEG. degrees	PPH. phillips pan head
FH. flat head	PTH. phillips truss head
GA. gauge	PTO. power take off
HF. hex flange	RH. right hand
HH. hex head	SFH. slotted fillister head
HHF. hex head flange	SHH. slotted hex head
HHFTF. hex head flange thread forming	SHWH. slotted hex washer head
HJ. hex jam	SPH. slotted pan head
HLH. hex lag head	SQH. square head
HOC. height-of-cut	SRH. slotted round head
HS. hex	STD. standard
HSBH. hex socket button head	TAP. self tapping
HSFH. hex socket flat head	TTH. torx truss head
HSH. hex socket head	WH. wing head
HWH. hex washer head	
HWHTF. hex washer head thread forming	
HYD. hydraulic	

Footnotes


- ❶ Not illustrated
- ❷ Not serviced separately
- ❸ Obtain parts from your local Honda dealer.



Deck, Side Chute, and Rear Door Assembly

Ref	Part No.	Qty.	Description
1	322-3	4	Screw-HH
2	105-1808-03	2	Plate-Hoc, Front
3	104-8694-03	1	Baffle-Front
4	3296-29	8	Nut-Lock, NI
5	106-8343	1	Housing ASM
5:1	105-6838	1	Decal-Danger
7	32128-32	2	Nut-HHF
8	3229-11	2	Screw-CARR
9	99-5293	1	Spring-Torsion
10	99-5292	1	Bracket-Cover
11	99-5291	1	Rod-Cover
12	105-3028	1	Chute-Side Discharge
13	106-8394	1	Discharge Door ASM
13:2	107-0795	1	Latch-Door
13:3	107-7456	1	Cap-Door
13:4	107-7461	1	Screw-Plastite
15	32112-6	1	Pushnut
16	107-0790	1	RH Rear HOC Plate ASM
18	105-3032	1	Spring-Door, Rear
19	106-8389	1	Door ASM-Service
19:1	106-8388	1	Decal-Warning, Door
22	46-6810	1	Screw And Washer ASM
23	46-8091	2	Screw-HWH
24	105-1842	1	Plug-Discharge, Rear


Ref	Part No.	Qty.	Description
25	105-1827	1	Rod-Pivot, Rear Door
27	104-9369	1	Plug-Dome
28	107-0783	1	LH Rear HOC Plate ASM
29	105-3006	4	Washer-Stepped
30	105-1834	1	Baffle-Rear



RWD Front Axle Assembly

Ref	Part No.	Qty.	Description
1	614650	2	Bolt-Shoulder
2	107-1916	2	8in Wheel ASM
3	322-6	2	Screw-HH
4	40-1940	2	Washer
5	105-3048	2	Washer-Flat
6	105-1807	2	Arm-Pivot, Front
7	105-1809	2	Arm-Spring
8	107-1904	2	Knob-Lever, HOC
9	105-1818	2	Bushing-Mount, HOC
10	3296-29	2	Nut-Lock, NI
11	46-8091	1	Screw-HWH
13	105-3005	1	Cover-Belt Opening
15	105-6849	3	Screw-Thread Forming
16	107-1908	1	Bumper-Wpm
17	105-6828	2	Screw
18	107-3764	1	Decal-Housing
19	107-3763	1	Decal-Housing


--	--	--	--



RWD Rear Axle and Transmission Assembly


Ref	Part No.	Qty.	Description
1	614650	2	Bolt-Shoulder
2	107-1918	2	Wheel Gear Asm, 8-Inch
2:3:1	27-6250	2	Bushing
3	65-2720	4	Klipring-Locking
4	105-3040	2	Gear-Pinion, 15t
5	614426	2	Washer-Stepped
6	105-6840	6	Washer-Thrust
7	107-1919	2	Cover-Wheel
8	32151-36	2	Ring-Retaining
9	105-1819	2	Arm-Pivot, Rear
10	105-1809	2	Arm-Spring
11	107-1904	2	Knob-Lever, HOC
12	104-8698	2	Retainer-Bearing, HOC
13	104-8699	2	Bearing-Ball
14	39-9650	2	Spring-Compression
15	612066	2	Key
16	106-3956	1	Transmission ASM
17	105-6814	1	Washer-Shield
18	105-1832-03	1	Bracket-Pivot
19	32144-4	2	Screw-HWH
20	92-5791	1	Spacer
21	100-1176	2	Pulley-Half
22	91-2258	1	V-Belt
23	3256-24	1	Washer-Flat

Ref	Part No.	Qty.	Description
24	3296-5	1	Nut-Lock, NI
25	105-1811	1	Brace-HOC Plate
26	105-1843	1	Shield-Trailing
28	322-6	4	Screw-HH
29	3229-11	2	Screw-CARR
30	3296-16	2	Nut-Lock, NI
31	36-4780	1	Washer




Transmission Assembly 106-3956

Ref	Part No.	Qty.	Description				
1	32144-4	4	Screw-HWH				
2	3285-19	1	Pin-Groove				
3	36-4780	1	Washer				
4	92-5790	1	Pinion				
5	100-1048	1	Bearing-Ball				
6	104-8671	1	Gear-Bevel, 37t				
7	106-3957	1	Shaft-Output				
8	104-8673	2	Bushing-Shaft, Output				
9	104-8674	1	Gearcase-Upper				
10	104-8675-03	1	Cover-Gearcase				
11	105-6839	1	Gasket-Gearcase				



Engine and Blade Assembly


Ref	Part No.	Qty.	Description				
1	105-8579	1	Bolt-Blade				
2		1	Engine-Gcv 160, Es Honda Model No. Gcv160ar3a1				
3	105-3029-03	1	Support-Blade				
4	104-8697-03	1	Blade-22 Inch				
5	106-3987	1	Blade Driver ASM				
6	95-1726	3	Screw-Taptite				
7	106-3999	1	Spacer-Driver				
8	105-3030-03	1	Guide-Belt				
9	105-1835	1	Cover-Belt, Rear				
10	46-8091	3	Screw-HWH				
12	92-1701	1	Stop-Rope				
20	107-3760	1	Decal-Recoil				



P2P Handle Assembly

Ref	Part No.	Qty.	Description
1	107-1902	1	Cable-Brake
2	92-2260	2	Screw-Handle
3	106-4161	2	Knob-Handle
4	3296-73	2	Nut-Lock, NI
5	106-8331	1	Anchor-Cable
6	107-1935	1	Guide-Rope
7	105-6841	2	Guide-RH
8	104-8680-05	1	Handle-Upper
9	104-8690	1	Spring-Torsion
10	106-8337	1	Handle-Control, Gray
11	106-8390	1	Decal-Handle
12	104-8679-03	1	Bail-Brake
13	99-1588	1	Bar-Control, Traction
14	99-1589	1	Lever-Traction
15	105-6842	2	Guide-LH
16	321-50	1	Screw-HH
17	92-7729	1	Anchor-Cable, Upper
18	3256-1	2	Washer-Flat
19	107-0784-05	1	Handle-Lower
20	105-1844	1	Cable-Traction
21	106-6805	2	Guide-Cable
22	614249	1	Strap-Tie
24	107-0768	1	Release Lever ASM
25	106-8345	1	Handle-Recoil


Ref	Part No.	Qty.	Description
26	107-7472	1	Spring-Torsion



Electric Start Assembly

Ref	Part No.	Qty.	Description
1	107-3757	1	Box-Battery
2	104-7648	2	Screw-Tek
3	107-3758	1	Cover-Battery
4	700918	1	Key
5	46-5780	1	Switch-Starter
5:1	3254-5	1	Washer-Tooth
5:2	218-461	1	Nut-HH
6	104-8692	1	Mount-Switch
7	106-8395	1	Harness-Wire
8	104-7401	1	Charger-12 Volt
11	104-7953	1	Decal-Harness
12	614249	2	Strap-Tie
15	106-8397	1	Battery-12 Volt
16	107-3774	1	Foam-Battery, Top
❶19	99-6124	2	Fuse-40 Amp
❶99	3256-51	1	Washer-Flat
❶99	47-2830	1	Metric Screw


--	--	--	--



Rear Bag Assembly

Ref	Part No.	Qty.	Description
1	106-8392	1	Grass Bag ASM
2	105-6831-03	1	Brace-Bag Frame ASM
3	107-1905	1	Handle-Bag, Top
4	107-1906	1	Handle-Bag, Bottom
5	32144-111	2	Screw-PPH


--	--	--	--



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Cylinder Barrel Assembly Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
1	12000-Z0L-405	1	Cylinder Asm.
3	12311-ZL8-000	1	Cover, Head
4	12355-ZL8-000	1	Cover, Breather (Breather Valve Asm.)
5	90013-883-000	4	Bolt-Flange
6	90014-952-000	1	Bolt, Flange (6x14)
7	91201-ZL8-003	1	Oil Seal (25.4x62x6)
8	98079-56846	1	Spark Plug (Bpr6es) (Ngk)




PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Oil Pan Assembly Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
❶	11300-ZM0-811	1	Pan Asm., Oil
❷	15650-ZOL-820	1	Gauge Asm., Oil Level
❸	15625-ZE6-000	1	Gasket, Oil Filler Cap
❹	15631-ZOL-820	1	Extension, Oil Filler
❺	15639-ZM0-000	1	Washer, Extension Lock
❽	16508-ZM0-010	1	Shaft, Governor Holder
❾	16510-ZM0-010	1	Governor Asm.
❿	16511-ZL8-000	2	Weight, Governor
⓫	16512-ZM0-000	1	Holder, Governor Weight
⓬	16513-ZE1-000	2	Pin, Governor Weight
⓭	16531-ZE1-000	1	Slider, Governor
⓮	16541-ZM0-000	1	Shaft, Governor Arm
⓯	90014-952-000	1	Bolt, Flange (6x14)

Ref	Part No.	Qty.	Description
❶❹	90121-952-000	8	Bolt, Flange (6x25)
❶❷	90451-ZE1-000	1	Washer, Thrust (6mm)
❶❸	90602-ZE1-000	1	Clip-Governor Holder
❶❹	91202-ZL8-003	1	Oil Seal (28x41.25x6)
❶❺	94101-06800	1	Washer
❶❻	94251-08000	1	Pin, Lock (8mm)
❶❼	94301-08200	2	Pin, Dowel (8x20)




PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Crankshaft Assembly Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
5	90402-ZL8-000	1	Washer, Thrust
9	13310-Z0L-V70	1	Crankshaft


--	--	--	--



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Camshaft Assembly Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
①	14320-ZL8-010	1	Pulley, Camshaft	⑭	12209-ZM0-003	1	Seal, Valve Stem
②	14324-ZL8-000	1	Shaft, Cam Pulley				
③	14400-Z0J-014	1	Belt, Timing (84hu7 G-014)				
④	14431-Z0J-000	1	Arm, In. Valve Rocker				
⑤	14441-Z0J-000	1	Arm, Ex. Valve Rocker				
⑥	14461-ZL8-000	2	Shaft, Rocker Arm				
⑦	14711-ZL8-000	1	Valve, In.				
⑧	14721-ZL8-000	1	Valve, Ex.				
⑨	14751-ZL8-000	2	Spring, Valve				
⑩	14771-Z0J-000	2	Retainer, Valve Spring				
⑪	90012-333-000	2	Screw, Tappet Adj.				
⑫	90206-001-000	2	Nut, Tappet Adj.				
⑬	91301-ZM0-V31	1	O-Ring (6.8x1.9)				




PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Recoil Starter Assembly Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
⑨	28462-Z0L-V71	1	Rope, Recoil Starter
⑪	90201-ZM0-000	3	Nut, Flange (6mm)
⑬	28400-Z0L-V70	1	Starter Asm., Recoil
⑮	66871-KY2-700	3	Nut, Cowl (Upper)
⑯	28461-Z0L-V71	1	Knob, Recoil Starter

--	--	--	--




PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Fan Cover Assembly Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
①	16854-ZH8-000	1	Rubber-Supporter (107mm)
②	16950-ZG9-M03	1	Petcock Asm.
③	16956-ZG9-M00	1	Bracket, Petcock
④	17620-ZL8-013	1	Cap Asm., Fuel Tank
⑤	17702-ZM0-000	1	Tube, Fuel
⑥	19610-Z0L-830ZA	1	Cover, Fan *nh1* (Black)
⑧	91501-Z0L-800	1	Collar, Fuel Petcock
⑨	90043-ZL8-000	3	Bolt, Stud
⑩	93891-05010-08	1	Screw-Washer (5x10)
⑪	17701-Z0L-000	1	Tube, Fuel Tank
⑫	95002-02080	1	Clip-Tube (B8)
⑬	95002-02100	2	Clip, Tube (B10)
⑭	95002-50000	1	Clip, Tube (C9)


--	--	--	--



Carburetor Assembly Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
①	16010-883-015	1	Gasket Set
②	16013-ZL1-003	1	Float Set
③	16015-887-782	1	Chamber Set, Float
⑤	16028-ZE0-005	1	Screw Set B
⑦	16100-Z0L-801	1	Carburetor Asm. (Bb62g A)
⑧	16155-ZM0-003	1	Valve, Float
⑨	16166-ZM0-003	1	Nozzle, Main
⑩	16211-ZL8-000	1	Insulator, Carburetor
⑪	16212-ZL8-000	1	Gasket, Insulator
⑫	16221-883-800	2	Gasket, Carburetor
⑬	16228-ZL8-000	1	Gasket, Carburetor (Choke Side)
⑭	19650-ZM0-000	1	Guide, Air
⑮	93500-05006-0H	1	Screw, Pan (5x6)


Ref	Part No.	Qty.	Description
⑯	99101-124-0600	1	Jet, Main (#60)
⑰	99101-124-0620	1	Jet, Main (#62)
⑱	99101-124-0650	1	Jet, Main (#65)
⑳	16024-ZE1-811	1	Screw Set-Drain



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIS, MAY NOT APPLY TO THIS MODEL.

Muffler Assembly Honda Model No. GCV160AR3A1


Ref	Part No.	Qty.	Description				
①	18310-ZM0-000	1	Muffler				
②	18321-Z0L-J00	1	Protector, Muffler (Cbu)				
③	90004-ZL8-000	2	Bolt, Flange (6x79) (Ct200)				
④	90013-883-000	3	Bolt-Flange				
⑤	18381-ZL8-305	1	Gasket, Muffler				
⑨	18350-ZL8-000	1	Arrester, Spark				
⑩	18356-ZL8-000	1	Plate, Arrester Number				
⑪	90055-ZE1-000	1	Screw-Tapping (4x6)				



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Starter Motor Assembly Honda Model No. GCV160AR3A1


Ref	Part No.	Qty.	Description				
①	22534-Z0L-820	1	Holder, Wire				
②	30549-Z0L-820	1	Clamp, Wire				
③	31200-Z0L-821	1	Motor Asm., Starter				
④	32222-Z0L-820	1	Wire, Terminal Ground				
⑤	90001-Z0L-820	2	Bolt, Special (6mm)				
⑥	90013-883-000	2	Bolt-Flange				
⑦	93500-05008-0A	1	Screw, Pan (5x8)				



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Control Assembly Honda Model No. GCV160AR3A1


Ref	Part No.	Qty.	Description				
①	16551-ZM0-010	1	Arm, Governor				
②	16555-Z0L-800	1	Rod, Governor				
③	16561-Z0L-000	1	Spring, Governor				
④	16562-ZM0-000	1	Spring, Throttle Return				
⑥	16580-Z0L-810	1	Base, Control				
⑫	90015-ZE5-010	1	Bolt-Governor Arm				
⑬	90016-ZE8-000	1	Bolt, Flange (6x45)				
⑮	94050-06000	1	Nut-Flange (6mm)				



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Choke Base Assembly Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description				
1	16251-Z0L-800	1	Seal, Choke Lever				
2	16592-ZJ1-000	1	Spring, Cable Return				
3	16612-Z0L-800	1	Lever, Choke				
4	16613-Z0L-800	1	Base, Choke				
5	16614-Z0L-800	1	Spring, Choke Lever				
6	16616-Z0L-800	1	Hook, Choke Spring				
7	16619-Z0L-800	1	Plate, Choke				
8	16632-Z0L-800	1	Rod, Stop				
9	90029-888-000	1	Bolt, Flange (6x16)				
10	90102-SP1-003	1	Screw, Tapping (4x8) (Po)				
11	90141-KT8-000	1	Screw, Pan (5x19)				
12	93500-04008-0H	1	Screw, Pan (4x8)				
13	94050-05000	1	Nut, Flange (5mm)				



PARTS SHOWN IN ILLUSTRATION BUT NOT CALLED OUT IN PARTS LIST, MAY NOT APPLY TO THIS MODEL.

Label Assembly Honda Model No. GCV160AR3A1

Ref	Part No.	Qty.	Description
①	87101-ZM0-010	1	Emblem (Gcv160 5.5)
⑨	87528-Z0L-800	1	Mark, Choke Indication
⑮	87601-Z0L-E70	1	Mark, Type (R3a1)

--	--	--	--	--

NOTES

LAWN-BOY®