



**Count on it.**

**Parts Catalog**

**Pro Force®  
Debris Blower**

Model No. 44558—Serial No. 400000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Frame, Wheel, Axle and Hitch Assembly .....	4
Frame Assembly No. 161-7874 .....	6
Hub and Axle Assembly No. 144-3630 .....	8
Wheel and Tire Assembly No. 144-3664 .....	10
Turbine Mounting Assembly .....	12
Turbine Assembly No. 140-6946SP .....	14
Nozzle Assembly .....	16
Driveshaft and Battery Assembly .....	18
Engine, Muffler and Fuel Tank Assembly .....	20
Fuel Tank Assembly No. 115-9048 .....	22
Fuel Delivery Assembly .....	24
Tethered Control Assembly .....	26
Wire Harness Assembly No. 122-3530 .....	28
Tethered Control Assembly No. 163-0320 .....	30
Red LED Indicator Lamp Assembly No. 122-0630 .....	32
Attachments and Accessories .....	34


# Frame, Wheel, Axle and Hitch Assembly



## Frame, Wheel, Axle and Hitch Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	161-7874	1	Frame ASM Service Kit	23	119-4041	10	Nut-HF
2	119-2958-01	2	Mount-Axle	25	13-6200	1	Pin-Hitch, Pointed
3	144-3630	2	Hub Axle Assembly	26	3256-82	8	Washer-Flat
4	112-6852	2	Fender	27	92-1298	1	Pin-Lynch
5	119-4042	8	Nut-HF, NI	28	3296-48	4	Nut-Hex
6	1-543286	2	Grommet	29	3232-17	4	Screw-CARR
7	3231-2	6	Bolt-CARR	30	161-4947-01	1	Tower-Control
8	2412-133	2	Clamp-R	31	323-10	3	Screw-HH
9	104-7050	1	Tube-Manual	32	93-8806	6	Washer-Hardened
10	144-3664	2	Wheel ASM	33	32128-19	3	Nut-HF Lock, Large Flg
11	323-14	2	Screw-HH	34	121-2870	3	Mount-2 Piece
12	112-6942-01	1	Hitch	36	131-6766	1	Decal-Fuses
13	3296-53	2	Nut-Lock, NI	37	131-6703	1	Bracket-Hold Down, Electrical
14	327-23	2	Screw-HH				
15	131-4381-01	1	Hitch-Clevis	38	3334-945	1	Tie-Cable
16	104-7048	1	Cap-Housing	39	32180-030	1	Clip-Tie
20	3230-9	4	Screw-CARR	40	133-8062	1	Decal-Spark Arrestor
21	3230-2	4	Bolt-CARR	42	2412-41	1	Clamp-R
22	322-5	2	Screw-HH				

# Frame Assembly No. 161-7874




## Frame Assembly No. 161-7874 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	144-3212	1	Frame ASM
1:2	140-6767	1	Decal-Warning,Db
1:3	115-5113	1	Decal-Protection, Eye And Ear

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	145-7461-01	1	Mount-Tank, 5GA
3	3230-2	4	Bolt-CARR
4	119-4041	4	Nut-HF

# Hub and Axle Assembly No. 144-3630




## Hub and Axle Assembly No. 144-3630 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	117-5115	1	Hub And Bearing ASM
2:1	117-8251	1	Hub ASM
2:1:2	114-3918	4	Stud-Wheel
2:1:3	254-72	2	Bearing-Cup, Tapered
2:2	254-94	2	Bearing-Cone, Tapered
2:3	112-1690	1	Seal-Oil

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2:4	241-119	1	Cap-Dust
2:5	139-2564	4	Nut-Lug
3	117-8259	1	Washer-Spindle
4	117-8260	1	Nut
5	93-0307	1	Nut-Lock, Retainer
6	3272-18	1	Pin-Cotter


# Wheel and Tire Assembly No. 144-3664



## Wheel and Tire Assembly No. 144-3664 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	137-2597	1	Rim
2	232-27	1	Stem-Valve
3	144-3665	1	Tire


# Turbine Mounting Assembly



## Turbine Mounting Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	117-8329	1	Bell-Inlet	11	119-4042	4	Nut-HF, NI
2	112-1952	1	Ring-Snap, EXT	12	115-5102	2	Decal
3	93-4632	1	Washer-Wavey	13	115-7109	8	Washer-Flat
4	131-9440	1	Cap-Front	14	94-7484	1	Bearing
5	3231-24	2	Screw-CARR	14:1	302-2	2	Fitting-Grease
6	140-6946SP	1	Turbine ASM-Horizontal	14:2	106-9662	1	Screw-Set, HSH
7	119-4041	11	Nut-HF	15	144-3316-01	1	Mount-Bearing
8	140-6983-01	2	Mount-Housing	16	100-6116	2	Screw-HHF
9	3231-22	2	Screw-CARR	17	139-1689	2	Nut-HF
10	322-6	11	Screw-HH	18	3234-42	2	Screw-HHF


# Turbine Assembly No. 140-6946SP



## Turbine Assembly No. 140-6946SP (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	92-9533	1	O-Ring	11	125-4287	8	Screw-HHF
2	112-1871	24	Vane-Stator	12	117-8303	24	Screw-HWH
3	112-1899	1	Nut	13	117-8356	1	Rotor
4	112-1951	4	Ring-Snap, EXT	14	119-6202	1	Washer-Tab
5	112-6764	2	Bearing-Ball	15	161-7875	4	Screw-HHSF
6	114-2164	1	Spacer	17	145-7583	1	Inner Housing
7	140-6945	1	Housing-Horizontal, Service ASM	18	140-6933	1	End-Oring
8	115-5131	2	Washer	19	120-6061	1	Bearing-Cap
9	115-9005	1	Washer-Tab	20	120-6063	1	End-Cap
10	140-6997	1	Shaft-Fan Long	22	3257-42	1	Key-Woodruff


# Nozzle Assembly



## Nozzle Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	163-0456-01	1	Brkt-Motor, Nozzle	16:3	3296-42	1	Nut-Lock, NI
2	112-1874	1	Pulley-Nozzle	17	321-3	2	Screw-HH
3	140-6982	4	Spacer-Bearing	18	251-259	1	Bearing-Ball
4	115-6870	8	Bearing-Ball, Sealed	19	144-3274	1	Motor-Reversible
5	140-6979	4	Roller-Bearing	20	114-8414	3	Screw-HHF
6	120-9679	4	Washer-Flat	21	115-5147	1	Pulley
7	321-9	4	Screw-HH	22	98-0668	1	Nut
8	104-7201	10	Nut-HF, NI	23	140-2220-01	1	Indicator
9	112-1853	1	Belt-V	24	140-2220-07	1	Indicator
10	144-3382	1	Nozzle-Toro Proforce Trailer	25	119-6906	4	Screw-HSBH
11	112-6899	1	Clamp-Nozzle	26	140-6814-03	1	Gauge-Rotation
12	3234-29	2	Screw-HHF	27	140-2247	1	Decal-Position, Chute
13	119-4041	2	Nut-HF	28	3234-17	2	Screw-HHF
14	163-0457-01	1	Cover-Pulley	29	105-4886	5	Nut-Tinnerman
15	32104-17	1	Screw-HWH	30	140-6848	1	Motor-Cover
16	110-9650	1	Leaf Spring ASM	31	3234-42	5	Screw-HHF
16:2	36-2250	1	Bolt-Shoulder				


# Driveshaft and Battery Assembly



## Driveshaft and Battery Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-6936-03	1	Shaft-Drive, Short	12	130-8569	1	Cover-Battery
2	119-4041	8	Nut-HF	13	3290-467	2	Pin-Hair
3	322-39	4	Screw-HH	14	106-5187	1	Battery- Dry, 12V, 525 CCA
4	131-6761	8	Washer	15	3257-5	2	Key-Woodruff
5	115-5129	4	Coupling-Rubber	16	138-6335	1	Retainer-Battery
7	114-2120	2	Washer	17	3231-5	1	Screw-CARR
8	131-6763	4	Spacer-Coupling, Rubber	18	119-4042	1	Nut-HF, NI
9	131-6762	4	Spacer-Coupling, Rubber	19	130-0932-01	1	Bracket-Cover
10	322-32	4	Screw-HH	20	107069	2	Clip
11	114-2122	2	Hub-Engine	21	321-4	2	Screw-HH


# Engine, Muffler and Fuel Tank Assembly



## Engine, Muffler and Fuel Tank Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	163-0495	1	Engine-Rehlko	13	119-4041	8	Nut-HF
2	127-8685	1	Canister-Carbon	14	92-1242	2	Decal
3	66-9302	4	Screw-HHF Lock	15	115-9048	1	Fuel Tank ASM
4	119-4042	4	Nut-HF, NI	16	119-6285	2	Strap-Hold Down, Tank
5	163-0401	1	Muffler	17	104-7201	8	Nut-HF, NI
6	161-4854-03	1	Mount-Muffler	18	145-7461-01	1	Mount-Tank, 5GA
7	110-1718	4	Screw-HHSF,Patch	21	3230-2	4	Bolt-CARR
8	105-4886	2	Nut-Tinnerman	22	144-3629-03	1	Guard-Gauges
9	80-6990	2	Washer-Hardened	24	2412-138	2	R-Clamp
10	323-6	2	Screw-HH	25	3230-18	1	Screw-CARR
11	33103-012	2	Screw-HHF	26	137-4808	1	Nut-Acorn
12	112-6876	1	Grill-Top				

# Fuel Tank Assembly No. 115-9048



## Fuel Tank Assembly No. 115-9048 (continued)


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	114-0284	1	Grommet	6	137-4127	1	Cap-Fuel
3	114-0285	1	Valve-Rollover	7	119-0509	1	Gauge ASM
4	46-6560	1	Bushing	7:2	119-0508	1	Seal
5	115-9044	1	Pipe-Stand				



## Fuel Delivery Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	106-5317	3	Hose-Fuel	9	2412-80	8	Clamp-Hose
2	115-7854	1	Filter-Fuel, Inline	10	32180-030	7	Clip-Tie
3	143-2545	1	Hose-Fuel	11	119-8561	1	Hose-Fuel
4	133-8499	1	Valve-Check, Vacuum	12	106-8150	2	Fitting-Straight
5	163-0402	1	Hose-Fuel	13	92-2379	4	Clamp-Hose
6	119-6073	1	Hose-Fuel	14	120-2235	1	Filter-Fuel
7	110-3254	1	Hose-Fuel	15	110-4109	1	Hose-Fuel
8	2412-98	2	Clamp-Hose	16	3290-378	1	Tie-Cable


# Tethered Control Assembly



## Tethered Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	122-3530	1	Harness-Wire, Proforce Blower Rf2Can	10	120-2244	1	Hourmeter
2	321-8	4	Screw-HH	11	1-807512	5	Bolt-CARR
3	99-7430	5	Relay-Mini	12	163-0320	1	Tethered Control ASM
4	321-4	2	Screw-HH	13	125-1360	1	Controller
5	104-7201	11	Nut-HF, NI	14	122-0630	1	Red LED Indicator Lamp ASM
6	125-5966	1	Cable-Battery, Negative	16	32180-030	3	Clip-Tie
7	3255-8	1	Washer-Lock	18	106-9169	1	Screw-HWH
8	33104-020	1	Screw-HHF	19	3296-2	1	Nut-Lock, NI
9	122-0629	1	Cable-Battery, Positive	20	32180-201	1	Cap-Plug

# Wire Harness Assembly No. 122-3530




## Wire Harness Assembly No. 122-3530 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
12	32180-282	2	Conn, Res, 120 Ohm
13	32180-089	1	Cap-Plug, 3 Way
14	121-8861	1	Fuse-Mini Blade, 2 Amp
15	121-8865	2	Fuse-Mini Blade, 7.5 Amp
16	121-8867	1	Fuse-Mini Blade, 15 Amp

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
17	32180-179	1	Cover-Bussman
21	32180-156	1	Cap-Plug, 6 Way
22	32180-091	1	Cap-Dust, 2 Way
23	108-9493	1	Diode-Tvs


# Tethered Control Assembly No. 163-0320



## Tethered Control Assembly No. 163-0320 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	163-0319	1	Box-Control	7	2412-73	1	Clamp-R
3	163-0323	1	Decal-Tether	8	3274-69	1	Screw-HSBH
4	163-0336	1	Decal-Tether, Start	9	3296-42	1	Nut-Lock, NI
5	121-5159	1	Switch-Ignition	10	119-1105	1	Bushing
5:1	121-5160	1	Nut-Hex	11	122-3817	1	Harness-Wire, Tether
5:2	122-2704	1	Nut-Face, M22 (Plastic)	12	3274-105	1	Screw-HSBH
5:3	121-5162	1	Set-Key, Ignition	13	3296-48	1	Nut-Hex
6	122-0304	2	Switch-Rocker, (On)-Off-(On)	99	119-6243	1	Hardware Kit

# Red LED Indicator Lamp Assembly No. 122-0630



# Red LED Indicator Lamp Assembly No. 122-0630 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	122-0634	1	Gasket-LED
2	122-0633	1	Washer-Locking
3	122-0632	1	Nut-Fixing

# Attachments and Accessories

## For 44558 — Pro Force Debris Blower

<b>Product Name</b>	<b>Model/Part</b>
LED Light Kit.....	44559
10 Gallon Kit, Pro Force Debris Blower.....	130-4371
Safety Chain Kit.....	139-3179
Alignment Tool Assembly.....	161-7891
Tapered Nozzle Kit.....	119-6280
Rectangular Nozzle Kit.....	119-6281
Telematics Kit.....	163-4515
Telematics Lite Kit.....	163-4516
New Red Paint - Gallon.....	361-11
External Antenna Kit, Wireless Hourmeter System.....	115-9524
Base Station Kit, Wireless Hourmeter System.....	115-9542
Wireless Hourmeter.....	115-4754
Repeater Kit, Wireless Hourmeter System.....	115-9543
Semi-Gloss Black Spray Paint.....	361-9
Toro Red 12oz Aerosol Can.....	361-10

**Notes:**



**Count on it.**