Form Number 3350-727

Replacement Handle Kit
200 Series Z Master® with ROPS

Model No. 107-3088

Parts Catalog

Ordering Replacement Parts
To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers
Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by **6:**1, the valve by **6:**2, and the wheel by **6:**3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

PROTOTYPE

©The Toro Company - 2003
All Rights Reserved



Dump Arm Assembly

Ref	Part No.	Qty.	Description
1	106-8955-03	1	Dump Arm ASM
2	108143	1	Clevis-Long
3	108145	1	Clevis-Short
4	3290-378	1	Tie-Cable
5	107-3078	1	Cable
6	3272-1	1	Pin-Cotter
7	9321204	1	Pin-Clevis
8	107-3091	1	Plate-Stop
9	104-9838	1	Grip-Foam
10	325-19	2	Screw-HH
11	325-20	2	Screw-HH
12	105-9741	4	Weight-Top, 200

PROTOTYPE