Form Number 3350-731

Mid-Size ProLine T-Bar Gear
15 HP with 36in Side Discharge Mower

Model No. 30317 - 240002001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

PROTOTYPE

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

©The Toro Company - 2004
All Rights Reserved

Contents

Description	Page
Engine Installation Assembly	3
Fuel Tank Assembly	4
Lower Control Assembly	5
Transmission Drive Assembly	6
Wheel Drive and Brake Assembly	7
Upper Handle Assembly	8
Control Panel Assembly	9
Carrier Frame Assembly	10
Spindle, Pulley and Belt Assembly	11
Spindle Assembly No. 106-0785	12
Outer Spindle Assembly 107-0787	13
Deck Assembly	14
Drive Belt and Tensioner Assembly	15
Crankshaft Assembly Kohler CV15T-41629	16
Crankcase Assembly Kohler CV15T-41629	17
Oil Pan/Lubrication Assembly Kohler CV15T-41629	18
Head/Valve/Breather Assembly Kohler CV15T-41629	19
Ignition/Electrical Assembly Kohler CV15T-41629	20
Blower Housing and Baffle Assembly Kohler CV15T-41629	21
Starting System Assembly Kohler CV15T-41629	22
Fuel System Assembly Kohler CV15T-41629	23
Engine Control Assembly Kohler CV15T-41629	24
Air Intake/Filtration Assembly Kohler CV15T-41629	25
Exhaust Assembly Kohler CV15T-41629	26

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR	as required
ASM	assembly
CARR	carriage
DEG	degrees
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HHFTF	hex head flange thread forming
HJ	hex jam
HLH	hex lag head
HOC	height-of-cut
HS	hex
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming
HYD	hydraulic
INC	incorporated
LH	left hand
NI	nylon insert
PPH	phillips pan head
PTH	phillips truss head
PTO	power take off
RH	right hand
SFH	slotted fillister head
SHH	slotted hex head
SHWH	slotted hex washer head
SPH	slotted pan head
SQH	square head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	torx truss head
WH	wing head


Footnotes

❶ Not illustrated

❷ Not serviced separately

❸ Obtain Parts From Your Local Kohler Dealer

PROTOTYPE




Engine Installation Assembly

Ref	Part No.	Qty.	Description
1	92-6877	1	Valve-Drain, Oil
3	106-0699	1	Decal-Warning, Hot Surfaces
❷4		1	Engine-Kohler, Cv15t-41629
5	32144-19	1	Screw-SHWH
6	2412-87	1	Clamp-Cable
7	2412-98	2	Clamp
8	47-2982	1	Hose-Fuel
9	104-8136	1	Harness-Wire
10	33104-025	1	Screw-HHF
11	3255-8	1	Washer-Lock
12	32128-20	2	Nut-HF
13	237-124	1	Grommet
14	104-6373	1	Tube-Retainer
15	1-613235	4	Washer
16	1-633630	2	Grommet-Brake
17	1-633545	2	Spacer
18	1-633543-03	1	Strap-Clutch, Brake
19	322-11	1	Screw-HH
20	3256-23	5	Washer-Flat
21	33114-025	4	Screw-HH
23	322-7	1	Screw-HH
24	3212-9	1	Screw-HH
25	112843	1	Washer
26	105-2635	1	Clutch/brake

Ref	Part No.	Qty.	Description
27	105-0827	1	Pulley-Drive
28	608006	1	Key-Square
29	94-5847-01	1	Cover-Pulley
30	56-6360	1	Filter-Fuel
31	2412-134	1	R-Clamp
32	12-3270	1	Screw
❶99	103-1964	1	Hose-Drain, Oil


PROTOTYPE



Fuel Tank Assembly

Ref	Part No.	Qty.	Description
1	88-3980	1	Gas Cap ASM
1:3	88-4010	1	Gasket-Cap, Gas
2	106-0730	1	Fuel Tank ASM
2:2	103-2605	1	Fitting-Fuel, Bulkhead
3	104-8121	2	Stud-Threaded
6	3256-23	4	Washer-Flat
7	1-633349	2	Spring-Tank, Fuel
8	3296-47	2	Nut-Lock, NI
9	106-0546-01	1	Gear Frame ASM
10	2412-98	4	Clamp
11	47-2982	1	Hose-Fuel
12	1-603770	1	Valve-Fuel
14	47-2966	1	Hose-Fuel
15	322-4	2	Screw-HH
16	3253-4	2	Washer-Lock
17	95-2814	1	Decal-Shut Off, Fuel
18	98-0776	1	Decal-Caution


PROTOTYPE



Lower Control Assembly

Ref	Part No.	Qty.	Description
1	32103-25	2	Nut-Wing
2	3256-23	6	Washer-Flat
3	3290-307	4	Pin-Hair
4	52-2890	2	Bushing-Nylon
5	74-0521	2	Fitting-Rod
6	283-6	2	Pin-Clevis
7	74-0040	4	Spacer-Pivot, Idler
8	67-6380-01	1	Bracket-Support, LH
9	67-6370-01	1	Bracket-Support, RH
10	323-16	2	Screw-HH
11	323-6	4	Screw-HH
12	3296-23	2	Nut-Lock, NI
13	95-2800	2	Pulley-Idler
14	95-2801	2	Spacer-Pulley
15	74-0220-01	1	Bracket-Idler, LH
16	74-0230-01	1	Bracket-Idler, RH
17	51-4450	2	Screw-Leveler
18	68-9690	2	Fitting-Rod
19	51-4380	1	Spring-Torsion, LH
20	51-4370	1	Spring-Torsion, RH
21	3296-39	6	Nut-Lock, NI
31	3234-32	6	Screw-HHF
32	32128-23	6	Nut-HF

PROTOTYPE




Transmission Drive Assembly

Ref	Part No.	Qty.	Description
1	47-1970	1	Grip
2	98-3274-03	1	Lever-Shift
3	3296-6	2	Nut-Lock, NI
4	98-5975	1	Washer-Belleville
5	1-323379	1	Washer
6	1-323500	1	Transmission
7	302-5	2	Fitting-Grease
8	1-323680	2	Coupler
9	51-4220	2	Guard-Coupler
10	1-323254	2	Flange-Output
11	321-4	4	Screw-HH
12	3257-5	3	Key-Woodruff
13	3245-9	2	Screw-Set
14	32151-62	2	Ring-Retaining
15	105-2698	2	Pulley-Transmission
16	104-1102	2	Shaft-Output
17	1-323252	2	Bearing-Shaft
18	95-1529	1	Rod-Shield
19	95-1526	1	Shield-Trailing
20	105-5646	1	Pulley-Driven
21	3245-1	1	Screw-Set, HSH
22	32120-64	1	Ring-Snap, External
23	105-5668	1	V-Belt
24	68-2190	1	Spring

Ref	Part No.	Qty.	Description
25	27-6230	1	Bolt-Wheel
26	323-9	1	Screw-HH
27	16-7509	1	Lever-Idler
27:1	256-155	2	Bushing-Flange
28	62-4540	1	Pulley
29	3296-39	1	Nut-Lock, NI
30	322-2	4	Screw-HH
31	3253-4	4	Washer-Lock
32	3296-42	4	Nut-Lock, NI
33	1-323389-03	2	Bracket-Plate, Shift
34	9264964	4	Screw-Hwh, Thd Cut
35	32128-20	2	Nut-HF
36	1-323387-03	1	Plate-Shift
37	3230-1	2	Bolt-CARR
38	98-3256	1	Decal-Speed, Ground

PROTOTYPE




Wheel Drive and Brake Assembly

Ref	Part No.	Qty.	Description
1	32151-72	4	Ring-Retaining
2	32151-56	2	Ring-Retaining, External
3	106-8792	2	Plate-Link, Brake
4	106-8779-01	2	Brake Arm ASM
6	3290-307	2	Pin-Hair
7	51-4580	2	Rod-Brake
8	32151-40	2	Ring-Retaining
9	106-8773	2	Brake Link ASM
10	51-4290	2	V-Belt
12	3296-29	8	Nut-Lock, NI
13	254-94	4	Bearing-Cone, Tapered
14	1-523157	2	Washer-Spacer
15	1-809082	2	Nut-SHH
16	106-0892	2	Wheel And Tire ASM
16:1	104-6322	1	Tire
16:2	106-0893	1	Wheel
16:3	232-27	1	Stem-Valve
17	242-50	8	Nut-Lug
18	241-119	2	Cap-Dust
19	1-413333	2	Hub/wheel ASM
19:2	254-72	2	Bearing-Cup, Tapered
19:3	302-19	1	Fitting-Grease
19:4	1-633926	4	Stud-Wheel
20	106-5544	2	Pulley-Wheel

Ref	Part No.	Qty.	Description
22	1-323262	2	Band-Brake
23	322-5	8	Screw-HH
24	1-543511	2	Seal-Grease
25	104-1197	2	Spacer-Wheel
26	104-1196-01	1	Axle ASM
27	1-806800	2	Pin-Cotter
28	32128-21	6	Nut-HF
29	3234-11	6	Screw-HHF


PROTOTYPE



Upper Handle Assembly

Ref	Part No.	Qty.	Description
1	105-4677	2	Rod-Control
2	3272-4	2	Pin-Cotter
3	237-141	2	Grommet-Rubber
4	82-2290	1	Decal
5	82-7680-03	1	Bail ASM
6	82-7690-03	1	Bar-Control
7	82-2280	1	Decal
8	106-5477-03	1	Control Pivot ASM
9	3272-11	2	Pin-Cotter
10	105-3158-03	1	Upper Handle ASM
11	283-55	2	Pin-Clevis
12	3290-378	1	Tie-Cable
13	32128-21	4	Nut-HF
14	3234-11	4	Screw-HHF
15	98-4387	1	Decal-Protection, Ear
16	32105-1	1	Screw-SHH
17	51-4850-03	1	Lever-Brake, Parking
18	52-2010	1	Decal-Lever, Parking
19	3296-2	1	Nut-Lock
20	218-595	1	Connector-Body
21	82-2190	1	Switch-Bail


PROTOTYPE



Control Panel Assembly

Ref	Part No.	Qty.	Description
1	105-0884	1	Decal-Danger
2	63-8360	1	Key-Ignition
3	107-4102	1	Cable-Throttle
4	32104-76	4	Screw
5	32105-14	4	Screw-SHH
6	3296-42	1	Nut-Lock, NI
7	104-8141	1	Module-Delay
8	93-1187-03	1	Panel-Bottom
9	321-2	1	Screw-HH
12	3296-2	4	Nut-Lock
13	29-5560	1	Switch-On/off
13:1	218-461	1	Nut-HH
13:2	3254-5	1	Washer-Tooth
14	2412-120	2	R-Clamp
15	104-7050	1	Housing-Manual
16	104-8140	1	Switch-PTO
17	104-8177-03	1	Panel-Control
18	106-5499	1	Decal-Control Panel
19	104-7048	1	Cap-Housing

PROTOTYPE




Carrier Frame Assembly

Ref	Part No.	Qty.	Description
1	106-0706	1	Carrier Frame ASM
1:2	32148-9	3	Insert-Nut
1:3	94-1291	4	Bushing
1:4	302-5	2	Fitting-Grease
2	105-3165-01	1	Cover-Frame, Carrier
3	106-0719	1	Decal
4	240-3	1	Grommet-Rubber
5	106-0565	3	Washer-Rubber
6	106-0887	3	Knob
7	12-3270	2	Screw
8	106-5473-01	1	Shield-Heat
9	3290-199	2	Nut-Speed
10	104-1105	4	Spacer-Support, Deck
11	1-513336	2	Bushing-Deck
12	321-5	2	Screw-HH
13	3256-22	2	Washer-Flat
14	32120-33	2	Ring-Retaining
15	105-0842	4	Spacer
16	106-0635	2	Decal-HOC
17	105-3159-01	2	Castor Fork ASM
18	32153-5	2	Nut-Lock
19	100-6451	2	Castor Wheel ASM
19:1	232-27	1	Stem-Valve
19:2	302-11	1	Fitting-Lube, 45 DEG

Ref	Part No.	Qty.	Description
19:3	83-4740	1	Bearing
19:4	62-5580	2	Bearing-Outside
19:5	100-6452	1	Tire-Tubeless
20	100-6453	2	Bushing-Spanner
21	325-19	2	Screw-HH
22	283-71	2	Pin-Lynch
23	3-6781	8	Washer-Thrust
24	106-5512	1	Decal-Service, Hydro Pistol Grip
24	106-5510	1	Decal-Service, Gear Pistol Grip
24	106-5506	1	Decal-Service, Gear Tbar
24	106-5504	1	Decal-Service, Hydro Tbar

PROTOTYPE




Spindle, Pulley and Belt Assembly

Ref	Part No.	Qty.	Description
1	106-0615	1	36" Deck ASM
1:2	32148-9	2	Insert-Nut
1:3	104-8185	1	Decal
1:4	68-8340	1	Decal-Torque
1:5	43-8480	1	Decal-Danger
1:6	106-5532	1	Decal-Scalp, Anti
1:7	67-5360	1	Decal-Danger
1:8	104-8569	1	Decal-Warning
1:9	106-0703	1	Decal
1:10	66-1340	1	Decal-Danger
2	51-3530	1	V-Belt-Drive, Deck
3	1-633166	1	Pulley-Idler
4	98-5975	1	Washer-Belleville
5	3256-24	2	Washer-Flat
6	323-6	1	Screw-HH
7	3231-22	11	Screw-CARR
8	106-0785	1	Spindle Housing ASM
9	32128-21	12	Nut-HF
10	56-2390	2	Blade-Sail, Extra High
11	92-9820	2	Stiffener-Blade
12	3256-6	2	Washer-Flat
13	44-2200	2	Screw-Blade
14	106-0787	1	Spindle Housing ASM
15	323-12	1	Screw-HH

Ref	Part No.	Qty.	Description
16	51-3641	1	Sleeve-Pivot, Idler
17	3211-5	1	Screw-HH
18	51-3660	1	Pulley-Idler
19	105-0889	1	Idler Arm ASM
20	3296-5	1	Nut-Lock, NI
21	105-2673	1	Spring-Extension


PROTOTYPE



Spindle Assembly No. 106-0785

Ref	Part No.	Qty.	Description
1	3219-7	1	Nut-Hex
2	7-4150	1	Washer
3	104-1117	1	Pulley And Hub ASM
4	106-0873	1	Shield-Bearing
5	104-6325	2	Bearing
6	106-0819	1	Housing-Spindle
7	106-0795	1	Spacer-Bearing
8	106-0781	1	Shaft-Spindle


PROTOTYPE



Outer Spindle Assembly 107-0787

Ref	Part No.	Qty.	Description
1	3219-7	1	Nut-Hex
2	7-4150	1	Washer
3	104-1118	1	Pulley And Hub ASM
4	106-0873	1	Shield-Bearing
5	104-6325	2	Bearing
6	106-0819	1	Housing-Spindle
7	106-0795	1	Spacer-Bearing
8	106-0782	1	Shaft-Spindle


PROTOTYPE



Deck Assembly

Ref	Part No.	Qty.	Description
1	105-4623	1	Deflector ASM
1:2	93-1122	1	Decal-Danger
2	105-4622	1	Spacer
3	104-8554	1	Spring-Torsion
4	3296-29	2	Nut-Lock, NI
5	106-0565	2	Washer-Rubber
6	106-0887	2	Knob
7	106-5475-01	1	Cover ASM
8	106-0684	2	Front Pin ASM
9	3220-3	2	Nut-Jam
10	1-613204	2	Balljoint
11	104-1156	2	Spacer
12	3296-39	4	Nut-Lock, NI
13	106-3365	2	Rear Pin ASM
14	3290-256	6	Pin-Hair
15	323-10	2	Screw-HH
16	323-8	2	Screw-HH
17	3256-23	2	Washer-Flat
18	98-5967	1	Spacer-Wheel
19	68-2730	2	Wheel-Gage
20	322-50	2	Screw-HH
23	32128-20	2	Nut-HF
24	322-1	2	Screw-HH


PROTOTYPE



Drive Belt and Tensioner Assembly

Ref	Part No.	Qty.	Description
1	106-5492	1	Belt-Drive, PTO
2	3296-39	1	Nut-Lock, NI
4	52-2860	3	Washer
5	104-6377	1	Tube-Idler
6	106-0734	1	Idler Arm ASM
6:1	1-513034	2	Sleeve-Bearing
6:2	302-5	1	Fitting-Grease
7	323-42	1	Screw-HH
8	323-6	1	Screw-HH
9	98-5975	1	Washer-Belleville
10	3256-24	1	Washer-Flat
11	1-413099	1	Pulley-Idler
12	105-8443	1	Spring-Extension


PROTOTYPE



Crankshaft Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description
❸1	12 014 30-S	1	Crankshaft (Includes 2)
❸2	12 139 01-S	1	Plug, Cup

PROTOTYPE




Crankcase Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description
❸1	12 032 03-S	1	Seal, Oil (Pto End)
❸2		1	Crankcase (Use: Short Block 12 522 18)
❸3	12 445 02-S	1	Strap, Lifting
❸4	M-839025-S	1	Screw, Hex Flange M8x1.25x25
❸5	24 380 13-S	4	Pin, Locating
❸6	12 067 05-S	1	Connecting Rod (Std)
❸	12 067 06-S	1	Connecting Rod (.25)
❸7	12 755 49-S	1	Kit, Camshaft (Includes 8,9)
❸8	12 089 31-S	1	Spring, Actuating
❸9	12 422 08-S	1	Shim, Camshaft-Blue
❸	12 422 09-S	1	Shim, Camshaft-Red
❸	12 422 10-S	1	Shim, Camshaft-Yellow
❸	12 422 11-S	1	Shim, Camshaft-Green
❸	12 422 12-S	1	Shim, Camshaft-Gray
❸	12 422 13-S	1	Shim, Camshaft-Black
❸	12 422 07-S	1	Shim, Camshaft-White
❸10	12 144 27-S	1	Shaft, Balance
❸11	12 874 07-S	1	Piston W/ring Set (Std) (Includes 12,13)
❸	12 874 11-S	1	Piston W/ring Set (.08)
❸	12 874 08-S	1	Piston W/ring Set (.25)
❸	12 874 09-S	1	Piston W/ring Set (.50)
❸12	12 018 02-S	2	Retainer, Piston Pin (2)

Ref	Part No.	Qty.	Description
❸13	12 108 07-S	1	Ring Set (Std & .08)
❸	12 108 08-S	1	Ring Set (.25)
❸	12 108 09-S	1	Ring Set (.50)
❸14	12 380 01-S	1	Pin, Governor Regulating
❸15	12 043 05-S	1	Gear, Governor
❸16	M-631005-S	1	Washer, Plain 6mm
❸17	12 144 02-S	1	Shaft, Governor Gear
❸18	52 139 09-S	1	Plug, Cup
❸19	12 755 64-S	1	Kit, Governor Cross Shaft W/clip (Includes 23)
❸20	X-25-102-S	1	Washer, Plain 1/4in
❸21	12 032 01-S	1	Seal, Governor Cross Shaft
❸22	M-631015-S	1	Washer, Plain 6 Mm
❸23	12 154 05-S	1	Clip, Hitch Pin


PROTOTYPE



Oil Pan/Lubrication Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description
❸1	12 038 01-S	1	Dipstick ASM (Includes 2,3)
❸2	25 755 13-S	1	Kit, Oil Fill Cap (Includes 3)
❸3	25 153 02-S	1	O-Ring, Dipstick
❸4	12 153 02-S	1	O-Ring, Upper Oil Fill Tube
❸5	12 123 04-S	1	Tube, Oil Fill
❸6	M-545020-S	1	Screw, Hex Flange M5x0.8x20
❸7	12 153 01-S	1	O-Ring, Lower Oil Fill Tube
❸8	25 162 07-S	1	Screen, Oil Pickup
❸9	12 096 03-S	1	Cover, Oil Pickup Screen
❸10	M-545016-S	1	Screw, Hex Flange M5x0.8x16
❸11	12 050 01-S	1	Filter, Oil
❸12	12 199 50-S	1	Pan Asm, Oil (Includes 13, 16-19)
❸13	25 462 09-S	1	Valve, Oil Pressure Relief
❸14	25 139 57-S	2	Plug, Pipe 3/8in Sq Hd
❸15	25 139 52-S	1	Plug, Pipe 1/8in Sq Hd
❸16	25 139 62-S	1	Plug, Pipe 3/8in Hex Ctsk
❸17	M-545016-S	3	Screw, Hex Flange M5x0.8x16
❸18	12 096 34-S	1	Cover, Oil Pump
❸19	12 153 06-S	1	O-Ring, Oil Pump Cover
❸20	12 393 01-S	1	Pump Asm, Oil
❸21	12 032 03-S	1	Seal, Oil (Pto End)
❸22	24 086 16-S	10	Screw, Hex Flange M8x1.25x45
❸23	24 086 17-S	1	Screw, Hex Flange M8x1.25x45

PROTOTYPE




Head/Valve/Breather Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description
❸1	25 351 01-S	2	Lifter, Valve
❸2	12 411 04-S	2	Rod, Push
❸3	12 041 10-S	1	Gasket, Cylinder Head
❸4	12 017 01-S	1	Valve, Intake (Std)
❸5	12 016 01-S	1	Valve, Exhaust (Std)
❸6	25 139 60-S	1	Plug, Pipe Hex Ctsk 1/8in Nptf
❸7	12 318 19-S	1	Cylinder Head
❸8	12 146 22-S	2	Plate, Guide
❸9	25 072 12-S	2	Stud, Rocker
❸10	25 186 01-S	2	Arm, Rocker
❸11	12 599 03-S	2	Pivot, Rocker Arm
❸12	25 100 29-S	2	Nut, Hex
❸13	25 086 112-S	2	Screw, Set
❸14	66 032 05-S	2	Seal, Valve Stem
❸15	12 089 34-S	2	Spring, Valve
❸16	12 173 01-S	2	Cap, Valve Spring
❸17	12 755 03-S	2	Kit, Retainer
❸18	12 468 05-S	1	Washer, Plain 13/32in
❸19	12 112 13-S	1	Spacer, Head Bolt Exhaust Port
❸20	20 086 02-S	5	Screw, Hex Flange M10x15x81
❸21	25 237 14-S	1	Clamp, Hose 11/16in
❸22	12 326 18-S	1	Hose, Breather
❸23	M-645016-S	3	Screw, Hex Flange M6x10x16
❸24	12 096 47-S	1	Cover, Valve

Ref	Part No.	Qty.	Description
❸25	M-545010-S	1	Screw, Hex Flange M5x0.8x10
❸26	66 018 04-S	1	Retainer, Breather Reed
❸27	12 402 02-S	1	Reed, Breather
❶❸	12 017 02-S	1	Valve, Intake (.25)
❶❸	12 016 02-S	1	Valve, Exhaust (.25)
❶❸	12 041 01-S	1	Gasket, Carburetor
❶❸	12 041 02-S	1	Gasket, Air Cleaner Base
❶❸	12 041 03-S	1	Gasket, Exhaust Manifold

PROTOTYPE




Ignition/Electrical Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description
❸1	12 086 14-S	1	Screw, Hex Flange M10x1.5x46
❸2	12 468 03-S	1	Washer, Plain 3/8in
❸3	24 162 03-S	1	Screen, Grass
❸4	25 086 47-S	4	Bolt, Shoulder M6x1.0x25
❸5	12 157 03-S	1	Fan
❸6	X-42-15-S	1	Key
❸7	12 025 56-S	1	Flywheel
❸8	12 403 01-S	1	Rectifier-Regulator
❸9	M-639016-S	2	Screw, Hex Flange M6x1.0x16
❸10	236602-S	1	Connector
❸11	41 155 03-S	1	Connector
❸12	M-548025-S	2	Screw, Hex Cap M50.8x25
❸13	237878-S	1	Kit, Stator (Includes 25 452 01-S)
❸14	12 132 02-S	1	Spark Plug
❸15	X-728-1-S	2	Clip, Cable
❸16	M-545010-S	2	Screw, Hex Flange M5x0.8x10
❸17	12 584 05-S	1	Module, Ignition
❸18	M-545020-S	2	Screw, Hex Flange M5x0.8x20
❶❸	X-22-11-S	1	Washer, Lock 1/4in
❶❸	12 518 01-S	1	Lead, White (19in-18 Gauge-Fully Insulated
❶		1	Female Terminal And Uninsulated Female
		1	Terminal)

Ref	Part No.	Qty.	Description
❶❸	25 518 05-S	1	Lead, Red (20in-18 Gauge-Uninsulated Female
		1	Terminals)
❶❸	24 518 12-S	1	Lead, Black (6in–12 Gauge–insulated Grip
		1	Barrel Eyelet Terminal)
❶❸	25 452 01-S	1	Terminal


PROTOTYPE




Blower Housing and Baffle Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description
❸1	M-545010-S	9	Screw, Hex Flange M5x0.8x10
❸2	12 146 07-S	1	Plate, Blower Housing
❸3	M-550010-S	6	Screw, Hex Flange M5x0.8x10
❸4	12 096 29-S	1	Cover, Starter Motor Opening
❸5	12 027 68-S	1	Housing, Blower
❸6	12 063 10-S	1	Baffle, Intake Side
❸7	12 313 03-S	1	Grommet, Spark Plug
❸8	12 063 08-S	1	Baffle, Cylinder Head
❸9	12 063 19-S	1	Baffle, Cylinder
❸	12 113 124-S	1	Decal, 15hp
❸	25 113 39-S	1	Decal, Clear Lamination

PROTOTYPE






Starting System Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description
❸1	M-550010-S	5	Screw, Hex Flange M5x0.8x10
❸2	12 165 01-S	1	Starter, Retractable (Includes 3-9)
❸3	12 081 01-S	1	Housing ASM
❸4	25 166 01-S	1	Handle, Recoil
❸5	12 160 01-S	1	Rope, Starting
❸6	12 089 06-S	1	Spring & Keeper ASM
❸7	12 093 01-S	1	Pulley
❸8	12 757 06-S	1	Kit, Dog Repair
❸9	41 086 09-S	1	Screw, Pozi Drive
❸10	15 109 01-S	1	Cup, Drive
❶❸	12 113 07-S	1	Decal, Starting


PROTOTYPE



Fuel System Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description
❸1	M-641060-S	2	Nut, Hex Flange M6x10
❸2	M-629116-S	2	Stud M6x10x116
❸3	12 853 140-S	1	Kit, Carburetor W/gaskets (Includes 4,5 [qty 1])
❸4	12 041 02-S	1	Gasket, Air Cleaner Base
❸5	12 041 01-S	2	Gasket, Carburetor
❸6	12 265 04-S	1	Deflector, Heat
❸7	47 154 01-S	1	Clip, Cable
❶❸	12 757 02-S	1	Kit, Float
❶❸	12 757 03-S	1	Kit, Carburetor Repair
❶❸	12 757 08-S	1	Kit, Choke Repair
❶❸	12 757 36-S	1	Kit, Throttle Shaft Bearing & Seal
❶❸	12 757 37-S	1	Kit, Bowl Replacement
❶❸	12 755 92-S	1	Kit, High Altitude W/gaskets


PROTOTYPE



Engine Control Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description
❸1	M-664020-S	2	Screw, Lobed Socket M6x10x20
❸2	M-545016-S	1	Screw, Hex Flange M5x0.8x16
❸3	12 237 01-S	1	Clamp, Cable
❸4	12 536 01-S	1	Control, Speed ASM (Includes 5-7)
❸5	12 086 39-S	1	Screw, Pan Hd W/loctite
❸6	12 089 11-S	1	Spring, Speed Control
❸7	12 089 23-S	1	Spring, Choke Return
❸8	12 089 19-S	1	Spring, Governor
❸9	12 755 83-S	1	Kit, Governor Lever (Includes 10-12)
❸10	12 100 07-S	1	Nut, Hex Flange 1/4in-20
❸11	52 211 04-S	1	Bolt, Round Head
❸12	12 090 28-S	1	Lever, Governor
❸13	25 158 08-S	1	Bushing, Linkage Retaining
❸14	12 079 01-S	1	Linkage, Throttle
❸15	25 158 11-S	1	Bushing, Throttle Linkage
❸16	12 079 07-S	1	Linkage, Choke


PROTOTYPE



Air Intake/Filtration Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description
❸1	12 743 04-S	1	Kit, Air Cleaner (Includes 2-11)
❸2	20 341 01-S	1	Knob, Air Cleaner Cover
❸3	12 096 44-S	1	Cover, Air Cleaner
❸4	12 083 12-S	1	Element, Precleaner
❸5	12 083 10-S	1	Element, Air Cleaner (Includes 6)
❸6	12 100 01-S	1	Wing Nut
❸7	12 032 11-S	1	Seal
❸8	12 072 04-S	1	Stud M6x10x66
❸9	12 086 01-S	2	Screw, #10 Hi-Lo Thread Forming
❸10	12 094 14-S	1	Base, Air Cleaner
❸11	12 041 02-S	1	Gasket, Air Cleaner Base
❶❸	12 113 04-S	1	Decal, Air Cleaner

PROTOTYPE



Exhaust Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description
❸1	12 068 44-S	1	Muffler
❸2	M-645016-S	2	Screw, Hex Flange M6x10x16
❸3	X-25-78-S	2	Washer, Plain
❸4	12 126 71-S	1	Bracket, Muffler
❸5	12 112 20-S	2	Spacer
❸6	M-645025-S	2	Screw, Hex Flange M6x10x20
❸7	25 072 04-S	2	Stud M8x1.25x33
❸8	12 041 03-S	1	Gasket, Exhaust Manifold
❸9	M-841080-S	2	Nut, Hex Flange M8x1.25
❶❸	M-545016-S	1	Screw, Hex Flange M5x0.8x16
❶❸	12 522 18	1	Short Block
❶❸	12 755 93-S	1	Gasket Set

PROTOTYPE

NOTES

PROTOTYPE



PROTOTYPE