



Mid-Size ProLine Pistol Grip, Hydro, 17 HP with 52in Side Discharge Mower

Model No. 30441 - 240000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Engine, Clutch and Brake Assembly	 3	Piston/Crankshaft Assembly Kawasaki FH541V-AS27	 22
Fuel Tank, Hydraulic Tank, Pump and Filter Assembly	 4	Valve/Camshaft Assembly Kawasaki FH541V-AS27	 23
Hydraulic Pump Assembly No. 106-5490	 5	Lubrication Equipment Assembly Kawasaki FH541V-AS27	 24
Hydraulic Pump Assembly No. 106-5489	 6	Cooling Equipment Assembly Kawasaki FH541V-AS27	 25
Wheel and Drive Assembly	 7	Electric Equipment Assembly Kawasaki FH541V-AS27	 26
Hydraulic Wheel Motor Assembly No. 104-1171	 8	Control Equipment Assembly Kawasaki FH541V-AS27	 27
Lower Control Assembly	 9	Carburetor Assembly Kawasaki FH541V-AS27	 28
Hydraulic Plumbing Assembly	 10	Muffler and Air Filter Assembly Kawasaki FH541V-AS27	 29
Upper Control Assembly	 11	Fuel Tank/Fuel Valve Assembly Kawasaki FH541V-AS27	 30
Control Panel Assembly	 12	Starter Assembly Kawasaki FH541V-AS27	 31
Battery Assembly	 13	Decals Kawasaki FH541V-AS27	 32
Parking Brake Assembly	 14		
Carrier Frame Assembly	 15		
Spline, Pulley and Belt Assembly	 16		
Outer Spindle Assembly 107-0787	 17		
Spindle Assembly No. 106-0785	 18		
Deck Assembly	 19		
Drive Belt and Tensioner Assembly	 20		
Cylinder/Crankcase Assembly Kawasaki FH541V-AS27	 21		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	INC. incorporated
ASM. assembly	LH. left hand
CARR. carriage	NI. nylon insert
DEG. degrees	PPH. phillips pan head
FH. flat head	PTH. phillips truss head
GA. gauge	PTO. power take off
HF. hex flange	RH. right hand
HH. hex head	SFH. slotted fillister head
HHF. hex head flange	SHH. slotted hex head
HHFTF. hex head flange thread forming	SHWH. slotted hex washer head
HJ. hex jam	SPH. slotted pan head
HLH. hex lag head	SQH. square head
HOC. height-of-cut	SRH. slotted round head
HS. hex	STD. standard
HSBH. hex socket button head	TAP. self tapping
HSFH. hex socket flat head	TTH. torx truss head
HS. hex socket head	WH. wing head
HWH. hex washer head	
HWHTF. hex washer head thread forming	
HYD. hydraulic	

Footnotes


- | | |
|--|---------------------------|
| ❶ Not illustrated | ❷ Not serviced separately |
| ❸ Obtain parts from your local Kawasaki dealer | |



Engine, Clutch and Brake Assembly


Ref	Part No.	Qty.	Description
1	32144-4	2	Screw-HWH
2	32149-1	2	Nut
3	106-8780	1	Harness-Wire
4	28-4210	1	Solenoid
5	237-124	1	Grommet
6	32128-20	2	Nut-HF
7	1-613235	4	Washer
8	104-6373	1	Tube-Retainer
9	1-633630	2	Grommet-Brake
10	1-633543-03	1	Strap-Clutch, Brake
11	1-633545	2	Spacer
12	322-11	1	Screw-HH
14	322-7	5	Screw-HH
15	3212-9	1	Screw-HH
16	112843	1	Washer
17	105-2635	1	Clutch/brake
18	44-5940	1	Pulley
19	608006	1	Key-Square
20	3256-23	5	Washer-Flat
21	94-5847-01	1	Cover-Pulley
24	103-1965	1	Valve-Drain, Oil
25	103-1966	1	Adapter
26	106-0699	1	Decal-Warning, Hot Surfaces
27		1	Engine-Kawasaki, Fh541v-As27

Ref	Part No.	Qty.	Description
28	3296-29	4	Nut-Lock, NI
29	2412-87	1	Clamp-Cable
30	3255-8	1	Washer-Lock
31	105-0834	1	Cable-Battery
32	32149-2	1	Nut
33	56-6360	1	Filter-Fuel
34	2412-72	1	Clip-Closed, Insulated
35	12-3270	1	Screw
99	103-1964	1	Hose-Drain, Oil




Fuel Tank, Hydraulic Tank, Pump and Filter Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	88-3980	1	Gas Cap ASM	15	324-5	4	Screw-HH
1:3	88-4010	1	Gasket-Cap, Gas	16	353-212	1	Elbow
2	106-0730	1	Fuel Tank ASM	16:1	237-42	1	O-Ring
2:2	103-2605	1	Fitting-Fuel, Bulkhead	17	1-633750	1	Filter-HYD
3	321-4	2	Screw-HH	17	1-633752	1	Filter-Hyd, Winter
4	103-1947	1	HYD Reservoir ASM	18	104-7836	1	Head-Filter
4:1		1	Reservoir-HYD	19	2412-98	4	Clamp
4:1:1	103-1948	1	Cap-Reservoir, HYD	20	47-2982	1	Hose-Fuel
4:1:2	103-1949	1	Gasket-Cap	21	1-603770	1	Valve-Fuel
4:2	1-523552	1	Decal-Tank, HYD	22	322-4	2	Screw-HH
5	353-374	5	Elbow-90 DEG	23	3253-4	2	Washer-Lock
5:1	237-42	1	O-Ring	24	47-2980	1	Hose-Fuel
6	32128-33	2	Nut-HF	25	237-124	1	Grommet
7	3256-23	4	Washer-Flat	26	3253-3	2	Washer-Lock
8	104-8121	2	Stud-Threaded	27	321-3	2	Screw-HH
9	1-633349	2	Spring-Tank, Fuel	28	106-5489	1	Pump-HYD
10	3296-47	2	Nut-Lock, NI				
11	32128-42	4	Nut-HF				
12	353-384	2	Fitting-Straight				
12:1	237-42	1	O-Ring				
13	106-5490	1	Pump-HYD				
14	340-4	4	Fitting-Hyd, Sraight				
14:1	237-30	1	O-Ring				
14:2	237-79	1	O-Ring				




Hydraulic Pump Assembly No. 106-5490

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	106-8751	1	Housing Kit	44	106-8760	1	Charge Relief Valve Kit
2	106-8752	1	End Cap Kit (W/poppets)	49	106-8761	1	Trunnion Seal/retainer Kit
3	106-8753	2	Pin-Headless, Straight	56	106-8762	1	Plug-HSH
4	106-8754	4	Bolt-HF	66	106-8763	1	Plug-HSH
5	106-8755	1	O-Ring	99	105-6184	1	Seal Overhaul Kit
6	106-8756	1	Charge Pump Kit				
7	104-2122	1	Gerotor ASM				
8	106-8757	1	O-Ring				
10	106-8758	2	Screw-HSH				
15	106-8759	1	Bypass Valve Kit				
18	103-2664	1	Input Shaft Kit				
19	104-5311	1	Bearing-Ball				
20	104-5310	1	Seal-Lip				
21	104-5308	1	Spacer				
22	104-5309	1	Ring-Retaining				
25	104-2106	1	Cylinder Block ASM				
29	94-1936	1	Spring-Block				
30	94-1937	1	Washer-Block, Thrust				
31	105-6185	1	Plate-Valve				
32	94-1907	1	Swashplate-Variable				
34	94-6922	1	Bearing-Thrust				
37	94-1909	1	Arm-Trunion				
38	94-1910	1	Guide-Slot				
42	98-3252	2	Valve-Check (W/poppet)				




Hydraulic Pump Assembly No. 106-5489

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	106-8751	1	Housing Kit	44	106-8760	1	Charge Relief Valve Kit
2	106-8752	1	End Cap Kit (W/poppets)	49	106-8761	1	Trunnion Seal/retainer Kit
3	106-8753	2	Pin-Headless, Straight	56	106-8762	1	Plug-HSH
4	106-8754	4	Bolt-HF	66	106-8763	1	Plug-HSH
5	106-8755	1	O-Ring	99	105-6184	1	Seal Overhaul Kit
6	106-8756	1	Charge Pump Kit				
7	104-2122	1	Gerotor ASM				
8	106-8757	1	O-Ring				
10	106-8758	2	Screw-HSH				
15	106-8759	1	Bypass Valve Kit				
18	103-2664	1	Input Shaft Kit				
19	104-5311	1	Bearing-Ball				
20	104-5310	1	Seal-Lip				
21	104-5308	1	Spacer				
22	104-5309	1	Ring-Retaining				
25	104-2106	1	Cylinder Block ASM				
29	94-1936	1	Spring-Block				
30	94-1937	1	Washer-Block, Thrust				
31	105-6185	1	Plate-Valve				
32	94-1907	1	Swashplate-Variable				
34	94-6922	1	Bearing-Thrust				
37	94-1909	1	Arm-Trunion				
38	94-1910	1	Guide-Slot				
42	98-3252	2	Valve-Check (W/poppet)				




Wheel and Drive Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	3296-6	1	Nut-Lock, NI	18	68-2190	1	Spring
2	98-0776	1	Decal-Caution	19	105-5649	1	V-Belt
3	95-2814	1	Decal-Shut Off, Fuel	20	27-6230	1	Bolt-Wheel
4	106-0548-01	1	Hydro Frame ASM	21	3296-39	1	Nut-Lock, NI
5	95-1526	1	Shield-Trailing	22	86-4770	1	Idler Lever ASM
6	104-1171	2	Motor-Wheel	23	62-4540	1	Pulley
7	340-6	4	Fitting-Hyd, Straight	24	323-9	1	Screw-HH
7:1	237-30	1	O-Ring	25	3241-5	4	Screw-Set
7:2	237-80	1	O-Ring	26	80-6090	2	Key-Pump
8	3257-8	2	Key-Woodruff	27	86-4740-01	2	Spacer-Frame
9	95-1529	1	Rod-Shield	28	3296-23	8	Nut-Lock, NI
10	105-0800	2	Wheel Hub/stud ASM	29	105-5643-01	2	Plate-Frame
10:2	10-6830	4	Stud-Type, Drive	30	32128-23	6	Nut-HF
11	106-0892	2	Wheel And Tire ASM				
11:1	104-6322	1	Tire				
11:2	106-0893	1	Wheel				
11:3	232-27	1	Stem-Valve				
12	85-7310	2	Nut-Motor, Wheel				
13	242-50	8	Nut-Lug				
14	325-11	8	Screw-HH				
15	3234-32	4	Screw-HHF				
15	3234-22	2	Screw-HHF				
16	105-5648	2	Pulley-Pump				
17	88-1880	1	Spring-Compression				




Hydraulic Wheel Motor Assembly No. 104-1171

Ref	Part No.	Qty.	Description				
1	1-000119	1	Seal Kit				
1:1		1	Ring-Back Up				
1:2		1	Seal-Commutator				
1:3		1	Seal-Shaft (Viton)				
1:4		1	Washer-Back Up, Steel				
1:5		5	Ring-Seal (Viton)				
1:7		1	Seal-Dirt And Water				
2	3257-8	1	Key-Woodruff				
3	85-7310	1	Nut-Motor, Wheel				
4	106-5549	6	Bolt-Special				
5	106-8764	1	Shaft-Coupling				




Lower Control Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	106-5484	1	RH Control Arm ASM	25	32128-20	14	Nut-HF
2	1-413350	2	Link-Control, Speed	26	1-613089	2	Tab-Spring, Extension
3	3219-2	5	Nut-Hex	27	1-603693	2	Spring-Extension
4	3256-23	14	Washer-Flat	28	104-9817-01	2	Plate-Side, Hydro
5	1-323245	1	Spring-Compression	29	322-38	6	Screw-HH
6	1-603676	3	Swivel-Adjustable, Short	30	322-3	4	Screw-HH
7	1-603903	1	Spacer	31	1-633102	2	Bearing-Flange, Side
8	1-413151	1	Knob-Tracking	32	104-9820	6	Spacer-Shield
9	3220-2	2	Nut	33	302-5	2	Fitting-Grease
10	1-303105	2	Yoke-Adjustable	34	103-1235	2	Swivel-Lever, Drive
11	105-4109	1	Decal-Tracking	35	106-5480	1	LH Control Arm ASM
12	1-808280	2	Pin-Clevis	36	32151-47	2	Ring-Retaining
13	3290-307	2	Pin-Hair	37	3246-3	4	Screw-HS
14	106-5538-01	1	Speed Control Crank ASM	38	3230-2	4	Bolt-CARR
15	3272-5	3	Pin-Cotter	39	322-4	2	Screw-HH
16	3296-29	18	Nut-Lock, NI	40	106-5539-01	1	Bracket-Neutral
17	1-809056	2	Screw	41	65-7410	1	Switch-Pole, Single
18	3296-4	2	Nut-Lock, NI	42	3256-1	2	Washer-Flat
19	1-603807	2	Spring-Return, Neutral	43	32144-4	2	Screw-HWH
20	1-603735	2	Bushing-Flanged	44	82-4570	1	Plate-Switch
21	105-9372	2	Stud-Adjustment	45	32144-1	2	Screw-Tapite
22	104-9802-01	2	Bracket-Mount, Spring	46	105-3163-01	1	Crank Support ASM
23	1-403180	2	Screw-HH	47	3256-24	2	Washer-Flat
24	32128-25	2	Nut-HF	48	322-7	4	Screw-HH




Hydraulic Plumbing Assembly

Ref	Part No.	Qty.	Description				
1	106-0824	1	HYD Hose ASM				
2	106-0825	1	HYD Hose ASM				
3	105-5697	1	HYD Hose ASM				
4	105-5699	1	HYD Hose ASM				
5	105-5698	1	HYD Hose ASM				
6	106-3368	1	HYD Hose ASM				
7	106-0826	1	HYD Hose ASM				




Upper Control Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	1-413219	2	Rod-Lever, Drive	24	106-5483	1	Latch-Thumb, LH
2	3234-11	2	Screw-HHF	25	321-10	2	Screw-HH
3	3234-24	2	Screw-HHF	26	106-5481	1	Latch-Thumb, RH
4	32128-21	4	Nut-HF	27	1-303363	1	Spring-Extension
5	106-5534	1	Rod-Control, Speed	28	103-0219	1	RH Drive Lever ASM
6	3290-307	3	Pin-Hair	28:2	1-413152	2	Sleeve-Bushing
7	1-323245	2	Spring-Compression	29	322-11	2	Screw-HH
8	3296-29	2	Nut-Lock, NI	30	321-3	2	Screw-HH
9	233-42	1	Knob	31	104-9803	1	Rod ASM
10	106-2748	1	Lever-Shift	32	106-5486	1	RH Opc Lever ASM
11	3290-378	1	Tie-Cable	33	32128-33	2	Nut-HF
12	1-603749	2	Bushing-Lever, Drive	34	1-603730	1	Plate-Lever, Shifter
13	1-613055	2	Pin-Clevis	35	1-603716	1	Washer-Friction
14	103-0218	1	LH Drive Lever ASM	36	1-323244	2	Washer-Friction
14:2	1-413152	2	Sleeve-Bushing	37	3256-23	1	Washer-Flat
15	1-303365	2	Bushing-Nylon				
16	1-803322	2	Screw-Set				
17	106-5485	1	LH Opc Lever ASM				
18	321-9	2	Screw-HH				
19	3296-42	2	Nut-Lock, NI				
20	104-9838	2	Grip-Foam				
21	32128-33	2	Nut-HF				
22	3256-2	2	Washer-Flat				
23	1-303435	6	Washer-Spring				




Control Panel Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	32105-14	2	Screw-SHH	28	105-3176	1	Handle ASM
2	105-4110	2	Decal-Lock, Neutral	28:2	106-5516	1	Decal-Panel, Control
3	104-8143	1	Hourmeter	28:3	98-4387	1	Decal-Protection, Ear
6	63-8360	1	Key-Ignition	33	106-5487	1	Gasket-Throttle
7	95-7489	1	Switch-PTO	34	104-7048	1	Cap-Housing
9	106-5501	1	Decal-Control, Throttle				
10	3296-2	6	Nut-Lock				
11	107-4072	1	Cable-Throttle				
12	32144-1	2	Screw-Taptite				
13	82-4570	1	Plate-Switch				
14	65-7410	1	Switch-Pole, Single				
15	3256-14	2	Washer-Flat				
16	105-4137-03	1	Plate-Mounting, Switch				
17	98-7249	1	Relay				
18	3290-321	2	Screw-HWH				
19	2412-134	1	R-Clamp				
20	88-9830	1	Key Switch ASM				
20:1	3254-5	1	Washer-Tooth				
20:2	218-461	1	Nut-HH				
21	32105-13	2	Screw-SHH				
22	2412-120	2	R-Clamp				
23	32104-76	4	Screw				
24	105-4112-03	1	Bracket-Cover				
25	104-7050	1	Housing-Manual				




Battery Assembly

Ref	Part No.	Qty.	Description				
1	77-0981	1	Boot-Terminal, Red	PROTOTYPE			
2	77-0980	1	Boot-Terminal, Black				
3	3296-42	2	Nut-Lock, NI				
4	104-8568-03	1	Plate-Hold Down, Battery				
5	3256-2	2	Washer-Flat				
6	32149-1	2	Nut				
7	105-0833	1	Cable-Battery, Black				
8	100-6457	1	Cable-Battery, Red				
9	322-3	2	Screw-HH				
10	104-8162	1	Battery (Dry)				
11	62-4300	1	Anti-Skid Pad				
12	105-3150-01	1	Battery Tray ASM				
13	104-8567	2	Holddown-Battery				
14	93-3190	1	Boot-Insulator, Terminal				




Parking Brake Assembly

Ref	Part No.	Qty.	Description				
1	3296-6	1	Nut-Lock, NI	PROTOTYPE			
2	106-0666-01	1	Brake Handle Support ASM				
3	104-2838	1	Decal-Brake				
4	3296-29	2	Nut-Lock, NI				
5	82-4570	1	Plate-Switch				
6	32144-1	2	Screw-Taptite				
7	95-1653	1	Switch-Pole, Single				
8	1-808285	2	Pin-Clevis				
9	106-0671-01	1	Handle-Brake				
10	257-7	1	Bearing-Thrust				
11	93-2364	1	Bolt-Shoulder				
12	1-633131	2	Yoke-Linkage, Brake				
13	1-303020	1	Grip-Lever				
14	3290-307	2	Pin-Hair				
15	322-5	2	Screw-HH				
16	106-0670	1	Rod-Connecting, Brake				
17	3220-3	1	Nut-Jam				
18	323-5	3	Screw-HH				
19	3296-39	3	Nut-Lock, NI				
20	106-0660-01	1	Parking Brake ASM				
21	3290-357	2	Nut-HHF				
22	27-5240	1	Bolt-Shoulder				
23	613386	1	Spring-Brake				
24	56-6590	1	Bolt-Wheel				



Carrier Frame Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	106-0708	1	Carrier Frame ASM	19:3	83-4740	1	Bearing
1:2	32148-9	3	Insert-Nut	19:4	62-5580	2	Bearing-Outside
1:3	94-1291	4	Bushing	19:5	100-6452	1	Tire-Tubeless
1:4	302-5	2	Fitting-Grease	20	100-6453	2	Bushing-Spanner
2	106-3360-01	1	Cover-Frame, Carrier	21	325-19	2	Screw-HH
3	106-0719	1	Decal	22	283-71	2	Pin-Lynch
4	240-3	1	Grommet-Rubber	23	3-6781	8	Washer-Thrust
5	106-0565	3	Washer-Rubber	24	106-5503	1	Decal-Service, Hydro Tbar
6	106-0887	3	Knob	24	106-5505	1	Decal-Service, Gear Tbar
7	12-3270	2	Screw	24	106-5511	1	Decal-Service, Gear Pistol Grip
8	106-3361-01	1	Shield-Heat	24	106-5513	1	Decal-Service, Hydro Pistol Grip
9	3290-199	2	Nut-Speed				
10	104-1105	4	Spacer-Support, Deck				
11	1-513336	2	Bushing-Deck				
12	321-5	2	Screw-HH				
13	3256-22	2	Washer-Flat				
14	32120-33	2	Ring-Retaining				
15	105-0842	4	Spacer				
16	106-0635	2	Decal-HOC				
17	105-3159-01	2	Castor Fork ASM				
18	32153-5	2	Nut-Lock				
19	100-6451	2	Castor Wheel ASM				
19:1	232-27	1	Stem-Valve				
19:2	302-11	1	Fitting-Lube, 45 DEG				



Spline, Pulley and Belt Assembly

Ref	Part No.	Qty.	Description
1	106-0619	1	Deck ASM
1:2	32148-10	2	Insert-Threaded
1:3	66-1340	1	Decal-Danger
1:4	106-0705	1	Decal
1:5	104-8569	1	Decal-Warning
1:6	67-5360	3	Decal-Danger
1:7	104-8186	1	Decal-Routing, Belt
1:8	68-8340	1	Decal-Torque
1:9	43-8480	1	Decal-Danger
1:10	106-5532	1	Decal-Scalp, Anti
2	104-6397	1	V-Belt
3	3256-24	5	Washer-Flat
4	323-8	1	Screw-HH
5	105-0850	1	Guide-Belt
6	98-5980	1	Guide-Belt
7	104-6396	1	Guide-Belt
8	32128-21	20	Nut-HF
9	52-4780	1	Rod-Belt
10	3231-22	18	Screw-CARR
11	104-6374	1	Plate-Spring
12	104-6375	1	Idler Arm ASM
13	3296-5	1	Nut-Lock, NI
14	7-0081	1	Washer-Flat
15	65-5940	1	Pulley-Idler


Ref	Part No.	Qty.	Description
16	104-6379	1	Bushing-Pulley
17	51-3650	1	Spring-Extension
18	3211-8	1	Screw-HH
19	51-3640	1	Sleeve
20	106-0787	2	Spindle Housing ASM
21	27-0990	3	Blade
22	44-2200	3	Screw-Blade
23	3256-6	3	Washer-Flat
24	92-9820	3	Stiffener-Blade
25	323-6	1	Screw-HH
26	323-11	1	Screw-HH
27	106-0785	1	Spindle Housing ASM
28	32128-25	1	Nut-HF
29	3256-3	1	Washer-Flat



Outer Spindle Assembly 107-0787


Ref	Part No.	Qty.	Description				
1	3219-7	1	Nut-Hex				
2	7-4150	1	Washer				
3	104-1118	1	Pulley And Hub ASM				
4	106-0873	1	Shield-Bearing				
5	104-6325	2	Bearing				
6	106-0819	1	Housing-Spindle				
7	106-0795	1	Spacer-Bearing				
8	106-0782	1	Shaft-Spindle				

PROTOTYPE



Spindle Assembly No. 106-0785


Ref	Part No.	Qty.	Description				
1	3219-7	1	Nut-Hex				
2	7-4150	1	Washer				
3	104-1117	1	Pulley And Hub ASM				
4	106-0873	1	Shield-Bearing				
5	104-6325	2	Bearing				
6	106-0819	1	Housing-Spindle				
7	106-0795	1	Spacer-Bearing				
8	106-0781	1	Shaft-Spindle				



Deck Assembly


Ref	Part No.	Qty.	Description
1	105-4623	1	Deflector ASM
1:2	93-1122	1	Decal-Danger
2	105-4622	1	Spacer
3	104-8554	1	Spring-Torsion
4	3296-29	3	Nut-Lock, NI
5	3296-39	10	Nut-Lock, NI
6	3256-24	6	Washer-Flat
7	68-2730	6	Wheel-Gage
8	99-2842	3	Spacer
9	106-3363-01	1	Cover-Belt, RH
10	106-3362-01	1	Cover-Belt, LH
11	106-0565	2	Washer-Rubber
12	106-0887	2	Knob
13	106-0684	2	Front Pin ASM
14	3220-3	2	Nut-Jam
15	1-613204	2	Balljoint
16	104-1156	2	Spacer
17	323-8	2	Screw-HH
18	106-3365	2	Rear Pin ASM
19	3290-256	6	Pin-Hair
20	323-10	2	Screw-HH
21	32128-20	6	Nut-HF
22	322-1	6	Screw-HH
23	3230-30	1	Screw-CARR

Ref	Part No.	Qty.	Description
24	106-0563	1	Spacer-Wheel
25	106-0545	1	Bushing-Roller
26	3256-23	3	Washer-Flat
27	98-5967	1	Spacer - Wheel
28	322-50	2	Screw-HH




Drive Belt and Tensioner Assembly

Ref	Part No.	Qty.	Description				
1	322-7	2	Screw-HH				
2	3256-23	2	Washer-Flat				
3	105-3173-01	1	Weight-Rear				
4	3296-29	2	Nut-Lock, NI				
5	3296-39	1	Nut-Lock, NI				
6	52-2860	3	Washer				
7	104-6377	1	Tube-Idler				
8	106-0734	1	Idler Arm ASM				
8:1	1-513034	2	Sleeve-Bearing				
8:2	302-5	1	Fitting-Grease				
9	323-42	1	Screw-HH				
10	323-6	1	Screw-HH				
11	98-5975	1	Washer-Belleville				
12	3256-24	1	Washer-Flat				
13	1-413099	1	Pulley-Idler				
14	105-8443	1	Spring-Extension				
15	106-0632	1	V-Belt				




Cylinder/Crankcase Assembly
Kawasaki FH541V-AS27

Ref	Part No.	Qty.	Description				
⑤11004	11004-7016	2	Gasket-Head				
⑤11008	11008-6043	1	Head-Comp-Cylinder, No. 1				
⑤11008A	11008-7020	1	Head-Comp-Cylinder, No. 2				
⑤11022	11022-7003	2	Case-Rocker				
⑤11060	11060-7001	2	Gasket-Rocker				
⑤11060A	11060-7008	1	Gasket-Crankcase, Cover				
⑤11061	11061-7001	1	Gasket-Breather				
⑤13271	13271-7016	1	Plate				
⑤14091	14091-7006	1	Cover				
⑤49015	49015-6253	1	Cover-Crankcase				
⑤49109	49109-7002	1	Element-Breather				
⑤49120	49120-7023	1	Crankcase-Comp				
⑤92033	92033-7003	2	Ring-Snap				
⑤92043	92043-7001	6	Pin				
⑤92049	92049-7001	4	Seal-Oil, Rvc2				
⑤92049A	92049-7015	1	Seal-Oil, Sd				
⑤92049B	92049-7016	1	Seal-Oil, Sd				
⑤92049C	92049-7019	1	Seal-Oil, So				
⑤92066	92066-7002	1	Plug				
⑤130	130B0612	4	Bolt-Flanged				
⑤130A	130B0640	4	Bolt-Flanged				
⑤130B	130T0850	17	Bolt-Flanged				
⑤130C	130T0875	2	Bolt-Flanged				
⑤172	172G0818	4	Bolt-Stud				




Piston/Crankshaft Assembly
Kawasaki FH541V-AS27

Ref	Part No.	Qty.	Description				
13001	13001-7010	2	Piston-Engine				
13002	13002-7001	2	Pin-Piston				
13008	13008-6060	2	Ring-Set, Piston				
13031	13031-7036	1	Crankshaft-Comp				
13251	13251-7010	2	Connecting Rod ASM				
92033	92033-7005	4	Ring-Snap				
92151	92151-7017	4	Bolt, 6x35				




Valve/Camshaft Assembly
Kawasaki FH541V-AS27

Ref	Part No.	Qty.	Description				
⑨12004	12004-7003	2	Valve-Intake				
⑨12005	12005-7003	2	Valve-Exhaust				
⑨12009	12009-7001	4	Retainer-Valve, Spring				
⑨12011	12011-2056	8	Collet				
⑨12016	12016-7001	4	Arm-Rocker				
⑨12032	12032-7001	4	Tappet				
⑨13070	13070-7001	2	Guide				
⑨13070A	13070-7004	1	Guide				
⑨13116	13116-2057	4	Rod-Push				
⑨13271	13271-7007	1	Plate				
⑨13271A	13271-7021	1	Plate-Governor				
⑨42036	42036-7009	1	Sleeve				
⑨49078	49078-7001	4	Spring-Engine, Valve				
⑨49118	49118-7004	1	Camshaft-Comp				
⑨92009	92009-2341	4	Screw				
⑨92015	92015-2253	4	Nut				
⑨92033	92033-7001	2	Ring-Snap				
⑨92140	92140-7002	6	Ball				
⑨92145	92145-7001	1	Spring				
⑨92153	92153-7019	4	Bolt				
⑨92200	92200-7001	1	Washer				




Lubrication Equipment Assembly
Kawasaki FH541V-AS27

Ref	Part No.	Qty.	Description				
13107	13107-7009	1	Shaft				
13271	13271-7017	1	Plate				
14075	14075-7009	1	Cap ASM				
16154	16154-2053	1	Rotor-Pump, In				
16154A	16154-2054	1	Rotor-Pump, Out				
49065	49065-2078	1	Filter-Oil				
49065A	49065-7004	1	Filter-Oil				
59051	59051-7011	1	Gear-Spur				
59231	59231-7005	1	Filler				
92043	92043-7003	2	Pin				
92066	92066-7003	2	Plug				
92140	92140-7003	1	Ball				
92145	92145-7002	1	Spring				
130	130B0612	3	Bolt-Flanged				
670	670D2016	1	O-Ring				




Cooling Equipment Assembly
Kawasaki FH541V-AS27

Ref	Part No.	Qty.	Description				
❸ 13270	13270-7007	1	Plate				
❸ 14037	14037-7021-9H	1	Screen				
❸ 49089	49089-7032	1	Shroud-Engine				
❸ 49089A	49089-7042	1	Shroud-Engine				
❸ 49089B	49089-7043	1	Shroud-Engine				
❸ 59041	59041-7010	1	Fan				
❸ 59066	59066-7024	1	Housing-Fan				
❸ 92004	92004-7006	2	Stud				
❸ 92153	92153-7007	3	Bolt				
❸ 92153A	92153-7008	1	Bolt				
❸ 130	130B0612	2	Bolt-Flanged				
❸ 130A	130B0616	2	Bolt-Flanged				
❸ 130B	130B0625	2	Bolt-Flanged				
❸ 130C	130B0816	1	Bolt-Flanged				
❸ 311	311B0600	2	Nut-Hex				




Electric Equipment Assembly
Kawasaki FH541V-AS27

Ref	Part No.	Qty.	Description				
②1066	21066-7011	1	Regulator-Voltage				
②1171	21171-7013	2	Ignition Coil ASM				
②1193	21193-7007	1	Flywheel ASM				
②6030	26030-7001	1	Harness				
②6031	26031-7002	1	Harness				
⑤9031	59031-7001	1	Coil-Charging				
⑨2004	92004-7009	2	Stud				
⑨2009	92009-2308	1	Screw				
⑨2066	92066-7002	1	Plug				
⑨2070	92070-7003	2	Plug-Spark, Rcj8y				
⑨2072	92072-7003	2	Band				
⑨2151	92151-2097	1	Bolt, 12x30				
⑨2200	92200-7002	1	Washer				
③130	130B0620	2	Bolt-Flanged				
③224	224B0520	4	Screw-Pan, Wp (Cross)				
③311	311B0600	2	Nut-Hex				
⑤10	510A5100	1	Key-Woodruff				




Control Equipment Assembly
Kawasaki FH541V-AS27

Ref	Part No.	Qty.	Description				
13107	13107-7010	1	Shaft				
13271	13271-7018	1	Plate				
16169	16169-7010	1	Link-Choke				
16171	16171-7001	1	Link				
39129	39129-7003	1	Spring-Governor				
49103	49103-7004	1	Arm-Governor				
49113	49113-7027	1	Panel Control ASM				
92009	92009-7007	2	Screw, 4x35				
92145	92145-7003	1	Spring				
92145A	92145-7004	1	Spring				
92145B	92145-7005	2	Spring				
92150	92150-2182	1	Bolt, 5x18				
92153	92153-7005	1	Bolt, 6x35				
92170	92170-7001	1	Clamp				
130	130B0612	2	Bolt-Flanged				
214	214B0408	2	Screw-Pan				
311	311B0600	1	Nut-Hex				
411	411b0600	1	Washer-Plain				




Carburetor Assembly
Kawasaki FH541V-AS27

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
11061	11061-7004	2	Gasket-Insulator	92093	92093-2100	1	Seal
11061A	11061-7009	1	Gasket-Chamber	92093A	92093-7003	1	Seal
11061B	11061-7010	1	Gasket-Screw	92145	92145-7015	1	Spring
11061C	11061-7018	1	Gasket-Cleaner, Air	130	130B0635	4	Bolt-Flanged
11061D	11061-7019	2	Gasket	172	172G0690	2	Bolt-Stud
13107	13107-7018	1	Shaft	214	214B0510	1	Screw-Pan
15003	15003-7106	1	Carburetor ASM				
16014	16014-7007	1	Screw-Pilot, Air				
16020	16020-7003	1	Chamber-Float				
16025	16025-7006	1	Valve-Throttle				
16030	16030-7003	1	Valve-Float				
16031	16031-7002	1	Float				
16041	16041-7016	1	Shaft-Carburetor, Choke				
16041A	16041-7018	1	Shaft-Carburetor, Throttle				
16073	16073-7007	1	Insulator				
16186	16186-7004	1	Choke Valve ASM				
21188	21188-7002	1	Solenoid				
39076	39076-7001	1	Limiter				
49121	49121-7010	1	Nozzle-Main				
59076	59076-7001	1	Manifold-Intake				
92009	92009-2083	2	Screw				
92009A	92009-2349	1	Screw				
92063	92063-7065	1	Jet-Main, No. 112				
92081	92081-2234	1	Spring				




Muffler and Air Filter Assembly
Kawasaki FH541V-AS27

Ref	Part No.	Qty.	Description				
❸11011	11011-7036	1	Case-Filter, Air				
❸11013	11013-7025	1	Element-Filter, Air				
❸11013A	11013-7031	1	Element-Filter, Air				
❸11051	11051-7005-9H	1	Bracket				
❸11060	11060-7021	2	Gasket-Muffler				
❸13270	13270-7008	1	Plate				
❸16060	16060-7016	1	Pipe-Intake				
❸18049	18049-7001	1	Pipe-Exhaust				
❸49070	49070-7015	1	Muffler-Comp				
❸92015	92015-1193	2	Nut				
❸92055	92055-7015	1	O-Ring				
❸92072	92072-7008	1	Band				
❸92170	92170-7002	1	Clamp				
❸92192	92192-7010	1	Tube				
❸92210	92210-7004	2	Nut				
❸92210A	92210-7019	1	Nut				
❸130	130B0816	2	Bolt-Flanged				
❸233	233B0416	1	Screw-Pan, Wp				
❸311	311B0400	1	Nut-Hex				
❸317	317R0800	4	Nut-Hex, Small				
❸461	461F0800	4	Washer-Spring				






Fuel Tank/Fuel Valve Assembly
Kawasaki FH541V-AS27

Ref	Part No.	Qty.	Description				
③ 23062	23062-7004-9H	1	Bracket-Comp				
③ 49019	49019-7001	1	Filter-Fuel				
③ 49040	49040-7001	1	Pump-Fuel				
③ 92170	92170-2088	4	Clamp				
③ 92191	92191-7002	1	Tube				
③ 92191A	92191-7003	1	Tube				
③ 92191B	92191-7004	1	Tube				
③ 130	130B0620	2	Bolt-Flanged				



Starter Assembly Kawasaki FH541V-AS27

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
13101	13101-7003	1	Gear ASM	130	130B0608	3	Bolt-Flanged
13165	13165-7001	4	Pawl-Recoil, Starter	130A	130B0816	2	Bolt-Flanged
13271	13271-7003-9H	1	Plate				
14020	14020-7001	1	Retainer				
21039	21039-7004	1	Brush				
21080	21080-7001	1	Armature				
21163	21163-7010	1	Starter-Electric				
32099	32099-7002	1	Case-Recoil, Starter				
39184	39184-7004	1	Bracket ASM				
46075	46075-7001	1	Grip-Recoil, Starter				
49080	49080-7001	1	Pulley-Starting				
49088	49088-7013	1	Starter-Recoil				
59101	59101-7001	1	Reel-Recoil, Starter				
59106	59106-7001	1	Rope				
59106A	59106-7005	1	Rope				
92145	92145-7006	1	Spring				
92145A	92145-7007	2	Spring				
92145B	92145-7008	1	Spring				
92151	92151-7008	1	Bolt				
92151A	92151-7013	1	Bolt				
92200	92200-7004	1	Washer				
92200A	92200-7005	1	Washer				
92210	92210-0003	4	Nut				



Decals
Kawasaki FH541V-AS27

Ref	Part No.	Qty.	Description				
56033	56033-7002	1	Label-Manual				
56070	56070-7001	1	Label-Warning				
56080	56080-2077	1	Label-Brand				
56080A	56080-7023	1	Label-Brand				

PROTOTYPE

NOTES

PROTOTYPE

NOTES

PROTOTYPE

NOTES

PROTOTYPE



PROTOTYPE