Form Number 3350-774

# Z147 Z Master®

## With 112cm SFS Side Discharge Mower

**Model No. 74161TE - 240000001 and up.**

# Parts Catalog

### Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

**Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by **6:**1, the valve by **6:**2, and the wheel by **6:**3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

**Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

PROTOTYPE

©The Toro Company - 2003
All Rights Reserved

# Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
CARR. . . . . carriage
DEG. . . . . degrees
FH. . . . . flat head
GA. . . . . gauge
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HS. . . . . hex
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
INC. . . . . incorporated
LH. . . . . left hand
NI. . . . . nylon insert
PPH. . . . . phillips pan head
PTH. . . . . phillips truss head
PTO. . . . . power take off
RH. . . . . right hand
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head
WH. . . . . wing head


# Footnotes

❶ Not illustrated
❷ Not serviced separately
❸ Obtain Parts From Kawasaki

# Contents


| Description | Page |
|---|---|
| Front Frame Assembly | 3 |
| Caster Wheel Assembly No. 1-634662 | 4 |
| Front Spring Assembly No. 103-1987 | 5 |
| Height-of-Cut Assembly | 6 |
| Main Frame Assembly | 7 |
| Fuel System Assembly | 8 |
| Parking Brake System Assembly | 9 |
| Steering Control Assembly | 10 |
| Pump Idler and Belt Assembly | 11 |
| Engine, Clutch and Muffler Assembly | 12 |
| Deck and Wheel Gage Assembly | 13 |
| Deck and Deflector Assembly No. 106-6565 | 14 |
| Deck Spindle Assembly | 15 |
| Idler, Pulley/Lift Strut and Chain Assembly | 16 |
| Hydraulic System Assembly | 17 |
| Hydraulic Pump Assembly No. 103-1942 | 19 |
| Deck Recycler Assembly | 20 |
| Electrical System Assembly | 21 |
| Seat and Roll-Over Protection System Assembly | 22 |
| Seat Assembly No. 107-1867 | 23 |
| Roll-Over Protection System Assembly No. 107-3066 | 24 |
| Cylinder/Crankcase Assembly Kawasaki FH500V-ES10 | 25 |
| Valve/Camshaft Assembly Kawasaki FH500V-ES10 | 26 |
| Air Filter/Muffler Assembly Kawasaki FH500V-ES10 | 27 |
| Fuel Tank/Fuel Valve Assembly Kawasaki FH500V-ES10 | 28 |
| Lubrication Equipment Assembly Kawasaki FH500V-ES10 | 29 |
| Piston/Crankshaft Assembly Kawasaki FH500V-ES10 | 30 |
| Label Assembly Kawasaki FH500V-ES10 | 31 |
| Carburetor Assembly Kawasaki FH500V-ES10 | 32 |
| Control Equipment Assembly Kawasaki FH500V-ES10 | 33 |
| Cooling Equipment Assembly Kawasaki FH500V-ES10 | 34 |
| Electric Equipment Assembly Kawasaki FH500V-ES10 | 35 |
| Starter Assembly Kawasaki FH500V-ES10 | 36 |


PROTOTYPE





# Front Frame Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 1-634662 | 2 | Caster Wheel ASM |
| 3 | 1-632511-01 | 2 | Caster |
| 4 | 1-543511 | 2 | Seal-Grease |
| 5 | 254-94 | 4 | Bearing-Cone, Taper |
| 6 | 1-633508 | 6 | Washer-Bellville |
| 7 | 3296-51 | 2 | Nut-Lock, NI |
| 8 | 1-543513 | 2 | Cap-Grease |
| 9 | 322-3 | 6 | Screw-HH |
| 10 | 3256-23 | 4 | Washer-Flat |
| 11 | 107-2108 | 1 | Floorpan ASM |
| 11:2 | 1-633553 | 1 | Pad-Antiskid |
| 11:3 | 106-7451 | 1 | Decal |
| 11:4 | 107-1866 | 1 | Decal-Danger, Slope |
| 12 | 1-653049 | 1 | Hinge-Floorpan |
| 13 | 100-3957 | 1 | Footrest ASM |
| 13:2 | 99-8940 | 1 | Decal-Service |
| 13:3 | 98-1977 | 1 | Decal-Warning |
| 13:4 | 1-633553 | 1 | Pad-Antiskid |
| 14 | 3229-10 | 10 | Screw-CARR |
| 15 | 32128-33 | 10 | Nut-HF |
| 16 | 3230-1 | 2 | Bolt-CARR |
| 17 | 99-3870-01 | 2 | Bracket-Floorpan |
| 18 | 32128-20 | 8 | Nut-HF |
| 20 | 107-1779 | 1 | Front Frame ASM |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 20:2 | 107-2132 | 1 | Decal-Warning |
| 21 | 32151-103 | 6 | Ring-Snap |
| 22 | 3256-29 | 6 | Washer-Flat |
| 23 | 3290-357 | 12 | Nut-HHF |
| 24 | 98-5975 | 12 | Washer-Belleville |
| 25 | 323-7 | 12 | Screw-HH |
| 26 | 3218-2 | 2 | Nut-Jam |
| 27 | 3274-18 | 2 | Screw-HSH |
| 31 | 103-1987 | 2 | Front Spring ASM |
| 33 | 107-1791-01 | 1 | LH Front Deck Lift ASM |
| 34 | 107-1792-01 | 1 | RH Front Deck Lift ASM |
| 35 | 302-19 | 4 | Fitting-Grease |
| 36 | 1-811010 | 2 | Plug |
| 38 | 254-72 | 4 | Bearing-Cup, Tapered |


PROTOTYPE




# Caster Wheel Assembly No. 1-634662

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 1-633582 | 1 | Wheel And Tire ASM |
| 1:1 | 1-633002 | 1 | Tire |
| 1:2 | 1-633583 | 1 | Wheel |
| 1:3 | 1-633584 | 2 | Bearing-Cup |
| 2 | 1-633581 | 2 | Spacer-Bearing |
| 3 | 1-633580 | 2 | Seal-Bearing |
| 4 | 1-633585 | 2 | Bearing-Cone, Taper |
| 5 | 1-633579 | 1 | Spacer-Caster, Front |
| 6 | 325-36 | 1 | Screw-HH |
| 7 | 3296-45 | 1 | Nut-Lock, NI |


PROTOTYPE




# Front Spring Assembly No. 103-1987

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 1-653011 | 1 | Rod-Lift, Deck |
| 2 | 1-633441 | 2 | Swivel-Deck Mount, Rear |
| 3 | 3217-11 | 4 | Nut-Hex |
| 4 | 3218-6 | 2 | Nut-Jam |
| 5 | 1-805517 | 1 | Washer |
| 6 | 1-653009 | 1 | Spring-Compression |
| 7 | 3256-27 | 1 | Washer-Flat |

PROTOTYPE





# Height-of-Cut Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 323-9 | 1 | Screw-HH |
| 2 | 32151-103 | 1 | Ring-Snap |
| 3 | 3290-357 | 5 | Nut-HHF |
| 4 | 3296-39 | 3 | Nut-Lock, NI |
| 5 | 1-652235-01 | 1 | Plate-Lift, Deck |
| 6 | 1-633080 | 1 | Bushing-Lever, Lift |
| 7 | 1-653230-01 | 1 | Plate-Lift, Deck |
| 8 | 1-806005 | 1 | Pin-Hair |
| 9 | 323-6 | 1 | Screw-HH |
| 10 | 323-13 | 1 | Screw-HH |
| 11 | 1-633082 | 1 | Bushing-Lever, Lift |
| 12 | 103-2078-03 | 1 | Handle-Lift |
| 13 | 1-633295 | 1 | Grip-Lever, Lift |
| 14 | 1-633097 | 1 | Pin-Hitch (W/lanyard) |
| 15 | 302-19 | 1 | Fitting-Grease |
| 16 | 103-1918 | 2 | Bushing |
| 17 | 106-6598-03 | 1 | Lift Arm ASM |
| 18 | 1-633325 | 1 | Spring-Compression |
| 19 | 3256-24 | 1 | Washer-Flat |
| 20 | 1-633068 | 2 | Arm-Lift, Deck |
| 21 | 323-29 | 2 | Screw-HH |
| 22 | 99-8942 | 1 | Decal-Deck Height, Outer |
| 23 | 99-8941 | 1 | Decal-Deck Height, Inner |
| 25 | 105-2699 | 1 | Decal-Noise |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 26 | 323-8 | 1 | Screw-HH |

PROTOTYPE





# Main Frame Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 1-513658 | 2 | Bumper |
| 2 | 106-6591 | 1 | Console ASM |
| 2:2 | 106-6590 | 1 | Decal-Control Panel |
| 2:3 | 99-8937 | 1 | Decal-Valve, Fuel |
| 2:4 | 98-4387 | 1 | Decal-Protection, Ear |
| 3 | 1-603336 | 1 | Control-Choke |
| 4 | 1-807513 | 2 | Bolt-CARR |
| 5 | 322-5 | 3 | Screw-HH |
| 6 | 3256-23 | 2 | Washer-Flat |
| 7 | 1-513592 | 1 | Knob-Ball |
| 8 | 322-3 | 2 | Screw-HH |
| 9 | 1-653089-03 | 1 | Bracket |
| 10 | 32128-20 | 12 | Nut-HF |
| 11 | 1-633696 | 1 | Cable-Throttle |
| 12 | 3296-2 | 2 | Nut-Lock |
| 13 | 105-6124 | 1 | Console |
| 13:2 | 99-8936 | 2 | Decal-Control, Motion |
| 13:3 | 99-8944 | 1 | Decal-Battery |
| 24 | 1-523420 | 2 | Bumper |
| 25 | 107-2118 | 1 | Main Frame ASM |
| 25:2 | 106-5517 | 2 | Decal-Surface, Hot |
| 25:3 | 105-6183 | 1 | Decal-Release, Drive |
| 26 | 3296-42 | 2 | Nut-Lock, NI |
| 27 | 1-633396 | 1 | Clip-Loom |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 28 | 1-653010 | 2 | Wheel And Tire ASM |
| 28:1 | 1-653160 | 1 | Tire |
| 28:2 | 1-653158 | 1 | Wheel |
| 28:3 | 232-27 | 1 | Stem-Valve |
| 29 | 242-50 | 8 | Nut-Lug |
| 30 | 322-2 | 6 | Screw-HH |
| 32 | 3256-3 | 2 | Washer-Flat |
| 33 | 3296-39 | 1 | Nut-Lock, NI |
| 36 | 3231-21 | 1 | Screw-CARR |
| 37 | 99-8947-03 | 1 | Stop-Cover |


PROTOTYPE




# Fuel System Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 106-9976 | 1 | LH Fuel Tank ASM |
| 1:2 | 103-2605 | 1 | Fitting-Fuel, Bulkhead |
| 2 | 106-9975 | 1 | RH Fuel Tank ASM |
| 2:2 | 103-2605 | 1 | Fitting-Fuel, Bulkhead |
| 3 | 3256-23 | 8 | Washer-Flat |
| 4 | 1-805005 | 4 | Washer-Lock |
| 5 | 322-3 | 4 | Screw-HH |
| 7 | 1-303077 | 6 | Clamp |
| 9 | 1-543296 | 2 | Grommet |
| 10 | 1-543526 | 2 | Hose-Fuel |
| 11 | 1-633347 | 1 | Valve-Fuel |
| 12 | 103-0216 | 1 | Hose-Fuel |
| 16 | 1-303335 | 1 | Tie-Plastic |
| 20 | 88-3980 | 2 | Gas Cap ASM |
| 20:3 | 88-4010 | 1 | Gasket-Cap, Gas |
| 21 | 1-633023 | 4 | Stud |
| 22 | 1-633349 | 4 | Spring-Tank, Fuel |
| 23 | 3296-47 | 4 | Nut-Lock, NI |

PROTOTYPE





# Parking Brake System Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 1-652073-03 | 1 | Crank-Brake, Park |
| 2 | 3272-10 | 2 | Pin-Cotter |
| 4 | 1-808285 | 2 | Pin-Clevis |
| 5 | 3219-3 | 4 | Nut-HH |
| 7 | 1-653068 | 4 | Spacer-Wheel |
| 9 | 325-13 | 8 | Screw-HH |
| 10 | 103-0355 | 2 | Band-Brake |
| 11 | 103-0590 | 2 | Hub-Wheel ASM |
| 11:1 | 103-0589 | 1 | Wheel Hub ASM |
| 11:2 | 1-633926 | 4 | Stud-Wheel |
| 12 | 103-2399 | 2 | Pin-Spring, Clevis |
| 13 | 1-806800 | 2 | Pin-Cotter |
| 14 | 103-0374 | 2 | Retainer-Band, Brake |
| 15 | 103-0384 | 6 | Spacer |
| 16 | 322-9 | 6 | Screw-HH |
| 17 | 103-0352-03 | 2 | Bracket-Brake |
| 18 | 1-633144 | 2 | Pin-Trunion |
| 19 | 3256-4 | 4 | Washer-Flat |
| 20 | 1-633454 | 2 | Spring-Brake |
| 21 | 323-4 | 9 | Screw-HH |
| 22 | 1-653074-03 | 1 | Handle-Brake, Park |
| 23 | 1-633268 | 1 | Grip-Lever, Brake |
| 24 | 1-653069 | 4 | Spacer-Wheel |
| 25 | 3253-7 | 8 | Washer-Lock |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 26 | 103-0131 | 8 | Nut-Square |
| 27 | 1-633102 | 4 | Bearing-Flange, Side |
| 28 | 3290-357 | 8 | Nut-HHF |
| 29 | 103-3116 | 1 | Shaft-Brake, Parking |
| 31 | 1481 | 2 | Fitting-Grease |
| 32 | 98-5975 | 1 | Washer-Belleville |
| 33 | 1-523157 | 2 | Washer-Spacer |
| 34 | 1-523328 | 2 | Motor-Wheel |
| 34:1 | 1-809036 | 1 | Nut-HH |
| 34:2 | 3257-42 | 1 | Key-Woodruff |
| ❶34:99 | 1-000139 | 1 | Bearing Kit |
| ❶34:99 | 103-2748 | 1 | Drive Link Kit |
| ❶34:99 | 1-000099 | 1 | Seal Kit |
| 35 | 32151-48 | 1 | E-Ring |
| 36 | 3256-28 | 1 | Washer-Flat |
| 37 | 103-4328 | 1 | Brake Rod ASM |
| 37:1 | 1-633131 | 2 | Yoke-Linkage, Brake |
| 37:2 | 1-653061 | 1 | Linkage-Handle, Brake |
| 37:3 | 3219-3 | 2 | Nut-HH |
| 38 | 103-4329 | 2 | Brake Rod ASM |
| 38:1 | 1-633131 | 1 | Yoke-Linkage, Brake |
| 38:2 | 103-0356 | 1 | Rod-Brake |
| 38:3 | 3219-3 | 1 | Nut-HH |

PROTOTYPE





# Steering Control Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 1-403180 | 2 | Screw-HH |
| 2 | 103-4101 | 2 | Pin-Damper |
| 3 | 3256-23 | 4 | Washer-Flat |
| 4 | 32120-35 | 2 | E-Ring |
| 5 | 103-4079 | 2 | Damper-Control, Motion |
| 7 | 1-633102 | 4 | Bearing-Flange, Side |
| 8 | 103-4774 | 1 | Control-Motion, LH |
| 9 | 32128-20 | 12 | Nut-HF |
| 10 | 103-4326 | 1 | Tracking Rod ASM |
| 10:1 | 1-543017 | 1 | Balljoint-RH |
| 10:2 | 3219-2 | 1 | Nut-Hex |
| 10:3 | 103-3060 | 1 | Knob-Tracking |
| 10:4 | 1-804524 | 2 | Nut |
| 10:5 | 1-323245 | 2 | Spring-Compression |
| 10:6 | 1-633152 | 1 | Balljoint-Thread, LH |
| 10:7 | 103-3066 | 1 | Link-Rod, Tracking |
| 11 | 3256-3 | 4 | Washer-Flat |
| 13 | 322-6 | 4 | Screw-HH |
| 14 | 3290-357 | 8 | Nut-HHF |
| 15 | 103-0631 | 1 | LH Lever ASM |
| 15:1 | 1-633257 | 1 | Grip-Control, Motion |
| 16 | 3219-2 | 4 | Nut-Hex |
| 19 | 323-4 | 8 | Screw-HH |
| 20 | 103-3717 | 2 | Arm-Control |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 21 | 1-803022 | 2 | Screw-Set |
| 23 | 103-4773 | 1 | Control-Motion, RH |
| 24 | 3296-39 | 6 | Nut-Lock, NI |
| 25 | 103-0407 | 2 | Arm-Shaft, Control |
| 26 | 98-5975 | 4 | Washer-Belleville |
| 27 | 323-6 | 4 | Screw-HH |
| 28 | 103-0632 | 1 | RH Lever ASM |
| 28:1 | 1-633257 | 1 | Grip-Control, Motion |
| 30 | 323-9 | 6 | Screw-HH |
| 31 | 1-603737 | 2 | Bolt-Return, Neutral |
| 32 | 1-603807 | 2 | Spring-Return, Neutral |
| 33 | 1-603735 | 2 | Bushing-Flanged |
| 36 | 3256-2 | 2 | Washer-Flat |
| 37 | 3220-2 | 2 | Nut |
| 38 | 1-303105 | 2 | Yoke-Adjustable |
| 39 | 1-808280 | 2 | Pin-Clevis |
| 40 | 3272-5 | 2 | Pin-Cotter |
| 41 | 103-4327 | 1 | Tracking ASM |
| 41:1 | 1-543017 | 1 | Balljoint-RH |
| 41:2 | 1-633152 | 1 | Balljoint-Thread, LH |
| 41:3 | 1-804524 | 1 | Nut |
| 41:4 | 103-3066 | 1 | Link-Rod, Tracking |
| 41:5 | 3219-2 | 3 | Nut-Hex |


PROTOTYPE




# Pump Idler and Belt Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 323-13 | 1 | Screw-HH |
| 2 | 3256-4 | 1 | Washer-Flat |
| 3 | 1-603044 | 1 | Bushing |
| 4 | 302-40 | 1 | Fitting-Grease |
| 5 | 3290-357 | 2 | Nut-HHF |
| 6 | 103-4480 | 1 | Spring-Extension |
| 7 | 323-9 | 2 | Screw-HH |
| 8 | 63-8410 | 1 | Washer |
| 9 | 98-5975 | 1 | Washer-Belleville |
| 10 | 3296-39 | 1 | Nut-Lock, NI |
| 11 | 3256-24 | 1 | Washer-Flat |
| 12 | 1-603843 | 1 | Pulley-Idler |
| 14 | 103-4760 | 1 | Belt-Cog |
| 15 | 103-4482 | 1 | Idler Arm ASM |
| 15:1 | 103-4681 | 2 | Sleeve-Bearing |
| 17 | 3234-11 | 1 | Screw-HHF |

PROTOTYPE





# Engine, Clutch and Muffler Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 3212-12 | 1 | Screw-HH |
| 2 | 1-603610 | 2 | Washer-Spring |
| 3 | 103-0690 | 1 | Clutch |
| 4 | 103-3913 | 1 | Sheave W/ Hub |
| 5 | 1-807259 | 1 | Key |
| 6 | 103-2308 | 1 | Spacer-Crankshaft |
| 7 | 322-9 | 4 | Screw-HH |
| 8 | 32128-20 | 27 | Nut-HF |
| 9 | 322-3 | 21 | Screw-HH |
| 10 | 3296-29 | 4 | Nut-Lock, NI |
| 11 | 103-3078-03 | 1 | Strap-Guard, RH Engine |
| 12 | 1-653095-03 | 1 | Shield-Engine |
| 13 | 103-3164-03 | 1 | Strap-Guard, LH Engine |
| 14 | 103-1324 | 1 | Muffler |
| 15 | 103-2560-03 | 1 | Shield-Heat |
| 17 | 103-1966 | 1 | Adapter |
| 18 | 103-1965 | 1 | Valve-Drain, Oil |
| 19 | 1-633630 | 2 | Grommet-Brake |
| 20 | 1-633545 | 2 | Spacer |
| 21 | 1-613235 | 4 | Washer |
| 22 | 322-6 | 1 | Screw-HH |
| 23 | 1-303335 | 2 | Tie-Plastic |
| 24 | 103-2614 | 1 | Spacer |
| 25 | 1-633543-03 | 1 | Strap-Clutch, Brake |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 26 | 322-22 | 1 | Screw-HH |
| 27 | 3256-3 | 3 | Washer-Flat |
| 28 | 1-653196 | 1 | Bracket-Support, Muffler |
| 30 | 1-653565-03 | 1 | Shield-Heat |
| 31 | 3230-1 | 3 | Bolt-CARR |
| 32 | 3256-23 | 3 | Washer-Flat |
| 33 | 3296-29 | 3 | Nut-Lock, NI |
| ❷36 | | 1 | Engine-Kawasaki, Fh500v-Es10 |
| 37 | 1-303334 | 2 | Washer-Spring |
| 38 | 103-2599 | 1 | Tailpipe |
| 39 | 103-2630 | 1 | Clamp |
| 40 | 103-2631 | 1 | Clamp |
| 41 | 103-2564-03 | 1 | RH Exhaust Guard ASM |
| 42 | 105-9370-03 | 1 | LH Exhaust Guard ASM |
| 45 | 105-9369-03 | 1 | RH Exhaust Guard ASM |
| 46 | 105-9365-03 | 1 | LH Rear Guard ASM |


PROTOTYPE




# Deck and Wheel Gage Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 3290-357 | 7 | Nut-HHF |
| 2 | 68-2730 | 5 | Wheel-Gage |
| 3 | 98-5967 | 1 | Spacer |
| 4 | 323-28 | 1 | Screw-HH |
| 11 | 32152-1 | 4 | Nut-Lock, NI |
| 12 | 32128-17 | 4 | Nut-Lock, Flange |
| 13 | 249-21 | 2 | Clamp-Slotted |
| 14 | 100-3961 | 1 | LH Cover ASM |
| 14:2 | 98-1977 | 1 | Decal-Warning |
| 15 | 100-3962 | 1 | RH Cover ASM |
| 15:2 | 98-1977 | 1 | Decal-Warning |
| 16 | 99-2842 | 3 | Spacer |
| 17 | 98-5975 | 3 | Washer-Belleville |
| 20 | 106-6565 | 1 | Deck And Deflector ASM |
| 22 | 3290-321 | 4 | Screw-HWH |
| 23 | 1-373034 | 3 | Washer |
| 27 | 100-3257-03 | 1 | Plate-Blowout, RH |
| 28 | 100-3258-03 | 1 | Plate-Blowout, LH |
| 29 | 12-3270 | 9 | Screw |


PROTOTYPE




# Deck and Deflector Assembly No. 106-6565

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷1 | | 1 | Deck ASM |
| 1:2 | 93-7828 | 1 | Decal- Warning, Deflector (Ce) |
| 1:3 | 98-1977 | 3 | Decal-Warning |
| 1:4 | 99-3943 | 1 | Decal-Routing, Belt |
| 1:5 | 93-7010 | 1 | Decal-Danger |
| 1:6 | 93-7818 | 1 | Decal-Torque, Blade Bolt |
| 1:7 | 99-8939 | 1 | Decal-Anti Scalp |
| 1:8 | 100-3967 | 1 | Decal |
| 1:10 | 93-7824 | 1 | Decal-Danger |
| 2 | 322-50 | 1 | Screw-HH |
| 3 | 105-4626 | 1 | Deflector ASM |
| 3:2 | 93-7824 | 1 | Decal-Danger |
| 4 | 105-4622 | 1 | Spacer |
| 5 | 104-8554 | 1 | Spring-Torsion |
| 6 | 3296-29 | 1 | Nut-Lock, NI |


PROTOTYPE




# Deck Spindle Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 3 | 54-0010 | 3 | Blade |
| 4 | 100-3977 | 3 | Spindle Housing ASM |
| 4:1 | 302-2 | 1 | Fitting-Grease |
| 4:2 | 7-4150 | 1 | Washer |
| 4:3 | 251-257 | 2 | Bearing-Ball |
| 4:4 | 67-7580 | 1 | Spacer-Bearing |
| 4:5 | 67-7570 | 1 | Spacer-Spindle |
| 4:6 | 32146-20 | 1 | Nut-Jam |
| 4:7 | 100-3975 | 1 | Pulley And Hub ASM |
| 4:8 | 67-7590 | 1 | Housing-Spindle |
| 4:9 | 100-3974 | 1 | Spindle Shaft ASM |
| 4:11 | 3256-27 | 1 | Washer-Flat |
| 4:12 | 3253-8 | 1 | Washer-Lock |
| 4:13 | 51-4060 | 1 | Screw-Blade |
| 5 | 32152-1 | 12 | Nut-Lock, NI |
| 6 | 3256-2 | 4 | Washer-Flat |
| 7 | 322-4 | 12 | Screw-HH |
| 8 | 98-3780 | 1 | V-Belt-Drive |

PROTOTYPE





# Idler, Pulley/Lift Strut and Chain Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 3217-7 | 1 | Nut-Hex |
| 3 | 3256-24 | 3 | Washer-Flat |
| 4 | 1-613098 | 2 | Pulley-Idler |
| 5 | 98-5975 | 3 | Washer-Belleville |
| 6 | 323-6 | 3 | Screw-HH |
| 8 | 103-3330 | 1 | Spring-Extension |
| 9 | 302-40 | 1 | Fitting-Grease |
| 10 | 99-8912 | 1 | Pulley-Idler, Flat |
| 11 | 99-8914 | 1 | Idler Arm ASM |
| 11:2 | 1-513034 | 2 | Sleeve-Bearing |
| 12 | 1-603384 | 1 | Bushing-Pivot, Idler |
| 13 | 3296-29 | 2 | Nut-Lock, NI |
| 14 | 3217-11 | 2 | Nut-Hex |
| 15 | 3253-8 | 2 | Washer-Lock |
| 16 | 1-800344 | 2 | Screw |
| 17 | 103-1081 | 2 | Strut ASM |
| 17:1 | 103-1072-01 | 1 | Strut |
| 17:2 | 3219-6 | 1 | Nut-Hex |
| 17:3 | 1-633029 | 1 | Balljoint-Spherical |
| 18 | 302-19 | 4 | Fitting-Grease |
| 19 | 1-632199-01 | 2 | Pin-Strut |
| 20 | 322-3 | 2 | Screw-HH |
| 21 | 103-1898 | 8 | Screw,hh 7/16-14x1.63 Special |
| 22 | 32128-37 | 16 | Nut-HF |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 23 | 1-633447 | 4 | Chain-Lift, Deck |
| 24 | 99-3946-01 | 1 | Plate-Retainer, Bolt |
| 25 | 1-800805 | 1 | Screw-HH |
| 26 | 94-2547 | 1 | Bolt-Eye |
| 27 | 3296-39 | 2 | Nut-Lock, NI |
| 28 | 1-809107 | 2 | Washer-Hardened |
| 29 | 107-3076 | 2 | Screw HH |
| 30 | 107-3077 | 2 | Screw HH |
| 31 | 112843 | 2 | Washer |
| 32 | 100-7123 | 4 | Spacer-Bedbar |

PROTOTYPE





# Hydraulic System Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 103-1942 | 2 | Pump-HYD |
| 3 | 103-1799 | 2 | Elbow-90 DEG |
| 3:1 | 237-42 | 1 | O-Ring |
| 5 | 103-1988 | 2 | Clamp-Hose |
| 7 | 1-653156 | 2 | Pulley |
| 8 | 1-803050 | 4 | Screw-Set |
| 9 | 1-807272 | 2 | Key |
| 10 | 323-7 | 4 | Screw-HH |
| 11 | 3290-357 | 4 | Nut-HHF |
| 16 | 103-1802 | 2 | Fitting-Hyd, 90 DEG |
| 16:1 | 237-42 | 1 | O-Ring |
| 17 | 103-1940 | 4 | Adapter-Hyd, Straight |
| 17:1 | 237-79 | 1 | O-Ring |
| 17:2 | 1-603992 | 1 | O-Ring |
| 18 | 1-633605 | 2 | Fitting-Hyd, 90 DEG |
| 18:1 | 1-603992 | 1 | O-Ring |
| 18:2 | 237-80 | 1 | O-Ring |
| 19 | 100-3964 | 1 | Hose-Front |
| 20 | 100-3965 | 1 | Hose-Rear |
| 21 | 103-2357 | 1 | HYD Hose ASM |
| 22 | 103-1801 | 1 | Adapter-Straight |
| 22:1 | 237-42 | 1 | O-Ring |
| 23 | 103-1912 | 1 | Adapter-Straight |
| 23:1 | 237-42 | 1 | O-Ring |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 24 | 103-1946 | 1 | Reservoir-HYD |
| 24:1 | 103-1948 | 1 | Cap-Reservoir, HYD |
| 24:2 | 103-1949 | 1 | Gasket-Cap |
| 25 | 103-3071-03 | 1 | Stand-Reservoir |
| 26 | 322-3 | 1 | Screw-HH |
| 27 | 321-3 | 2 | Screw-HH |
| 29 | 103-3077 | 1 | HYD Hose ASM |
| 30 | 103-2930 | 1 | HYD Hose ASM |
| 32 | 103-2889 | 1 | Filter Head ASM |
| 32:1 | 103-1912 | 2 | Adapter-Straight |
| 32:1:1 | 237-42 | 1 | O-Ring |
| 33 | 32128-20 | 2 | Nut-HF |
| 34 | 1-633752 | 1 | Filter-Hyd, Winter |
| 34 | 1-633750 | 1 | Filter-HYD |
| 35 | 322-6 | 2 | Screw-HH |
| 37 | 103-1716 | 3 | Clamp-Hose |
| 38 | 322-5 | 1 | Screw-HH |
| 39 | 105-6187 | 2 | Hose ASM W/ Sleeve |
| 40 | 1-603991 | 2 | Fitting-Straight |
| 40:1 | 237-80 | 1 | O-Ring |
| 40:2 | 1-603992 | 1 | O-Ring |
| 41 | 107-2130 | 1 | Shield ASM |
| 41:1 | 107-2129-03 | 1 | Shield-Heat |
| 41:2 | 107-2131 | 1 | Decal - Hot Surface, Ce |


PROTOTYPE




# Hydraulic System Assembly (continued)

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 42 | 105-3619 | 2 | Spacer |
| 45 | 3256-22 | 2 | Washer-Flat |


PROTOTYPE




# Hydraulic Pump Assembly No. 103-1942

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 105-6184 | 1 | Seal Overhaul Kit |
| 2 | 105-6185 | 1 | Plate-Valve |
| 3 | 103-2664 | 1 | Input Shaft Kit |
| 4 | 94-6922 | 1 | Bearing-Thrust |
| 5 | 103-2666 | 1 | Cylinder Block Kit |
| 7 | 106-2053 | 1 | Shock Valve Kit |


PROTOTYPE




# Deck Recycler Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 3290-456 | 4 | Washer-Belleville |
| 2 | 32149-1 | 8 | Nut |
| 3 | 3296-29 | 4 | Nut-Lock, NI |
| 4 | 3256-23 | 4 | Washer-Flat |
| 5 | 92-7952 | 3 | Blade-Recycler |
| 6 | 93-1196 | 1 | Kicker-Center, Rear |
| 7 | 322-2 | 1 | Screw-HH |
| 8 | 93-7651 | 1 | Baffle-RH |
| 9 | 322-5 | 3 | Screw-HH |
| 10 | 84-5760 | 3 | Plate-Kicker |
| 11 | 322-6 | 4 | Screw-HH |
| 12 | 59-4310 | 3 | Spacer |
| 13 | 93-7652 | 1 | Baffle-LH |
| 14 | 105-2675-01 | 1 | Guard-Left |
| 15 | 105-2672-01 | 1 | Guard-Right |
| 16 | 12-3270 | 7 | Screw |

PROTOTYPE





# Electrical System Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 1-543792 | 2 | Wingnut |
| 2 | 1-633652-03 | 1 | Strap-Holddown |
| 3 | 1-633651 | 2 | Bolt-Holddown |
| 4 | 103-0705 | 1 | Cable-Ground, Negative |
| 5 | 1-543391 | 1 | Insulator-Battery |
| 6 | 321-4 | 5 | Screw-HH |
| 7 | 3256-2 | 2 | Washer-Flat |
| 8 | 32128-33 | 6 | Nut-HF |
| 9 | 105-1692 | 1 | Battery |
| 9:1 | 104-4163 | 1 | Decal-Battery |
| 9:2 | 104-4164 | 1 | Decal-Battery |
| 10 | 103-0707 | 1 | Cable-Battery, Positive |
| 11 | 1-800282 | 1 | Screw-HH |
| 12 | 1-523415 | 1 | Spring-Switch, Seat |
| 13 | 3290-500 | 8 | Screw-PPH |
| 14 | 1-652072-03 | 1 | Bracket-Switch, Seat |
| 15 | 322-3 | 3 | Screw-HH |
| 16 | 32128-20 | 5 | Nut-HF |
| 17 | 1-653036 | 1 | Washer |
| 18 | 1-513152 | 1 | Switch-Closed, Normally |
| 19 | 1-633181 | 4 | Plate-Tapped |
| 20 | 1-816001 | 2 | Fuse-Blade Type, 20 Amp |
| 21 | 103-0623 | 1 | Harness-Wire |
| 22 | 1-303287 | 3 | Tie-Plastic |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 23 | 1-543393 | 3 | Insulator-Solenoid |
| 24 | 1-643275 | 2 | Relay |
| 25 | 1-633306 | 1 | Wire-Starter |
| 26 | 1-513075 | 1 | Switch-Solenoid |
| 27 | 1-543286 | 2 | Grommet |
| 28 | 1-633396 | 2 | Clip-Loom |
| 29 | 1-513051 | 2 | Switch-Open, Normally |
| 30 | 1-303335 | 4 | Tie-Plastic |
| 31 | 1-513374 | 1 | Meter-Hour |
| 32 | 1-633111 | 1 | Switch |
| 33 | 100-6186 | 1 | Module-Delay, Seat |
| 34 | 88-9830 | 1 | Key Switch ASM |
| 34:1 | 3254-5 | 1 | Washer-Tooth |
| 34:2 | 218-461 | 1 | Nut-HH |
| 35 | 63-8360 | 2 | Key-Ignition |
| 36 | 1-633673 | 1 | Switch-Delta |
| 37 | 3296-2 | 5 | Nut-Lock |
| 38 | 1-807513 | 4 | Bolt-CARR |
| 42 | 3256-14 | 1 | Washer-Flat |
| 43 | 103-1193 | 1 | Clip-Half, Loom |
| 44 | 1-807533 | 1 | Bolt-CARR |


PROTOTYPE




# Seat and Roll-Over Protection System Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 17 | 103-1731 | 1 | Rod-Retainer, Seat |
| 18 | 107-1867 | 1 | Seat ASM |
| 19 | 99-4693 | 1 | Decal |
| 20 | 2412-120 | 2 | R-Clamp |
| 21 | 104-7048 | 1 | Cap-Housing |
| 22 | 32104-76 | 2 | Screw |
| 23 | 104-7050 | 1 | Housing-Manual |
| 24 | 322-5 | 1 | Screw-HH |
| 26 | 3296-42 | 2 | Nut-Lock, NI |
| 50 | 107-3066 | 1 | Rops ASM |


PROTOTYPE




# Seat Assembly No. 107-1867

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 103-0290 | 1 | Cushion-Seat, Bottom |
| 2 | 104-7754 | 1 | Cushion-Seat, Back |
| 5 | 1-543401 | 4 | Spacer-Track |
| 6 | 1-643255 | 1 | Track-Seat |
| 7 | 1-633859 | 1 | Frame-Seat |
| 10 | 321-30 | 11 | Screw-HH |
| 11 | 32128-20 | 4 | Nut-HF |
| 17 | 3256-22 | 11 | Washer-Flat |
| 18 | 105-3620 | 1 | Armrest Kit |
| 18:1 | 1-633710 | 2 | Cushion-Armrest |
| 18:2 | 3256-22 | 4 | Washer-Flat |
| 18:3 | 322-10 | 2 | Screw-HH |
| 18:4 | 105-3623 | 2 | Channel-Armrest |
| 18:5 | 32153-3 | 2 | Nut-Lock |
| 18:6 | 105-3621 | 1 | Bracket-Armrest, RH |
| 18:7 | 105-3622 | 1 | Bracket-Armrest, LH |
| 18:8 | 321-30 | 6 | Screw-HH |
| 18:9 | 3296-42 | 4 | Nut-Lock, NI |
| 18:10 | 325-2 | 2 | Screw-HH |
| 18:11 | 3296-23 | 2 | Nut-Lock, NI |
| 20 | 103-4469 | 1 | Seatbelt Kit |
| 20:2 | 3212-4 | 2 | Screw-HH |
| 20:3 | 3296-38 | 2 | Nut-Lock NI |

PROTOTYPE





# Roll-Over Protection System Assembly No. 107-3066

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 2 | 32128-23 | 2 | Nut-HF |
| 3 | 107-3060 | 2 | Pin Latch ASM |
| 4 | 107-3124 | 2 | Clip |
| 6 | 106-0887 | 2 | Knob |
| 7 | 325-13 | 2 | Screw-HH |
| 9 | 62-9130 | 1 | Grip-Handle |
| 10 | 107-3083 | 1 | Latch ASM |
| 11 | 3256-24 | 1 | Washer-Flat |
| 12 | 323-20 | 1 | Screw-HH |
| 14 | 107-0075 | 1 | Bushing-Latch, Seat |
| 16 | 107-0076 | 1 | Spring-Torsion |
| 17 | 3296-39 | 1 | Nut-Lock, NI |
| 18 | 3296-29 | 2 | Nut-Lock, NI |
| 20 | 98-5975 | 8 | Washer-Belleville |
| 21 | 323-6 | 8 | Screw-HH |
| 22 | 3290-357 | 8 | Nut-HHF |
| 23 | 107-3059 | 1 | Catch-Latch, Seat |
| 24 | 322-4 | 2 | Screw-HH |
| 25 | 107-3154 | 2 | Nut-Push |
| 28 | 107-3052-03 | 1 | Frame-Support, Seat |
| 29 | 103-4469 | 1 | Seatbelt Kit |
| 29:2 | 3212-4 | 2 | Screw-HH |
| 29:3 | 3296-38 | 2 | Nut-Lock NI |
| 30 | 107-3079 | 1 | Template-Mount, Rops |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 31 | 107-2112 | 1 | Decal-Warning |
| 32 | 107-3069 | 1 | Decal-Warning, Folding Rops Ce |
| 33 | 107-1866 | 1 | Decal-Danger, Slope |
| 47 | 107-2102 | 1 | Decal-Warning, Folding Rops |

PROTOTYPE





# Cylinder/Crankcase Assembly
# Kawasaki FH500V-ES10

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸11004 | 11004-7001 | 2 | Gasket-Head |
| ❸11008 | 11008-7001 | 1 | Head-Comp-Cylinder No. 1 |
| ❸11008A | 11008-7002 | 1 | Head-Comp-Cylinder |
| ❸11022 | 11022-7001 | 2 | Case-Rocker |
| ❸11060 | 11060-7001 | 2 | Gasket-Rocker Case |
| ❸11060A | 11060-7002 | 1 | Gasket, Breather |
| ❸11060B | 11060-7007 | 1 | Gasket, Crankcase Cover |
| ❸14090 | 14090-7001 | 1 | Cover, Breather |
| ❸27010 | 27010-7001 | 1 | Switch |
| ❸49015 | 49015-6205 | 1 | Cover-Crankcase |
| ❸49109 | 49109-7001 | 1 | Element-Breather |
| ❸49120 | 49120-6117 | 1 | Crankcase-Comp |
| ❸59071 | 59071-7003 | 1 | Joint |
| ❸92033 | 92033-7003 | 2 | Ring-Snap |
| ❸92043 | 92043-7001 | 6 | Pin |
| ❸92049 | 92049-7001 | 4 | Seal-Oil |
| ❸92049A | 92049-7002 | 1 | Seal-Oil |
| ❸92049B | 92049-7004 | 1 | Seal-Oil |
| ❸92049C | 92049-7005 | 1 | Seal-Oil |
| ❸92066 | 92066-7003 | 2 | Plug |
| ❸130 | 130B0612 | 4 | Bolt-Flanged |
| ❸130A | 130B0640 | 4 | Bolt-Flanged |
| ❸130B | 130T0850 | 16 | Bolt-Flanged |
| ❸130C | 130T0875 | 2 | Bolt-Flanged |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸172 | 172G0818 | 4 | Bolt-Stud |
| ❸670 | 670D2016 | 3 | 0-Ring |


PROTOTYPE





# Valve/Camshaft Assembly
# Kawasaki FH500V-ES10

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸12004 | 12004-7001 | 2 | Valve-Intake |
| ❸12005 | 12005-7001 | 2 | Valve-Exhaust |
| ❸12009 | 12009-7001 | 4 | Retainer-Valve Spring |
| ❸12011 | 12011-2056 | 8 | Collet |
| ❸12016 | 12016-7001 | 4 | Arm-Rocker |
| ❸12032 | 12032-7001 | 4 | Tappet |
| ❸13070 | 13070-7001 | 2 | Guide |
| ❸13070A | 13070-7002 | 1 | Guide |
| ❸13116 | 13116-2057 | 4 | Rod Push |
| ❸13270 | 13270-7002 | 1 | Plate |
| ❸13270A | 13270-7003 | 1 | Plate |
| ❸42036 | 42036-7001 | 1 | Sleeve |
| ❸49078 | 49078-7001 | 4 | Spring-Engine Valve |
| ❸49118 | 49118-7002 | 1 | Camshaft-Comp |
| ❸92009 | 92009-2341 | 4 | Screw |
| ❸92015 | 92015-2253 | 4 | Nut |
| ❸92033 | 92033-7001 | 2 | Ring-Snap |
| ❸92140 | 92140-7002 | 6 | Ball |
| ❸92145 | 92145-7001 | 1 | Spring |
| ❸92151 | 92151-7001 | 4 | Bolt |
| ❸92200 | 92200-7001 | 1 | Washer |

PROTOTYPE





# Air Filter/Muffler Assembly
# Kawasaki FH500V-ES10

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸11010 | 11010-7001 | 1 | Air Filter ASM |
| ❸11013 | 11013-7001 | 1 | Element-Air Filter |
| ❸11013A | 11013-7002 | 1 | Element-Air Filter |
| ❸11038 | 11038-7001 | 1 | Air Filter Case ASM |
| ❸11050 | 11050-7006 | 1 | Bracket |
| ❸11060A | 11060-7021 | 2 | Gasket-Muffler |
| ❸27012 | 27012-7001 | 2 | Hook-Air Filter |
| ❸59071 | 59071-7001 | 2 | Joint |
| ❸92015 | 92015-1193 | 2 | Nut |
| ❸92191 | 92191-7001 | 1 | Tube |
| ❸92210 | 92210-7004 | 1 | Nut |
| ❸130 | 130B0612 | 2 | Bolt-Flanged |
| ❸232 | 232B0514 | 2 | Screw-Pan |
| ❸317 | 317R0800 | 4 | Nut-Hex |
| ❸461 | 461F0800 | 4 | Washer-Lock |


PROTOTYPE




# Fuel Tank/Fuel Valve Assembly
# Kawasaki FH500V-ES10

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸23062A | 23062-7004-9H | 1 | Bracket-Comp |
| ❸49019 | 49019-7001 | 1 | Filter-Fuel |
| ❸49040B | 49040-7001 | 1 | Pump-Fuel |
| ❸92170 | 92170-2088 | 4 | Clamp |
| ❸92191 | 92191-7002 | 1 | Tube |
| ❸92191A | 92191-7003 | 1 | Tube |
| ❸92191B | 92191-7004 | 1 | Tube |
| ❸130 | 130B0620 | 2 | Bolt-Flanged |


PROTOTYPE




# Lubrication Equipment Assembly
# Kawasaki FH500V-ES10

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸13107A | 13107-7009 | 1 | Shaft |
| ❸13271 | 13271-7017 | 1 | Plate |
| ❸14075 | 14075-7001 | 1 | Cap ASM |
| ❸16154 | 16154-2053 | 1 | Rotor-Pump,in |
| ❸16154A | 16154-2054 | 1 | Rotor-Pump,out |
| ❸49065 | 49065-2078 | 1 | Filter-Oil |
| ❸49065D | 49065-7001 | 1 | Filter-Oil |
| ❸59051 | 59051-7004 | 1 | Gear-Spur |
| ❸59231 | 59231-7001 | 1 | Filler |
| ❸92043 | 92043-7003 | 1 | Pin |
| ❸92066 | 92066-7003 | 2 | Plug |
| ❸92140 | 92140-7003 | 1 | Ball |
| ❸92145 | 92145-7002 | 1 | Spring |
| ❸130 | 130B0612 | 3 | Bolt-Flanged |
| ❸670 | 670D2016 | 1 | 0-Ring |


PROTOTYPE





# Piston/Crankshaft Assembly
# Kawasaki FH500V-ES10

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸13001B | 13001-7008 | 2 | Piston-Engine |
| ❸13002 | 13002-7001 | 2 | Pin-Piston |
| ❸13008 | 13008-6055 | 2 | Ring Set-Piston |
| ❸13029C | 13029-7004 | 0 | Piston-Engine |
| ❸13031 | 13031-7001 | 1 | Crankshaft-Comp |
| ❸13251B | 13251-7003 | 2 | Connecting Rod ASM |
| ❸13251D | 13251-7004 | 2 | Connecting Rod ASM |
| ❸92033B | 92033-7005 | 4 | Ring-Snap |
| ❸130 | 130G0630 | 4 | Bolt-Flanged |

PROTOTYPE





# Label Assembly
# Kawasaki FH500V-ES10

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸56033 | 56033-7001 | 1 | Decal-Manual |
| ❸56080A | 56080-7011 | 1 | Decal-Brand |

PROTOTYPE





# Carburetor Assembly
# Kawasaki FH500V-ES10

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸11003 | 11003-2105 | 1 | Seat-Valve |
| ❸11060 | 11060-2406 | 1 | Gasket |
| ❸11060A | 11060-7003 | 2 | Gasket-Insulator |
| ❸11060B | 11060-7004 | 1 | Gsket-Air Filter |
| ❸11060C | 11060-7005 | 2 | Gasket |
| ❸11065 | 11065-2061 | 1 | Cap |
| ❸15003C | 15003-7037 | 1 | Carburetor ASM |
| ❸16014 | 16014-2080 | 1 | Screw-Pilot Air |
| ❸16020 | 16020-2141 | 1 | Chamber-Float |
| ❸16021 | 16021-2060 | 1 | Screw-Throttlestop |
| ❸16025B | 16025-2195 | 1 | Valve-Throttle #135 |
| ❸16030 | 16030-2067 | 1 | Valve-Float |
| ❸16031 | 16031-2066 | 1 | Float |
| ❸16035D | 16035-2077 | 1 | Jet-Air #0.8 |
| ❸16035F | 16035-2081 | 1 | Jet-Air, #1.2 |
| ❸16041 | 16041-2253 | 1 | Shaft-Carburetor, Choke |
| ❸16041A | 16041-7006 | 1 | Shaft-Carburetor |
| ❸16073 | 16073-7001 | 1 | Insulator |
| ❸16126B | 16126-7008 | 1 | Valve |
| ❸21188 | 21188-2011 | 1 | Solenoid |
| ❸26011 | 26011-2281 | 1 | Wire-Lead |
| ❸39076 | 39076-2053 | 1 | Limiter |
| ❸43058 | 43058-3716 | 1 | Ring |
| ❸49121B | 49121-2231 | 1 | Nozzle-Main |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸59076 | 59076-7001 | 1 | Manifold-Intake |
| ❸92009 | 92009-2015 | 1 | Screw |
| ❸92009A | 92009-2024 | 2 | Screw |
| ❸92009B | 92009-2081 | 1 | Screw |
| ❸92009C | 92009-2400 | 1 | Screw |
| ❸92022 | 92022-2231 | 1 | Washer |
| ❸92022A | 92022-2239 | 1 | Washer |
| ❸92027 | 92027-2025 | 1 | Ring |
| ❸92033 | 92033-2067 | 1 | Ring-Snap |
| ❸92043 | 92043-2226 | 1 | Pin |
| ❸92063B | 92063-2380 | 1 | Jet-Main |
| ❸92064B | 92064-2127 | 1 | Jet-Pilot |
| ❸92081 | 92081-2009 | 2 | Spring |
| ❸92081A | 92081-2256 | 2 | Spring |
| ❸92093 | 92093-2002 | 1 | Seal |
| ❸92145 | 92145-2061 | 1 | Spring |
| ❸92191A | 92191-7016 | 1 | Tube |
| ❸130 | 130B0635 | 4 | Bolt |
| ❸172 | 172G0685 | 2 | Stud |
| ❸214 | 214B0510 | 1 | Screw-P |
| ❸482 | 482L4000 | 1 | Circlip-Type-E |


PROTOTYPE




# Control Equipment Assembly
# Kawasaki FH500V-ES10

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸11051 | 11051-7008 | 1 | Bracket |
| ❸13107C | 13107-7010 | 1 | Shaft |
| ❸13271 | 13271-7018 | 1 | Plate |
| ❸16169 | 16169-7001 | 1 | Link-Choke |
| ❸16171 | 16171-7001 | 1 | Link |
| ❸39129 | 39129-7003 | 1 | Spring-Governor |
| ❸39129A | 39129-7003 | 1 | Spring-Governor |
| ❸49103B | 49103-7004 | 1 | Arm-Governor |
| ❸49113B | 49113-7004 | 1 | Panel-Comp-Control |
| ❸92009A | 92009-7007 | 1 | Screw, 4x30 |
| ❸92145 | 92145-7003 | 1 | Spring |
| ❸92145A | 92145-7004 | 1 | Spring |
| ❸92145B | 92145-7005 | 1 | Spring |
| ❸92150 | 92150-2182 | 2 | Bolt |
| ❸92153 | 92153-7005 | 1 | Bolt |
| ❸92170 | 92170-7001 | 2 | Clamp |
| ❸130 | 130B0612 | 2 | Bolt-Flanged |
| ❸214 | 214B0408 | 2 | Screw-Pan |
| ❸311 | 311B0600 | 1 | Nut |
| ❸411 | 411b0600 | 1 | Washer |


PROTOTYPE




# Cooling Equipment Assembly
# Kawasaki FH500V-ES10

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸13270 | 13270-7007 | 1 | Plate |
| ❸14037 | 14037-7003-9H | 1 | Screen |
| ❸23062 | 23062-7008 | 1 | Bracket-Comp |
| ❸49089 | 49089-7001 | 1 | Shroud-Engine |
| ❸49089A | 49089-7002 | 1 | Shroud-Engine |
| ❸49089B | 49089-7003 | 1 | Shroud-Engine |
| ❸55020 | 55020-7004 | 1 | Guard |
| ❸59041 | 59041-7001 | 1 | Fan |
| ❸59066 | 59066-7002 | 1 | Housing-Fan |
| ❸92004 | 92004-7006 | 2 | Stud |
| ❸92009 | 92009-7008 | 3 | Screw |
| ❸92015 | 92015-1170 | 4 | Nut |
| ❸92026 | 92026-7001 | 3 | Spacer |
| ❸92026A | 92026-7003 | 1 | Spacer |
| ❸92026B | 92026-7007 | 1 | Spacer |
| ❸92200 | 92200-2078 | 1 | Washer |
| ❸130 | 130B0612 | 5 | Bolt-Flanged |
| ❸130A | 130B0616 | 2 | Bolt-Flanged |
| ❸130B | 130B0620 | 1 | Bolt-Flanged |
| ❸130C | 130B0625 | 2 | Bolt-Flanged |
| ❸130D | 130B0816 | 1 | Bolt-Flanged |
| ❸311 | 311B0600 | 2 | Nut |


PROTOTYPE




# Electric Equipment Assembly
# Kawasaki FH500V-ES10

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸21066 | 21066-7001 | 1 | Regulator-Voltage |
| ❸21171 | 21171-7001 | 2 | Ignition Coil ASM |
| ❸21193C | 21193-7007 | 1 | Flywheel ASM |
| ❸26011 | 26011-7001 | 1 | Wire-Lead |
| ❸26030 | 26030-7001 | 1 | Harness |
| ❸59031 | 59031-7001 | 1 | Coil-Charging |
| ❸92004 | 92004-2147 | 2 | Stud |
| ❸92009 | 92009-2308 | 2 | Screw |
| ❸92070A | 92070-7003 | 2 | Plug-Spark (Rcj8y) |
| ❸92072A | 92072-7003 | 2 | Band |
| ❸92151 | 92151-2097 | 1 | Bolt |
| ❸92200 | 92220-7002 | 1 | Washer |
| ❸130 | 130B0620 | 1 | Bolt-Flanged |
| ❸224 | 224B0520 | 4 | Screw-Pan-Wp-Cros |
| ❸510 | 510A5100 | 1 | Key |

PROTOTYPE




# Starter Assembly
# Kawasaki FH500V-ES10

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❸13101 | 13101-7001 | 1 | Gear ASM |
| ❸21039 | 21039-7001 | 1 | Brush |
| ❸21080 | 21080-7001 | 1 | Armature |
| ❸21163 | 21163-7001 | 1 | Starter-Electric |
| ❸39184 | 39184-7001 | 1 | Bracket ASM |
| ❸92151 | 92151-7013 | 1 | Bolt |
| ❸130 | 130B0816 | 2 | Bolt-Flanged |

PROTOTYPE

# NOTES

PROTOTYPE

# NOTES

PROTOTYPE

# NOTES

PROTOTYPE




PROTOTYPE