



**Count on it.**

Form No. 3472-281 Rev B

# Parts Catalog

## Pro Force® Debris Blower

Model No. 44553—Serial No. 418100000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Engine, Muffler and Fuel Tank Assembly ..... 4

Fuel Tank Assembly No. 115-9048 ..... 5

Fuel Delivery Assembly ..... 6

Electrical System Assembly ..... 7

Wire Harness Assembly No. 122-1747..... 8

Tail Light Assembly ..... 9

Frame, Wheel, Axle and Hitch Assembly ..... 10

Hub and Axle Assembly No. 144-3630..... 12

Frame Assembly..... 13

Axle Assembly No. 119-2966 ..... 14

Hitch Assembly No. 119-3005 ..... 15


Turbine Mounting Assembly ..... 16

Turbine Assembly No. 140-6946SP ..... 17

Nozzle Assembly ..... 18

Driveshaft and Battery Assembly..... 19


Attachments and Accessories ..... 20



## Engine, Muffler and Fuel Tank Assembly


| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 145-7468    | 1    | Engine-Kohler    |
| 2    | 127-8685    | 1    | Canister-Carbon  |
| 3    | 66-9302     | 4    | Screw-HHF Lock   |
| 4    | 104-8301    | 4    | Nut-HF, NI       |
| 5    | 112-6862    | 1    | Muffler          |
| 6    | 119-6171-03 | 1    | Mount-Muffler    |
| 7    | 110-1718    | 4    | Screw-HHSF,Patch |
| 8    | 105-4886    | 2    | Nut-Tinnerman    |
| 9    | 80-6990     | 2    | Washer-Hardened  |
| 10   | 323-6       | 2    | Screw-HH         |
| 11   | 33103-012   | 2    | Screw-HHF        |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 12   | 112-6876    | 1    | Grill-Top             |
| 13   | 104-8300    | 8    | Nut-HF, NI            |
| 14   | 92-1242     | 2    | Decal                 |
| 15   | 115-9048    | 1    | Fuel Tank ASM         |
| 16   | 119-6285    | 2    | Strap-Hold Down, Tank |
| 17   | 104-7201    | 12   | Nut-HF, NI            |
| 18   | 145-7461-01 | 1    | Mount-Tank, 5GA [red] |
| 19   | 140-6766-01 | 1    | Plate-Mount           |
| 20   | 3229-8      | 4    | Screw-CARR            |
| 21   | 3230-2      | 4    | Bolt-CARR             |
| 22   | 144-3629-03 | 1    | Guard-Gauges          |



## Fuel Tank Assembly No. 115-9048


| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 2    | 114-0284    | 1    | Grommet        |
| 3    | 114-0285    | 1    | Valve-Rollover |
| 4    | 46-6560     | 1    | Bushing        |
| 5    | 115-9044    | 1    | Pipe-Stand     |
| 6    | 137-4127    | 1    | Cap-Fuel       |
| 7    | 119-0509    | 1    | Gauge ASM      |
| 7:2  | 119-0508    | 1    | Seal           |



## Fuel Delivery Assembly


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 106-5317    | 3    | Hose-Fuel           |
| 2    | 115-7854    | 1    | Filter-Fuel, Inline |
| 3    | 119-8150    | 1    | Hose-Fuel           |
| 4    | 133-8499    | 1    | Valve-Check, Vacuum |
| 5    | 107-9298    | 1    | Hose-Fuel           |
| 6    | 119-6073    | 1    | Hose-Fuel           |
| 7    | 110-3254    | 1    | Hose-Fuel           |
| 8    | 2412-98     | 2    | Clamp-Hose          |

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 9    | 2412-80     | 5    | Clamp-Hose       |
| 10   | 32180-030   | 6    | Clip-Tie         |
| 11   | 119-8561    | 1    | Hose-Fuel        |
| 12   | 106-8150    | 2    | Fitting-Straight |
| 13   | 92-2379     | 4    | Clamp-Hose       |
| 14   | 120-2235    | 1    | Filter-Fuel      |
| 15   | 110-4109    | 1    | Hose-Fuel        |
| 16   | 3290-378    | 1    | Tie-Cable        |




## Electrical System Assembly

| Ref.    | Part Number | Qty. | Description                          | Ref.  | Part Number | Qty. | Description                |
|---------|-------------|------|--------------------------------------|-------|-------------|------|----------------------------|
| 1       | 122-1747    | 1    | Harness-Wire, Proforce Blower Rf2Can | 13    | 3229-3      | 4    | Screw-CARR                 |
| 2       | 121-5159    | 1    | Switch-Ignition                      | 14    | 125-1360    | 1    | Controller                 |
| 2:1     | 121-5160    | 1    | Nut-Hex                              | 16    | 321-8       | 4    | Screw-HH                   |
| 2:2     | 122-2704    | 1    | Nut-Face, M22 (Plastic)              | 17    | 121-2761    | 1    | Mount-Transmitter          |
| 2:3     | 121-5162    | 1    | Set-Key, Ignition                    | 18    | 3229-11     | 1    | Screw-CARR                 |
| 3       | 99-7430     | 4    | Relay-Mini                           | 19    | 125-1270    | 1    | Remote ASM                 |
| 4       | 321-4       | 6    | Screw-HH                             | 19:3  | 121-2906    | 1    | Pin-Lanyard                |
| 5       | 104-7201    | 15   | Nut-HF, NI                           | 19:4  | 121-2908    | 6    | Screw-PPH                  |
| 6       | 125-5966    | 1    | Cable-Battery, Negative              | 19:12 | 125-1294    | 1    | Backer-Gasket              |
| 7       | 3255-8      | 1    | Washer-Lock                          | 19:13 | 163-0307    | 1    | Gasket-HH                  |
| 8       | 33104-020   | 1    | Screw-HHF                            | 20    | 32180-030   | 3    | Clip-Tie                   |
| 9       | 122-0629    | 1    | Cable-Battery, Positive              | 21    | 122-0630    | 1    | Red LED Indicator Lamp ASM |
| 10      | 120-2244    | 1    | Hourmeter                            | 21:1  | 122-0634    | 1    | Gasket-LED                 |
| 12      | 132-9600    | 1    | Controller                           | 21:2  | 122-0633    | 1    | Washer-Locking             |
| 12:20   | 140-6605    | 1    | Antenna Service Kit                  | 21:3  | 122-0632    | 1    | Nut-Fixing                 |
| 12:20:1 | 125-1567    | 1    | Antenna                              | 25    | 106-9169    | 1    | Screw-HWH                  |
| 12:20:2 | 127-2323    | 1    | O-Ring                               | 26    | 3296-12     | 1    | Nut-Lock, NI               |
| 12:20:3 | 127-2506    | 1    | Spacer                               |       |             |      |                            |



## Wire Harness Assembly No. 122-1747


| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 12   | 32180-043   | 2    | Resistor-120 Ohm         |
| 13   | 32180-089   | 1    | Cap-Plug, 3 Way          |
| 14   | 121-8861    | 1    | Fuse-Mini Blade, 2 Amp   |
| 15   | 121-8865    | 2    | Fuse-Mini Blade, 7.5 Amp |
| 16   | 121-8867    | 1    | Fuse-Mini Blade, 15 Amp  |
| 17   | 32180-179   | 1    | Cover-Bussman            |
| 22   | 32180-156   | 1    | Cap-Plug, 6 Way          |
| 23   | 32180-091   | 1    | Cap-Dust, 2 Way          |



## Tail Light Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 122-3327    | 1    | Harness-Wire             |
| 2    | 104-8301    | 4    | Nut-HF, NI               |
| 3    | 3231-9      | 4    | Screw-CARR               |
| 4    | 74-2390     | 2    | Reflector-Red            |
| 5    | 104-6962    | 2    | Reflector-Amber          |
| 6    | 3229-10     | 2    | Screw-CARR               |
| 7    | 3290-412    | 4    | Rivet-Blind              |
| 8    | 119-3003-03 | 1    | Bracket-Light Mount (LH) |
| 9    | 119-3004-03 | 1    | Bracket-Light Mount (RH) |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 10   | 145-7635-03 | 1    | Bracket-License Plate |
| 11   | 145-7637    | 1    | Lamp-License, LED     |
| 12   | 32105-14    | 4    | Screw-SHH             |
| 13   | 3296-12     | 4    | Nut-Lock, NI          |
| 14   | 119-3046    | 2    | Tail-Light            |
| 15   | 321-6       | 2    | Screw-HH              |
| 16   | 104-7201    | 4    | Nut-HF, NI            |
| 17   | 3290-379    | 1    | Tie-Cable             |



## Frame, Wheel, Axle and Hitch Assembly

| Ref.  | Part Number | Qty. | Description                   |
|-------|-------------|------|-------------------------------|
| 1     | 161-7874    | 1    | Frame ASM Service Kit         |
| 1:1   | 144-3212    | 1    | Frame ASM, Service            |
| 1:1:2 | 140-6767    | 1    | Decal-Warning,Db              |
| 1:1:3 | 115-5113    | 1    | Decal-Protection, Eye And Ear |
| 1:2   | 145-7461-01 | 1    | Mount-Tank, 5GA [red]         |
| 1:3   | 3230-2      | 4    | Bolt-CARR                     |
| 1:4   | 104-8300    | 4    | Nut-HF, NI                    |
| 2     | 119-2958-01 | 2    | Mount-Axle                    |
| 3     | 144-3630    | 2    | Hub Axle Assembly             |
| 4     | 112-6852    | 2    | Fender                        |
| 5     | 104-8301    | 8    | Nut-HF, NI                    |
| 6     | 1-543286    | 2    | Grommet                       |
| 7     | 3231-2      | 6    | Bolt-CARR                     |
| 8     | 2412-133    | 2    | Clamp-R                       |
| 9     | 104-7050    | 1    | Tube-Manual                   |
| 10    | 144-3664    | 2    | Wheel-Assembly                |
| 10:1  | 137-2597    | 1    | Rim                           |
| 10:2  | 232-27      | 1    | Stem-Valve                    |
| 10:3  | 144-3665    | 1    | Tire                          |
| 11    | 323-14      | 2    | Screw-HH                      |


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 12   | 112-6942-01 | 1    | Hitch                  |
| 13   | 3296-53     | 2    | Nut-Lock, NI           |
| 14   | 327-23      | 2    | Screw-HH               |
| 15   | 131-4381-01 | 1    | Hitch-Clevis           |
| 16   | 104-7048    | 1    | Cap-Housing            |
| 20   | 3230-9      | 4    | Screw-CARR             |
| 21   | 3230-2      | 4    | Bolt-CARR              |
| 22   | 322-5       | 2    | Screw-HH               |
| 23   | 104-8300    | 10   | Nut-HF, NI             |
| 25   | 13-6200     | 1    | Pin-Hitch, Pointed     |
| 25:1 | 3290-343    | 1    | Pin-Hair               |
| 26   | 3256-82     | 8    | Washer-Flat            |
| 27   | 92-1298     | 1    | Pin-Lynch              |
| 28   | 3296-48     | 4    | Nut-Hex                |
| 29   | 3232-17     | 4    | Screw-CARR             |
| 30   | 125-6055-01 | 1    | Tower-Control, Wa      |
| 31   | 323-10      | 3    | Screw-HH               |
| 32   | 93-8806     | 6    | Washer-Hardened        |
| 33   | 32128-19    | 3    | Nut-HF Lock, Large Flg |
| 34   | 121-2870    | 3    | Mount-2 Piece          |
| 35   | 119-6165    | 1    | Decal-Ignition         |



## Frame, Wheel, Axle and Hitch Assembly (continued)


| Ref. | Part Number | Qty. | Description                      |
|------|-------------|------|----------------------------------|
| 36   | 131-6766    | 1    | Decal-Fuses                      |
| 37   | 131-6703    | 1    | Bracket-Hold Down,<br>Electrical |
| 38   | 3334-945    | 1    | Tie-Cable                        |

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 39   | 32180-030   | 1    | Clip-Tie               |
| 40   | 133-8062    | 1    | Decal-Spark Arrestor   |
| 41   | 140-6843    | 1    | Decal - Proforce Frame |



## Hub and Axle Assembly No. 144-3630


| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 2     | 117-5115    | 1    | Hub And Bearing ASM   |
| 2:1   | 117-8251    | 1    | Hub ASM               |
| 2:1:2 | 114-3918    | 4    | Stud-Wheel            |
| 2:1:3 | 254-72      | 2    | Bearing-Cup, Tapered  |
| 2:2   | 254-94      | 2    | Bearing-Cone, Tapered |
| 2:3   | 112-1690    | 1    | Seal-Oil              |
| 2:4   | 241-119     | 1    | Cap-Dust              |
| 2:5   | 139-2564    | 4    | Nut-Lug               |
| 3     | 117-8259    | 1    | Washer-Spindle        |
| 4     | 117-8260    | 1    | Nut                   |
| 5     | 93-0307     | 1    | Nut-Lock, Retainer    |
| 6     | 3272-18     | 1    | Pin-Cotter            |



## Frame Assembly

| Ref.  | Part Number | Qty. | Description                   |
|-------|-------------|------|-------------------------------|
| 1     | 161-7874    | 1    | Frame ASM Service Kit         |
| 1:1   | 144-3212    | 1    | Frame ASM, Service            |
| 1:1:2 | 140-6767    | 1    | Decal-Warning, Db             |
| 1:1:3 | 115-5113    | 1    | Decal-Protection, Eye And Ear |
| 1:2   | 145-7461-01 | 1    | Mount-Tank, 5GA [red]         |
| 1:3   | 3230-2      | 4    | Bolt-CARR                     |
| 1:4   | 104-8300    | 4    | Nut-HF, NI                    |
| 2     | 119-2966    | 1    | Axle ASM                      |
| 3     | 112-6852    | 2    | Fender                        |
| 4     | 104-8301    | 2    | Nut-HF, NI                    |
| 5     | 1-543286    | 2    | Grommet                       |
| 6     | 2412-133    | 2    | Clamp-R                       |
| 7     | 104-7050    | 1    | Tube-Manual                   |
| 8     | 119-3013    | 2    | Wheel And Tire ASM            |
| 8:1   | 119-3009    | 1    | Tire                          |
| 8:2   | 119-3010    | 1    | Rim                           |
| 8:3   | 232-27      | 1    | Stem-Valve                    |
| 9     | 323-14      | 2    | Screw-HH                      |
| 10    | 119-3005    | 1    | Hitch ASM                     |


| Ref. | Part Number | Qty. | Description                   |
|------|-------------|------|-------------------------------|
| 11   | 104-7048    | 1    | Cap-Housing                   |
| 15   | 3230-9      | 4    | Screw-CARR                    |
| 16   | 3230-2      | 4    | Bolt-CARR                     |
| 17   | 322-5       | 2    | Screw-HH                      |
| 18   | 104-8300    | 10   | Nut-HF, NI                    |
| 20   | 3256-82     | 8    | Washer-Flat                   |
| 21   | 3233-26     | 4    | Screw-CARR, Shortneck         |
| 22   | 99-5107     | 4    | Nut-HF Nylock                 |
| 24   | 125-6055-01 | 1    | Tower-Control, Wa             |
| 25   | 323-10      | 3    | Screw-HH                      |
| 26   | 93-8806     | 6    | Washer-Hardened               |
| 27   | 32128-19    | 3    | Nut-HF Lock, Large Flg        |
| 28   | 121-2870    | 3    | Mount-2 Piece                 |
| 29   | 119-6165    | 1    | Decal-Ignition                |
| 30   | 131-6766    | 1    | Decal-Fuses                   |
| 31   | 131-6703    | 1    | Bracket-Hold Down, Electrical |
| 32   | 3334-945    | 1    | Tie-Cable                     |
| 33   | 32180-030   | 1    | Clip-Tie                      |
| 34   | 133-8062    | 1    | Decal-Spark Arrestor          |



## Axle Assembly No. 119-2966

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    |             | 1    | Axle-Torsion ●        |
| 2    | 254-94      | 4    | Bearing-Cone, Tapered |
| 3    | 119-3016    | 1    | Hub ASM               |
| 3:2  | 114-3918    | 5    | Stud-Wheel            |
| 3:3  | 254-72      | 2    | Bearing-Cup, Tapered  |
| 4    | 112-1690    | 2    | Seal-Oil              |
| 5    | 117-8259    | 2    | Washer-Spindle        |
| 6    | 117-8260    | 2    | Nut                   |
| 7    | 3272-18     | 2    | Pin-Cotter            |
| 8    | 93-0307     | 2    | Nut-Lock, Retainer    |
| 9    | 241-119     | 2    | Cap-Dust              |
| 10   | 139-2564    | 10   | Nut-Lug               |


● Not serviced separately



## Hitch Assembly No. 119-3005

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    |             | 1    | Tube-Hitch ●          |
| 2    | 117-8371    | 1    | Receiver-Hitch, Ball  |
| 3    | 3234-41     | 3    | Screw-HHF             |
| 4    | 119-3006    | 1    | Hook-Light            |
| 5    | 104-8301    | 3    | Nut-HF, NI            |
| 6    | 80-6990     | 2    | Washer-Hardened       |
| 7    | 119-3045    | 2    | Chain-Safety, Trailer |
| 8    | 105-9245    | 1    | Pin-Lock              |
| 9    | 119-6162    | 1    | Decal-Tire            |


● Not serviced separately



## Turbine Mounting Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 117-8329    | 1    | Bell-Inlet             |
| 2    | 112-1952    | 1    | Ring-Snap, EXT         |
| 3    | 93-4632     | 1    | Washer-Wavey           |
| 4    | 131-9440    | 1    | Cap-Front              |
| 5    | 3231-24     | 2    | Screw-CARR             |
| 6    | 140-6946SP  | 1    | Turbine ASM-Horizontal |
| 7    | 104-8300    | 11   | Nut-HF, NI             |
| 8    | 140-6983-01 | 2    | Mount-Housing          |
| 9    | 3231-22     | 2    | Screw-CARR             |
| 10   | 322-6       | 11   | Screw-HH               |


| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 11   | 104-8301    | 4    | Nut-HF, NI     |
| 12   | 115-5102    | 2    | Decal          |
| 13   | 115-7109    | 8    | Washer-Flat    |
| 14   | 94-7484     | 1    | Bearing        |
| 14:1 | 302-2       | 2    | Fitting-Grease |
| 14:2 | 106-9662    | 1    | Screw-Set, HSH |
| 15   | 144-3316-01 | 1    | Mount-Bearing  |
| 16   | 100-6116    | 2    | Screw-HHF      |
| 17   | 99-5107     | 2    | Nut-HF Nylock  |
| 18   | 3234-42     | 2    | Screw-HHF      |



## Turbine Assembly No. 140-6946SP

| Ref. | Part Number | Qty. | Description                     |
|------|-------------|------|---------------------------------|
| 1    | 92-9533     | 1    | O-Ring                          |
| 2    | 112-1871    | 24   | Vane-Stator                     |
| 3    | 112-1899    | 1    | Nut                             |
| 4    | 112-1951    | 4    | Ring-Snap, EXT                  |
| 5    | 112-6764    | 2    | Bearing-Ball                    |
| 6    | 114-2164    | 1    | Spacer                          |
| 7    | 140-6945    | 1    | Housing-Horizontal, Service ASM |
| 8    | 115-5131    | 2    | Washer                          |
| 9    | 115-9005    | 1    | Washer-Tab                      |
| 10   | 140-6997    | 1    | Shaft-Fan Long                  |


| Ref. | Part Number | Qty. | Description   |
|------|-------------|------|---------------|
| 11   | 125-4287    | 8    | Screw-HHF     |
| 12   | 117-8303    | 24   | Screw-HWH     |
| 13   | 117-8356    | 1    | Rotor         |
| 14   | 119-6202    | 1    | Washer-Tab    |
| 15   | 161-7875    | 4    | Screw-HHSF    |
| 17   | 145-7583    | 1    | Inner Housing |
| 18   | 140-6933    | 1    | End-Oring     |
| 19   | 120-6061    | 1    | Bearing-Cap   |
| 20   | 120-6063    | 1    | End-Cap       |
| 22   | 3257-42     | 1    | Key-Woodruff  |



## Nozzle Assembly

| Ref. | Part Number | Qty. | Description                  |
|------|-------------|------|------------------------------|
| 1    | 140-6849-01 | 1    | Bracket-Motor, Covered       |
| 2    | 112-1874    | 1    | Pulley-Nozzle                |
| 3    | 140-6982    | 4    | Spacer-Bearing               |
| 4    | 115-6870    | 8    | Bearing-Ball, Sealed         |
| 5    | 140-6979    | 4    | Roller-Bearing               |
| 6    | 120-9679    | 4    | Washer-Flat                  |
| 7    | 321-9       | 4    | Screw-HH                     |
| 8    | 104-7201    | 12   | Nut-HF, NI                   |
| 9    | 112-1853    | 1    | Belt-V                       |
| 10   | 144-3382    | 1    | Nozzle-Toro Proforce Trailer |
| 11   | 112-6899    | 1    | Clamp-Nozzle                 |
| 12   | 3234-29     | 2    | Screw-HHF                    |
| 13   | 104-8300    | 2    | Nut-HF, NI                   |
| 14   | 112-6924    | 1    | Guard-Belt, Drive            |
| 15   | 321-37      | 2    | Screw-HH                     |
| 16   | 110-9650    | 1    | Leaf Spring ASM              |
| 16:2 | 36-2250     | 1    | Bolt-Shoulder                |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 16:3 | 3296-42     | 1    | Nut-Lock, NI          |
| 17   | 321-3       | 2    | Screw-HH              |
| 18   | 251-259     | 1    | Bearing-Ball          |
| 19   | 144-3274    | 1    | Motor-Reversible      |
| 20   | 114-8414    | 3    | Screw-HHF             |
| 21   | 115-5147    | 1    | Pulley                |
| 22   | 98-0668     | 1    | Nut                   |
| 23   | 140-2220-01 | 1    | Indicator             |
| 24   | 140-6685-07 | 1    | Indicator             |
| 25   | 119-6906    | 4    | Screw-HSBH            |
| 26   | 140-6814-03 | 1    | Gauge-Rotation        |
| 27   | 140-2247    | 1    | Decal-Position, Chute |
| 28   | 3234-17     | 2    | Screw-HHF             |
| 29   | 105-4886    | 4    | Nut-Tinnerman         |
| 30   | 140-6848    | 1    | Motor-Cover           |
| 31   | 3234-42     | 4    | Screw-HHF             |



## Driveshaft and Battery Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 140-6936-03 | 1    | Drive-Shaft, Short [black] |
| 2    | 104-8300    | 8    | Nut-HF, NI                 |
| 3    | 322-39      | 4    | Screw-HH                   |
| 4    | 131-6761    | 8    | Washer                     |
| 5    | 115-5129    | 4    | Coupling-Rubber            |
| 6    | 323-7       | 2    | Screw-HH                   |
| 7    | 114-2120    | 2    | Washer                     |
| 8    | 131-6763    | 4    | Spacer-Coupling, Rubber    |
| 9    | 131-6762    | 4    | Spacer-Coupling, Rubber    |
| 10   | 322-32      | 4    | Screw-HH                   |
| 11   | 114-2122    | 2    | Hub-Engine                 |

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 12   | 130-8569    | 1    | Cover-Battery              |
| 13   | 3290-467    | 2    | Pin-Hair                   |
| 14   | 106-5187    | 1    | Battery- Dry, 12V, 525 CCA |
| 15   | 3257-5      | 2    | Key-Woodruff               |
| 16   | 138-6335    | 1    | Retainer-Battery           |
| 17   | 3231-5      | 1    | Screw-CARR                 |
| 18   | 104-8301    | 1    | Nut-HF, NI                 |
| 19   | 130-0932-01 | 1    | Bracket-Cover              |
| 20   | 107069      | 2    | Clip                       |
| 21   | 321-4       | 2    | Screw-HH                   |

# Attachments and Accessories

## For 44553 Pro Force Debris Blower

| Product Name                                 | Model/Part |
|----------------------------------------------|------------|
| Tapered Nozzle Kit.....                      | 119-6280   |
| Rectangular Nozzle Kit .....                 | 119-6281   |
| 10 Gallon Kit, Pro Force Debris Blower ..... | 130-4371   |
| Chute Position Indicator Kit.....            | 140-2257   |
| Service-Turbine, Kit .....                   | 145-7489   |
| Kit-Service, Nozzle Roller Conversion .....  | 145-7630   |
| ALIGNMENT TOOL ASM .....                     | 161-7891   |
| Toro Red 12oz Aerosol Can .....              | 361-10     |
| New Red Paint - Gallon .....                 | 361-11     |
| Semi-Gloss Black Spray Paint .....           | 361-9      |
| LED Light Kit, Pro Force Debris Blower ..... | 44559      |
| Spark Arrestor Screen .....                  | 94-8157    |

**Notes:**

**Notes:**

**Notes:**



**Count on it.**