Form No. 3473-388 Rev B

TORO®

Count on it.

Parts Catalog

TimeMaster® 30in

Lawn Mower

Model No. 21220—Serial No. 418331859 and Up

Register at www.Toro.com.
Original Instructions (EN)

3473-388 B

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Housing Assembly 4
Spindle and Belt Assembly 6
Side Discharge Chute Assembly 8
Grass Bag Assembly 10
Engine and Belt Assembly 12
Front Wheel and Height-of-Cut Assembly 14
Rear Wheel and Height-of-Cut Assembly 16
Handle Assembly 18
Attachments and Accessories 20

© 2025—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved

Housing Assembly



Housing Assembly (continued)

Ref.	Part Number	Qty.	Description
1	136-5873	1	Housing ASM
3	145-3920-01	1	Frame-30"
4	3230-5	2	Bolt-CARR
5	139-5415	1	Rod-Release, Handle
6	120-7018	1	Grip-Lever
7	121-9114	1	Bracket-Door, LH
8	121-9115	1	Bracket-Door, RH
9	120-7048	1	Rear Deflector ASM
9:3	131-4514	1	Decal-Warning
10	115-2859	1	Spring-Torsion
11	114-7924	1	Spring-Torsion
12	46-8091	3	Screw-HWH
13	138-3224	2	Bracket-Cable, Traction
14	120-5225	1	Plug-Mulch
15	120-6241	1	Shield-Trailing
16	49-2040	9	Screw-HWHTF
19	139-1692	2	Screw-PTH
20	133-8062	1	Decal-Spark Arrestor
21	3296-29	2	Nut-Lock, NI
26	130-2352-01	1	Baffle-Control
28	32144-86	1	Screw-HWHTF
29	145-3921	1	Spacer
31	137-3087	1	Nut-Hex
32	125-5072	1	Frame Plate Kit
32:1	125-2542	1	Plate-Frame
32:2	3229-3	3	Screw-CARR
32:3	3296-42	3	Nut-Lock, NI
36	147-0471	1	Plug-Button
38	139-5408	1	Belt Cover ASM
38:2	121-2391	1	Decal-Cover, Belt
39	133-8177	1	Chute

Spindle and Belt Assembly



Spindle and Belt Assembly (continued)

Ref.	Part Number	Qty.	Description
1	121-9107	2	Spindle ASM
1:2	120-7935	2	Spacer
1:3	138-9770	2	Bearing-Ball
2	139-1731	9	Screw-Thd Roll, HWH
3	139-6612	1	Shaft-Spindle
4	139-6613	1	Shaft-Spindle
5	121-9100	2	Sprocket
6	130-6664	1	Pulley-Brake, Spindle
7	109-9505	2	Washer-Spring
8	3296-19	2	Nut-Hex
9	63-7400	1	Washer-Rebound
10	133-8102	1	Brake Arm ASM
11	121-2305	2	Washer-Friction, Composite
12	138-3244	1	Spacer
13	9114524	1	Bolt-TAP, HH
14	139-1723	4	Washer-Flat
16	3296-29	3	Nut-Lock, NI
17	161-4815	2	Idler-Pulley
18	145-4016	1	Bracket-Idler
19	120-7024	2	Screw-Shoulder, HWH
20	120-3335	1	Belt-Synchronous
21	120-5245-03	1	Guide-Belt, Spindle
22	120-5236	2	Adapter-Blade
23	121-5808	1	Spring-Extension, Brake
24	125-2466	2	Bolt-Blade
25	49-2040	2	Screw-HWHTF
26	120-7082	1	Pulley-Idler
27	322-6	1	Screw-HH
28	3296-47	1	Nut-Lock,NI
29	116-6358-03	2	Blade-Rotary
30	121-2336	1	Spring-Flat
33	322-9	1	Screw-HH
35	133-1964	1	Spacer

Side Discharge Chute Assembly



Side Discharge Chute Assembly (continued)

Ref.	Part Number	Qty.	Description
1	94-8072	1	Decal-Danger
3	137-4795	2	Screw
6	133-2630	1	Side Deflector Service ASM
6:1	125-5091	1	Deflector-Side
6:2	127-0721	1	Spring-Torsion, Cover
6:3	112-6416	1	Bracket-Cover
6:4	99-5291	1	Rod-Cover
7	121-2319	1	Chute-Discharge, Side
8	133-9289	1	Fitting-Washout
8:2	133-9290	1	O-Ring
9	139-1700	2	Screw-HWH, Thd Roll
11	95-3270	1	Connector-Hose
12	120-9570	1	Decal-Warning
13	125-5092	1	Decal-Placement, Foot

Grass Bag Assembly



Grass Bag Assembly (continued)

Ref.	*Part Number*	*Qty.*	*Description*
1	121-5766-03	1	Frame-Bag
2	161-8188	1	Bag ASM-Grass

Engine and Belt Assembly



Engine and Belt Assembly (continued)

Ref.	Part Number	Qty.	Description
1		1	Engine-Briggs,14D9350111F1 ●■
10	137-9176	1	Pulley-Engine
11	121-5765	1	V-Belt
12	120-9470	1	V-Belt, Traction
13	139-1734	1	Guide-Belt, Wa
14	95-1727	3	Screw-Taptite
15	3290-465	1	Washer-Belleville
16	26-0671	1	Screw-HH
17	32144-1	2	Screw-Taptite
18	131-0889-03	1	Guard-Engine
19	126-2713	2	Screw-HHF, Patch

● Not serviced separately

■ Obtain parts from www.briggsandstratton.com

Front Wheel and Height-of-Cut Assembly



Front Wheel and Height-of-Cut Assembly (continued)

Ref.	Part Number	Qty.	Description
1	46-8091	3	Screw-HWH
2	120-9535	1	Grip-Lever
3	119-4042	2	Nut-HF, NI
4	147-0519	2	Bushing-Pivot, Front
4:1	15-4318	1	Resin-Nylon 66
5	139-1753	1	Front Axle ASM
6	120-7037-03	1	Plate-HOC, LH
7	120-7038-03	1	Plate-HOC, RH
8	120-7043	1	Arm-Spring
9	125-2510	2	8 Inch Wheel ASM
10	125-5027	1	Front Cover ASM
10:2	120-7047	1	Artwork-Toro Timemaster
11	700057	1	Screw-HWH
12	3230-23	6	Bolt-CARR
13	3296-29	6	Nut-Lock, NI
14	130-6658	4	Screw-Flange, Plastic

Rear Wheel and Height-of-Cut Assembly



Rear Wheel and Height-of-Cut Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-4796	1	Grip-Lever, Lift
2	121-5799	1	Conduit-Convoluted
3	49-2040	2	Screw-HWHTF
4	119-4042	2	Nut-HF, NI
5	104-8699	1	Bearing-Ball
6	106-5681	1	Pin-Stop
7	133-2603	2	Bearing-Ball
8	110-7191	2	Washer-Thrust
9	131-5399	2	Gear-Pinion, 15T
10	120-3342-03	1	Plate-HOC, LH
11	120-3343-03	1	Plate-HOC, RH
12	137-9124	1	Arm-Spring
13	120-5209	1	Key-Arm, Spring
14	136-5929	2	Retainer-Bearing
15	131-9665	1	Transmission Kit
15:1:1	130-2370	1	Transmission Pulley Kit
15:2	130-2369	2	Pin-Snap
15:3	32151-61	1	Ring-Retaining
16	120-6233	2	Cover-Gear
17	139-1747	1	Rear Axle ASM
18	125-2509	2	10 Inch Wheel Gear ASM
19	138-3233	1	Mount-Bearing
20	120-7026	1	Spring-Extension
21	120-7027	1	Spring-Extension
22	121-5800	2	Conduit-Convoluted
23	701243	8	Screw-Thd Roll, HWH
24	32144-4	1	Screw-HWH
25	32151-61	1	Ring-Retaining
26	36-4780	2	Washer-Plain
27	138-5338	1	Bracket-Stop
28	3296-47	1	Nut-Lock,NI
29	125-2497	1	Decal-HOC, Rear
30	130-2369	2	Pin-Snap

Handle Assembly



Handle Assembly (continued)

Ref.	Part Number	Qty.	Description
1	145-4021-05	1	Handle-Lower, ASM
2	145-4004-05	1	Handle-Upper
3	139-1694	2	Bolt-Shoulder, HHF
4	3296-29	2	Nut-Lock, NI
5	140-2367	1	Guide-Curved, LH (Rwd)
6	140-2366	1	Guide-Curved, RH (Rwd)
7	139-5464	1	Rod-Control, Traction
8	139-6554	1	Lever-Traction, Rwd
9	140-4194	1	Spring-Torsion
10	139-6569	1	Handle-Personal Pace, Curved
11	139-6567	1	Bottom-Handle, RH
12	139-6568	1	Bottom-Handle, LH
13	94-4496	10	Screw-PPH
14	161-1162-03	1	Bail-Brake, BBC Welded
15	161-3177	1	Cable-Brake
16	145-4007	1	Cable-Traction
19	106-9169	1	Screw-HWH
20	107-7462	1	Spring-Torsion
21	107-7463	1	Spacer
22	161-4788	1	Lever
23	32128-17	1	Nut-Lock, Flange
24	139-6577	2	Pin-Handle, Pp
25	132-4516	2	Plug-Square
26	137-3107	2	Screw-Handle
27	117-5976	2	Knob-Handle
28	114-7988	1	Guide-Cable
29	144-0220	1	Handle-Assist
30	99-6005	2	Bolt-Carriage
31	137-4808	2	Nut-Acorn
33	120-9683	1	Washer-Plain
34	140-4357	1	Decal-Battery Charging
35	136-5912	1	Anchor-Cable
36	23-0660	1	Switch-Starter
36:1	218-461	1	Nut-HH
36:2	3254-5	1	Washer-Lock
37	108-3795	1	Housing-Switch, Key
38	108-3796	1	Cover-Swtch
39	700918	1	Key
40	136-9126	1	Charger, Battery (12V)
41	139-1703	2	Screw-Plastic, PPH
42	108-9751	1	Decal-Switch, Ignition
43	32144-1	1	Screw-Taptite
44	136-5895	1	Harness-Wire
44:4	99-6124	1	Fuse-40 Amp ●
45	108-0987	1	Foam-Battery
46	120-3329	1	Cover-Battery
48	112-8884	1	Knob
49	321-57	1	Screw-HH
50	3256-1	1	Washer-Flat
51	3296-73	1	Nut-Lock, NI
52	145-5601	1	Decal-Handle, Pp
53	139-1709	1	Screw-Shoulder
54	137-3085	1	Nut-Hex
55	106-8397	1	Battery-Wet, 12V 3Ah, Sealed

● Not illustrated

Attachments and Accessories

For 21220 TimeMaster 30in Lawn Mower

Product Name	Model/Part
Fuel Stabilizer .05 oz	130-2393
Engine Maintenance Kit	130-8146
4-Cycle Fuel, Snow And Lawn 32oz Can	131-3823
Toro Premium Fuel Treatment 12oz Bottle	131-6572
Oil-30/10W-30 Synthetic (Quart)	138-6053
Traction Assist Handle Kit	144-6377
Hi-Lift Replacement Blade Kit	20122P
Lawn Striping Kit with 30in Roller	20602
Toro 4-Cycle SAE 30 Oil (32oz Bottle)	38903
Summer Oil-Case of 24 (20oz Bottles)	38916
Bag-Walk Behind (Toro)	490-7318
Mower Cover	490-7461

Notes:

Notes:

Notes:

Count on it.