Form No. 3453-569 Rev C

TORO®

Count on it.

Parts Catalog

Multi Pro® WM

Turf Sprayer

Model No. 41240—Serial No. 410400000 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3453-569 C

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Frame, Stand and Boom Mount Assembly 4
Control Console Assembly 6
Turf Sprayer Finishing Kit No. 131-3301 8
Hydraulic Motor Assembly No. 131-5810 9
Multi Pro WM Turf Sprayer Finishing Kit No. 131-3302 10
Driveshaft Assembly No. 125-0680 11
Pump Mount Assembly 12
Pump Assembly No. 145-3382 13
Spray Tank Assembly 15
200 Gallon Spray Tank Assembly No. 138-8371 16
Spray Tank Lid Assembly No. 138-6283 17
Filter Assembly No. 130-7096 18
Spray Valve Assembly 19
Manifold Assembly 20
Regulating Valve Body Assembly No. 127-9804 21
Regulating Actuator Assembly No. 144-6163 22
Actuator On/Off Assembly No. 140-7377 23
Pressure Filter Assembly No. 131-3791 24
Manifold Valve Kit No. 131-0253 25
Manifold Valve Kit No. 131-7256 26
Section Manifold Valve Assembly 27
On/Off Manifold Valve Kit No. 127-9803 28
Actuator On/Off Assembly No. 140-7377 29
Bypass Valve Assembly No. 127-9805 30
Hose Assembly 31
Boom Lift Assembly 33
Hydraulic Cylinder Assembly No. 117-0701 34
On-Off Boom Lift Valve Assembly No. 136-2400 35
Electrical Assembly 36
Center Boom Assembly 37
LH Single Turret Body Assembly No. 108-3725 39
Double Turret Body Assembly No. 108-3727 40
RH Single Body Turret Assembly No. 108-3726 41
Boom Mounting Assembly 42
Boom Pivot Assembly 43
Left and Right Hand Boom Assembly 44
Attachments and Accessories 45

© 2025—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved




Frame, Stand and Boom Mount Assembly

Ref.	Part Number	Qty.	Description
1	127-3984	1	Skid ASM
1:2	127-3936	2	Decal-Danger
2	131-5791-03	1	Tube
3	131-5796-03	1	Mount-Tank, Eye Wash
5	132-7745	1	Fresh Water Tank ASM
5:2	120-0616	3	Decal-Water, Fresh
8	125-0798	2	Cover-Access
9	125-8108-03	1	Jack Stand-Rear, RH
10	125-8138-03	1	Guard-Relay
11	136-7199	2	Bolt-Shoulder
12	104-8301	4	Nut-HF, NI
13	93-9719	4	Block-Wear
14	321-4	4	Screw-HH
15	3296-42	4	Nut-Lock, NI
16	120-5587	2	Pin-Clevis
17	3290-343	4	Pin-Hair
18	125-0809	2	Bracket-Mount, Front
19	100-6116	2	Screw-HHF

Ref.	Part Number	Qty.	Description
20	99-5107	2	Nut-HF Nylock
22	92-2667-03	2	Bracket-Mount
23	125-0840-03	1	Jack Stand-Rear
24	125-0841-03	2	Stand-Front
25	283-83	4	Pin-Clevis
26	283-55	2	Pin-Clevis
27	49-2040	4	Screw-HWHTF
29	3231-2	4	Bolt-CARR
31	3234-14	2	Screw-HHF
32	104-8300	10	Nut-HF, NI
33	125-8094	16	Pad-Tank
34	127-3985	1	Skid Cover ASM
34:2	127-3937	1	Decal-Warning, Engine Cover
35	106-6777	2	Handle-Latch, Swell
36	106-6778	2	Bushing-Latch, Swell
37	1-804254	2	Nut-Lock, HH
38	92-1233	2	Pin-Clevis

● Not illustrated



Frame, Stand and Boom Mount Assembly (continued)


Ref.	Part Number	Qty.	Description
39	92-1298	4	Pin-Lynch
45	322-5	1	Screw-HH
46	3218-2	1	Nut-Hex Jam
47	3256-23	2	Washer-Plain
48	322-11	2	Screw-HH
49	95-9648	2	Knob
50	3234-7	4	Screw-HHF
51	132-7628-03	2	Band-Tank, Eye Wash
52	106-5052	1	Cap-Water, Fresh
53	132-7706	1	Elbow-90 DEG
55	100-7011	1	Spigot-90 DEG

Ref.	Part Number	Qty.	Description
56	3290-355	4	Pin-Hair
57	117-0546	1	Rod-Bag, Storage
58	147-4666	1	Storage Mount, ASM
58:1	145-3366	1	Bracket-Mount, Bag
58:2	140-7369	3	Magnet
58:3	3290-55	3	Rivet-Pop
59	103-5971	1	Bag-Storage
99	125-0842-03	2	Stand-Extension, Front ●
99	283-55	4	Pin-Clevis ●
99	3290-343	4	Pin-Hair ●
99	T0000-3423	2	Jack-Sidewind ●

● Not illustrated

ITEM 4 Used with
MANUAL WORKMAN FINISH KIT, 131-3302

ITEM 35 Used with
AUTOMATIC WORKMAN FINISH KIT, 131-3301




Control Console Assembly

Ref.	Part Number	Qty.	Description
1	131-5795-03	1	Bracket-Console
2	131-9618	1	Control-Console
2:2	131-9607-03	1	Plate-Switch
2:3	3290-409	4	Rivet
2:4	131-5808	1	Decal-Switch
3	115-1900	1	Controller
4	120-6310	1	LCD Display ASM Kantrak 1700
4:1	120-4630	1	Nut-Display
4:2	120-6311	1	Decal-Display
5	120-8546	1	Gauge-Pressure
6	100-8490	1	Switch-Rocker, On-None-On
7	100-1535	1	Switch-Rocker, (On)-Off-(On)
8	125-0899	2	Switch-Rocker
9	125-7996	1	Switch-Pb, Momentary
11	109-8054	2	Bushing-Flange
12	125-4021-0P	1	Bracket - Pivot, Console [prime
13	125-4020-03	1	Panel-Control
14	95-9648	1	Knob
15	99-7420	3	Plug-Hole
16	131-9605	1	Fitting-Elbow-90
17	100-8674	1	Coupler-Tube
18	119-5329	1	Plug-Hole
19	93-6083	4	Screw-HWH
20	3290-495	1	Pin-Klik
21	120-0834	3	Screw-HSBH
22	104-7201	3	Nut-HF, NI
23	3234-5	2	Screw-HHF
24	104-8300	5	Nut-HF, NI
25	3256-71	6	Washer-Flat
26	322-43	6	Screw-HH
27	130-8294	1	Decal-Console
28	125-4052	1	Decal-Console, Upper
29	125-4054	1	Pin
30	3234-17	3	Screw-HHF
32	125-8139	1	Decal-Master Boom Switch
33	95-8999	3	Switch-Rocker, On-None-On


ITEM 4 Used with
MANUAL WORKMAN FINISH KIT, 131-3302

ITEM 35 Used with
AUTOMATIC WORKMAN FINISH KIT, 131-3301



Control Console Assembly (continued)


Ref.	*Part Number*	*Qty.*	*Description*
34	1-323142	1	Nut-Push
35	163-2995	1	Display-LCD, Svc Only



Turf Sprayer Finishing Kit No. 131-3301

Ref.	Part Number	Qty.	Description
1	127-9796-03	1	Mount-Arm, Torque
2	131-5810	1	Motor-Hydraulic
3	117-8045	1	Coupler
4	127-9794-03	1	Bracket-Motor
5	110-5331	2	Spring-Compression
6	3256-23	1	Washer-Plain
7	322-14	1	Screw-HH
8	104-8300	1	Nut-HF, NI
9	120-0628-03	1	Guard-Shaft, Pump
10	100-6116	2	Screw-HHF
11	108-3745	2	Nut-HHF, Whiz
12	106-1990	1	Key-Woodruff
13	3241-7	4	Screw-SQH
15	112-0273	1	HYD Hose ASM
15:3	237-42	1	O-Ring
16	130-7181	1	Upper Lift Hose Valve ASM
16:3	237-42	1	O-Ring

Ref.	Part Number	Qty.	Description
17	106-7969	1	Coupler-Quick, Male
18	106-7968	1	Coupler-Quick, Female
19	130-7184	2	HYD Hose ASM
19:1	237-79	1	O-Ring
20	105-4170	2	Coupler-Male
21	340-6	2	Fitting-Straight
21:1	237-30	1	O-Ring
21:2	237-80	1	O-Ring
22	3234-42	2	Screw-HHF
23	104-8301	2	Nut-HF, NI
24	56-7976	2	Clamp-Tube
25	32144-57	1	Screw-Thd Roll
26	3334-945	2	Tie-Cable
27	95-8999	1	Switch-Rocker, On-None-On
28	122-0372	1	Harness-Wire
30	2412-147	1	Clamp-R




Hydraulic Motor Assembly No. 131-5810

Ref.	*Part Number*	*Qty.*	*Description*
1	106-1989	1	Seal Kit
1:1		6	Seal-Ring ■
1:2		1	Seal-Commutator ■
1:3		1	Seal-Dirt And Water ■
1:4		1	Washer-Backup ■
1:5		1	Seal-Shaft ■
1:6		1	Ring-Back Up ● ■
2	106-1990	1	Key-Woodruff

● Not illustrated


■ Not serviced separately



Multi Pro WM Turf Sprayer Finishing Kit No. 131-3302


Ref.	*Part Number*	*Qty.*	*Description*
1	106-1990	1	Key-Woodruff
2	125-0680	1	Driveshaft-PTO
3	125-8054-03	1	Bracket-Shield, Driveshaft
4	107069	2	Clip
5	127-3986	1	Shield-Driveshaft
5:2	127-3981	1	Decal-Warning
6	3234-4	2	Screw-HHF
7	3247-2	2	Screw-Set, HSH
8	112-0274	1	Hose-HYD

Ref.	*Part Number*	*Qty.*	*Description*
8:3	237-42	1	O-Ring
9	112-0273	1	HYD Hose ASM
9:3	237-42	1	O-Ring
10	106-7969	1	Coupler-Quick, Male
11	106-7968	1	Coupler-Quick, Female
12	56-7976	2	Clamp-Tube
13	32144-57	1	Screw-Thd Roll
14	3334-945	3	Tie-Cable




Driveshaft Assembly No. 125-0680

Ref.	*Part Number*	*Qty.*	*Description*
1	125-0679	1	Yoke-Shaft
2	54-9180	2	U-Joint Kit
2:1	62-3820	1	Fitting-Grease
3	125-8109	1	Shaft-Slip Yoke
4	94-7379	1	Tube-Yoke, Slip
5	99-4476	1	Spring Lock Yoke ASM
6	99-4477	1	Yoke Spring Lock Repair Kit
7	302-5	1	Fitting-Grease



Pump Mount Assembly


Ref.	*Part Number*	*Qty.*	*Description*
1	145-3382	1	Pump ASM
3	125-8053-03	1	Mount-Pump
5	3234-11	4	Screw-HHF
6	3290-357	4	Nut-HSF
7	3234-6	4	Screw-HHF
8	32128-49	6	Nut-HHF
12	2412-147	1	Clamp-R
13	3234-42	1	Screw-HHF
14	104-8301	1	Nut-HF, NI
15	133-2867-03	1	Bracket-Mount Valve Drain
16	3234-38	2	Screw-HHF



Pump Assembly No. 145-3382

Ref.	Part Number	Qty.	Description
1	120-0773	20	Bolt-Hex
2		6	Cover-Pump ●
3	120-0777	6	Bolt-Hex
4	120-0778	6	Disc-Diaphragm
5	120-0779	6	Diaphragm
6	120-0780	6	Disc-Backing, Diaphragm
7	120-0781	6	Rod-Connecting
8	99-0861	10	Valve-Pump
9	100-6651	12	O-Ring
10	120-0783	2	Seal-Oil
11	120-0786	2	Seal
12	120-0785	2	Plug
13	133-2877	1	Tube-Banjo, Long
14	133-2878	2	Nut
15	133-2879	2	Nipple-Grease
16	133-2880	2	Cap-Grease Nipple, Yellow
17	136-2252	1	Bolt-Hex
18	133-2875	1	Plate-Nipple, Grease
19	133-2876	1	Tube-Banjo, Short
20	120-0774	4	Bolt-Hex
21	120-0787	1	Foot-Pump
22	133-2830	2	Bolt-Banjo
23	136-2251	4	Gasket
24	133-2821	1	Housing-Pump, Main
25	120-0788	2	Bearing-Ball
26	133-2820	2	Spacer-Metal
27	120-0791	2	Bearing-Ball
28	133-2827	1	Distance Ring
29	133-2825	1	Shaft-Crank
30	120-0793	2	Valve W/Hole
31	120-0794	3	Bolt-Hex
32	133-2822	1	Housing-Pump, Front
33	120-0784	4	Bolt-Hex
34	120-0796	1	Pump Kit
34:1	120-0777	6	Bolt-Hex
34:2	99-0861	10	Valve-Pump


● Not serviced separately



Pump Assembly No. 145-3382 (continued)

Ref.	Part Number	Qty.	Description
34:3	120-0793	2	Valve W/Hole
34:4	100-6651	12	O-Ring
34:5	120-0778	6	Disc-Diaphragm
34:6	120-0779	6	Diaphragm
35	145-3399	1	Pump Head Kit


● Not serviced separately



Spray Tank Assembly

Ref.	Part Number	Qty.	Description
1	138-8371	1	200 Gallon Tank
2	100-8642	1	Screen-Suction
3	130-7096	1	Filter ASM
4	100-8641	1	Vane-Screen
5	117-7928	1	Adapter ASM
5:2	100-6989	1	O-Ring
6	110-5082-03	1	Bracket-Anti Siphon
7	41140	1	Elbow
8	110-5090	1	Grommet
9	110-5088	1	Hose-Fill
10	100-6779	1	Coupling-Female
11	108-0069	1	Valve-Ball
12	110-5224	1	Fitting-Barbed, Straight
13	2412-34	1	Clamp-Hose
14	100-8635	6	Fork
15	117-7996	1	Fork
16	119-9419	1	Basket-Filter
17	125-4081-03	4	Band-Tank
18	3256-24	4	Washer-Plain


Ref.	Part Number	Qty.	Description
19	323-58	2	Bolt-TAP, HH
20	104-8301	4	Nut-HF, NI
22	127-3920-03	1	Bracket-Storage
23	3290-343	4	Pin-Hair
24	41316	1	Adapter-Quick
25	100-6714	1	Foot-Tube, Suction
26	108-3270	1	Screw-TAP
27	125-8128	1	Tube-Suction
28	100-8649	1	Hose-Suction
29	2412-130	2	Clamp-Hose
30	3234-7	2	Screw-HHF
31	3231-21	2	Screw-CARR
32	3234-5	2	Screw-HHF
35	132-7787	1	Coupler-Quick
36	114-9566	1	Clamp-R
37	104-8300	1	Nut-HF, NI
38	3290-378	1	Tie-Cable
39	136-2272	1	Tubing-Convoluted, Slit



200 Gallon Spray Tank Assembly No. 138-8371


Ref.	*Part Number*	*Qty.*	*Description*
2	108-3358	6	Fitting-Bulkhead
2:1	107-2864	1	Gasket-Bulkhead
3	106-4933	2	Hosebarb ASM
3:1	100-8637	1	O-Ring
4	117-7851	1	Bulkhead ASM
4:2	100-8646	1	Gasket-Bulkhead
4:3	100-8647	1	Nut-Bulkhead
5	100-7051	6	Nut-Bulkhead
6	119-9378	1	Gasket-Lid, Tank
7	138-6283	1	Lid ASM - Sprayer Tank

Ref.	*Part Number*	*Qty.*	*Description*
8	107-8635	8	Screw-PFH
9	125-8064	2	Decal-Tank
10	120-0622	1	Decal-Warning
11	100-8635	2	Fork
12	127-3967	1	Shield-Sump, Bottom
13	127-3960	1	Shield-Sump, Center
14	127-3962	1	Shield-Sump, Rear
15	127-3961	1	Shield-Sump, Front
16	127-3988	1	Shield-Sump, Side




Spray Tank Lid Assembly No. 138-6283

Ref.	*Part Number*	*Qty.*	*Description*
1	119-9381	1	Ring-Lid
2	119-9382	1	Arm-Lid
3	119-9383	1	Vent-Lid
4	119-9384	1	Cover-Lid
5	119-9385	1	Pin-Pivot
6	138-6281	1	Seal - Tank Lid
7	119-9386	2	O-Ring
8	119-9387	1	Cap-Lid



Filter Assembly No. 130-7096

Ref.	*Part Number*	*Qty.*	*Description*
1	100-8643	1	Housing-Filter
2	106-4942	1	Hosebarb-Straight
2:1	100-6989	1	O-Ring
3	100-8636	1	Fork-Special
4	100-8646	1	Gasket-Bulkhead
5	100-8647	1	Nut-Bulkhead
6	100-8644	2	Pin-Expansion




Spray Valve Assembly

Ref.	Part Number	Qty.	Description
1	131-3704	1	Bracket-Fitting, Tee
2		1	Manifold ASM - Agitation, Mpwm ●
5	138-6128	1	Flow Meter ASM
6	117-7996	1	Fork
7		1	Manifold ASM-Section Valve, Mpwm ●
9	104-9090	2	Gasket
10	104-9089	2	Clamp-Screw, Worm
11	100-6704	3	Tee
12	117-7874	1	Relief Valve ASM
13	106-4947	2	Connector
13:1	100-8637	2	O-Ring
18	133-2881	1	Fitting
19	133-2883	1	Fitting
21	3234-47	2	Screw-HHF
22	3256-61	2	Washer-Flat
23	32144-32	2	Screw-PPH

Ref.	Part Number	Qty.	Description
25	100-8635	12	Fork
26	3290-379	2	Tie-Cable
27	3234-42	6	Screw-HHF
28	104-8301	6	Nut-HF, NI
30	131-9636	1	Trim-Manifold, Agitation
31	AU112950	3	Protector-Hose
32	3290-378	6	Tie-Cable
33	132-4325-03	1	Mount-Bracket, Agitation
34	132-4302	1	Mount-Valve
35	131-0249	1	On/Off 2-Way Valve Kit
36	131-0264	1	Agitation Throttling Handle Kit
36:1	131-0263	1	Screw-Handle
37	33113-012	4	Screw-HH
38	127-9829	2	Clamp/Gasket Kit
38:2	127-1145	1	Gasket-Flange
39	133-2882	1	O-Ring
40	133-2884	1	O-Ring


● Not serviced separately



Manifold Assembly

Ref.	Part Number	Qty.	Description
1	137-4292	1	Mount-Valve
2	127-9804	1	Regulating Valve Body ASM
3	144-6163	1	Kit-Actuator Regulating Pi
4	140-7377	2	Kit-Actuator Pi, On/Off
5	127-9829	8	Clamp/Gasket Kit
5:2	127-1145	1	Gasket-Flange
6	127-9811	3	Fitting-Cap, Female
6:1	133-0398	1	Pin-Fork
7	131-3791	1	Filter-Pressure
8	131-0253	2	Manifold Valve Kit
9	127-9815	2	Fitting-Cap
10	131-0265	1	Agitation Regulating Handle Kit

Ref.	Part Number	Qty.	Description
10:1	131-0263	1	Screw-Handle
10:2	127-1197	1	O-Ring-Stem
11	131-0266	1	Master Regulating Handle Kit
11:1	131-0263	1	Screw-Handle
11:2	127-1197	1	O-Ring-Stem
12	104-7201	6	Nut-HF, NI
13	3234-4	6	Screw-HHF
14	322-22	2	Screw-HH
15	104-8300	2	Nut-HF, NI
16	131-7256	2	Manifold Valve Kit
17	107-0279	2	Washer




Regulating Valve Body Assembly No. 127-9804

Ref.	*Part Number*	*Qty.*	*Description*
1	130-8248	1	Vavle Stem Kit
1:1	127-1197	2	O-Ring-Stem
2	127-1196	1	Washer-Stem, Valve
3	127-1195	1	Seat-Stem, Valve
4	127-1190	1	Fork-Stem, Valve
5	127-1113	1	Ball-V
6	130-7317	2	Endcap Kit
6:1	127-1192	1	Seat-Ball
6:2	127-1188	1	O-Ring, Seat (Ball)
6:3	127-1189	1	O-Ring, Endcap

Ref.	*Part Number*	*Qty.*	*Description*
6:4	127-1187	1	O-Ring, Endcap
99	130-7304	1	Valve Repair Kit ●
99:1	127-1197	2	O-Ring-Stem
99:2	127-1196	2	Washer-Stem, Valve
99:3	127-1195	1	Seat-Stem, Valve
99:4	127-1190	1	Fork-Stem, Valve
99:5	127-1192	2	Seat-Ball
99:6	127-1188	2	O-Ring, Seat (Ball)
99:7	127-1187	2	O-Ring, Endcap
99:8	127-1189	2	O-Ring, Endcap


● Not illustrated



Regulating Actuator Assembly No. 144-6163

Ref.	*Part Number*	*Qty.*	*Description*
1		1	Actuator-Regulating Pi ●
1:1	130-7301	1	Hairpin-Actuator
2	127-6984	1	Decal-Valve, Regulating


● Not serviced separately



Actuator On/Off Assembly No. 140-7377


Ref.	*Part Number*	*Qty.*	*Description*
1		1	Actuator - On/Off ●
1:1	130-7301	1	Hairpin-Actuator
2	127-6979	1	Decal-Valve, Agitation
3	127-6981	1	Decal-Valve, On/Off
4	127-6982	1	Decal-Valve, Master Boom
5	127-6976	1	Decal-Valve, Bypass Adjust

● Not serviced separately



Pressure Filter Assembly No. 131-3791

Ref.	*Part Number*	*Qty.*	*Description*
1	136-0397	1	Bowl-Strainer
2	136-0398	1	Rubber-Gasket
3	136-0410	1	Strainer Cap
4	136-0399	1	Rubber-Gasket
99	133-0384	1	Screen-Teejet, 30 Mesh
99	133-0385	1	Screen-Teejet, 50 Mesh
99	133-0386	1	Screen-Teejet, 80 Mesh
99	133-0387	1	Screen-Teejet, 100 Mesh




Manifold Valve Kit No. 131-0253

Ref.	*Part Number*	*Qty.*	*Description*
1	130-8248	1	Vavle Stem Kit
1:1	127-1197	2	O-Ring-Stem
2	127-1113	1	Ball-V
3	130-7317	1	Endcap Kit
3:1	127-1192	1	Seat-Ball
3:2	127-1188	1	O-Ring, Seat (Ball)
3:3	127-1189	1	O-Ring, Endcap
3:4	127-1187	1	O-Ring, Endcap
4	130-8249	1	Endcap Kit
4:1	127-1192	1	Seat-Ball
4:2	127-1188	1	O-Ring, Seat (Ball)
4:3	127-1189	1	O-Ring, Endcap

Ref.	*Part Number*	*Qty.*	*Description*
5	127-1196	1	Washer-Stem, Valve
6	127-1195	1	Seat-Stem, Valve
7	127-1190	1	Fork-Stem, Valve
99	130-7304	1	Valve Repair Kit ●
99:1	127-1197	2	O-Ring-Stem
99:2	127-1196	2	Washer-Stem, Valve
99:3	127-1195	1	Seat-Stem, Valve
99:4	127-1190	1	Fork-Stem, Valve
99:5	127-1192	2	Seat-Ball
99:6	127-1188	2	O-Ring, Seat (Ball)
99:7	127-1187	2	O-Ring, Endcap
99:8	127-1189	2	O-Ring, Endcap

● Not illustrated




Item 99:7 not used on this kit.

Manifold Valve Kit No. 131-7256

Ref.	*Part Number*	*Qty.*	*Description*
1	130-8248	1	Vavle Stem Kit
1:1	127-1197	2	O-Ring-Stem
2	127-1194	1	Ball-Valve, 3Way
3	130-8249	1	Endcap Kit
3:1	127-1192	1	Seat-Ball
3:2	127-1188	1	O-Ring, Seat (Ball)
3:3	127-1189	1	O-Ring, Endcap
4	127-1196	1	Washer-Stem, Valve
5	127-1195	1	Seat-Stem, Valve
6	127-1190	1	Fork-Stem, Valve
7	130-7317	1	Endcap Kit
7:1	127-1192	1	Seat-Ball

Ref.	*Part Number*	*Qty.*	*Description*
7:2	127-1188	1	O-Ring, Seat (Ball)
7:3	127-1189	1	O-Ring, Endcap
7:4	127-1187	1	O-Ring, Endcap
99	130-7304	1	Valve Repair Kit ●
99:1	127-1197	2	O-Ring-Stem
99:2	127-1196	2	Washer-Stem, Valve
99:3	127-1195	1	Seat-Stem, Valve
99:4	127-1190	1	Fork-Stem, Valve
99:5	127-1192	2	Seat-Ball
99:6	127-1188	2	O-Ring, Seat (Ball)
99:7	127-1187	2	O-Ring, Endcap
99:8	127-1189	2	O-Ring, Endcap

● Not illustrated




Section Manifold Valve Assembly

Ref.	Part Number	Qty.	Description
1	131-0258	1	Mount-Valves, Boom
2	127-9803	3	On/Off Manifold Valve Kit
3	140-7377	3	Kit-Actuator Pi, On/Off
3:1		1	Actuator - On/Off ●
3:1:1	130-7301	1	Hairpin-Actuator
3:2	127-6979	1	Decal-Valve, Agitation
3:3	127-6981	1	Decal-Valve, On/Off
3:4	127-6982	1	Decal-Valve, Master Boom
3:5	127-6976	1	Decal-Valve, Bypass Adjust
4	127-9829	4	Clamp/Gasket Kit

Ref.	Part Number	Qty.	Description
4:2	127-1145	1	Gasket-Flange
5	127-1185	1	Fitting-Cap, Port
6	127-9805	3	Bypass Valve ASM
7	127-9810	1	Male Cap Fitting Kit
7:2	127-1187	1	O-Ring, Endcap
8	127-1144	1	Fitting-Adapter
9	3234-4	4	Screw-HHF
10	104-7201	4	Nut-HF, NI
11	131-3709	1	Coupler

● Not serviced separately




On/Off Manifold Valve Kit No. 127-9803

Ref.	*Part Number*	*Qty.*	*Description*
1	130-8248	1	Vavle Stem Kit
1:1	127-1197	2	O-Ring-Stem
2	127-1194	1	Ball-Valve, 3Way
3	130-7317	2	Endcap Kit
3:1	127-1192	1	Seat-Ball
3:2	127-1188	1	O-Ring, Seat (Ball)
3:3	127-1189	1	O-Ring, Endcap
3:4	127-1187	1	O-Ring, Endcap
4	127-1196	1	Washer-Stem, Valve
5	127-1195	1	Seat-Stem, Valve


Ref.	*Part Number*	*Qty.*	*Description*
6	127-1190	1	Fork-Stem, Valve
99	130-7304	1	Valve Repair Kit ●
99:1	127-1197	2	O-Ring-Stem
99:2	127-1196	2	Washer-Stem, Valve
99:3	127-1195	1	Seat-Stem, Valve
99:4	127-1190	1	Fork-Stem, Valve
99:5	127-1192	2	Seat-Ball
99:6	127-1188	2	O-Ring, Seat (Ball)
99:7	127-1187	2	O-Ring, Endcap
99:8	127-1189	2	O-Ring, Endcap

● Not illustrated




Actuator On/Off Assembly No. 140-7377

Ref.	*Part Number*	*Qty.*	*Description*
1	140-7315	1	Actuator - On/Off
1:1	130-7301	1	Hairpin-Actuator
2	127-6979	1	Decal-Valve, Agitation
3	127-6981	1	Decal-Valve, On/Off
4	127-6982	1	Decal-Valve, Master Boom
5	127-6976	1	Decal-Valve, Bypass Adjust



Bypass Valve Assembly No. 127-9805

Ref.	*Part Number*	*Qty.*	*Description*
1	131-0298	1	Bypass Needle Kit
1:1	127-1182	1	Needle-Bypass
1:2	127-1181	2	Oring-Bypass Needle
2	127-1180	1	Knob-Bypass
3	127-1179	1	Fork-Bypass Knob
4	127-1187	1	O-Ring, Endcap
5	133-0398	2	Pin-Fork




Reference **Spray Tank Assembly** page and **Spray Tank Valve Assembly** page for hose locations and orientation

Hose Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	139-3095	1	Hose-Agitation, ASM
1:1	117-7862	3	Hose-Main Agitation
1:2	117-7866	3	Tee-Hosebarb
1:3	117-7867	1	Elbow-Hosebarb
1:4	119-0441	4	Hose-Agitaiton
1:5	131-0213	1	90 DEG Barb Fitting Kit
1:5:1	133-0398	1	Pin-Fork
1:6	131-3731	4	Agitation Nozzle ASM
1:6:1	131-3732	1	Fitting-Barb
1:6:2	120-8579	1	Nozzle-Agitation
1:6:3	121-4996	1	O-Ring
1:7	131-3785	1	Hose-Supply
1:8	2412-34	16	Clamp-Hose
2	125-0645	1	Upper Suction Hose ASM
2:1	110-5156	1	Suction Elbow ASM
2:1:1	100-8637	1	O-Ring
2:2	106-4952	1	Hosebarb-90 DEG
2:2:1	100-6989	1	O-Ring
2:4	41327	2	Clamp-Hose
3	133-2868	1	Drain Hose ASM
3:1	106-4933	1	Hosebarb ASM

Ref.	*Part Number*	*Qty.*	*Description*
3:1:1	100-8637	1	O-Ring
3:3	2412-34	1	Clamp-Hose
5	132-4329	1	Hose-Supply
5:2	106-4932	1	Hosebarb-Straight
5:2:1	100-8637	1	O-Ring
5:3	131-0241	1	Fitting-Elb 90
5:4	2412-34	2	Clamp-Hose
6	132-4331	1	Hose-Agitation, Bypass
6:2	106-4933	1	Hosebarb ASM
6:2:1	100-8637	1	O-Ring
6:3	127-1142	1	Fitting-STR
6:4	2412-34	2	Clamp-Hose
8	125-0639	1	Regulating Hose ASM
8:1	106-4933	2	Hosebarb ASM
8:1:1	100-8637	1	O-Ring
8:3	2412-34	2	Clamp-Hose
9	132-4333	1	Hose-Bypass
9:2	106-4933	1	Hosebarb ASM
9:2:1	100-8637	1	O-Ring
9:3	131-0213	1	90 DEG Barb Fitting Kit
9:3:1	133-0398	1	Pin-Fork




Reference **Spray Tank Assembly** page and **Spray Tank Valve Assembly** page for hose locations and orientation

Hose Assembly (continued)

Ref.	*Part Number*	*Qty.*	*Description*
9:4	2412-34	2	Clamp-Hose
10	125-0643	1	Lower Suction Hose ASM
10:1	117-7965	1	Hosebarb ASM
10:1:1	100-6989	1	O-Ring
10:2	117-7982	1	Hosebarb ASM
10:2:2	100-8637	1	O-Ring
10:4	41327	2	Clamp-Hose
11	132-4330	1	Hose-Regulating
11:2	106-4932	1	Hosebarb-Straight
11:2:1	100-8637	1	O-Ring
11:3	127-9806	1	Fitting Kit


Ref.	*Part Number*	*Qty.*	*Description*
11:3:1	133-0398	1	Pin-Fork
11:4	2412-34	2	Clamp-Hose
12	132-4332	1	Hose-Master
12:2	107-8704	1	Hosebarb
12:3	131-0213	1	90 DEG Barb Fitting Kit
12:3:1	133-0398	1	Pin-Fork
12:4	2412-34	2	Clamp-Hose
13	132-4326	1	Hose-Agitation, Supply
13:2	127-9806	2	Fitting Kit
13:2:1	133-0398	1	Pin-Fork
13:3	2412-34	2	Clamp-Hose



Boom Lift Assembly

Ref.	Part Number	Qty.	Description
1	119-4856-03	1	Plate-Mount, Cylinders
2	117-0701	2	Hydraulic Cylinder ASM
3	104-8300	6	Nut-HF, NI
4	131-0297-03	1	Plate-Stiffener, Boom
5	112-7884	2	Pin-Pivot
6	110-5053	2	Screw-HHF
7	3234-29	2	Screw-HHF
8	130-8201-03	1	Mount-Valve
9	136-2400	1	On-Off Boom Lift Valve ASM
10	340-2	2	Fitting-Straight
10:1	237-22	1	O-Ring
10:2	237-42	1	O-Ring

Ref.	Part Number	Qty.	Description
11	59-7410	1	Fitting-Diagnostic
11:1	237-42	1	O-Ring
12	354-79	1	Cap-Dust
13	322-14	2	Screw-HH
15	110-5067	2	Screw-CARR
16	99-5107	2	Nut-HF Nylock
17	119-4859	4	Hose ASM
17:3	237-78	1	O-Ring
18	106-7968	1	Coupler-Quick, Female
19	106-7969	1	Coupler-Quick, Male
20	127-9717	2	Hose ASM
20:1	237-42	1	O-Ring




Hydraulic Cylinder Assembly No. 117-0701

Ref.	*Part Number*	*Qty.*	*Description*
1	119-8026	1	Seal Kit ●
1:1		1	O-Ring ■
1:2		1	Ring-Backup ■
1:3		1	Bp Seal ■
1:4		1	Bs Seal ■
1:5		1	Dust Seal ■
1:6		1	O-Ring ■
2	119-8027	1	Rod End
3	3220-6	1	Nut-Jam

● Not illustrated


■ Not serviced separately



On-Off Boom Lift Valve Assembly No. 136-2400

Ref.	*Part Number*	*Qty.*	*Description*
3	136-2430	2	Valve-Check, Po
3:1	120-0886	1	Seal Kit
4	107-7517	1	Valve-Solenoid
4:1	105-9156	1	Seal Kit
4:2	107-7812	1	Nut-Solenoid
5	120-2587	2	Valve-Solenoid
5:1	112-6520	1	Seal Kit ●
6	119-8036	5	Coil
7	120-2586	2	Spacer-Coil
8	110-8903	2	Orifice-Control, Flow (0.055)
9	125-8849	2	Orifice-Flow Control
10	340-92	4	Fitting-Straight
10:1	237-78	1	O-Ring
10:2	237-21	1	O-Ring
11	110-2634	2	Nut-Coil


● Not illustrated



Electrical Assembly

Ref.	Part Number	Qty.	Description
1	122-1444	1	Harness-Wire
1:13	94-6710	1	Fuse-2 Amp
1:15	114241	2	Fuse-Blade, 7.5 Amp
1:16	218-578	1	Fuse-Blade, 10 Amp
1:17	109355	1	Fuse-Blade, 15 Amp
1:18	32180-043	2	Resistor-120 Ohm
1:24	109103	1	Fuse-Blade, 30 Amp
2	127-3966	1	Decal-Fuse Block
3	108-9455	1	Harness-Wire, Fusible Link
4	112-9921	2	Bolt ASM
4:1	32180-107	1	Bolt-Clamp, Battery


Ref.	Part Number	Qty.	Description
4:2	32180-108	2	Nut-Hex Shoulder
5	106-1429	3	Clamp-J
6	99-7435	1	Relay
7	99-7430	1	Relay-Mini
8	125-8067	1	Plug-Plastic
9	104-0395	1	Plug-Plastic
10	3234-13	1	Screw-HHF
11	104-7201	1	Nut-HF, NI
12	32180-110	1	Insulator-Lead Cast
13	132-7773	1	Connector-Hose
14	122-1445	1	Harness-Wire



Center Boom Assembly


Ref.	Part Number	Qty.	Description
1	136-0381	1	Boom-LH
1:2	120-0617	2	Decal-Warning, Pinch, Crush
2	144-6199	2	Spring-Extension
3	108-3725	1	LH Single Body Turret ASM
4	108-3727	1	Double Turret Body ASM
5	108-3726	1	RH Single Body Turret ASM
6	3213-8	4	Screw-HH
7	104-8300	7	Nut-HF, NI
8	108-3717	1	Hose-Boom
9	108-3439	1	Tee
10	2412-129	7	Clamp-Hose
11	144-6198-03	2	Cradle-ASM, Lower [black]
12	3290-378	2	Tie-Cable
13	104-8301	12	Nut-HF, NI
14	140-6355	2	Cradle ASM-Upper
15	108-3457	2	Spacer
17	108-3489	4	Cap-Tube
18	110-5052	6	Screw-HHF
19	108-3495	2	Cover-Slide
20	108-3743	2	Washer

Ref.	Part Number	Qty.	Description
21	108-3744	2	Screw-Shoulder
22	114-9566	2	Clamp-R
23	95-9186	3	Cap
23:1	40998	1	Seat-Gasket
24	95-9187	6	Cap-Blank
24:1	40998	1	Seat-Gasket
25	108-3735	1	Hose-Boom, Center (LH)
26	108-3718	1	Hose-Boom, Center (RH)
27	3256-68	2	Washer-Flat
28	110-5070	2	Bumper
29	127-3923	1	Conduit-Convoluted
30	132-4335	1	Hose-Center Boom
30:1	127-9770	1	Hose-Shutoff
30:2	127-9807	1	Straight Fitting Kit
30:2:1	133-0398	1	Pin-Fork
30:3	2412-129	1	Clamp-Hose
31	127-8955-03	1	Mount-Boom
32	127-8956-03	1	Mount-Boom
33	110-5057	4	Capscrew-HHF
34	108-3745	4	Nut-HHF, Whiz
35	110-5050	4	Screw-HHF



Center Boom Assembly (continued)


Ref.	Part Number	Qty.	Description
36	3234-42	2	Screw-HHF
37	136-0382	1	Boom-RH
37:2	120-0617	2	Decal-Warning, Pinch, Crush
38	110-6894	4	Washer-Pivot
39	3296-19	4	Nut-Hex
40	3246-4	4	Screw-Set
41	144-6201-03	2	Tube-Lower Craddle



LH Single Turret Body Assembly No. 108-3725

Ref.	*Part Number*	*Qty.*	*Description*
1	95-9200	1	Plug
2	95-9198	1	O-Ring
3	95-9197	1	E-Clip
4	95-9199	2	O-Ring
5	108-3264	1	Seal-Viton
6	108-3265	1	O-Ring-Viton
7	95-9196	1	Turret
8	41003	1	Diaphragm


Ref.	*Part Number*	*Qty.*	*Description*
9	95-9193	1	Cap-Diaphram
10	95-9192	1	Body-Split Eyelet
11	95-9191	1	O-Ring
12	99-0811	1	Screw-Clamp
13	99-0812	1	Clamp-Upper
14	99-0814	1	Pin-Pivot
15	95-9201	1	Shank-Hose
16	322-3	1	Screw-HH



Double Turret Body Assembly No. 108-3727

Ref.	*Part Number*	*Qty.*	*Description*
1	95-9200	1	Plug
2	95-9198	1	O-Ring
3	95-9197	1	E-Clip
4	95-9199	2	O-Ring
5	108-3264	1	Seal-Viton
6	108-3265	1	O-Ring-Viton
7	95-9196	1	Turret
8	41003	1	Diaphragm


Ref.	*Part Number*	*Qty.*	*Description*
9	95-9193	1	Cap-Diaphram
10	95-9192	1	Body-Split Eyelet
11	95-9191	1	O-Ring
12	99-0811	1	Screw-Clamp
13	99-0812	1	Clamp-Upper
14	99-0814	1	Pin-Pivot
15	95-9202	1	Shank-Hose
16	322-3	1	Screw-HH



RH Single Body Turret Assembly No. 108-3726

Ref.	*Part Number*	*Qty.*	*Description*
1	95-9200	1	Plug
2	95-9198	1	O-Ring
3	95-9197	1	E-Clip
4	95-9199	2	O-Ring
5	108-3264	1	Seal-Viton
6	108-3265	1	O-Ring-Viton
7	95-9196	1	Turret
8	41003	1	Diaphragm


Ref.	*Part Number*	*Qty.*	*Description*
9	95-9193	1	Cap-Diaphram
10	95-9192	1	Body-Split Eyelet
11	95-9191	1	O-Ring
12	99-0811	1	Screw-Clamp
13	99-0812	1	Clamp-Upper
14	99-0814	1	Pin-Pivot
15	95-9201	1	Shank-Hose
16	322-3	1	Screw-HH



Boom Mounting Assembly


Ref.	*Part Number*	*Qty.*	*Description*
3	100-8541	4	Bushing-A Arm
4	108-3436	2	Pin-Clevis
5	3290-468	2	Pin-Cotter
9	108-3419	2	Pivot Pin ASM
10	108-3605	8	Plate-Backing
13	108-3748	2	Screw-HHF
15	104-8300	2	Nut-HF, NI
20		2	Pivot Bracket Assembly ●

● Not serviced separately



Boom Pivot Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	137-1673	1	Bracket-Pivot
2	137-1674	2	Hinge
3	110-5054	2	Washer-Flat
4	108-3738	2	Screw-HH
5	108-3459	2	Boot-Hinge
6	120-8541	2	Dampener-Hinge
7	108-3440	2	Spring-Breakaway, Boom
8	108-3444	2	Retainer-Spring
9	3296-15	2	Nut-Lock, NI
10	302-5	4	Fitting-Grease
11	110-5050	8	Screw-HHF
12	104-8301	8	Nut-HF, NI



Left and Right Hand Boom Assembly

Ref.	Part Number	Qty.	Description
1	108-3524-03	1	Boom-RH
2	108-3525-03	1	Boom-LH
3	119-9368	4	Block Slide
4	108-3725	2	LH Single Body Turret ASM
5	108-3727	4	Double Turret Body ASM
6	108-3726	2	RH Single Body Turret ASM
7	104-8300	8	Nut-HF, NI
8	136-0437	2	Hose-Formed
9	40506	2	Hose-Jumper
10	2412-129	18	Clamp-Hose
11	119-9369	8	Screw-HHF
12	108-3439	2	Tee
13	240-3	4	Grommet-Rubber
14	136-0436	2	Hose-Formed
15	95-9186	8	Cap
15:1	40998	1	Seat-Gasket
16	95-9187	16	Cap-Blank

Ref.	Part Number	Qty.	Description
16:1	40998	1	Seat-Gasket
17	107-8650	2	Conduit-Convoluted
18	3290-378	4	Tie-Cable
19	132-4334	1	Hose-Left Boom
19:1	131-3790	1	Hose-Boom, RH
19:2	127-9807	1	Straight Fitting Kit
19:2:1	133-0398	1	Pin-Fork
19:3	2412-129	1	Clamp-Hose
22	104-8904	2	Decal-Grasp Boom Here
23	108-3735	2	Hose-Boom, Center (LH)
24	132-4324	1	Hose-Boom
24:1	127-9769	1	Hose-Supply
24:2	127-9807	1	Straight Fitting Kit
24:2:1	133-0398	1	Pin-Fork
24:3	2412-129	1	Clamp-Hose
99	119-9434	1	Decal-Magnetic

Attachments and Accessories

For 41240 Multi Pro WM Turf Sprayer

Product Name	Model/Part
Cab Kit	07392
Premium ATF (Drum)	108-1185
Premium ATF (Pail)	108-1186
Premium All Purpose Grease (Tube)	108-1190
License Plate Kit	120-8506
Covered Boom Spring Upgrade Kit	120-8508
Premium Engine Oil 10w30 (55 Gallon Drum)	121-6392
Premium Engine Oil 10w30 (5 Gallon Pail)	121-6393
Fan Kit (EFI, Gas Engine Only)	127-9719
Lance Suction Assembly	127-9826
Multi Pro WM Turf Sprayer Finishing Kit (Automatic)	131-3301
Multi Pro WM Turf Sprayer Finishing Kit (Manual)	131-3302
Cab Finishing Kit, 2016 and After Multi Pro WM Turf Sprayer	133-2725
Ultra Sonic Boom Finishing Kit, 2013 and After Multi Pro WM Turf Sprayer	133-2808
Foam Marker Finishing Kit	136-0459
Pump Head Kit	145-3399
Rear Work Light Kit	41010
Single Nozzle Kit	41023
Hand Spray Wand Kit	41118
Pro Foam Concentrate (4 x 1 Gallon)	41157
Nozzalert - Mp Nozzle Flow System	41166
Jackstand Kit	41216
Ultra Sonic Boom Leveling Kit	41219
Tank Clean Rinse Kit	41241
Chemical Pre-Mix Kit	41244
Electric Hose Reel Kit	41245
Foam Marker Kit	41249
Drift Reduction Boom Shroud Kit	41602
Pro-Foam	41607

Notes:

Notes:



Count on it.