



**Count on it.**

**Parts Catalog**

**GrandStand® Mower**

**With 48in TURBO FORCE® Cutting Unit**

Model No. 72518—Serial No. 420000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|   |    |
|---|----|
| 48 Inch Deck Assembly .....                 | 4  |
| Deck Decal Assembly No. 139-8093 .....      | 6  |
| Spindle Assembly No. 137-9780 .....         | 8  |
| Deflector Assembly No. 163-4031 .....       | 10 |
| Ground Drive Assembly .....                 | 12 |
| LH Transmission Assembly No. 138-5838 ..... | 14 |
| RH Transmission Assembly No. 138-5839 ..... | 16 |
| Overflow Hose Assembly .....                | 18 |
| Motion Control Assembly .....               | 20 |
| Control Handle Assembly No. 132-5157 .....  | 22 |
| Control Handle Assembly No. 132-5158 .....  | 24 |
| Parking Brake Assembly .....                | 26 |
| Deck Lift Assembly .....                    | 28 |
| HOC Lever Assembly No. 161-6735 .....       | 30 |
| HOC Link Assembly No. 130-6615 .....        | 32 |
| Frame Assembly .....                        | 34 |
| Wheel and Bearing Assembly .....            | 36 |
| Platform Assembly .....                     | 38 |
| Engine Assembly .....                       | 40 |
| Fuel Tank Assembly .....                    | 42 |
| Electrical Assembly .....                   | 44 |
| Attachments and Accessories .....           | 46 |


# 48 Inch Deck Assembly



## 48 Inch Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 139-8093           | 1           | 48 Deck ASM           | 22          | 108-4052           | 1           | Spring-Torsion          |
| 2           | 137-9780           | 3           | Spindle ASM           | 23          | 137-9787           | 3           | Bushing-Hex             |
| 3           | 138-6061           | 3           | Sheave-Blade, Drive   | 24          | 109-9220           | 3           | Screw-Sems              |
| 4           | 109-6982           | 3           | Wireform-Cover        | 25          | 145-3450           | 1           | Gs Torsion Idler ASM li |
| 5           | 109-6936           | 1           | Cover-Belt, LH        | 26          | 127-1971           | 1           | Pulley-Idler            |
| 6           | 109-6935           | 1           | Cover-Belt, RH        | 27          | 323-20             | 1           | Screw-HH                |
| 7           | 117-0410-01        | 1           | 48 Inch Baffle ASM    | 28          | 114-1908-01        | 1           | Skid                    |
| 8           | 139-8105-01        | 1           | Plate-Baffle, Formed  | 29          | 130-6649-01        | 1           | Bracket-Skid            |
| 9           | 107-8541-01        | 1           | Baffle-Discharge      | 30          | 109-2872           | 1           | Spacer-Pulley           |
| 10          | 117-5758-05        | 4           | Bracket-Cover         | 31          | 132-4718           | 1           | Pulley-Idler, Flat      |
| 11          | 163-4031           | 1           | Rubber Deflector ASM  | 32          | 3231-44            | 1           | Screw-CARR              |
| 12          | 104-8301           | 39          | Nut-HF, NI            | 33          | 132-5153           | 1           | Shield-Dust             |
| 13          | 140-1243           | 3           | Blade-16.50 High Flow | 52          | 94-7582            | 1           | Bolt-Shoulder           |
| 14          | 3231-2             | 8           | Bolt-CARR             | 53          | 100-4852           | 1           | Washer-Hardened         |
| 15          | 145-3481           | 1           | Gs 48 Deck Belt-V     | 54          | 116-7306           | 3           | Nut-Hex                 |
| 16          | 32144-70           | 4           | Screw-HWHTF           | 55          | 103-2802           | 3           | Washer                  |
| 17          | 109-6658           | 1           | Nut-Flange, NI        | 56          | 138-6045           | 3           | Shaft-Spindle           |
| 18          | 92-1624            | 2           | Screw-HWH Thd Form    | 57          | 137-9784           | 3           | Guard-Bottom            |
| 19          | 105-4622           | 1           | Spacer                | 58          | 3231-25            | 1           | Bolt-CARR               |
| 20          | 322-50             | 1           | Screw-HH              | 59          | 109-1092           | 1           | Knob                    |
| 21          | 104-8300           | 1           | Nut-HF, NI            |             |                    |             |                         |


# Deck Decal Assembly No. 139-8093



## Deck Decal Assembly No. 139-8093 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|---------------------------|
| 2           | 161-6620           | 2           | Decal-Danger, Deck | 5           | 131-3507           | 1           | Decal-Belt, Tension (CE)  |
| 3           | 107-1690           | 1           | Decal              | 6           | 138-1147           | 1           | Decal - Baffle Adjustment |
| 4           | 116-8283           | 1           | Decal-Torque, Bolt |             |                    |             |                           |


# Spindle Assembly No. 137-9780



## Spindle Assembly No. 137-9780 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 116-0720           | 2           | Bearing-Ball       |
| 3           | 138-6042           | 1           | Spacer-Bearing     |

# Deflector Assembly No. 163-4031



## Deflector Assembly No. 163-4031 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 110-0759           | 1           | Deflector-Rubber      | 5           | 106-3248-03        | 1           | Strap-Discharge    |
| 2           | 161-9815-01        | 1           | Plate-Deflector Mount | 6           | 3231-5             | 4           | Screw-CARR         |
| 3           | 108-4059-01        | 1           | Plate-Hinge, Rear     | 7           | 104-8301           | 4           | Nut-HF, NI         |
| 4           | 106-3253-01        | 1           | Plate-Hinge, Front    |             |                    |             |                    |




## Ground Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 138-5838           | 1           | LH Transmission ASM        | 20          | 3229-25            | 3           | Screw-CARR             |
| 2           | 138-5839           | 1           | RH Transmission ASM        | 21          | 104-7201           | 3           | Nut-HF, NI             |
| 3           | 131-1131-05        | 1           | Support-Transaxle          | 22          |                    | 1           | Gs Overflow Hose ASM ■ |
| 4           | 93-2569            | 4           | Screw-HHF                  | 23          | 109-0309           | 1           | Hose-Fuel              |
| 5           | 116-4701           | 16          | Screw-HHF                  | 24          | 92-2379            | 1           | Clamp-Hose             |
| 6           | 104-8301           | 18          | Nut-HF, NI                 | 25          | 131-7469           | 1           | Rod-Bypass, RH         |
| 7           | 138-1108-05        | 1           | Skid Plate                 | 26          | 131-7470           | 1           | Rod-Bypass, LH         |
| 9           | 117-5351           | 1           | Spacer                     | 27          | 108-2992           | 2           | Pin-Hair               |
| 10          | 1-413088           | 1           | Bushing-Lever, Lift        | 28          | 32180-030          | 1           | Clip-Tie               |
| 11          | 131-1175           | 1           | Arm-Idler                  | 29          | 140-1888           | 2           | Wheel And Tire ASM     |
| 12          | 114-0463           | 2           | Washer-Friction, Composite | 29:1        | 140-1889           | 1           | Rim-8 Inch Black       |
| 13          | 110-9981           | 1           | Washer-Plain               | 29:2        | 120-6466           | 1           | Tire                   |
| 14          | 3234-39            | 1           | Screw-HHF                  | 29:3        | 232-27             | 1           | Stem-Valve             |
| 15          | 93-1622            | 1           | Pulley-Idler               | 30          | 139-2564           | 8           | Nut-Lug                |
| 16          | 3231-4             | 1           | Screw-CARR                 | 31          | 132-7584           | 2           | Spacer-Hex             |
| 17          | 138-1104           | 1           | Spring-Extension           | 32          | 104-8300           | 2           | Nut-HF, NI             |
| 18          | 131-1124           | 1           | Belt-V                     | 33          | 3290-250           | 2           | Pin-Cotter             |
| 19          | 132-1135           | 1           | Tank-HYD                   | 34          | 2412-129           | 2           | Clamp-Hose             |
| 19:2        | 133-8677           | 1           | Cap-Vented                 | 35          | 3290-378           | 1           | Tie-Cable              |
| 19:5        | 140-9463           | 1           | Strainer-Neck, Removable ● |             |                    |             |                        |

● Not illustrated

■ Not serviced separately

# LH Transmission Assembly No. 138-5838




# LH Transmission Assembly No. 138-5838 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|---------------------------------|
| 1           | 132-4737           | 1           | Nut-Lock                  | 15:1        |                    | 2           | Filter (1A6370-26450) ■         |
| 2           | 132-4738           | 1           | Fan                       | 15:2        | 136-5410           | 2           | O-Ring                          |
| 3           | 132-4739           | 1           | Pulley                    | 15:3        |                    | 4           | Sealing Washer ● ■              |
| 5           | 104-3265           | 1           | Pin                       | 16          | 137-4109           | 1           | Spring-Torsion                  |
| 6           | 132-4700           | 1           | Lever-Bypass              | 17          | 137-9509           | 4           | Stud-Wheel                      |
| 8           | 133-1468           | 1           | Brake Kit,Left            | 18          | 138-4613           | 1           | Cap-Oil Filter                  |
| 8:1         |                    | 1           | O-Ring ■                  | 21          | 137-9509           | 1           | Stud-Wheel                      |
| 8:2         |                    | 1           | Brake Arm ■               | 23          | 139-5587           | 1           | Seal-Axle, Ua                   |
| 8:3         |                    | 1           | Roll Pin ■                | 24          | 163-7372           | 1           | Axle ASM Kit                    |
| 8:4         |                    | 1           | Brake Shaft ■             | 25          | 139-5589           | 2           | Drain Bolt                      |
| 8:5         |                    | 1           | Brake Actuator ■          | 26          | 139-5590           | 1           | Expansion Fitting               |
| 8:6         |                    | 1           | Brake Disc ■              | 27          | 139-5591           | 1           | Grommet Seal, Expansion Fitting |
| 8:7         |                    | 1           | Brake Shoe ■              |             |                    |             |                                 |
| 8:8         |                    | 1           | Shim Kit ■                | 28          | 139-7871           | 1           | Expansion Fitting - W/ Seal     |
| 9           | 132-4735           | 1           | Cap-Oil                   | 28:3        |                    | 1           | M8*20 Flange Bolt ■             |
| 11          | 136-5401           | 1           | Lever-Control, RH         | 29          | 163-4195           | 1           | Kit-Seal, Hydro                 |
| 15          | 144-3842           | 1           | 2 Transmission Filter Kit |             |                    |             |                                 |

● Not illustrated

■ Not serviced separately

# RH Transmission Assembly No. 138-5839




# RH Transmission Assembly No. 138-5839 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|---------------------------------|
| 1           | 132-4737           | 1           | Nut-Lock           | 15          | 144-3842           | 1           | 2 Transmission Filter Kit       |
| 2           | 132-4738           | 1           | Fan                | 15:1        |                    | 2           | Filter (1A6370-26450) ■         |
| 3           | 132-4739           | 1           | Pulley             | 15:2        | 136-5410           | 2           | O-Ring                          |
| 5           | 104-3265           | 1           | Pin                | 15:3        |                    | 4           | Sealing Washer ● ■              |
| 6           | 132-4700           | 1           | Lever-Bypass       | 16          | 137-4109           | 1           | Spring-Torsion                  |
| 8           | 133-1462           | 1           | RH Brake Kit       | 17          | 137-9509           | 4           | Stud-Wheel                      |
| 8:1         |                    | 1           | O-Ring ■           | 18          | 138-4613           | 1           | Cap-Oil Filter                  |
| 8:2         |                    | 1           | Arm-Brake ■        | 19          | 139-5587           | 1           | Seal-Axle, Ua                   |
| 8:3         |                    | 1           | Pin-Roll ■         | 20          | 163-7372           | 1           | Axle ASM Kit                    |
| 8:4         |                    | 1           | Shaft-Brake ■      | 21          | 139-5589           | 2           | Drain Bolt                      |
| 8:5         |                    | 1           | Actuator-Brake ■   | 22          | 139-5590           | 1           | Expansion Fitting               |
| 8:6         |                    | 1           | Disc-Brake ■       | 23          | 139-5591           | 1           | Grommet Seal, Expansion Fitting |
| 8:7         |                    | 1           | Shoe-Brake ■       | 28          | 139-7871           | 1           | Expansion Fitting - W/ Seal     |
| 8:8         |                    | 1           | Shim Kit ■         | 28:3        |                    | 1           | M8*20 Flange Bolt ■             |
| 9           | 132-4735           | 1           | Cap-Oil            | 29          | 163-4195           | 1           | Kit-Seal, Hydro                 |
| 11          | 136-5401           | 1           | Lever-Control, RH  |             |                    |             |                                 |

● Not illustrated

■ Not serviced separately



# Overflow Hose Assembly



## Overflow Hose Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 145-3444           | 1           | Hose-Hydraulic     | 4           | 147-0201           | 1           | R-Clamp            |
| 2           | 139-4055           | 1           | Fitting Tee        | 5           | 147-0204           | 1           | Hydraulic Hose     |
| 3           | 147-0202           | 1           | Hydraulic Hose     | 6           | 145-3599           | 4           | Hose Clamp         |


# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 132-5157           | 1           | LH Control Handle ASM | 9:5         | 1-603807           | 1           | Spring-Return, Neutral    |
| 2           | 132-5158           | 1           | RH Control Handle ASM | 10          | 138-4620           | 1           | RH Control Rod ASM        |
| 3           | 119-0222           | 2           | Grip                  | 10:1        | 138-4647           | 1           | Ball Joint-LH             |
| 4           | 103-9928           | 2           | Bearing               | 10:2        | 138-4648           | 1           | Ball Joint-RH             |
| 5           | 120-3288           | 1           | Tab-Pivot, LH         | 10:4        | 3219-3             | 1           | Nut-Hex                   |
| 6           | 3229-1             | 4           | Screw-CARR            | 11          | 3231-28            | 2           | Screw-CARR                |
| 7           | 104-7201           | 6           | Nut-HF, NI            | 12          | 104-8301           | 4           | Nut-HF, NI                |
| 8           | 120-3287           | 1           | Tab-Pivot, RH         | 13          | 3256-24            | 2           | Washer-Plain              |
| 9           | 138-4619           | 1           | LH Control Rod ASM    | 14          | 132-7538           | 1           | Bracket-Adjustment, Speed |
| 9:1         | 138-4647           | 1           | Ball Joint-LH         | 15          | 126-1499           | 2           | Cam                       |
| 9:2         | 138-4648           | 1           | Ball Joint-RH         | 16          | 323-7              | 2           | Screw-HH                  |
| 9:4         | 3219-3             | 1           | Nut-Hex               |             |                    |             |                           |



# Control Handle Assembly No. 132-5157



## Control Handle Assembly No. 132-5157 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 2           | 131-3562           | 1           | Bearing-Sleeve     | 7           | 116-2670           | 1           | Screw-Shoulder     |
| 4           | 323-10             | 1           | Screw-HH           | 8           | 104-8300           | 1           | Nut-HF, NI         |
| 5           | 104-8301           | 1           | Nut-HF, NI         | 9           | 132-5146           | 1           | Spring-Extension   |
| 6           | 110-7191           | 2           | Washer-Thrust      |             |                    |             |                    |


# Control Handle Assembly No. 132-5158



## Control Handle Assembly No. 132-5158 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 3           | 104-8301           | 1           | Nut-HF, NI         | 7           | 104-8300           | 1           | Nut-HF, NI         |
| 4           | 323-10             | 1           | Screw-HH           | 8           | 131-3562           | 1           | Bearing-Sleeve     |
| 5           | 110-7191           | 2           | Washer-Thrust      | 9           | 132-5146           | 1           | Spring-Extension   |
| 6           | 116-2670           | 1           | Screw-Shoulder     |             |                    |             |                    |


# Parking Brake Assembly



## Parking Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-5170           | 1           | Brake Handle ASM     | 7           | 32144-4            | 2           | Screw-HWH          |
| 2           | 137-3061           | 5           | Bolt-CARR            | 8           | 132-1187           | 1           | Clamp-Cable        |
| 3           | 104-8300           | 6           | Nut-HF, NI           | 9           | 132-7582           | 1           | Mount-Cable, Brake |
| 4           | 132-5168           | 1           | RH Brake Caliper ASM | 10          | 1-633268           | 1           | Grip-Lever         |
| 5           | 132-5169           | 1           | LH Brake Caliper ASM | 11          | 131-1195           | 2           | Cable-Brake        |
| 6           | 104-8301           | 2           | Nut-HF, NI           |             |                    |             |                    |


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 120-8405-01        | 1           | Shaft-Cross, Front                   | 25          | 3231-7             | 4           | Screw-CARR              |
| 2           | 109-9409           | 2           | Support-Bearing, Cross Shaft (Front) | 26          | 104-8301           | 7           | Nut-HF, NI              |
| 3           | 109-9410           | 2           | Bearing-Cross Shaft, Front           | 27          | 32128-19           | 4           | Nut-HF Lock, Large Flg  |
| 4           | 116-1700           | 4           | Bolt-CARR                            | 28          | 109-9066           | 4           | Yoke-Adjust, Deck       |
| 5           | 99-5107            | 8           | Nut-HF Nylock                        | 29          | 322-47             | 4           | Screw-HH                |
| 6           | 127-0369           | 6           | Bushing                              | 30          | 3218-2             | 8           | Nut-Hex Jam             |
| 7           | 10-8110            | 3           | Washer-Thrust                        | 31          | 130-6589           | 2           | Link-Lift               |
| 8           | 3256-62            | 3           | Washer-Plain                         | 32          | 109-9840           | 2           | Screw-Shoulder, HHF     |
| 9           | 120-8411-01        | 1           | Arm-Lift, RH                         | 33          | 109-9065           | 2           | Screw-HH                |
| 10          | 32151-29           | 3           | Ring-Retaining                       | 34          | 116-2428           | 2           | Bushing-Flanged         |
| 11          | 120-8410-01        | 1           | Arm-Lift, LH                         | 35          | 3256-4             | 2           | Washer-Flat             |
| 12          | 161-6735           | 1           | HOC Lever ASM                        | 36          | 3296-48            | 4           | Nut-Hex                 |
| 13          | 119-6223           | 2           | Washer                               | 37          | 95-6448            | 2           | Spacer                  |
| 14          | 138-4932           | 3           | Nut-Hex Flg                          | 38          | 138-1111           | 1           | Spacer                  |
| 15          | 138-4931           | 3           | Screw-Lock                           | 39          | 132-7581           | 1           | HOC Plate And Decal ASM |
| 16          | 130-6615           | 1           | HOC Link ASM                         | 40          | 138-4887           | 1           | Plate-HOC, Inner        |
| 17          | 3218-6             | 1           | Nut-Jam                              | 41          | 116-4701           | 3           | Screw-HHF               |
| 18          | 98-5975            | 1           | Washer-Belleville                    | 42          | 121-1760           | 2           | Spacer                  |
| 19          | 323-58             | 1           | Bolt-TAP, HH                         | 43          | 116-5584           | 1           | Pin-HOC                 |
| 20          | 116-0886           | 1           | Spring-Extension                     | 44          | 116-0756           | 2           | Deck Lift Chain ASM     |
| 21          | 116-0780           | 4           | Screw-Shoulder, HHF                  | 44:1        | 1-633447           | 1           | Chain-Lift, Deck        |
| 22          | 3256-28            | 4           | Washer-Flat                          | 44:2        | 109-9065           | 1           | Screw-HH                |
| 23          | 127-1948-03        | 2           | Link-Lift                            | 44:3        | 32128-37           | 1           | Nut-HF                  |
| 24          | 137-4129           | 1           | Deck Strut ASM                       | 45          | 130-0742           | 2           | Bolt-Shoulder           |
| 24:2        | 137-4108           | 4           | Bushing-Rubber                       | 46          | 43-0940            | 2           | Spacer                  |
| 24:3        | 108-6544           | 4           | Spacer                               | 47          | 133-1431           | 1           | Spacer-Split            |


# HOC Lever Assembly No. 161-6735



## HOC Lever Assembly No. 161-6735 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|---------------------|
| 1           | 161-6736-01        | 1           | Lift Lever ASM [red] | 8           | 103-1363           | 4           | Rivet               |
| 2           | 136-0530           | 1           | Rod-Latch, Release   | 9           | 614672             | 1           | Screw-Shoulder, HWH |
| 3           | 114-8187           | 1           | Spring-Compression   | 10          | 110-8982           | 1           | Washer-Spring       |
| 4           | 114-1207           | 1           | Washer-Special       | 11          | 104-7201           | 1           | Nut-HF, NI          |
| 5           | 115-2750           | 1           | Knob                 | 12          | 104-8301           | 1           | Nut-HF, NI          |
| 6           | 115-3592           | 1           | Grip                 | 13          | 138-4888           | 1           | Latch-HOC           |
| 7           | 119-2309           | 1           | Bolt-Shldr,HH        | 14          | 138-4863           | 1           | Plug-Wear           |

# HOC Link Assembly No. 130-6615



## HOC Link Assembly No. 130-6615 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 1           | 1-633029           | 1           | Balljoint-Spherical |
| 2           | 117-5291           | 1           | Balljoint-Spherical |
| 3           | 3220-6             | 1           | Nut-Jam             |


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 4           | 117-5293           | 1           | Nut-Jam            |
| 5           | 130-6614           | 1           | Link-Height Of Cut |



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|-------------------------------|
| 2           | 131-7423-01        | 1           | Frame                     | 23          | 114-1926           | 4           | Bumper-Rubber                 |
| 8           | 140-4283           | 1           | Tower Decal ASM           | 24          | 147-6343-01        | 2           | Fork-Caster                   |
| 8:2         | 147-7921           | 1           | Decal-Oil Level           | 25          | 1-811010           | 2           | Plug                          |
| 8:4         | 116-8775           | 1           | Decal-Fill, Fuel          | 26          | 1-543509           | 4           | Bearing-Roller, Tapered       |
| 8:5         | 139-2878           | 1           | Decal-Warning             | 27          | 116-5647           | 2           | Seal-Grease                   |
| 8:6         | 131-3526           | 1           | Decal-Controls            | 28          | 1-633508           | 6           | Washer-Bellville              |
| 8:7         | 147-0212           | 1           | Decal - Fuse              | 29          | 103-4882           | 2           | Cap-Grease                    |
| 9           | 3234-42            | 4           | Screw-HHF                 | 30          | 163-4060           | 1           | Engine Guard ASM W/<br>Decals |
| 10          | 119-4042           | 8           | Nut-HF, NI                | 30:4        | 94-2579            | 1           | Decal                         |
| 11          | 131-7455           | 1           | Plate-Striker             | 30:5        | 133-4641           | 2           | Decal-Warning, No Riders      |
| 12          | 3229-11            | 1           | Screw-CARR                | 31          | 1-513658           | 4           | Bumper                        |
| 13          | 104-7201           | 1           | Nut-HF, NI                | 33          | 3230-10            | 2           | Bolt-CARR                     |
| 14          | 105-4886           | 4           | Nut-Tinnerman             | 34          | 3296-51            | 2           | Nut-Lock, NI                  |
| 15          | 3230-5             | 3           | Bolt-CARR                 | 35          | 3290-271           | 2           | Rivet-Pop                     |
| 16          | 119-4041           | 9           | Nut-HF                    | 38          | 140-4259           | 1           | Decal-Panel, Control          |
| 17          | 107-3844           | 3           | Washer                    | 48          | 93-6079            | 2           | Spacer-Nylon                  |
| 18          | 140-5485           | 2           | Mf Wheel Tire Bearing ASM | 52          | 132-7578-01        | 1           | Guard-Fan, RH                 |
| 18:2        | 103-2768           | 2           | Guard-Seal                | 53          | 132-7598-01        | 1           | Guard-Fan, LH                 |
| 18:3        | 3296-45            | 1           | Nut-Hex                   | 64          | 119-4061           | 8           | Screw-HHF                     |
| 18:4        | 325-20             | 1           | Screw-HH                  | 77          | 131-3529           | 1           | Decal-Service Aid             |
| 19          | 132-5161-01        | 1           | Tube-Mount, Fuel Tank     | 80          | 133-8062           | 1           | Decal-Spark Arrestor          |
| 20          | 132-1145-05        | 1           | Brackct-Cross             | 86          | 104-9368           | 3           | Plug-Dome                     |
| 21          | 117-3591           | 2           | Decal-Commercial          |             |                    |             |                               |


# Wheel and Bearing Assembly



## Wheel and Bearing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 1-633585           | 2           | Bearing-Cone, Taper | 4           | 126-5359           | 1           | Caster Axle ASM       |
| 2           | 103-0063           | 2           | Seal-Caster         | 5           | 140-5483           | 1           | Mf Wheel And Tire ASM |
| 3           | 103-3051           | 1           | Spacer-Nut          |             |                    |             |                       |


# Platform Assembly



## Platform Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 120-8499-05        | 1           | Hinge-Pad                  | 14          | 3231-2             | 2           | Bolt-CARR          |
| 2           | 117-9739           | 1           | Pad-Cushion                | 15          | 3231-27            | 2           | Screw-CARR         |
| 3           | 3256-23            | 4           | Washer-Plain               | 16          | 163-3498-01SP      | 1           | Platform ASM       |
| 4           | 121-7999           | 4           | Screw-HH, Patch            | 17          | 126-7157           | 1           | Mat-Platform       |
| 5           | 114-0463           | 4           | Washer-Friction, Composite | 18          | 3345-771           | 1           | Shield Clamp Kit   |
| 6           | 133-1426           | 2           | Knob                       | 19          | 32144-70           | 2           | Screw-HWHTF        |
| 7           | 116-2886           | 2           | Slide-Bushing              | 20          | 119-8650           | 1           | Pin-Latch          |
| 8           | 3253-4             | 2           | Washer-Lock                | 21          | 114-5348           | 1           | Spring             |
| 9           | 137-4808           | 2           | Nut-Acorn                  | 22          | 1-603175           | 1           | Knob-Ball          |
| 10          | 111044             | 4           | Spacer                     | 23          | 132-7583           | 2           | Bushing-Flanged    |
| 11          | 114-1915-01        | 2           | Link-Pad                   | 24          | 104-8301           | 2           | Nut-HF, NI         |
| 12          | 3256-4             | 6           | Washer-Flat                | 25          | 323-45             | 2           | Screw-HH           |
| 13          | 3296-59            | 4           | Nut-Lock, NI               |             |                    |             |                    |

# Engine Assembly




## Engine Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|-------------------------|
| 1           |                    | 1           | Engine-Kohler, Evc730 ●■ | 20          | 131-3586-05        | 1           | Stop-Clutch             |
| 1:1         | 131-7400           | 1           | Bracket-Muffler          | 21          | 32144-70           | 4           | Screw-HWHTF             |
| 1:2         | 110-6697           | 2           | Gasket-Exhaust           | 22          | 147-1664           | 1           | Throttle ASM            |
| 1:3         | 68-9400            | 4           | Nut-Flange               | 22:1        | 145-6187           | 1           | Lever-Control           |
| 2           | 98-5975            | 4           | Washer-Belleville        | 22:2        | 147-1674           | 1           | Cable-Throttle          |
| 3           | 126-0983           | 4           | Screw-BHTF               | 23          | 1-807533           | 2           | Bolt-CARR               |
| 5           | 132-1168           | 1           | Bracket-Muffler          | 24          | 32128-17           | 2           | Nut-Lock, Flange        |
| 6           | 3234-42            | 2           | Screw-HHF                | 25          | 1-603175           | 1           | Knob-Ball               |
| 7           | 133-4613           | 2           | Support-Muffler          | 26          | 163-4101           | 1           | Muffler Guard ASM       |
| 8           | 119-4042           | 2           | Nut-HF, NI               | 26:2        | 94-2579            | 1           | Decal                   |
| 9           | 133-4634           | 1           | Muffler-Kohler           | 26:3        | 127-0392           | 1           | Decal-Hot Surface       |
| 10          | 133-4639           | 2           | Bracket-Muffler, Koh     | 30          | 131-3530-05        | 1           | Bracket-Mounting, Guard |
| 12          | 3234-17            | 4           | Screw-HHF                | 31          | 106-9758           | 1           | Screw-CARR              |
| 13          | 32128-25           | 9           | Nut-HF                   | 32          | 137-3061           | 4           | Bolt-CARR               |
| 14          | 1-807259           | 1           | Key                      | 34          | 3290-378           | 1           | Tie-Cable               |
| 15          | 120-8498           | 1           | Pulley                   | 35          | 133-4657           | 1           | Hose ASM                |
| 16          | 131-1100           | 1           | Clutch                   | 35:2        | 353-508            | 1           | Plug-HH                 |
| 17          | 1-543610           | 1           | Washer-Flat              | 35:2:1      | 237-42             | 1           | O-Ring                  |
| 18          | 1-603610           | 1           | Washer-Spring            | 36          | 94-9695            | 1           | Filter-Fuel             |
| 19          | 3212-6             | 1           | Screw-HH                 | 37          | 98020              | 1           | Filter-Oil              |

● Not serviced separately

■ Obtain parts from [www.kohlerplus.com](http://www.kohlerplus.com)


# Fuel Tank Assembly



## Fuel Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-7560           | 1           | Fuel Tank ASM         | 2           | 110-8255           | 1           | Hose-Fuel          |
| 1:2         | 46-6560            | 2           | Bushing               | 3           | 98-2952            | 1           | Fitting-Straight   |
| 1:3         | 137-4127           | 1           | Cap-Fuel              | 4           | 132-7576           | 1           | Hose-Fuel          |
| 1:4         | 104-5228           | 1           | Fitting-Elbow, 90 DEG | 5           | 132-7545           | 1           | Fuel Line ASM      |
| 1:5         | 145-6195           | 1           | ASM, Tube-Fuel        |             |                    |             |                    |

# Electrical Assembly



## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 147-7942           | 1           | Harness-Wire, Grandstand   | 11          | 115-3864           | 1           | Cable-Battery, Positive    |
| 1:4         | 109101             | 1           | Fuse-Blade, 20 Amp         | 11:1        | 1-543393           | 1           | Insulator-Solenoid         |
| 1:8         | 109355             | 2           | Fuse-Blade, 15 Amp         | 11:2        | 109-2407           | 1           | Insulator-Battery          |
| 1:9         | 218-578            | 1           | Fuse-Blade, 10 Amp         | 12          | 109-5715           | 2           | Nut-HHF, Smooth            |
| 1:10        | 116-0053           | 2           | Cap-Plug                   | 13          | 139-6367           | 1           | Switch-Rocker, (On)-On-Off |
| 1:11        | 110928             | 1           | Fuse-Blade, 5 Amp          | 14          | 137-4101           | 1           | Switch-Ignition            |
| 1:12        | 103-3895           | 1           | Diode                      | 15          | 63-8360            | 1           | Key-Ignition               |
| 2           | 82-2190            | 3           | Switch-Bail                | 16          | 3253-3             | 1           | Washer-Lock                |
| 3           | 104-8162           | 1           | Battery                    | 17          | 3217-5             | 1           | Nut-Hex                    |
| 4           | 130-6635-01        | 1           | Bracket-Hold Down, Battery | 18          | 3290-500           | 1           | Screw-PPH                  |
| 5           | 104-7201           | 2           | Nut-HF, NI                 | 19          | 3256-14            | 1           | Washer-Flat                |
| 6           | 1-633651           | 2           | Bolt-Holddown              | 20          | 3296-2             | 1           | Nut-Lock, NI               |
| 7           | 112-7063           | 1           | Cable-Battery, Black       | 21          | 1-643275           | 1           | Relay                      |
| 8           | 140-1884           | 1           | Module-Meter, Hour         | 22          | 67-1300            | 1           | Decal                      |
| 9           | 3256-23            | 2           | Washer-Plain               | 23          | 1-643267           | 1           | Indicator-LED, Red         |
| 10          | 322-3              | 2           | Screw-HH                   | 30          | 3290-378           | 2           | Tie-Cable                  |

# Attachments and Accessories

## For 72518 — GrandStand Mower With 48in TURBO FORCE Cutting Unit

| <b>Product Name</b>                          | <b>Model/Part</b> |
|--|-------------------|
| Air Cleaner Filter.....                      | 100-4556          |
| Filter Air Safety.....                       | 103-1326          |
| Hypr-Oil 500 (quart).....                    | 114-4713          |
| Hypr-Oil 500 (gallon).....                   | 114-4714          |
| Hypr-Oil 500-5 (5 gallon).....               | 114-4715          |
| Harness Wire Splitter.....                   | 121-5988          |
| Spark Plug.....                              | 130-8380          |
| Fuel Filter.....                             | 130-8381          |
| Toro Premium Fuel Treatment 12oz Bottle..... | 131-6572          |
| Speed Setting Tool.....                      | 132-7595          |
| Stand-On Weight Kit.....                     | 133-1428          |
| Chute Gate Kit W/ Bag.....                   | 133-1434          |
| Trash Bag Assembly.....                      | 133-1435          |
| Roller Striper Kit.....                      | 133-1436          |
| Light Kit.....                               | 133-1437          |
| Electric Accessory Port.....                 | 133-1438          |
| HOC Set Blocks.....                          | 133-1439          |
| Anti-Scalp Kit, 48/52 Grandstand Deck.....   | 133-1440          |
| Trimmer Rack.....                            | 133-1441          |
| Hydro Oil Change Kit.....                    | 133-1457          |
| Strobe Light Kit.....                        | 133-1495          |
| 5 Gallon Bucket.....                         | 133-2533          |
| Hydraulic Cap Lock Kit.....                  | 136-5420          |
| Bucket Mount Kit.....                        | 136-5681          |
| Bagger Enhancement Kit.....                  | 139-1529          |
| Recycler Kit.....                            | 139-6650          |
| 18x8.5n10 X-Tweel Turf.....                  | 139-7890          |
| Blade-16.50 High Flow.....                   | 140-1243          |
| Pneumatic Castor Wheel Kit.....              | 140-4311          |
| Blade-16.50 Medium Flow.....                 | 140-4860          |
| Blade-16.50 Low Flow.....                    | 140-4861          |
| Blade-16.50 Atomic.....                      | 140-4862          |
| Blade-16.50 Recycler.....                    | 140-4863          |
| 6 Pack-Blade, 16.5 High Flow.....            | 140-4887          |
| 6 Pack-Blade, 16.5 Med Flow.....             | 140-4888          |
| 6 Pack-Blade, 16.5 Low Flow.....             | 140-4889          |
| 6 Pack-Blade, 16.5 Atomic.....               | 140-4890          |
| 6 Pack-Blade, 16.5 Recycler.....             | 140-4891          |
| 2 Transmission Filter Kit.....               | 144-3842          |
| Blade-16.50 High Flow.....                   | 147-6250          |
| 6 Pack-Blade, 16.50 High Flow.....           | 147-6254          |
| Kit-pneumatic Caster Tire.....               | 161-3470          |
| Kit-semi Pneu Caster Tire.....               | 161-3471          |
| Soft Bag (3 Bushel).....                     | 30104             |
| 10W30 4-Cycle Engine Oil (32oz Bottle).....  | 38280             |
| Toro 4-Cycle SAE 30 Oil (32oz Bottle).....   | 38903             |

# Attachments and Accessories (continued)

|                         |         |
|-------------------------|---------|
| Twin Bagger Kit.....    | 78524   |
| Blower Drive 48In ..... | 78525   |
| Spark Arrestor .....    | 98-9099 |
| Filter-Oil.....         | 98020   |



**Count on it.**