



**Count on it.**

Form No. 3478-355 Rev A

# Parts Catalog

## Trans Pro 200 Tow-Behind Trailer

Model No. 04239—Serial No. 419000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Pull Frame Assembly ..... 4

Tongue Assembly ..... 5


Attachments and Accessories ..... 6



## Pull Frame Assembly

| Ref.  | Part Number | Qty. | Description     | Ref. | Part Number | Qty. | Description                 |
|-------|-------------|------|-----------------|------|-------------|------|-----------------------------|
| 1     | 140-7592SP  | 1    | Frame-Main      | 12   | 104-8300    | 6    | Nut-HF, NI                  |
| 2     | 140-9612SP  | 1    | Support-Center  | 13   | 139-2564    | 8    | Nut-Lug                     |
| 3     | 144-3664    | 2    | Wheel ASM       | 14   | 140-9689    | 2    | Rod-Support                 |
| 3:1   | 137-2597    | 1    | Rim             | 15   | 100-1663    | 4    | Pin-Hitch                   |
| 3:2   | 232-27      | 1    | Stem-Valve      | 16   | 140-5266    | 2    | Pad-Strip, Roller           |
| 3:3   | 144-3665    | 1    | Tire            | 17   | 144-5679    | 6    | Rivet-Drive                 |
| 4     | 161-3233SP  | 2    | Hub ASM-3Wd     | 18   | 86-1480     | 2    | Washer                      |
| 4:1   |             | 1    | Hub ASM ●       | 19   | 138-9738    | 2    | Decal, Transpro 200         |
| 4:1:2 | 251-82      | 2    | Bearing-Ball    | 20   | 140-5279    | 1    | Decal-Danger                |
| 4:1:3 | 144-5662    | 1    | Spacer-Bearing  | 21   | 140-5280    | 2    | Decal-Tire Pressure, Torque |
| 7     | 3296-49     | 2    | Nut-Lock, NI    | 22   | 140-5281    | 1    | Decal-Warning, No Riders    |
| 8     | 126-1492    | 2    | Bearing-Flanged | 24   | 3290-271    | 2    | Rivet-Pop                   |
| 9     | 126-1696    | 2    | Screw-HWHTF     | 25   | 125-8214    | 2    | Decal-Toro Logo             |
| 10    | 140-7570-03 | 2    | Mount-Roller    | 26   | 133-8061    | 1    | Decal-Warning               |
| 11    | 3230-22     | 6    | Screw-CARR      |      |             |      |                             |

● Not serviced separately



## Tongue Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 140-7504-01 | 1    | Hitch              |
| 2    | 161-3226    | 1    | Handle             |
| 3    | 137-2374    | 2    | Bushing-Flange     |
| 4    | 117-8772    | 1    | Bearing-Ball       |
| 5    | 161-3224    | 1    | Lever-Slide        |
| 6    | 161-3222    | 1    | Slide              |
| 7    | 3296-42     | 1    | Nut-Lock, NI       |
| 8    | 144-5654    | 1    | Spring-Compression |
| 9    | 161-3219    | 1    | Pin-Flag           |
| 10   | 120-9551    | 1    | Screw-HWH          |
| 11   | 321-5       | 1    | Screw-HH           |
| 12   | 3296-56     | 1    | Nut-Lock, NI       |
| 13   | 108-4925    | 2    | Washer             |

| Ref. | Part Number | Qty. | Description  |
|------|-------------|------|--------------|
| 14   | 322-12      | 1    | Screw-HH     |
| 15   | 3296-29     | 1    | Nut-Lock, NI |
| 16   | 127-5861    | 1    | Pin-Tow      |
| 17   | 32121-123   | 1    | Pin-Roll     |
| 18   | 09491       | 1    | Washer-Plain |
| 19   | 09456       | 1    | Nut          |
| 20   | 94-1392     | 2    | Pad-Rubber   |
| 22   | 119-7568    | 1    | Screw-HSBH   |
| 23   | 29-8910     | 6    | Washer       |
| 24   | 120-0922    | 2    | Screw-HH     |
| 25   | 3296-76     | 2    | Nut-Lock, NI |
| 26   | 119-7577    | 1    | Screw-BHCS   |
| 27   | 3256-51     | 2    | Washer-Flat  |

# Attachments and Accessories

## For 04239 — Trans Pro 200 Tow-Behind Trailer

| Product Name               | Model/Part |
|----------------------------|------------|
| Axle Kit, GR1000 .....     | 144-5663   |
| Axle Kit, Flex 2120 .....  | 144-5664   |
| Axle Kit, Flex 18/21 ..... | 144-5668   |
| Wheel Kit, Bogey .....     | 145-0058   |

**Notes:**



**Count on it.**