



Count on it.

Form No. 3478-391 Rev A

Parts Catalog

Recycler® S55ABC 55cm Lawn Mower

Model No. 21772—Serial No. 420000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Housing Assembly 4

Housing Decal Assembly No. 145-1525..... 6

Grass Bag Assembly 8

Decal Assembly 10

Engine and Blade Assembly..... 12

Front Wheel and Height-of-Cut Assembly 14


Rear Wheel and Height-of-Cut Assembly..... 16

Handle Assembly 18

Starter Switch Assembly 20

Attachments and Accessories 22


Housing Assembly



Housing Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	145-1525	1	Housing ASM	14	32104-120	2	Screw-PPH
2	115-4667-01	1	Baffle-Front	16	139-5476	1	ASM-Rear Door, In Mold
3	137-3099	13	Screw-Plastite, HWH	16:2	140-2394	1	Artwork-Door, In-Mold
4	139-5440	1	Baffle-Rear, Rwd	18	139-5478	1	Spring-Torsion, LH
7	140-4038	1	Screw-Shldr,HWH	19	139-5479	1	Spring-Torsion, RH
9	140-2368	1	ASM-Chute, In Mold	30	139-5457	1	Bumper-Front
10	139-5443	1	Deflector-Recycle	31	139-5467	3	Screw-Plastic, HWH
11	139-5444	1	Knob-Recycle	32	144-0210	1	ASM-Intake, Rwd
12	139-5445	1	Latch-Recycle	33	140-2384	1	Cover-Intake, Bottom
13	140-4192	1	Spring-Compression	35	145-1487	1	Decal-Vortex Rwd


Housing Decal Assembly No. 145-1525



Housing Decal Assembly No. 145-1525 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	112-8760	1	Decal-Danger
3	125-5092	1	Decal-Placement, Foot


Grass Bag Assembly



Grass Bag Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	139-5470-03	1	ASM-Frame, Bag
2	147-0597	1	ASM-Bag, Grass


Decal Assembly



Decal Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	112-8760	1	Decal-Danger	10	140-4183	1	Decal
4	125-5092	1	Decal-Placement, Foot	11	140-4184	2	Decal

Engine and Blade Assembly



Engine and Blade Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1		1	Engine-Briggs 104M020052F1 ●■	17	117-5970	1	Pulley
2	132-4469	1	Plate-Anchor	18	110-1790	1	Belt
3	107-0759	1	Bolt-Shoulder	19	126-8108	1	Drum
4	107-0797	1	Bushing	20	139-1711	2	Screw-HH
5	139-1722	1	Washer-Flat	21	139-1705	1	Nut-Hex
6	137-3094	1	Nut-Hex	22	115-2892	1	Cover
7	125-1063	1	Plate-Brake	23	2412-72	1	Clip-Closed, Insulated
8	603773	2	Nut-Hex Lock	25	138-3225	1	Disk
9	32144-102	3	Screw-HWH	26	107-7487	1	Support-Blade
10	107-0758	1	Spacer-Bearing	27	131-9683-03	1	Blade
11	38-7820	3	Bearing-Ball	28	108-3766-03	1	Support-Blade
12	138-3217	1	Retainer-Belt	29	139-1706	2	Nut-Flange, Lock
13	605256	1	Spacer	30	120-9698	1	Bolt-CARR
14	138-3222	1	Plate-Guide	31	106-6801	1	Anchor-Cable
15	119-4162	1	Screw-CARR	32	119-4040	1	Nut-HF, NI
16	108-3792	1	Spring-Tension, Brake	33	161-3167	1	Decal-Shroud

● Not serviced separately

■ Obtain parts from www.briggsandstratton.com


This exploded view diagram illustrates the assembly of a car headlight. The main components are shown in their relative positions as they would be assembled. The headlight housing (1) is the central component. The lens (2) is shown being inserted into the housing. The mounting bracket (3) is shown being attached to the housing. The mounting bracket (4) is shown being attached to the housing. The mounting bracket (5) is shown being attached to the housing. The mounting bracket (6) is shown being attached to the housing. The mounting bracket (7) is shown being attached to the housing. The mounting bracket (8) is shown being attached to the housing. The mounting bracket (9) is shown being attached to the housing. The mounting bracket (10) is shown being attached to the housing. The mounting bracket (11) is shown being attached to the housing. The mounting bracket (12) is shown being attached to the housing. The mounting bracket (13) is shown being attached to the housing.

Front Wheel and Height-of-Cut Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	115-1956-05	2	Plate-HOC,Front Fsvq
2	137-3052	4	Screw-HH
3	119-4038	6	Nut-Hex
4	105-1809	2	Arm-Spring
5	105-3042	2	Knob-Lever, HOC
6	137-9128	2	Arm-Pivot, Front
7	105-1818	2	Bushing-Mount, HOC

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8	120-9696	2	Screw-HH
9	139-1704	2	Washer-Flat
11	139-5449	2	Washer-Wheel Bolt
12	140-2355	2	ASM-8" Wheel, Idler
13	145-3899	2	Wheel Bolt
13	614650	2	Bolt-Shoulder


Rear Wheel and Height-of-Cut Assembly



Rear Wheel and Height-of-Cut Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	145-5651-05	1	Plate-HOC, LH (ISO)	14	114-7977-03	1	Bracket-Transmission
2	145-5650-05	1	Plate-HOC, RH (ISO)	15	140-4041	1	V-Belt
3	137-3052	4	Screw-HH	16	120-9676	3	Screw-Plastite
4	119-4038	4	Nut-Hex	17	110-7191	2	Washer-Thrust
5	100-1445	2	Bolt-CARR	18	131-5399	2	Gear-Pinion, 15T
6	139-1724	2	Nut-Lock	19	32151-61	2	Ring-Retaining
7	132-4486	2	Arm-Spring	20	140-2362	2	ASM-Cover, Gear (Dk Gray)
8	105-3042	2	Knob-Lever, HOC	20:2	614426	1	Washer-Stepped
9	139-5451	2	Arm-Pivot, Rear	22	140-2350	2	ASM-9.65" Wheel, Geared
10	108-9779	2	Retainer-Bushing, HOC	23	614650	2	Bolt-Shoulder
11	104-8699	2	Bearing-Ball	25	137-3099	2	Screw-Plastite, HWH
12	108-9782	2	Bushing-Sleeve	26	139-6597	1	Shield-Trailing
13	139-6561	1	Transmission-Rwd	35	139-1692	2	Screw-PTH


Handle Assembly



Handle Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	144-6516-05	1	Handle-Curved	33	139-6567	1	Bottom-Handle, RH
6	139-6599	2	Bolt-Shoulder, Handle	34	139-6568	1	Bottom-Handle, LH
7	119-4038	2	Nut-Hex	35	94-4496	10	Screw-PPH
8	131-9663	2	Screw-CARR	39	139-6581	1	Anchor-Cable, Rwd
9	117-5976	2	Knob-Handle	41	139-6595	1	Cable-Traction, Rwd (Pp)
20	140-2367	1	Guide-Curved, LH (Rwd)	47	137-3094	2	Nut-Hex
21	140-2366	1	Guide-Curved, RH (Rwd)	48	86-9671	1	Guide-Rope
24	139-5464	1	Rod-Control, Traction	50	114-7988	1	Guide-Cable
25	139-6554	1	Lever-Traction, Rwd	60	145-1459	1	Decal - Ads, Handle
27	120-9683	1	Washer-Plain	63	139-6577	2	Pin-Handle, Pp
30	140-4194	1	Spring-Torsion				
32	139-6569	1	Handle-Personal Pace, Curved				

Starter Switch Assembly



Starter Switch Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	117-5975	1	Switch Housing ASM	9	161-4788	1	Lever
2	138-3634	1	Screw-HH	10	139-1712	1	Nut-Hex Flange
3	147-0505-03	1	Bail-Brake [black]	11	112-8884	1	Knob
4	115-8439	1	Cable-Brake	12	614249	2	Tie-Cable
5	139-1709	1	Screw-Shoulder	13	139-1699	1	Washer-Flat
6	106-9169	1	Screw-HWH	14	137-3094	1	Nut-Hex
7	107-7462	1	Spring-Torsion	15	137-3085	1	Nut-Hex
8	107-7463	1	Spacer				

Attachments and Accessories

For 21772 — Recycler S55ABC 55cm Lawn Mower

Product Name	Model/Part
22 Inch Atomic Blade	59534P
Lawnmower Cover	490-7462
Lawn Striping Kit with 22in Roller	20601
Bag-Walk Behind (Toro)	490-7318
Fuel Stabilizer .05 oz	130-2393
Summer Oil-Case of 24 (20oz Bottles)	38916
4-Cycle Fuel, Snow And Lawn 32oz Can	131-3823
Toro Premium Fuel Treatment 12oz Bottle	131-6572
Oil-30/10W-30 Synthetic (Quart)	138-6053
Toro 4-Cycle SAE 30 Oil (32oz Bottle)	38903
Chute ASM	147-8696

Notes:



Count on it.