



Two-Bearing Conversion Kit DFS Bagger for 200 Series Z Master®

Model No. 107-7652

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers


Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.



Two-Bearing Conversion Kit Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	105-2438	1	Plug	26	106-8964-03	3	Spacer-Bearing (Use As Required To Tension Belt.)
2	106-7147	1	Cap-Grease	27	106-7119	1	Bearing
3	3296-48	2	Nut-Lock, NI	28	302-55	1	Fitting-Grease
4	3296-42	17	Nut-Lock, NI	29	3296-23	2	Nut-Lock, NI
5	106-7128-03	1	Cover-Scroll	30	107-7654	1	Template, Base Frame
6	32146-20	2	Nut-Jam				
7	7-4150	2	Washer				
8	302-11	1	Fitting-Lube, 45 DEG				
9	106-7126	1	Bearing-Flange				
10	324-5	2	Screw-HH				
11	3256-22	26	Washer-Flat				
12	106-8950	1	Scroll-Top				
13	9114604	8	Screw-Truss Head				
14	105-9716	1	Key-Square				
15	106-8951	1	Fan-Balancing				
16	3246-4	2	Screw-Set				
17	32151-33	1	Ring-Retaining, Ext				
18	321-5	9	Screw-HH				
19	106-7149	1	Shaft-Fan				
20	325-10	2	Screw-HH				
21	3256-26	4	Washer-Flat				
23	5-1077	1	Key-Square				
24	106-8976	1	Pulley-V				
25	107-7653-03	1	Spacer				