



Hydraulic Tank Relocation Kit

100 Series Z Master®

Model No. 107-3080

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers


Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.


For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.



MODEL YEAR 2001 AND BEFORE, KOHLER ENGINE



MODEL YEAR 2002 , ALL ENGINES



MODEL 2001 AND BEFORE, KAWASAKI ENGINE

Hydraulic Tank Relocation Kit Assembly

Ref	Part No.	Qty.	Description
1	321-6	1	Screw-HH
2	3256-22	2	Washer-Flat
3	103-3071-03	1	Stand-Reservoir
4	322-3	1	Screw-HH
5	322-5	1	Screw-HH
6	32128-20	2	Nut-HF
7	107-3085	1	Hose ASM
8	2412-81	1	Clamp-R
9	107-3086	1	Hose ASM
10	107-3087	1	Template-Tank, HYD
16	1-633750	1	Filter-HYD

O	T	O	T Y P E