



Count on it.

Parts Catalog

**53cm Heavy-Duty 60V
Recycler®/Rear Bagger
Lawn Mower**

Model No. 22275T—Serial No. 415200000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

| | |
|---|----|
| Housing Assembly | 4 |
| Grass Bag Assembly | 6 |
| Motor Module and Blade Assembly | 8 |
| Motor Module Assembly No. 140-4161 Lower Shroud Assembly..... | 10 |
| Motor Module Assembly No. 140-4161 Upper Shroud Assembly..... | 12 |
| Front Wheel and Height-of-Cut Assembly | 14 |
| Transmission and Rear Wheel Assembly | 16 |
| Handle Assembly | 18 |
| Attachments and Accessories | 20 |


Housing Assembly



Housing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1 | 136-5897 | 1 | Housing ASM | 9 | 140-3880-03 | 1 | Guard-Engine |
| 1:2 | 112-8760 | 1 | Decal-Danger | 10 | 119-4041 | 2 | Nut-HF |
| 2 | 125-1002-01 | 1 | Floor-Chute | 11 | 3230-3 | 2 | Screw-CARR |
| 3 | 3229-2 | 1 | Screw-CARR | 16 | 32115-15 | 1 | Nut-Push |
| 4 | 104-7201 | 1 | Nut-HF, NI | 17 | 32144-86 | 1 | Screw-HWHTF |
| 5 | 125-5041 | 2 | Kicker | 18 | 125-8435-03 | 1 | Guard-Toe, Front |
| 6 | 49-2040 | 7 | Screw-HWHTF | 23 | 119-2368 | 1 | Decal-Recycler |
| 7 | 125-5038 | 1 | Cover-Belt, Front | 24 | 125-8420 | 1 | Decal |
| 8 | 125-8380 | 1 | Cover-Belt, Rear | | | | |


Grass Bag Assembly



Grass Bag Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------------|
| 1 | 125-1017 | 1 | Rod-Door, Bag | 7 | 125-1008 | 1 | Plug-Mulch |
| 2 | 125-8402 | 1 | Bag Door ASM | 8 | 125-1007 | 1 | Shield-Trailing |
| 2:2 | 116-7583 | 1 | Decal-Warning | 9 | 125-8413 | 1 | Rod-Shield, Trailing |
| 3 | 125-1019 | 1 | Spring-Torsion | 10 | 133-8193-03 | 1 | Bracket-Mount, Handle (LH) |
| 4 | 1-513658 | 2 | Bumper | 11 | 133-8194-03 | 1 | Bracket-Mount, Handle (RH) |
| 5 | 121-1399-03 | 1 | Frame-Bag | 12 | 32144-70 | 4 | Screw-HWHTF |
| 6 | 147-8624 | 1 | Bag-Grass, ASM | | | | |

Motor Module and Blade Assembly




Motor Module and Blade Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|-----------------------------------|
| 1 | 140-4161 | 1 | Motor Module | 7 | 133-8183-03 | 1 | Blade-Recycling 21In (Bagging) |
| 2 | 95-1727 | 3 | Screw-Taptite | 8 | 125-1069-03 | 1 | Accelerator-Blade |
| 3 | 125-8396 | 1 | Pulley-Driver | 9 | 125-2466 | 1 | Bolt-Blade |
| 4 | 125-1004 | 1 | Driver-Blade | 10 | 125-1024 | 1 | Cover-Belt |
| 5 | 125-8370 | 1 | Protector-Crankshaft | 11 | 49-2040 | 1 | Screw-HWHTF |
| 6 | 32144-70 | 3 | Screw-HWHTF | | | | |

Motor Module Assembly No. 140-4161

Lower Shroud Assembly




Motor Module Assembly No. 140-4161

Lower Shroud Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1 | 139-6628 | 1 | Base-Mount, Motor | 10 | 140-4162 | 1 | Controller-Motor |
| 2 | 140-4119 | 1 | Motor-2Kw | 11 | 139-6642 | 4 | Screw |
| 3 | 131-9732 | 3 | Insert-Mount, Motor | 12 | 139-6635 | 1 | Bracket-Foam |
| 4 | 137-4795 | 3 | Screw | 13 | 138-3273 | 1 | Screw-Plastic, PPH |
| 5 | 115-7373 | 4 | Nut-Lock | 14 | 139-6636 | 1 | Foam |
| 6 | 140-4118 | 1 | Shroud-Lower | 15 | 133-1918 | 1 | Bail Switch ASM |
| 7 | 139-6632 | 1 | Battery Reciever ASM | 15:4 | 104-6478 | 1 | Spring-Extension |
| 8 | 139-6633 | 1 | Shroud-Motor | 16 | 139-6637 | 1 | Harness-Wire |
| 9 | 130-6658 | 6 | Screw-Flange, Plastic | | | | |

Motor Module Assembly No. 140-4161

Upper Shroud Assembly




Motor Module Assembly No. 140-4161

Upper Shroud Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1 | 140-3886 | 1 | Shroud-Upper | 6 | 139-6641 | 1 | Spring-RH |
| 2 | 114-5896 | 2 | Magnet | 7 | 95-4234 | 2 | Screw-PPH |
| 3 | 130-6658 | 8 | Screw-Flange, Plastic | 8 | 140-4126 | 1 | Decal-Hood, Top |
| 4 | 139-6639 | 1 | Hood | 9 | 140-4127 | 1 | Decal-Hood, Front |
| 5 | 139-6640 | 1 | Spring-LH | | | | |


Front Wheel and Height-of-Cut Assembly



Front Wheel and Height-of-Cut Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|---------------------|
| 1 | 121-1439 | 2 | Plate-HOC, Front | 11 | 121-1431-03 | 2 | Arm-Spring |
| 2 | 49-2040 | 4 | Screw-HWHTF | 12 | 104-2065 | 2 | Screw-HWH |
| 3 | 136-5871 | 2 | Bushing-Axle, Front (HOC) | 13 | 130-6420 | 2 | Arm-Pivot, Front |
| 4 | 130-6434 | 2 | Retainer-Bushing, Axle | 14 | 139-1689 | 2 | Nut-HF |
| 5 | 321-37 | 4 | Screw-HH | 15 | 323-13 | 2 | Screw-HH |
| 6 | 104-7201 | 4 | Nut-HF, NI | 16 | 74-1671 | 2 | Spacer-Cover, Wheel |
| 7 | 133-2644 | 2 | Axle-Front HOC | 17 | 133-2639 | 2 | Wheel |
| 8 | 119-4042 | 2 | Nut-HF, NI | 17:2 | 133-2603 | 2 | Bearing-Ball |
| 9 | 125-1093 | 2 | Knob-Lever, HOC | 17:3 | 125-1077 | 1 | Spacer |
| 10 | 131-5377 | 2 | Key-Arm, Spring | 18 | 119-4041 | 2 | Nut-HF |

Transmission and Rear Wheel Assembly



Transmission and Rear Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|----------------------|
| 1 | 140-4011 | 1 | Transmission-HD | 15 | 104-2065 | 2 | Screw-HWH |
| 2 | 140-4012-03 | 1 | Belt Guide ASM | 16 | 121-1448-03 | 2 | Arm-Spring, Rear |
| 3 | 27-0220 | 3 | Screw-Special | 17 | 136-5894 | 2 | Bearing Retainer ASM |
| 4 | 130-9681 | 1 | Cover-Shaft, Transmission | 17:2 | 133-2606 | 2 | Bearing-Ball, Custom |
| 5 | 125-8395 | 1 | Belt-V | 18 | 133-2668 | 2 | Screw-HH |
| 6 | 127-6848 | 2 | Cover-Bearing | 19 | 133-2635 | 2 | Cover-Wheel |
| 7 | 32151-10 | 2 | Ring-Retaining | 20 | 32151-61 | 4 | Ring-Retaining |
| 8 | 98-1452 | 2 | Washer-Thrust | 21 | 131-5399 | 2 | Gear-Pinion, 15T |
| 9 | 130-6422 | 2 | Plate-HOC, Rear | 22 | 74-1671 | 2 | Spacer-Cover, Wheel |
| 10 | 49-2040 | 6 | Screw-HWHTF | 23 | 133-2640 | 2 | 9-Inch Wheel ASM |
| 11 | 323-13 | 2 | Screw-HH | 23:1 | | 1 | Wheel ● |
| 12 | 133-2641 | 2 | Arm-Pivot, Rear | 23:1:2 | 133-2603 | 2 | Bearing-Ball |
| 13 | 131-5377 | 2 | Key-Arm, Spring | 23:1:3 | 125-1077 | 1 | Spacer |
| 14 | 125-1093 | 2 | Knob-Lever, HOC | 24 | 119-4042 | 2 | Nut-HF, NI |

● Not serviced separately

Handle Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|----------------------------|
| 1 | 134-5087-03 | 2 | Lower Handle | 15 | 136-7081 | 1 | Screw-CARR |
| 2 | 145-4022-03 | 1 | Handle-Upper | 16 | 104-7201 | 3 | Nut-HF, NI |
| 3 | 3230-4 | 2 | Screw-CARR | 17 | 161-8211 | 1 | Cable-Traction |
| 4 | 119-4041 | 8 | Nut-HF | 18 | 144-3180 | 1 | Cable-Brake |
| 5 | 322-39 | 4 | Screw-HH | 19 | 340182 | 2 | Pin-Pivot |
| 6 | 137-3009 | 8 | Washer-Cup | 21 | 09688 | 2 | Washer-Nylon |
| 7 | 134-5187-03 | 1 | Guard-Cable, Handle | 22 | 111-9662 | 1 | OPC Lever - Engine |
| 8 | 108-0988 | 2 | Screw-CARR | 23 | 111-9381-03 | 1 | Lever-Clutch, Gearbox |
| 9 | 137-3016 | 2 | Nut-HF | 24 | 42-3560 | 1 | Bolt-Shoulder |
| 10 | 140-3891 | 1 | Starter Switch ASM | 25 | 115-1794 | 2 | Screw-HHF |
| 10:3 | 140-4231 | 1 | Starter Button Service ASM | 26 | 94-2691 | 1 | Screw-HWH Taptite |
| 12 | 140-4168-03 | 1 | Guard-Housing, Switch | 27 | 144-3175 | 1 | Decal-Controls (60V Start) |
| 13 | 134-5188 | 2 | Spacer | 28 | 144-6379 | 2 | Plug-Round Tube, 1 In. |
| 14 | 137-9142 | 1 | Screw-CARR | 29 | 131-0822 | 1 | Decal |

Attachments and Accessories

For 22275T — 53cm Heavy-Duty 60V Recycler/Rear Bagger Lawn Mower

| Product Name | Model/Part |
|---|-------------------|
| Cup-Anti Scalp..... | 125-8440 |
| Deck Side Guard Kit | 130-9701 |
| Rear Discharge Kit..... | 130-9734 |
| 21in Recycling Blade | 144-3178-03 |
| 60v Battery Charger 5 Amp International | 81805 |
| 60V 6.0 AH Battery CE | 81860 |
| 60V 7.5 AH Battery CE | 81875 |

Notes:

Notes:

Notes:



Count on it.