



Count on it.

Parts Catalog

**30in TurfMaster® HDX
Walk-Behind
Lawn Mower**

Model No. 22217—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Housing Assembly	4
Spindle and Blade Assembly	6
Side Discharge Chute Assembly	8
Grass Bag Assembly	10
Housing Decal Assembly	12
Engine and Fuel Tank Assembly	14
Front Bumper and Wheel Assembly	16
Transmission and HOC Assembly	18
Handle Assembly	20
Attachments and Accessories	22


Housing Assembly



Housing Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	136-5900	1	Deck ASM	22	116-6229	1	Seal-Door
3	145-3920-01	1	Frame-30"	23	32151-72	1	Ring-Retaining
4	133-8177	1	Chute	24	116-7573	1	Spring-Torsion, Cover
5	3230-5	2	Bolt-CARR	25	116-8355	1	Rear Door ASM
8	3296-29	2	Nut-Lock, NI	25:2	116-7583	1	Decal-Warning
10	139-5406	1	Cover-Belt	28	116-6966	1	Clip-Seal
12	46-8091	4	Screw-HWH	29	121-5793-03	1	Door-Access
13	138-3224	1	Bracket-Cable, Traction	30	121-5840	2	Fastener
14	120-5225	1	Plug-Mulch	31	130-2352-01	1	Baffle-Control
15	121-5841	1	Shield-Trailing	32	119-4041	4	Nut-HF
16	49-2040	9	Screw-HWHTF	33	137-3061	4	Bolt-CARR
17	1-513658	2	Bumper	36	32144-86	1	Screw-HWHTF
18	65-5100	1	Handle-Door	37	138-5332-01	1	Cover-Frame
19	139-1692	2	Screw-PTH	38	107069	1	Clip
20	116-6351-03	1	Bracket-Hinge	40	126-7151	1	Plug-Button
21	116-6933	1	Pin-Hinge				


Spindle and Blade Assembly



Spindle and Blade Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-9107	2	Spindle ASM	16	161-4815	2	Idler-Pulley
1:2	120-7935	2	Spacer	17	145-4016	1	Bracket-Idler
1:3	138-9770	2	Bearing-Ball	18	120-7024	2	Screw-Shoulder, HWH
2	139-1731	8	Screw-Thd Roll, HWH	19	120-3335	1	Belt-Synchronous
3	139-6612	1	Shaft-Spindle	20	120-5245-03	1	Guide-Belt, Spindle
4	139-6613	1	Shaft-Spindle	21	120-5236	2	Adapter-Blade
5	121-9100	2	Sprocket	22	121-5808	1	Spring-Extension, Brake
6	130-6664	1	Pulley-Brake, Spindle	23	125-2466	2	Bolt-Blade
7	109-9505	2	Washer-Spring	24	49-2040	2	Screw-HWHTF
8	3296-19	2	Nut-Hex	25	120-7082	1	Pulley-Idler
9	322-13	1	Screw-HH	26	322-6	1	Screw-HH
10	136-5903	1	Brake Arm ASM	27	3296-47	1	Nut-Lock,NI
10:4	131-0819	2	Bushing-Sleeve	28	116-6358-03	2	Blade-Rotary
11	5-4460	2	Washer-Pivot	29	121-2336	1	Spring-Flat
13	9114524	1	Bolt-TAP, HH	30	131-0823	1	Spacer-Brake
14	3256-3	4	Washer-Flat	33	133-1964	1	Spacer
15	3296-29	3	Nut-Lock, NI	34	32144-57	2	Screw-Thd Roll


Side Discharge Chute Assembly



Side Discharge Chute Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	322-38	1	Screw-HH	7:3	121-9196	1	Bracket-Chute
2	121-9195	1	Hinge	7:4	46-8560	2	Screw-HHFTF
3	137-4795	2	Screw	7:5	112-6416	1	Bracket-Cover
4	125-2478	1	Spacer	7:6	94-4496	2	Screw-PPH
5	121-9193	1	Spring-Torsion	7:7	3230-18	2	Screw-CARR
6	125-5093-01	1	Cover-Discharge	7:8	119-4041	2	Nut-HF
7	116-9754	1	Side Discharge Chute ASM	8	119-4041	1	Nut-HF
7:2	116-9752-03	1	Guard-Chute				


Grass Bag Assembly



Grass Bag Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-8627	1	Bag-Grass, ASM
3	116-5596-03	1	Frame-Bag

Housing Decal Assembly



Housing Decal Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	139-1674	1	Decal	8	145-3851	1	Decal-Danger, CE
6	133-8062	1	Decal-Spark Arrestor	9	116-8528	1	Decal
7	94-8072	1	Decal-Danger	10	120-9570	2	Decal-Warning

Engine and Fuel Tank Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	119-1892	1	Hose-Fuel	16	109-0304	2	Hose-Fuel
2	137-9181	1	Pulley-Engine	17	1-603770	1	Valve-Fuel
3	121-5765	1	V-Belt	18	2412-98	6	Clamp-Hose
4	133-8151	1	Belt-V	20	115-0962	1	Hose-Vent, Canister
5	138-5331-03	1	Rod-Guide, Belt	21	130-6440-03	1	Bracket-Mount, Throttle
6	95-1727	3	Screw-Taptite	22	3229-30	1	Screw-CARR
7	3290-465	1	Washer-Belleville	23	130-9655	1	Control-Throttle
8	3212-4	1	Screw-HH	24	104-7201	1	Nut-HF, NI
9	109-6528	1	Decal-Recoil	26	139-0717	1	Filter-Fuel
10		1	Engine-Kawasaki Fj180V ●■	27	116-9313	1	Decal-Warning, Engine
11	115-0954-03	1	Mount-Tank	28	130-9654	1	Wire-Control
12	114-0280	1	Tank-Fuel	29	130-9656	1	Decal-Throttle, Choke
13	137-4127	1	Cap-Fuel	30	49-2040	2	Screw-HWHTF
14	116-8929	3	Screw-HWH Trs,Patch	31	145-3960	3	Washer-Lock
15	46-8091	2	Screw-HWH				


● Not serviced separately

■ Obtain parts from www.kawpower.com

Front Bumper and Wheel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	119-4041	11	Nut-HF	12	120-9465	1	Spring-Torsion
2	121-5781	4	Bushing-Front	13	3274-55	1	Screw-HSBH
3	321-7	4	Screw-HH	14	3296-42	4	Nut-Lock, NI
4	119-4042	2	Nut-HF, NI	15	137-3061	10	Bolt-CARR
5	139-8968	1	Front Axle ASM	16	94-2413	1	Nut-U
6	133-2639	2	Wheel	17	121-2337	1	Spring-Torsion
6:2	133-2603	2	Bearing-Ball	18	136-9077	1	Decal-HOC, Front
6:3	125-1077	1	Spacer	19	125-2486	1	Spacer
7	139-6616	1	Front Bumper ASM	20	121-9187-03	1	Shield
7:2	139-1675	1	Decal-Turfmaster HDX	21	117-0871	1	Decal
7:3	116-7581	1	Decal-Warning	22	3256-22	2	Washer-Flat
8	121-9168-03	2	Brace	23	321-8	2	Screw-HH
9	131-9690	1	Mandrell-Spring	24	104-7201	2	Nut-HF, NI
10	94-5780	1	Screw-HWH	25	323-13	2	Screw-HH
11	139-1744	1	Lock-Height, Adj	26	74-1671	2	Spacer-Cover, Wheel


Transmission and HOC Assembly



Transmission and HOC Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	137-9172-03	1	HOC Plate Assembly	20	52-2860	1	Washer
2	137-9173-03	1	HOC Plate Assembly	21	119-2267	1	Screw-Shoulder, BHTF
3	701243	7	Screw-Thd Roll, HWH	22	120-9471	1	Bolt-Shoulder
4	137-9183	2	Bearing Retainer ASM	23	139-1737	1	Lock-Height, Adj
5	137-4779	4	Bearing-Ball, Custom	24	138-5393	1	Spring-Extension
6	136-9111	2	Gear-Pinion, 15T	25	119-4041	4	Nut-HF
7	32151-61	2	Ring-Retaining	26	3230-2	1	Bolt-CARR
8	137-3061	1	Bolt-CARR	27	137-9185	2	Cover-Bearing
9	136-7095	2	Cover-Wheel	28	133-2670	1	Transmission-Mv702
10	133-8104-03	1	Bracket-Transmission, Front	28:1	139-1837	1	Pulley & Fan Repair Kit
11	3230-4	2	Screw-CARR	28:2	139-1842	1	Idler Pulley Repair Kit
12	121-2368	1	Spring-Torsion	28:2:3	139-1845	1	Spring-Tension, Belt
13	119-4042	2	Nut-HF, NI	28:3	139-8974	1	Clutch Lever Repair Kit
14	125-2540	1	Washer-Plain	29	120-7950	2	Screw-Torx
15	137-9174	2	10.5 In. Wheel ASM	30	36-4780	2	Washer-Plain
17	121-2397	1	Bracket	31	3296-47	1	Nut-Lock,NI
18	139-8967	1	Rear Axle ASM	39	609471	1	Screw
19	116-7127	1	Decal-HOC, Rear				

Handle Assembly



Handle Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-0540-03	1	Handle	10	140-3985	1	Screw-Handle
2	116-8208-03	2	Support-Handle	11	137-4759	1	Cable-BBC
3	116-7230	4	Screw-HHF	12	137-4807	1	Cable-Traction
4	3230-4	2	Screw-CARR	13	3256-1	1	Washer-Flat
5	119-4041	3	Nut-HF	24	116-2690	1	Bushing-Stepped
6	139-1815	1	Bail-Traction, Coated	25	109-9318	1	Spring-Lever, BBC
7	137-4810	1	Bail-BBC, Coated	26	116-2998	1	Lever-BBC

Attachments and Accessories

For 22217 — 30in TurfMaster HDX Walk-Behind Lawn Mower

Product Name	Model/Part
Atomic Blade 15.4in.....	120-9500-03
Mulching Kit.....	125-5064
Idler Pulley Kit.....	126-7890

Notes:



Count on it.