



NEW HOLLAND ..

44in Vac-Bagger MZ Series Riding Mowers

Model No. 716257006 - T04ZL0001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR.	as required	HYD.	hydraulic
ASM.	assembly	INC.	incorporated
CARR.	carriage	LH.	left hand
DEG.	degrees	NI.	nylon insert
FH.	flat head	PPH.	phillips pan head
GA.	gauge	PTH.	phillips truss head
HF.	hex flange	PTO.	power take off
HH.	hex head	RH.	right hand
HHF.	hex head flange	SFH.	slotted fillister head
HHFTF.	hex head flange thread forming	SHH.	slotted hex head
HJ.	hex jam	SHWH.	slotted hex washer head
HLH.	hex lag head	SPH.	slotted pan head
HOC.	height-of-cut	SQH.	square head
HS.	hex	SRH.	slotted round head
HSBH.	hex socket button head	STD.	standard
HSFH.	hex socket flat head	TAP.	self tapping
HS.	hex socket head	TTH.	torx truss head
HWH.	hex washer head	WH.	wing head
HWHTF.	hex washer head thread forming		

Contents


Description	Page
Drive Component Assembly	 3
Blower Housing Assembly	 4
Bag Top Assembly	 5
Deck Component Assembly	 6
Bagger Assembly	 7
Weight Assembly	 8



Drive Component Assembly

Ref	Part No.	Qty.	Description
1	79-7110	1	Spring-Compression
2	79-2020	1	Spring-Rod
3	79-1970	1	Idler Arm ASM
4	3296-39	2	Nut-Lock, NI
5	92-7099	1	Pulley-Idler
6	3256-4	4	Washer-Flat
7	107213	1	Spacer
8	3256-24	1	Washer-Flat
9	323-10	2	Screw-HH
10	93-8013	1	Bushing
11	93-1622	1	Pulley-Idler
12	3230-16	4	Screw-CARR
13	93-8007	1	V-Belt
14	79-7280-03	1	Support-Shield, Belt
15	100284	2	Bushing
16	3256-26	1	Washer-Flat
17	3272-7	1	Pin-Cotter
18	79-7440	1	Bracket-Support, Housing
19	32128-20	4	Nut-HF
20	3256-3	1	Washer-Flat
21	79-7390	1	Spring-Extension
22	93-8012-03	1	Latch-Blower
23	93-8016-03	1	Mounting-Blower
24	3256-23	1	Washer-Flat


Ref	Part No.	Qty.	Description
25	3272-10	1	Pin-Cotter
26	3296-29	1	Nut-Lock, NI
27	98-3499	1	Washer-Flat
28	3230-2	1	Bolt-CARR



Blower Housing Assembly


Ref	Part No.	Qty.	Description				
1	32128-20	6	Nut-HF				
2	3220-6	2	Nut-Jam				
3	3253-8	2	Washer-Lock				
4	251-341	4	Flange				
5	251-288	2	Bearing-Ball				
6	3230-16	6	Screw-CARR				
7	107-7308	1	Blower - Housing Service				
7:4	22-9741	1	Spacer-Interlock				
7:5	82-5690	1	Retainer-Duct				
7:6	3290-479	1	Fastener-Panel				
8	3229-11	6	Screw-CARR				
9	79-4300-03	1	Impeller				
10	79-7170-03	1	Cover-Blower, Bottom				
11	3256-22	6	Washer-Flat				
12	3296-56	6	Nut-Lock, NI				
13	3257-40	1	Key-Hi Pro				
14	79-1470	1	Shaft-Blower				
15	7038	1	Spacer				
16	79-1460	1	Pulley-Blower				

5




Deck Component Assembly

Ref	Part No.	Qty.	Description				
1	3230-8	1	Screw-CARR				
2	93-8008	1	Pulley				
3	3230-16	4	Screw-CARR				
4	100-4184	1	Screw-CARR				
5	93-9344-03	1	Bracket-Pivot				
6	321-4	2	Screw-HH				
7	107-2495	1	ASM-Shield, Belt				
7:1	93-8022	1	Bracket-Support, Shield				
7:2	79-0470	4	Rivet-Pop				
7:3	88-1870	1	Bracket-Support, Shield				
8	93-8009	1	Tube-Latch				
9	3296-42	2	Nut-Lock, NI				
10	100-4188-03	1	Baffle-Rear				
11	19-4050	2	Knob				
12	93-8023	1	Tube-Spacer				
13	93-8020-03	1	Pivot-Bracket				
14	3296-29	8	Nut-Lock, NI				
15	3256-23	6	Washer-Flat				
16	100-4189-03	1	Ring-Bagging, RH				
17	55-4940-03	3	Blade				
18	107-2496-03	1	Cover-Pulley (Black)				
19	46-8560	1	Screw-HHF				
20	93-9910-03	2	Link - Adjusting, HOC				



Bagger Assembly

Ref	Part No.	Qty.	Description				
1	105-6980	2	Bag				
2	114972-03	2	Frame-Bag				
3	3230-1	4	Bolt-CARR				
4	114973-03	2	Hanger-Bag				
5	114974-03	2	Clamp				
6	3296-29	4	Nut-Lock, NI				
7	323-6	4	Screw-HH				
8	3256-24	4	Washer-Flat				
9	3296-39	4	Nut-Lock, NI				
10	106-2199-03	1	Bagger Support ASM				



Weight Assembly

Ref	Part No.	Qty.	Description
1	105-6972-03	1	Weight - Bagger
2	323-11	2	Screw-HH
3	3256-24	4	Washer-Flat
4	3296-39	2	Nut-Lock, NI

NOTES

NOTES

NOTES

