



**NEW HOLLAND** ..

## **36in Tiller**

### **New Holland MY Series Yard Tractors**

**Model No. 715704016 - T04MK0001 and up.**

## **Parts Catalog**

### **Ordering Replacement Parts**

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

### **Understanding Reference Numbers**

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### **Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

### **Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR. ....	as required	HYD. ....	hydraulic
ASM. ....	assembly	INC. ....	incorporated
CARR. ....	carriage	LH. ....	left hand
DEG. ....	degrees	NI. ....	nylon insert
FH. ....	flat head	PPH. ....	phillips pan head
GA. ....	gauge	PTH. ....	phillips truss head
HF. ....	hex flange	PTO. ....	power take off
HH. ....	hex head	RH. ....	right hand
HHF. ....	hex head flange	SFH. ....	slotted fillister head
HHFTF. ....	hex head flange thread forming	SHH. ....	slotted hex head
HJ. ....	hex jam	SHWH. ....	slotted hex washer head
HLH. ....	hex lag head	SPH. ....	slotted pan head
HOC. ....	height-of-cut	SQH. ....	square head
HS. ....	hex	SRH. ....	slotted round head
HSBH. ....	hex socket button head	STD. ....	standard
HSFH. ....	hex socket flat head	TAP. ....	self tapping
HSH. ....	hex socket head	TTH. ....	torx truss head
HWH. ....	hex washer head	WH. ....	wing head
HWHTF. ....	hex washer head thread forming		

## Footnotes

- ❶ Not serviced separately

## Contents

<b>Description</b>	<b>Page</b>
Tiller Gear Case Assembly	..... 3
Hitch Assembly	..... 5
Tiller Drive Jackshaft Assembly	..... 6
Pulley Box Assembly	..... 7




## Tiller Gear Case Assembly

Ref	Part No.	Qty.	Description
1	93-1609-03	1	Guard ASM
2	3272-11	7	Pin-Cotter
3	3296-39	8	Nut-Lock, NI
4	3230-1	12	Bolt-CARR
5	3256-23	12	Washer-Flat
6	3296-29	12	Nut-Lock, NI
7	93-1605-03	2	Cover-Tine End
10	103118	4	Seal
11	281-3	2	Plug-Pipe
12		1	RH Bearing ASM
12:1	93-1600-03	1	Gearcase-Tiller
12:2	6838	1	Bearing-Needle
12:3	1532	1	Bearing-Needle
12:4	1540	1	Bearing-Needle
13		1	LH Bearing ASM
13:1	93-1600-03	1	Gearcase-Tiller
13:2	6838	1	Bearing-Needle
13:3	1532	1	Bearing-Needle
13:4	1529	1	Bearing-Needle
14	106011	2	Washer
15	32120-33	2	Ring-Retaining
16	106009	1	Tine Shaft ASM
18	32121-41	2	Pin-Roll
19	1535	1	Washer-Thrust

Ref	Part No.	Qty.	Description
20	83-3340	1	Tube-Spacer
21	32120-72	1	Ring-Snap
22	3528	1	Gear-Pinion
23	6848	1	Chain
24	106007	1	Gear And Shaft ASM
26	323-42	1	Screw-HH
27	323-23	1	Screw-HH
29	100441	1	Seal-Oil
30	323-25	1	Screw-HH
31	104387	1	Shaft-Input
32	3257-5	1	Key-Woodruff
33	323-21	1	Screw-HH
34	323-13	3	Screw-HH
35	324-4	8	Screw-HH
36	92-1653-03	1	Tine-RH
37	93-1604-03	1	Tine-LH
38	3296-48	8	Nut-Lock, NI
39	93-1601-03	2	Plate-Tine Mounting
40	93-1602-03	1	RH Tine ASM
41	93-1603-03	1	LH Tine ASM
42	9208	4	Pin-Clevis
43	323-15	1	Screw-HH
44	100-8746	1	Tine Shield ASM
44:2	92-7112	2	Decal-Danger





## Hitch Assembly

Ref	Part No.	Qty.	Description
1	3296-29	4	Nut-Lock, NI
2	3230-1	4	Bolt-CARR
3	93-1608-03	1	Hitch ASM
4	79-2280	1	Clevis ASM
5	92-7074	1	Chain-Lift
6	4629	1	Spring
7	100653	1	Eyebolt
8	93-1606-03	1	Bracket-Spring
9	3296-39	3	Nut-Lock, NI
10	93-1607-03	1	Hitch ASM
11	92-7104	1	Pulley-Idler
12	93-3658	1	Spacer
13	79-0400	1	Guide-Belt
14	323-11	1	Screw-HH
15	93-0345	1	Pulley
16	1005	1	Key-Straight
17	3242-2	2	Screw-SQH
19	1-303105	1	Yoke-Adjustable
20	323-9	1	Screw-HH
21	9202204	1	Washer
22	92-7023-03	1	Catch-Spring
23	105474	1	Spacer
25	106-8273	1	Rod-Lift
26	3256-24	1	Washer-Flat

Ref	Part No.	Qty.	Description
27	3272-6	2	Pin-Cotter
28	3219-2	1	Nut-Hex
29	1-808280	1	Pin-Clevis
30	105474	1	Spacer
31	323-13	1	Screw-HH







**NEW HOLLAND**

