Form No. 3474-921 Rev B

TORO®

Count on it.

Parts Catalog

eTimeCutter™ eMR4275 Zero Turn Riding Mower

Model No. 75642—Serial No. 418178767 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3474-921 B

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Frame Assembly 4
Deck Lift Assembly 6
Caster Wheel Assembly 8
Traction Drive Assembly 10
Electric Transaxle Assembly No. 161-4488 12
Brake Assembly 14
Rear Tire Assembly 16
Seat Pan Assembly 18
Seat Assembly No. 147-8761 20
Motion Control Assembly 22
Battery Box Assembly 24
Battery Box Assembly No. 161-4483 26
Styling Pod Assembly 28
Electrical Assembly 30
Decal Specific Assembly 32
42 Inch Deck and Decal Assembly 34
Attachments and Accessories 36

© 2026—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


Frame Assembly



Frame Assembly (continued)

Ref.	Part Number	Qty.	Description
1	147-3005-01	1	Frame ASM [red]
2	138-7596-07	1	Footrest
3	138-2527-01	1	Brace-Cross, Lower
4	139-3260-01	1	Bracket-Mount Damper, Lower
9	140-2098	2	Axle Stub ASM
9:2	109-3678	2	Bearing-Ball
10	138-7200	2	Cap-Grease
11	145-0415-01	1	Plate-Mount, Drive
12	145-0416-01	1	Plate-Mount, Mr Drive
13	147-5205-07	1	Guard-Rear
14	147-7579-01	1	Guard-Rear, Upper
15	147-7640	1	Decal-Etimecutter
16	145-1978	1	Decal-Logo, Silver
18	139-2429	4	Screw-HHF
19	139-2428	4	Screw-HWH
20	139-2430	4	Nut-HF, NI
21	139-2596	10	Screw-HHF
22	138-7516	2	Guard-Rail
23	137-3099	4	Screw-Plastite, HWH
24	140-3460	2	Bumper-Rubber
25	137-4803	2	Bumper-Rubber
26	119-4041	12	Nut-HF
27	138-9753	22	Screw
29	117-1232-03	1	Bracket-Hitch


Deck Lift Assembly



Deck Lift Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-7093-03	1	Deck Lift ASM
2	138-6021	2	Bracket-Pivot, Decklift
3	140-5063	2	Washer-Hardened, Cz
4	137-9844	1	LH Arm ASM
5	137-9846	1	RH Arm ASM
6	137-9847	2	Screw-Shoulder
7	138-2564	2	Plate-Adjustment, HOC
8	139-2350-01	1	Bracket-HOC
9	140-2748	1	Decal-HOC
10	138-6050	1	Rod-Mount, Deck
11	139-2611	7	Washer-Flat
12	139-2562	7	Pin-Hair
13	119-8810	1	Pin-Pivot
14	139-1725	1	Nut-Hex
16	137-7087-03	1	Lever-Lift
18	1-633268	1	Grip-Lever
26	139-2596	1	Screw-HHF
27	138-9753	5	Screw
28	119-4041	1	Nut-HF
29	119-4042	2	Nut-HF, NI

Caster Wheel Assembly




Caster Wheel Assembly (continued)

Ref.	Part Number	Qty.	Description
1	139-3274-01	2	Fork ASM
2	147-5203	2	Tire ASM
2:1	147-2936	1	Tire
2:3	232-27	1	Stem-Valve
2:4	136-4190	2	Bearing
2:99	105-0844	1	Tube-Inner ●
3	147-7593	2	Spacer-Spanner
4	139-2607	2	Screw-HH
5	139-2617	2	Nut-Lock, NI
6	136-5590	4	Washer
7	138-7208	4	Guard-Seal
8	115-1151	2	Washer-Flat
9	139-2598	2	Screw-HHF

● Not illustrated


Traction Drive Assembly



Traction Drive Assembly (continued)

Ref.	Part Number	Qty.	Description
1	161-4488	1	Transaxle-Electric, 18"
2	144-5335-01	1	Bracket-Transmission
3	147-5202	7	Screw-HH
4	119-4041	7	Nut-HF
5	138-9753	3	Screw
6	139-2564	8	Nut-Lug


Electric Transaxle Assembly No. 161-4488



Electric Transaxle Assembly No. 161-4488 (continued)

Ref.	Part Number	Qty.	Description
2	161-6416	2	Motor ASM [service]
3	161-4491	2	Wheel Hub ASM
3:1	161-4492	4	Stud-Wheel
3:2	161-4647	1	Nut-Hub
4	161-4493	1	Arm-Brake ASM
5	161-4494	1	Switch-Brake ASM
7	161-4496	7	Spacer
8	161-4497	3	Rod-Cross


Brake Assembly



Brake Assembly (continued)

Ref.	Part Number	Qty.	Description
1	147-5182-03	1	Bracket-Pedal, Brake
2	147-7741	1	Bushing-Flange
3	5-4460	1	Washer-Pivot
4	145-0490	1	Cable-Brake
5	147-5201-03	1	Bracket-Cable, Brake
6	147-5181-03	1	Pedal-Brake
7	142-6275	1	Screw-HHF
8	120-5116	1	Washer-Wave
9	119-4041	1	Nut-HF
10	137-7040	1	Spring-Return, Pedal
11	147-3048	1	Cover-Brake, Parking
12	135-2015	1	Screw-Shoulder
13	120-7950	2	Screw-Torx
14	138-9753	3	Screw
15	139-1271	1	Decal-Brake, Parking
16	3290-378	1	Tie-Cable

Rear Tire Assembly




Rear Tire Assembly (continued)

Ref.	Part Number	Qty.	Description
1	139-5846	2	Tire ASM
1:1	126-1618	1	Tire
1:3	232-27	1	Stem-Valve
1:99	107-2491	1	Tube-Tire ●

● Not illustrated


Seat Pan Assembly



Seat Pan Assembly (continued)

Ref.	Part Number	Qty.	Description
1	147-7739	1	Subframe ASM
1:2	147-7616	1	Decal-Danger
1:3	140-0357	1	Decal-Myride
4	138-7517	2	Bracket-Mount, Swing Arm
5	138-7548	1	Screw-HHF
6	138-7549	1	Tube-Spacer
7	138-2563	1	Arm, Swing
8	138-2573	4	Bushing-Flange
9	138-2547	2	Bolt-Shoulder
10	137-1983	1	Spring-Torsion, LH
11	137-7018	1	Spring-Torsion, RH
12	138-7566-03	1	Plate-Adjuster
13	138-9813	1	Rod-Adjustment
14	138-9788	1	Bracket-Cable
15	139-2361-03	1	Bracket Lower
16	138-9812	1	Cable-Adjustment, Myride
17	138-9776	2	Retainer-Spring
18	138-7522	2	Bracket-Seat
19	120-7950	2	Screw-Torx
20	147-7727-03	1	Pan-Seat [black]
21	135-2015	1	Screw-Shoulder
22	147-8761	1	Seat ASM
26	133-9318-03	1	Bracket-Shock Mount, Upper (LH)
27	133-9319-03	1	Bracket-Shock Mount, Upper (RH)
28	147-7746	1	Shock/Spring ASM
29	136-7198	2	Bolt-Shoulder
30	138-2596	1	Rod-Prop, Seat
31	135-0505	3	Bumper-Seat
32	138-9753	12	Screw
33	138-9814	1	Pulley - Cam
34	138-9822	1	Lever - Adjustment
35	92-1057	1	Bolt-Shoulder
36	139-5858	1	Spring-Compression
37	140-3759	1	Bolt-Shoulder,HHF
38	140-5176	1	Knob-Mr
39	138-9848	1	Spring-Extension
40	139-1716	2	Screw-HH
41	119-4041	7	Nut-HF
42	119-4042	6	Nut-HF, NI
43	139-5800	1	Bushing - Flange
45	137-3083	1	Pin-Hair
46	115-1166	1	Washer-Plain
47	32120-47	1	Ring-Retaining, External
58	119-4036	4	Screw-HHF


Seat Assembly No. 147-8761



Seat Assembly No. 147-8761 (continued)

Ref.	Part Number	Qty.	Description
2	161-6183	1	Toro Back Cover
3	147-8736	1	Seat Switch Delta 6500-02 Open
4	161-6184	1	Toro Seat Cover
5	147-8740	1	Slide ASM-Seat
6	119-4036	4	Screw-HHF
7	82-2190	1	Switch-Bail


Motion Control Assembly



Motion Control Assembly (continued)

Ref.	Part Number	Qty.	Description
1	140-8322-03	1	Plate-Control Box, RH
2	140-8342-03	1	Plate-Control Box, LH
3	147-7552	2	Spacer-Sensor
4	147-7551	4	Bushing-Flange
5	147-2903	2	Arm-Actuator
6	147-3009	1	Pin-Lever Pivot, LH
7	147-3010	1	Pin-Lever Pivot, RH
8	119-8952	2	Washer-Spcl
9	132-6853	2	Damper-Non Cavitating
10	120-7950	2	Screw-Torx
11	139-5803	2	Eccentric
12	139-5811	2	Bolt-Pivot, Eccentric
13	120-2273	2	Washer-Flat
14	133-9299-05	2	Arm-Control
15	117-1240	2	Washer
16	119-8925	2	Washer-Belleville
17	139-2556	2	Bolt-Pivot
18	119-4042	2	Nut-HF, NI
19	133-7057	1	Handle-Control, RH
19:1	121-0726	1	Grip
20	133-7055	1	Handle-Control, LH
20:1	121-0726	1	Grip
21	139-2597	4	Screw-HHF
22	138-7215	2	Stud-Damper
23	137-3088	6	Nut-Hex
24	119-1138	2	Screw-HHF,Patch
27	138-7539	2	Spring-Torsion
28	138-9753	10	Screw


Battery Box Assembly



Battery Box Assembly (continued)

Ref.	Part Number	Qty.	Description
1	147-7605	4	Isolator-1 In OD (5/16-18)
2	161-4468-01	1	Battery Mount ASM [red]
3	147-7672-03	2	Mount-Box, Rear
4	119-4041	8	Nut-HF
5	138-9753	2	Screw
6	147-2192	1	Resistor-Regen
7	145-6922	2	Screw-HWH Thd Roll Zct+w
8	161-4483	1	Box-Battery, ASM
9	139-2598	4	Screw-HHF


Battery Box Assembly No. 161-4483



Battery Box Assembly No. 161-4483 (continued)

Ref.	Part Number	Qty.	Description
2	147-5348	1	Cover-Box, Battery
3	147-5345	1	Filter-Air
4	147-5344	1	Housing-Filter
5	161-4648	2	Hinge-Box ASM, Battery
6	147-5342	1	Box-Battery, Outer
7	161-4486	16	Screw-Plastic 4Mmx14MM, Globe
8	161-4487	1	Fan-ASM
9	161-4645	3	Magnet-Lid, Battery Box
10	161-4646	3	Magnet-Base, Battery Box
11	147-4208	1	Decal-60V, Lithium
12	147-7621	1	Decal-Lithium


Styling Pod Assembly



Styling Pod Assembly (continued)

Ref.	Part Number	Qty.	Description
1	138-9810-03	1	Bracket-Pod
2	138-6071-03	1	Support-Pod, LH
3	145-0501	1	Pod-LH
3:5	147-7620	1	Decal - Control Lever, LH
4	147-7742	1	Pod-RH, Myride
4:4	147-7619	1	Decal - Control Lever, RH
4:5	139-2397	1	Decal-Adjustment
5	145-0502-03	1	Plate-Cover, Pod
6	130-8451	4	Rivet-Trifold
7	138-9753	3	Screw
8	120-7950	6	Screw-Torx
9	107069	1	Clip
10	147-7576	1	Pod-Control
11	147-7577-03	1	Cover-Console
12	3258-166	1	Screw-PRH
13	145-5837	2	Screw-Plastic,Tbfh
14	147-7614	1	Decal-Panel, Control
15	147-7629	1	Plug-Pod, LH
16	147-7691	1	Plug-Sc
17	147-7641	1	Decal-60V Lithium
18	147-7666	1	Cover-Switch
19	147-7715	1	Decal-Gt Display


Electrical Assembly



Electrical Assembly (continued)

Ref.	Part Number	Qty.	Description
1	147-7667-03	1	Mount-Controllers
2	147-7631	1	Controller-Master
3	147-7635	2	Controller-Traction
4	147-7633	2	Controller-Deck
5	80-9330	1	Audio Alarm ASM
5:1	104-5107	1	Nut-Plastic, Knurled
6	110-8823	1	Block-Junction
7	105-6849	2	Screw-Forming, Thread
8	145-0586	6	Clip-Controller
9	138-5775	6	Screw-Delta Point
10	147-5200-03	1	Mount-Holder, Fuse
11	140-8373	2	Sensor
12	147-7729	4	Screw-HWH
13	147-7730	4	Nut-Hex NI
14	110-6765	2	Switch
15	139-6368	1	Switch-Rocker, On-None-On
16	145-0467	2	Switch-Rocker On- None-On
17	140-7955	1	Port-Power, USB
18	139-6393	1	Harness-Wire, 2 Blade
19	147-2198	1	Display
20	161-6249	2	Holder-Fuse
20:1	136-8682	4	Washer-Lock
20:2	3256-74	8	Washer-Flat
20:3	117-4059	4	Nut-Hex
21	32144-4	6	Screw-HWH
23	122-2559	2	Fuse-100 Amp
24	147-5340	1	Busbar-2, Switch
25	122-2513	1	Switch-Ignition, Suns
25:1	121-5160	1	Nut-Hex
25:2	122-2704	1	Nut-Face, M22 (Plastic)
25:3	121-5162	1	Set-Key, Ignition
26	147-7584	1	Harness-Wire, Power Cable
27	147-7668	1	Cover-Bottom
28	147-7670	1	Cover-Controller
29	117-2382	2	Plug-Plastic
30	120-7950	2	Screw-Torx
31	147-7680	1	Cover-Outer
32	139-7488-01	1	Mount-Head Lights
33	32144-70	2	Screw-HWHTF
34	139-5825	2	ASM-Light,LED
35	94-4496	4	Screw-PPH
36	147-7681-03	2	Cover-Sensor
38	147-7719-03	1	Cover-Wire
39	138-9753	8	Screw
40	137-3099	5	Screw-Plastite, HWH
41	32180-078	1	Clip-Edge
42	3290-378	1	Tie-Cable
43	145-7110	1	Adapter-Switch, Key
45	119-4042	1	Nut-HF, NI
46	147-8762	1	Harness-Wire, LED Lights
47	32180-030	1	Clip-Tie
48	147-0290	1	Decal-Light, Warning


Decal Specific Assembly



Decal Specific Assembly (continued)

Ref.	Part Number	Qty.	Description
4	161-4550	1	Decal Emr4275

42 Inch Deck and Decal Assembly



42 Inch Deck and Decal Assembly (continued)

Ref.	Part Number	Qty.	Description
1	147-7654	1	42 In Deck And Decal ASM
1:2	147-7615	2	Decal-Danger, Deck
1:3	137-8127	2	Decal-No Spray
1:4	130-0731	1	Decal-Danger
5	140-8379	2	Motor-Deck
6	136-7174	8	Screw-Thd Roll, HWH
7	140-8361	2	Driver-Blade
8	144-1948-03	2	Blade-21.60 In, Combination
9	145-0411	2	Bolt-Blade, Sems
10	137-2019	1	Rod-Pivot
11	138-7502	1	Deflector-Discharge
12	138-7268	1	Spring-Torsion
13	121-4600	1	Nut-Hex
14	1-603299	2	Roller-Scalp, Anti
15	139-2551	2	Bolt-Shoulder
16	139-5871	2	Pin-Deck
17	119-4042	4	Nut-HF, NI
18	140-4184	1	Decal
19	147-7678-03	1	Baffle-Recycling [welded][black]
20	139-2630	4	Bolt-CARR
21	119-4041	6	Nut-HF
22	119-3389-03	2	Kicker-Flanged
23	32144-70	4	Screw-HWHTF
27	161-6305-03	1	Deflector-42"

Attachments and Accessories

For 75642 — eTimeCutter eMR4275 Zero Turn Riding Mower

Product Name	Model/Part
Seat Cover w/Arm Rest	117-0097
Arm Rest Kit	147-8773
42 Inch Bagging Enhancement Kit	161-4521
42 Inch Striping Kit	161-4523
Heavy Duty Spring Kit	161-4525
Deck Footlift Assist Kit	161-4527
Floormat Kit	161-4529
Caster Wheel Kit	161-4530
53cm 60V Snowblower Bare Tool	31853T
Storage Cover	490-7516
Battery Charger, Six Pod 60V 12 Amp CE	66560
Battery -LI-ION, 60V 10 AH, 540WH	66910
Slope Sensor Kit, Zero-Turn-Radius Riding Mower	79681
Rops Kit	79682
Bagger	79841
60V Battery Charger 2 Amp CE	81802
60v Battery Charger 5 Amp International	81805
60V 2.0 AH Battery International	81820
60V 2.5 AH Battery CE	81825
60V 4.0 AH Battery CE	81850
60V 6.0 AH Battery CE	81860
60V 7.5 AH Battery CE	81875

Notes:

Notes:

Notes:



Count on it.