Form No. 3467-186 Rev B

TORO®

Count on it.

Parts Catalog

eTimeCutter™ 42in

Riding Mower

Model No. 75841—Serial No. 416499999 and Up

Register at www.Toro.com.
Original Instructions (EN)

3467-186 B

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Frame Assembly 4
Decklift Assembly 6
Caster Wheel Assembly 8
Traction Drive Assembly 10
Electric Transaxle Assembly No. 161-4488 12
Brake Assembly 14
Rear Tire Assembly 16
Seat Assembly 18
Motion Control Assembly 20
Battery Box Assembly 22
Battery Box Assembly No. 161-4483 24
Pod Assembly 26
Electrical Assembly 28
42 Inch Deck and Decal Assembly 30
Attachments and Accessories 32

© 2026—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved

Frame Assembly



Frame Assembly (continued)

Ref.	Part Number	Qty.	Description
1	147-3005-01	1	Frame ASM [red]
2	138-9827-07	1	Footrest
3	138-9791-01	1	Brace-Cross
5	138-6036-03	1	Support-Seat
6	161-4457	1	Pan-Floor ASM
6:2	147-7617	1	Decal - Warning
8	139-3220	1	Tread-Step
9	140-2098	2	Axle Stub ASM
9:2	109-3678	2	Bearing-Ball
10	138-7200	2	Cap-Grease
11	145-0415-01	2	Plate-Mount, Drive
13	147-5205-07	1	Guard-Rear
14	147-7579-01	1	Guard-Rear, Upper
15	147-8705	1	Decal-Timecutter
16	145-1978	1	Decal-Logo, Silver
17	138-2548	2	Spring-Compression
18	139-2429	4	Screw-HHF
19	139-2428	4	Screw-HWH
20	139-2430	4	Nut-HF, NI
21	139-2596	8	Screw-HHF
26	119-4041	8	Nut-HF
27	138-9753	22	Screw
28	701178	2	Cap-Protector

Decklift Assembly



Decklift Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-7093-03	1	Deck Lift ASM
2	138-6021	2	Bracket-Pivot, Decklift
3	140-5063	2	Washer-Hardened, Cz
4	137-9844	1	LH Arm ASM
5	137-9846	1	RH Arm ASM
6	137-9847	2	Screw-Shoulder
7	138-2564	2	Plate-Adjustment, HOC
8	139-2350-01	1	Bracket-HOC
9	139-2392	1	Decal-HOC
10	138-6050	1	Rod-Mount, Deck
11	139-2611	7	Washer-Flat
12	139-2562	7	Pin-Hair
13	119-8810	1	Pin-Pivot
14	139-1725	1	Nut-Hex
16	137-7087-03	1	Lever-Lift
18	1-633268	1	Grip-Lever
26	139-2596	1	Screw-HHF
27	138-9753	5	Screw
28	119-4041	1	Nut-HF
29	119-4042	2	Nut-HF, NI

Caster Wheel Assembly



Caster Wheel Assembly (continued)

Ref.	Part Number	Qty.	Description
1	139-3274-01	2	Fork ASM
2	147-5203	2	Tire ASM
2:1	147-2936	1	Tire
2:3	232-27	1	Stem-Valve
2:4	136-4190	2	Bearing
2:99	105-0844	1	Tube-Inner ●
3	147-7593	2	Spacer-Spanner
4	139-2607	2	Screw-HH
5	139-2617	2	Nut-Lock, NI
6	136-5590	4	Washer
7	138-7208	4	Guard-Seal
8	115-1151	2	Washer-Flat
9	139-2598	2	Screw-HHF

● Not illustrated

Traction Drive Assembly



Traction Drive Assembly (continued)

Ref.	Part Number	Qty.	Description
1	161-4488	1	Transaxle-Electric, 18"
2	144-5335-01	1	Bracket-Transmission
3	147-5202	7	Screw-HH
4	119-4041	7	Nut-HF
5	138-9753	3	Screw
6	139-2564	8	Nut-Lug

Electric Transaxle Assembly No. 161-4488



Electric Transaxle Assembly No. 161-4488 (continued)

Ref.	Part Number	Qty.	Description
2	161-6416	2	Motor ASM [service]
3	161-4491	2	Wheel Hub ASM
3:1	161-4492	4	Stud-Wheel
3:2	161-4647	1	Nut-Hub
4	161-4493	1	Arm-Brake ASM
5	161-4494	1	Switch-Brake ASM
7	161-4496	7	Spacer
8	161-4497	3	Rod-Cross

Brake Assembly



Brake Assembly (continued)

Ref.	Part Number	Qty.	Description
1	147-5182-03	1	Bracket-Pedal, Brake
2	147-7741	1	Bushing-Flange
3	5-4460	1	Washer-Pivot
4	145-0490	1	Cable-Brake
5	147-5201-03	1	Bracket-Cable, Brake
6	147-5181-03	1	Pedal-Brake
7	142-6275	1	Screw-HHF
8	120-5116	1	Washer-Wave
9	119-4041	1	Nut-HF
10	137-7040	1	Spring-Return, Pedal
11	147-3048	1	Cover-Brake, Parking
12	135-2015	1	Screw-Shoulder
13	120-7950	2	Screw-Torx
14	138-9753	3	Screw
15	139-1271	1	Decal-Brake, Parking
16	3290-378	1	Tie-Cable
17	32180-030	1	Clip-Tie

Rear Tire Assembly



Rear Tire Assembly (continued)

Ref.	Part Number	Qty.	Description
1	139-5846	2	Tire ASM
1:1	126-1618	1	Tire
1:3	232-27	1	Stem-Valve
1:99	107-2491	1	Tube-Tire ●

● Not illustrated

Seat Assembly



Seat Assembly (continued)

Ref.	Part Number	Qty.	Description
19	120-7950	1	Screw-Torx
20	138-9781-03	1	Pan-Seat
22	147-7744	1	Seat-16 In
22:2	82-2190	1	Switch-Bail
48	138-7555	1	Rod-Pivot
49	137-3010	2	Screw-BHCS
51	139-2398	1	Cable-Lanyard
53	37-8771	2	Bolt-Shoulder, HF
54	5-4460	2	Washer-Pivot
55	137-3052	2	Screw-HH
56	147-5287	1	Washer-Flat

Motion Control Assembly



Motion Control Assembly (continued)

Ref.	Part Number	Qty.	Description
1	140-8322-03	1	Plate-Control Box, RH
2	140-8342-03	1	Plate-Control Box, LH
3	147-7552	2	Spacer-Sensor
4	147-7551	4	Bushing-Flange
5	147-2903	2	Arm-Actuator
6	147-3009	1	Pin-Lever Pivot, LH
7	147-3010	1	Pin-Lever Pivot, RH
8	119-8952	2	Washer-Spcl
9	132-6853	2	Damper-Non Cavitating
10	120-7950	4	Screw-Torx
11	139-5803	2	Eccentric
12	139-5811	2	Bolt-Pivot, Eccentric
13	120-2273	2	Washer-Flat
14	133-9299-05	2	Arm-Control
15	117-1240	2	Washer
16	119-8925	2	Washer-Belleville
17	139-2556	2	Bolt-Pivot
18	119-4042	2	Nut-HF, NI
19	133-7057	1	Handle-Control, RH
19:1	121-0726	1	Grip
20	133-7055	1	Handle-Control, LH
20:1	121-0726	1	Grip
21	139-2597	4	Screw-HHF
22	138-7215	2	Stud-Damper
23	137-3088	6	Nut-Hex
24	119-1138	2	Screw-HHF,Patch
25	139-3280-01	1	Plate-Kick
26	145-0421	1	Box-Storage
27	138-7539	2	Spring-Torsion
28	138-9753	10	Screw

Battery Box Assembly



Battery Box Assembly (continued)

Ref.	Part Number	Qty.	Description
1	147-7605	4	Isolator-1 In OD (5/16-18)
2	161-4468-01	1	Battery Mount ASM [red]
3	147-7672-03	2	Mount-Box, Rear
4	119-4041	8	Nut-HF
5	138-9753	2	Screw
6	147-2192	1	Resistor-Regen
7	145-6922	2	Screw-HWH Thd Roll Zct+w
8	161-4483	1	Box-Battery, ASM
9	139-2598	4	Screw-HHF

Battery Box Assembly No. 161-4483



Battery Box Assembly No. 161-4483 (continued)

Ref.	Part Number	Qty.	Description
2	147-5348	1	Cover-Box, Battery
3	147-5345	1	Filter-Air
4	147-5344	1	Housing-Filter
5	161-4648	2	Hinge-Box ASM, Battery
6	147-5342	1	Box-Battery, Outer
7	161-4486	16	Screw-Plastic 4Mmx14MM, Globe
8	161-4487	1	Fan-ASM
9	161-4645	3	Magnet-Lid, Battery Box
10	161-4646	3	Magnet-Base, Battery Box
11	147-4208	1	Decal-60V, Lithium
12	147-7621	1	Decal-Lithium

Pod Assembly



Pod Assembly (continued)

Ref.	Part Number	Qty.	Description
1	138-6070-03	1	Support-Pod, RH
2	138-6071-03	1	Support-Pod, LH
3	145-0501	1	Pod-LH
3:5	147-7620	1	Decal - Control Lever, LH
4	147-8768	1	Pod-RH
4:4	147-7619	1	Decal - Control Lever, RH
5	145-0502-03	1	Plate-Cover, Pod
6	130-8451	4	Rivet-Trifold
7	138-9753	4	Screw
8	120-7950	6	Screw-Torx
9	107069	1	Clip
10	147-7576	1	Pod-Control
11	147-7577-03	1	Cover-Console
12	3258-166	1	Screw-PRH
13	145-5837	2	Screw-Plastic,Tbfh
14	147-7614	1	Decal-Panel, Control
15	147-7629	1	Plug-Pod, LH
16	147-7691	1	Plug-Sc
17	147-7641	1	Decal-60V Lithium
18	147-7666	1	Cover-Switch
19	147-7715	1	Decal-Gt Display

Electrical Assembly



Electrical Assembly (continued)

Ref.	Part Number	Qty.	Description
1	147-7667-03	1	Mount-Controllers
2	147-7631	1	Controller-Master
3	147-7635	2	Controller-Traction
4	147-7633	2	Controller-Deck
5	80-9330	1	Audio Alarm ASM
5:1	104-5107	1	Nut-Plastic, Knurled
6	110-8823	1	Block-Junction
7	105-6849	2	Screw-Forming, Thread
8	145-0586	6	Clip-Controller
9	138-5775	6	Screw-Delta Point
10	147-5200-03	1	Mount-Holder, Fuse
11	140-8373	2	Sensor
12	147-7729	4	Screw-HWH
13	147-7730	4	Nut-Hex NI
14	110-6765	2	Switch
15	139-6368	1	Switch-Rocker, On-None-On
16	145-0467	2	Switch-Rocker On- None-On
17	140-7955	1	Port-Power, USB
18	139-6393	1	Harness-Wire, 2 Blade
19	147-2198	1	Display
20	161-6249	2	Holder-Fuse
20:1	136-8682	4	Washer-Lock
20:2	3256-74	8	Washer-Flat
20:3	117-4059	4	Nut-Hex
21	32144-4	6	Screw-HWH
23	122-2559	2	Fuse-100 Amp
24	147-5340	1	Busbar-2, Switch
25	122-2513	1	Switch-Ignition, Suns
25:1	121-5160	1	Nut-Hex
25:2	122-2704	1	Nut-Face, M22 (Plastic)
25:3	121-5162	1	Set-Key, Ignition
26	147-7584	1	Harness-Wire, Power Cable
27	147-7668	1	Cover-Bottom
28	147-7670	1	Cover-Controller
29	117-2382	2	Plug-Plastic
30	120-7950	2	Screw-Torx
31	147-7680	1	Cover-Outer
32	139-7488-01	1	Mount-Head Lights
33	32144-70	2	Screw-HWHTF
34	139-5825	2	ASM-Light,LED
35	94-4496	4	Screw-PPH
36	147-7681-03	2	Cover-Sensor
37	108-4925	2	Washer
38	147-7719-03	1	Cover-Wire
39	138-9753	8	Screw
40	137-3099	5	Screw-Plastite, HWH
41	32180-078	1	Clip-Edge
42	3290-378	1	Tie-Cable
43	145-7110	1	Adapter-Switch, Key
44	119-4041	2	Nut-HF
45	119-4042	1	Nut-HF, NI
46	147-8762	1	Harness-Wire, LED Lights
47	32180-030	1	Clip-Tie
48	147-0290	1	Decal-Light, Warning

42 Inch Deck and Decal Assembly



42 Inch Deck and Decal Assembly (continued)

Ref.	Part Number	Qty.	Description
1	147-7654	1	42 In Deck And Decal ASM
1:2	147-7615	2	Decal-Danger, Deck
1:3	137-8127	2	Decal-No Spray
1:4	130-0731	1	Decal-Danger
5	140-8379	2	Motor-Deck
6	136-7174	8	Screw-Thd Roll, HWH
7	140-8361	2	Driver-Blade
8	144-1948-03	2	Blade-21.60 In, Combination
9	145-0411	2	Bolt-Blade, Sems
10	137-2019	1	Rod-Pivot
11	138-7502	1	Deflector-Discharge
12	138-7268	1	Spring-Torsion
13	121-4600	1	Nut-Hex
14	1-603299	2	Roller-Scalp, Anti
15	139-2551	2	Bolt-Shoulder
16	139-5871	2	Pin-Deck
17	119-4042	4	Nut-HF, NI
18	147-7562	1	Decal-Iron Forged, 42
20	139-2630	3	Bolt-CARR
21	119-4041	5	Nut-HF
24	137-3052	2	Screw-HH
25	137-3041	4	Screw-HH
26	119-4040	4	Nut-HF, NI
27	161-6305-03	1	Deflector-42"

Attachments and Accessories

For 75841 — eTimeCutter 42in Riding Mower

Product Name	Model/Part
Seat Cover W/O Arm Rest - TC 18in	117-0096
Armrest Kit	140-2058
42in Recycler Kit, TimeCutter 4275 Riding Mower	161-4519
42 Inch Bagging Enhancement Kit	161-4521
42 Inch Striping Kit	161-4523
Deck Footlift Assist Kit	161-4527
Floormat Kit	161-4528
Caster Wheel Kit	161-4530
21in Stripe WPM Push Bare Tool	21611T
Power Clear 21in 60V Self-PPL (BT)	39921T
Storage Cover	490-7516
60V Cordless Blower (Bare Tool)	51820T
60V Cordless Trimmer (Bare Tool)	51830T
60v 24in Max Hedge Trimmer (Bare Tool)	51840T
16in 60V Max Chainsaw (Bare Tool)	51850T
60V Six Pod Battery Charger 12 AMP	66550
60V LI-ION Battery 10.0 AH	66810
Slope Sensor Kit, Zero-Turn-Radius Riding Mower	79681
Rops Kit	79682
Bagger	79841
60V Battery Charger 2 AMP	88602
60V Rapid Battery Charger 5.4 AMP	88605
60V Battery 2.0 AH	88620
60V LI-ION Battery 2.5 AH	88625
60V LI-ION, Battery 4.0 AH	88640
60V LI-ION Battery 5.0 AH	88650
60V LI-ION Battery 6.0 AH	88660
60V LI-ION Battery 7.5 AH	88675

Notes:

Notes:

Notes:

Count on it.