



36in Tiller XT Series Garden Tractors

Model No. 79484 - 230000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Tiller Gear Case Assembly	 3	Pulley Box Assembly No. 106-5562 (Optional)	 7
Hitch Assembly	 5		
Tiller Drive Jackshaft Assembly	 6		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR.	as required	HYD.	hydraulic
ASM.	assembly	INC.	incorporated
CARR.	carriage	LH.	left hand
DEG.	degrees	NI.	nylon insert
FH.	flat head	PPH.	phillips pan head
GA.	gauge	PTH.	phillips truss head
HF.	hex flange	PTO.	power take off
HH.	hex head	RH.	right hand
HHF.	hex head flange	SFH.	slotted fillister head
HHFTF.	hex head flange thread forming	SHH.	slotted hex head
HJ.	hex jam	SHWH.	slotted hex washer head
HLH.	hex lag head	SPH.	slotted pan head
HOC.	height-of-cut	SQH.	square head
HS.	hex	SRH.	slotted round head
HSBH.	hex socket button head	STD.	standard
HSFH.	hex socket flat head	TAP.	self tapping
HS.	hex socket head	TTH.	torx truss head
HWH.	hex washer head	WH.	wing head
HWHTF.	hex washer head thread forming		


Footnotes

- ❶ Not serviced separately




Tiller Gear Case Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	93-1609-01	1	Guard ASM	20	83-3340	1	Tube-Spacer
2	3272-11	7	Pin-Cotter	21	32120-72	1	Ring-Snap
3	3296-39	8	Nut-Lock, NI	22	3528	1	Gear-Pinion
4	3230-1	12	Bolt-CARR	23	6848	1	Chain
5	3256-23	12	Washer-Flat	24	106007	1	Gear And Shaft ASM
6	3296-29	12	Nut-Lock, NI	26	323-42	1	Screw-HH
7	93-1605-01	2	Cover-Tine End	27	323-23	1	Screw-HH
10	103118	4	Seal	29	100441	1	Seal-Oil
11	281-3	2	Plug-Pipe	30	323-25	1	Screw-HH
12		1	RH Bearing ASM	31	104387	1	Shaft-Input
12:1	93-1600-03	1	Gearcase-Tiller	32	3257-5	1	Key-Woodruff
12:2	6838	1	Bearing-Needle	33	323-21	1	Screw-HH
12:3	1532	1	Bearing-Needle	34	323-13	3	Screw-HH
12:4	1540	1	Bearing-Needle	35	324-4	8	Screw-HH
13		1	LH Bearing ASM	36	92-1653-03	1	Tine-RH
13:1	93-1600-03	1	Gearcase-Tiller	37	93-1604-03	1	Tine-LH
13:2	6838	1	Bearing-Needle	38	3296-48	8	Nut-Lock, NI
13:3	1532	1	Bearing-Needle	39	93-1601-03	2	Plate-Tine Mounting
13:4	1529	1	Bearing-Needle	40	93-1602-03	1	RH Tine ASM
14	106011	2	Washer	41	93-1603-03	1	LH Tine ASM
15	32120-33	2	Ring-Retaining	42	9208	4	Pin-Clevis
16	106009	1	Tine Shaft ASM	43	323-15	1	Screw-HH
18	32121-41	2	Pin-Roll	44	92-6514	1	Tine Shield/decals ASM
19	1535	1	Washer-Thrust	44:2	92-7112	2	Decal-Danger



Tiller Gear Case Assembly (continued)


Ref	Part No.	Qty.	Description
46	93-9279-03	1	Guard-Tiller
47	106-5838	1	Decal-Workhorse



Hitch Assembly


Ref	Part No.	Qty.	Description
1	3296-29	4	Nut-Lock, NI
2	3230-1	4	Bolt-CARR
3	93-1608-01	1	Hitch ASM
4	79-2280	1	Clevis ASM
5	92-7074	1	Chain-Lift
6	4629	1	Spring
7	100653	1	Eyebolt
8	93-1606-03	1	Bracket-Spring
9	3296-39	3	Nut-Lock, NI
10	93-1607-03	1	Hitch ASM
11	92-7104	1	Pulley-Idler
12	93-3658	1	Spacer
13	79-0400	1	Guide-Belt
14	323-11	1	Screw-HH
15	93-0345	1	Pulley
16	1005	1	Key-Straight
17	3242-2	2	Screw-SQH
19	1-303105	1	Yoke-Adjustable
20	323-9	1	Screw-HH
21	9202204	1	Washer
22	92-7023-03	1	Catch-Spring
23	105474	1	Spacer
25	106-8273	1	Rod-Lift
26	3256-24	1	Washer-Flat

Ref	Part No.	Qty.	Description
27	3272-6	2	Pin-Cotter
28	3219-2	1	Nut-Hex
29	1-808280	1	Pin-Clevis
30	105474	1	Spacer
31	323-13	1	Screw-HH



Tiller Drive Jackshaft Assembly

Ref	Part No.	Qty.	Description				
1	3242-2	4	Screw-SQH				
2	106-8298-03	1	Support-Jackshaft				
3	3296-29	6	Nut-Lock, NI				
4	110567	2	Flange-Zerk Relube				
5	110568	2	Flange				
6	110569	2	Bearing And Collar				
7	94-7840	1	Shaft-Jack				
8	94-7842	2	Pulley-V				
9	106-5813	1	V Belt-Traction				
10	937089	2	Key-Woodruff				
11	3230-1	6	Bolt-CARR				
12	32120-46	1	Ring-Retaining				
13	302-5	1	Fitting-Grease				
14	98-1644	2	Bushing-Flanged				
15	703454	1	V-Belt				
16	106-8275	1	Idler ASM				
17	3296-39	1	Nut-Lock, NI				
18	92-7104	1	Pulley-Idler				
19	323-9	1	Screw-HH				
20	92-7305	1	Spring-Extension				



Pulley Box Assembly No. 106-5562 (Optional)

Ref	Part No.	Qty.	Description				
1	106-5625	1	Upper Pulley ASM				
2	106-5634	2	Spacer-Pulley				
3	251-82	2	Bearing-Ball				
4	106-5633	1	Spacer-Bearing				
5	105-1397	2	Ferrule-Adjuster				
6	3296-22	2	Nut-Lock, NI				
7	92-7101	2	Pulley-Flat Idler				
8	106-5636	2	Idler Arm ASM				
9	3231-4	2	Screw-CARR				
10	256-156	4	Bushing-Flange				
13	32120-47	2	Ring-Retaining, External				
14	106-5627	1	Lower Pulley ASM				
15	3256-28	1	Washer-Flat				
16	3220-7	1	Nut-Jam				
17	106-4024	2	Rod-Tension				
18	105-1492	2	Knob-Adjusting				
19	933156	4	Pin-Roll				
20	106-9892	2	Spring-Compression				
21	106-9888	2	Washer-Flat				
23	65-2690	2	Decal-Surface, Hot				

