Form No. 3482-169 Rev A

TORO®

Count on it.

Parts Catalog

# TimeMaster® 30in

## Lawn Mower

**Model No. 21219—Serial No. 420876683 and Up**

Register at www.Toro.com.
Original Instructions (EN)

*3482-169* A

# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

**Understanding Reference Numbers**

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

**Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

**Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents


Deck and Bag Assembly . . . . . 4
Spindle and Belt Assembly . . . . . 6
Side Discharge Chute Assembly . . . . . 8
Grass Bag Assembly . . . . . 10
Engine and Belt Assembly . . . . . 12
Front Wheel and Height-of-Cut Assembly . . . . . 14
Rear Wheel and Height-of-Cut Assembly . . . . . 16
Handle Assembly . . . . . 18
Attachments and Accessories . . . . . 20

**© 2026—The Toro® Company**
**8111 Lyndale Avenue South**
**Bloomington, MN 55420**



**Contact us at www.Toro.com.**
**Printed in the USA.**
**All Rights Reserved**


# Deck and Bag Assembly



# Deck and Bag Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 136-5873 | 1 | Housing ASM |
| 3 | 140-3977-01 | 1 | Frame-30" |
| 4 | 3230-5 | 2 | Bolt-CARR |
| 5 | 139-5415 | 1 | Rod-Release, Handle |
| 6 | 120-7018 | 1 | Grip-Lever |
| 7 | 121-9114 | 1 | Bracket-Door, LH |
| 8 | 121-9115 | 1 | Bracket-Door, RH |
| 9 | 120-7048 | 1 | Rear Deflector ASM |
| 9:3 | 131-4514 | 1 | Decal-Warning |
| 10 | 115-2859 | 1 | Spring-Torsion |
| 11 | 114-7924 | 1 | Spring-Torsion |
| 12 | 46-8091 | 3 | Screw-HWH |
| 13 | 138-3224 | 2 | Bracket-Cable, Traction |
| 14 | 120-5225 | 1 | Plug-Mulch |
| 15 | 120-6241 | 1 | Shield-Trailing |
| 16 | 49-2040 | 8 | Screw-HWHTF |
| 19 | 139-1692 | 2 | Screw-PTH |
| 20 | 133-8062 | 1 | Decal-Spark Arrestor |
| 21 | 3296-29 | 2 | Nut-Lock, NI |
| 26 | 130-2352-01 | 1 | Baffle-Control |
| 28 | 32144-86 | 3 | Screw-HWHTF |
| 29 | 1-323283 | 1 | Spacer-Shield |
| 30 | 139-5409 | 1 | Screw-HH |
| 31 | 137-3087 | 1 | Nut-Hex |
| 32 | 125-5072 | 1 | Frame Plate Kit |
| 32:1 | 125-2542 | 1 | Plate-Frame |
| 32:2 | 3229-3 | 3 | Screw-CARR |
| 32:3 | 3296-42 | 3 | Nut-Lock, NI |
| 34 | 161-8301 | 3 | Spacer-Frame, 30 In. |
| 35 | 108-4862 | 1 | Screw-HWH Thd Roll |
| 36 | 147-0471 | 1 | Plug-Dome |
| 38 | 139-5408 | 1 | Belt Cover ASM |
| 38:2 | 121-2391 | 1 | Decal-Cover, Belt |
| 39 | 133-8177 | 1 | Chute |


# Spindle and Belt Assembly



# Spindle and Belt Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 121-9107 | 2 | Spindle ASM |
| 1:2 | 120-7935 | 2 | Spacer |
| 1:3 | 138-9770 | 2 | Bearing-Ball |
| 2 | 139-1731 | 9 | Screw-Thd Roll, HWH |
| 3 | 139-6612 | 1 | Shaft-Spindle |
| 4 | 139-6613 | 1 | Shaft-Spindle |
| 5 | 121-9100 | 2 | Sprocket |
| 6 | 130-6664 | 1 | Pulley-Brake, Spindle |
| 7 | 109-9505 | 2 | Washer-Spring |
| 8 | 3296-19 | 2 | Nut-Hex |
| 9 | 139-1726 | 1 | Washer-Rebound |
| 10 | 133-8102 | 1 | Brake Arm ASM |
| 11 | 114-0463 | 2 | Washer-Friction, Composite |
| 12 | 161-8318 | 1 | Spacer |
| 13 | 9114524 | 1 | Bolt-TAP, HH |
| 14 | 139-1723 | 4 | Washer-Flat |
| 16 | 3296-29 | 3 | Nut-Lock, NI |
| 17 | 161-4815 | 2 | Idler-Pulley |
| 18 | 145-4016 | 1 | Bracket-Idler |
| 19 | 120-7024 | 2 | Screw-Shoulder, HWH |
| 20 | 120-3335 | 1 | Belt-Synchronous |
| 21 | 120-5245-03 | 1 | Guide-Belt, Spindle |
| 22 | 120-5236 | 2 | Adapter-Blade |
| 23 | 163-7226 | 1 | Spring-Extension, Brake |
| 24 | 125-2466 | 2 | Bolt-Blade |
| 25 | 49-2040 | 2 | Screw-HWHTF |
| 26 | 120-7082 | 1 | Pulley-Idler |
| 27 | 322-6 | 1 | Screw-HH |
| 28 | 3296-47 | 1 | Nut-Lock,NI |
| 29 | 116-6358-03 | 2 | Blade-Rotary |
| 30 | 121-2336 | 1 | Spring-Flat |
| 33 | 322-9 | 1 | Screw-HH |
| 35 | 133-1964 | 1 | Spacer |


# Side Discharge Chute Assembly



# Side Discharge Chute Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 94-8072 | 1 | Decal-Danger |
| 3 | 137-4795 | 2 | Screw |
| 6 | 133-2630 | 1 | Side Deflector Service ASM |
| 6:1 | 125-5091 | 1 | Deflector-Side |
| 6:2 | 163-7225 | 1 | Spring-Torsion, Cover |
| 6:3 | 112-6416 | 1 | Bracket-Cover |
| 6:4 | 99-5291 | 1 | Rod-Cover |
| 7 | 121-2319 | 1 | Chute-Discharge, Side |
| 8 | 133-9289 | 1 | Fitting-Washout |
| 8:2 | 133-9290 | 1 | O-Ring |
| 9 | 139-1700 | 2 | Screw-HWH, Thd Roll |
| 11 | 95-3270 | 1 | Connector-Hose |
| 12 | 120-9570 | 1 | Decal-Warning |
| 13 | 125-5092 | 1 | Decal-Placement, Foot |


# Grass Bag Assembly



# Grass Bag Assembly (continued)

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 121-5766-03 | 1 | Frame-Bag |
| 2 | 161-8188 | 1 | Bag ASM-Grass |

# Engine and Belt Assembly




# Engine and Belt Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | | 1 | Engine-Briggs, 14D9320110F1 ● |
| 10 | 137-9176 | 1 | Pulley-Engine |
| 11 | 121-5765 | 1 | V-Belt |
| 12 | 120-9470 | 1 | V-Belt, Traction |
| 13 | 139-1734 | 1 | Guide-Belt, Wa |
| 14 | 95-1727 | 3 | Screw-Taptite |
| 15 | 3290-465 | 1 | Washer-Belleville |
| 16 | 26-0671 | 1 | Screw-HH |
| 17 | 32144-1 | 2 | Screw-Taptite |
| 18 | 131-0889-03 | 1 | Guard-Engine |
| 19 | 126-2713 | 2 | Screw-HHF, Patch |
| 30 | 133-8113 | 1 | Decal-Shroud |

● Not serviced separately


# Front Wheel and Height-of-Cut Assembly



# Front Wheel and Height-of-Cut Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 46-8091 | 3 | Screw-HWH |
| 2 | 120-9535 | 1 | Grip-Lever |
| 3 | 119-4042 | 2 | Nut-HF, NI |
| 4 | 147-0519 | 2 | Bushing-Pivot, Front |
| 4:1 | 15-4318 | 1 | Resin-Nylon 66 |
| 5 | 139-1753 | 1 | Front Axle ASM |
| 6 | 120-7037-03 | 1 | Plate-HOC, LH |
| 7 | 120-7038-03 | 1 | Plate-HOC, RH |
| 8 | 120-7043 | 1 | Arm-Spring |
| 9 | 125-2510 | 2 | 8 Inch Wheel ASM |
| 10 | 125-5027 | 1 | Front Cover ASM |
| 10:2 | 120-7047 | 1 | Artwork-Toro Timemaster |
| 11 | 700057 | 1 | Screw-HWH |
| 12 | 137-3061 | 6 | Bolt-CARR |
| 13 | 3296-29 | 6 | Nut-Lock, NI |
| 14 | 130-6658 | 4 | Screw-Flange, Plastic |


# Rear Wheel and Height-of-Cut Assembly



# Rear Wheel and Height-of-Cut Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 137-4796 | 1 | Grip-Lever, Lift |
| 2 | 121-5799 | 1 | Conduit-Convoluted |
| 3 | 49-2040 | 2 | Screw-HWHTF |
| 4 | 119-4042 | 2 | Nut-HF, NI |
| 5 | 104-8699 | 1 | Bearing-Ball |
| 6 | 106-5681 | 1 | Pin-Stop |
| 7 | 133-2603 | 2 | Bearing-Ball |
| 8 | 110-7191 | 2 | Washer-Thrust |
| 9 | 131-5399 | 2 | Gear-Pinion, 15T |
| 10 | 120-3342-03 | 1 | Plate-HOC, LH |
| 11 | 120-3343-03 | 1 | Plate-HOC, RH |
| 12 | 137-9124 | 1 | Arm-Spring |
| 13 | 120-5209 | 1 | Key-Arm, Spring |
| 14 | 136-5929 | 2 | Retainer-Bearing |
| 15 | 131-9665 | 1 | Transmission Kit |
| 15:1:1 | 130-2370 | 1 | Transmission Pulley Kit |
| 15:2 | 130-2369 | 2 | Pin-Snap |
| 15:3 | 32151-61 | 1 | Ring-Retaining |
| 16 | 147-0404 | 2 | Cover-Gear |
| 17 | 147-0401 | 1 | Rear Axle ASM |
| 18 | 125-2509 | 2 | 10 Inch Wheel Gear ASM |
| 19 | 138-3233 | 1 | Mount-Bearing |
| 20 | 120-7026 | 1 | Spring-Extension |
| 21 | 120-7027 | 1 | Spring-Extension |
| 22 | 121-5800 | 2 | Conduit-Convoluted |
| 23 | 701243 | 8 | Screw-Thd Roll, HWH |
| 24 | 32144-4 | 1 | Screw-HWH |
| 25 | 32151-61 | 1 | Ring-Retaining |
| 26 | 36-4780 | 2 | Washer-Plain |
| 27 | 138-5338 | 1 | Bracket-Stop |
| 28 | 3296-47 | 1 | Nut-Lock,NI |
| 29 | 125-2497 | 1 | Decal-HOC, Rear |
| 30 | 130-2369 | 2 | Pin-Snap |

# Handle Assembly



# Handle Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 145-4021-05 | 1 | Handle-Lower, ASM |
| 2 | 145-4004-05 | 1 | Handle-Upper |
| 3 | 139-1694 | 2 | Bolt-Shoulder, HHF |
| 4 | 3296-29 | 2 | Nut-Lock, NI |
| 5 | 140-2367 | 1 | Guide-Curved, LH (Rwd) |
| 6 | 140-2366 | 1 | Guide-Curved, RH (Rwd) |
| 7 | 139-5464 | 1 | Rod-Control, Traction |
| 8 | 139-6554 | 1 | Lever-Traction, Rwd |
| 9 | 140-4194 | 1 | Spring-Torsion |
| 10 | 139-6569 | 1 | Handle-Personal Pace, Curved |
| 11 | 139-6567 | 1 | Bottom-Handle, RH |
| 12 | 139-6568 | 1 | Bottom-Handle, LH |
| 13 | 94-4496 | 10 | Screw-PPH |
| 14 | 161-1162-03 | 1 | Bail-Brake, BBC Welded |
| 15 | 161-3177 | 1 | Cable-Brake |
| 16 | 145-4007 | 1 | Cable-Traction |
| 17 | 117-5975 | 1 | Switch Housing ASM |
| 18 | 139-6581 | 1 | Anchor-Cable, Rwd |
| 19 | 106-9169 | 1 | Screw-HWH |
| 20 | 163-7224 | 1 | Spring-Torsion |
| 21 | 107-7463 | 1 | Spacer |
| 22 | 164-0581 | 1 | Lever [bbc, Timemaster] |
| 23 | 32128-17 | 1 | Nut-Lock, Flange |
| 24 | 139-6577 | 2 | Pin-Handle, Pp |
| 25 | 132-4516 | 2 | Plug-Square |
| 26 | 137-3107 | 2 | Screw-Handle |
| 27 | 117-5976 | 2 | Knob-Handle |
| 28 | 114-7988 | 1 | Guide-Cable |
| 29 | 144-0220 | 1 | Handle-Assist |
| 30 | 99-6005 | 2 | Bolt-Carriage |
| 31 | 137-4808 | 2 | Nut-Acorn |
| 33 | 120-9683 | 1 | Washer-Plain |
| 48 | 112-8884 | 1 | Knob |
| 49 | 321-57 | 1 | Screw-HH |
| 50 | 3256-1 | 1 | Washer-Flat |
| 51 | 3296-73 | 1 | Nut-Lock, NI |
| 52 | 145-5601 | 1 | Decal-Handle, Pp |
| 53 | 139-1709 | 1 | Screw-Shoulder |
| 54 | 137-3085 | 1 | Nut-Hex |

# Attachments and Accessories

## For 21219 — TimeMaster 30in Lawn Mower

| Product Name | Model/Part |
|---|---|
| Fuel Stabilizer .05 oz | 130-2393 |
| Engine Maintenance Kit | 130-8146 |
| 4-Cycle Fuel, Snow And Lawn 32oz Can | 131-3823 |
| Toro Premium Fuel Treatment 12oz Bottle | 131-6572 |
| Oil-30/10W-30 Synthetic (Quart) | 138-6053 |
| Traction Assist Handle Kit | 144-6377 |
| Hi-Lift Replacement Blade Kit | 20122P |
| Lawn Striping Kit with 30in Roller | 20602 |
| Toro 4-Cycle SAE 30 Oil (32oz Bottle) | 38903 |
| Summer Oil-Case of 24 (20oz Bottles) | 38916 |
| Bag-Walk Behind (Toro) | 490-7318 |
| Mower Cover | 490-7461 |

## Notes:

## Notes:

## Notes:




**Count on it.**