



Form No. 3468-540 Rev B

**Count on it.**

# Parts Catalog

## 48in Z Master® 4000 Series Riding Mower

Model No. 74000—Serial No. 416266456 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                                             |    |
|-------------------------------------------------------------|----|
| Frame Assembly . . . . .                                    | 4  |
| Roll-Over Protection System Assembly No. 139-8062 . . . . . | 6  |
| Hydraulic Drive Assembly . . . . .                          | 8  |
| LH Transaxle Assembly No. 145-3696 . . . . .                | 10 |
| RH Transaxle Assembly No. 145-3695 . . . . .                | 12 |
| Throttle Cable and Guard Assembly . . . . .                 | 14 |
| Fuel System Assembly . . . . .                              | 16 |
| Fuel Tank Assembly No. 139-6722 . . . . .                   | 18 |
| Seat Mount Assembly . . . . .                               | 20 |
| Seat Assembly No. 144-2632 . . . . .                        | 22 |
| Motion Control Assembly . . . . .                           | 24 |
| Left and Right Control Arm Assembly . . . . .               | 26 |
| Caster Wheel Assembly . . . . .                             | 28 |
| Caster and Wheel Assembly . . . . .                         | 30 |
| Rear Wheel Assembly . . . . .                               | 32 |
| Electrical Assembly . . . . .                               | 34 |
| Wire Harness Assembly No. 139-8078 . . . . .                | 36 |
| Deck Lift Assembly . . . . .                                | 38 |
| Deck Strut Assembly No. 140-1179 . . . . .                  | 40 |
| Engine, Clutch and Muffler Assembly . . . . .               | 42 |
| Decal Assembly . . . . .                                    | 44 |
| Deck Assembly . . . . .                                     | 46 |
| Deck Decal Assembly No. 147-4995 . . . . .                  | 48 |
| Deflector Assembly No. 144-2635 . . . . .                   | 50 |
| Idler Arm Assembly No. 139-1087 . . . . .                   | 52 |
| Attachments and Accessories . . . . .                       | 54 |

Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 147-7830           | 1           | Frame ASM-48/52        | 14          | 3234-42            | 8           | Screw-HHF              |
| 1:1         |                    | 1           | Frame ASM-48/52 ●      | 17          | 138-9753           | 6           | Screw                  |
| 1:1:2       | 126-4363           | 2           | Decal-Warning          | 19          | 109-9233           | 2           | Bumper-Push-In, Rubber |
| 1:1:3       | 144-2687           | 1           | Decal, Belt Routing    | 22          | 140-4995           | 1           | Toeboard               |
| 2           | 139-8062           | 1           | ASM-ROPS               | 22:2        | 126-8383           | 1           | Decal-Danger           |
| 6           | 138-6098           | 1           | Floor Pan ASM          | 23          | 140-4992           | 1           | Step                   |
| 6:2         | 109-9233           | 2           | Bumper-Push-In, Rubber | 24          | 117-2382           | 6           | Plug-Plastic           |
| 12          | 139-6717-01        | 1           | Plate-Hydro            | 25          | 140-4994-01        | 1           | Bracket-Light          |
| 13          | 109-6658           | 8           | Nut-Flange, NI         | 32          | 140-7950           | 1           | Floormat-Fixed Seat    |

● Not serviced separately

# Roll-Over Protection System Assembly

## No. 139-8062



# Roll-Over Protection System Assembly

## No. 139-8062 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Upper ROPS ASM ●    | 5           | 103-4553           | 2           | ROPS Fold Pin ASM  |
| 1:2         | 107-3069           | 1           | Decal-Warning       | 6           | 99-5107            | 6           | Nut-HF Nylock      |
| 2           |                    | 1           | RH Lower ROPS ASM ● | 7           | 109-5337           | 2           | Bumper-ROPS        |
| 3           |                    | 1           | LH Lower ROPS ASM ● | 8           | 109-9505           | 4           | Washer-Spring      |
| 4           | 126-9209           | 2           | Bolt-Shoulder       | 9           | 325-13             | 4           | Screw-HH           |

● Not serviced separately

# Hydraulic Drive Assembly



## Hydraulic Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 145-3696           | 1           | LH Transaxle ASM W/Arm  | 5           | 3229-28            | 2           | Screw-CARR          |
| 2           | 145-3695           | 1           | RH Transaxle ASM W/Arm  | 6           | 140-1225           | 1           | ASM-Hose, Hydraulic |
| 3           | 3234-38            | 8           | Screw-HHF               | 15          | 104-7201           | 2           | Nut-HF, NI          |
| 4           | 119-9908           | 1           | Hydraulic Reservoir ASM | 18          | 140-7994           | 1           | Belt-V              |
| 4:1         | 109-3320           | 1           | Cap-Reservoir, HYD      |             |                    |             |                     |

# LH Transaxle Assembly No. 145-3696



## LH Transaxle Assembly No. 145-3696 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-----------------------------|
| 61          | 147-1671           | 1           | Kit, Input Shaft   | 136         | 144-6597           | 1           | Kit, Fan And Pulley         |
| 88          | 145-3637           | 1           | Seal, Brake        | 140         | 144-6601           | 1           | Fitting-5/8 Beaded, 7/8 SAE |
| 100         | 144-6598           | 1           | Kit, Filter        | 164         | 125-4684           | 1           | Spring-Extension            |
| 102         | 144-6599           | 1           | Kit, Filler Cap    | 173         | 139-8091           | 1           | Plate-Lever, Bypass         |
| 118         | 144-6594           | 1           | Hub-4 Bolt         | 174         | 119-1415           | 1           | Pin-Cotter, Locking         |
| 120         | 144-6595           | 1           | Nut, Slotted       | 201         | 144-6600           | 1           | Kit, Seal                   |

# RH Transaxle Assembly No. 145-3695




## RH Transaxle Assembly No. 145-3695 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 61          | 147-1671           | 1           | Kit, Input Shaft   |
| 88          | 145-3637           | 1           | Seal, Brake        |
| 100         | 144-6598           | 1           | Kit, Filter        |
| 102         | 144-6599           | 1           | Kit, Filler Cap    |
| 118         | 144-6594           | 1           | Hub-4 Bolt         |
| 120         | 144-6595           | 1           | Nut, Slotted       |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------------|
| 136         | 144-6597           | 1           | Kit, Fan And Pulley         |
| 140         | 144-6601           | 1           | Fitting-5/8 Beaded, 7/8 SAE |
| 164         | 125-4684           | 1           | Spring-Extension            |
| 173         | 139-8091           | 1           | Plate-Lever, Bypass         |
| 174         | 119-1415           | 1           | Pin-Cotter, Locking         |
| 201         | 144-6600           | 1           | Kit, Seal                   |

# Throttle Cable and Guard Assembly



## Throttle Cable and Guard Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 147-2408-03        | 1           | Guard-Muffler           | 39:2        | 133-8062           | 1           | Decal-Spark Arrestor    |
| 2           | 147-6259           | 1           | Rear Guard ASM          | 41          | 138-9753           | 6           | Screw                   |
| 2:2         | 106-5517           | 2           | Decal-Warning           | 43          | 139-6735           | 1           | Cable-Control, Choke    |
| 2:3         | 147-7364           | 1           | Decal-Hitch             | 44          | 139-6734           | 1           | Cable-Control, Throttle |
| 3           | 144-6551-01        | 1           | Console-RH              | 45          | 1-603175           | 1           | Knob-Ball               |
| 4           | 145-1287-01        | 1           | Console-LH              | 46          | 105-8278           | 1           | Decal                   |
| 6           | 140-4867           | 1           | RH Cover ASM            | 48          | 87-6620            | 4           | Screw-Tph Thd Form      |
| 6:2         | 99-8936            | 1           | Decal-Control, Motion   | 49          | 126-9939           | 1           | Decal-Fill, Fuel        |
| 7           | 140-4866           | 1           | LH Cover ASM            | 50          | 140-7987           | 1           | Decal-4000 Series, RH   |
| 7:2         | 99-8936            | 1           | Decal-Control, Motion   | 51          | 140-7979           | 1           | Side Pod, LH            |
| 11          | 1-807513           | 2           | Bolt-CARR               | 52          | 140-7980           | 1           | Side Pod, RH            |
| 12          | 3296-2             | 2           | Nut-Lock, NI            | 53          | 140-7968           | 1           | Cup Holder              |
| 24          | 3230-22            | 2           | Screw-CARR              | 54          | 3230-18            | 4           | Screw-CARR              |
| 25          | 104-8300           | 16          | Nut-HF, NI              | 55          | 140-7996-03        | 1           | Plate-Cover, LH Front   |
| 27          | 126-6267           | 4           | Screw-TTH               | 58          | 140-7998-03        | 1           | Plate-Cover, RH Front   |
| 30          | 126-6268           | 6           | Screw-TTH               | 60          | 130-8451           | 4           | Rivet-Trifold           |
| 31          | 3220-3             | 1           | Nut-HJ                  | 61          | 120-7950           | 8           | Screw-Torx              |
| 32          | 139-1149           | 1           | Decal - 4000 Series, LH | 62          | 140-8019           | 1           | Cupholder-RH            |
| 37          | 145-6964-01        | 1           | Guard-Rear, LH          | 66          | 144-2642           | 2           | Rod-Support, Pod        |
| 38          | 140-1221-01        | 1           | Guard-Rear, Top         | 67          | 3296-59            | 4           | Nut-Lock, NI            |
| 39          | 145-7012           | 1           | RH Rear Guard ASM       |             |                    |             |                         |

# Fuel System Assembly



## Fuel System Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 139-6722           | 1           | *obs* Fuel Tank ASM  | 7:1         | 109-0298           | 1           | Line-Fuel                 |
| 2           | 137-4119           | 1           | Cap-Fuel, Ratcheting | 7:2         | 114-3766           | 1           | Hose-Fuel                 |
| 3           | 104-2490           | 2           | Clamp-Hose           | 7:3         | 1-603770           | 1           | Valve-Fuel                |
| 4           | 131-8834           | 2           | Bumper               | 7:4         | 2412-98            | 4           | Clamp-Hose                |
| 5           | 104-7201           | 2           | Nut-HF, NI           | 8           | 126-5523           | 3           | Clip                      |
| 6           | 139-8067           | 1           | Vent Hose ASM        | 9           | 140-4957           | 1           | ASM-Fuel Vent             |
| 6:1         | 138-3152           | 2           | Hose-Fuel            | 9:1         | 138-3152           | 1           | Hose-Fuel                 |
| 6:2         | 120-2234           | 1           | Fitting-Tee          | 9:2         | 116-4630           | 1           | Fitting-Orifice, Straight |
| 6:3         | 140-4956           | 1           | Hose-Fuel            | 9:3         | 116-4344           | 1           | Hose-Fuel                 |
| 7           | 139-8068           | 1           | Fuel Hose ASM        |             |                    |             |                           |

# Fuel Tank Assembly No. 139-6722




## Fuel Tank Assembly No. 139-6722 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------|
| 2           | 46-6560            | 4           | Bushing                |
| 3           | 140-4955           | 1           | Connector Elbow-90 DEG |
| 4           | 133-9269           | 1           | Grommet-Fuel           |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | 139-8058           | 1           | Gauge-Fuel         |
| 6           | 126-9057           | 2           | Fitting-90 DEG     |
| 7           | 140-4954           | 1           | *obs* Fitting-Tee  |

# Seat Mount Assembly



## Seat Mount Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 140-1165-03        | 1           | Pan-Seat [black]          | 14          | 5-0652             | 4           | Spacer                     |
| 4           | 104-8300           | 6           | Nut-HF, NI                | 15          | 144-2632           | 1           | Seat ASM-Suspension        |
| 5           | 144-2669           | 1           | Decal-Service Aid         | 16          | 109-9233           | 1           | Bumper-Push-In, Rubber     |
| 7           | 147-2436-03        | 1           | Plate-Tank Retainer, Rear | 17          | 147-4987-03        | 1           | Plate-Tank Retainer, Front |
| 8           | 3230-23            | 2           | Bolt-CARR                 | 18          | 130-0733           | 2           | Pad-Rubber                 |
| 10          | 138-9753           | 6           | Screw                     | 19          | 147-4954-01        | 1           | Plate-Backer               |
| 12          | 135-0505           | 4           | Bumper-Seat               | 20          | 130-8451           | 2           | Rivet-Trifold              |
| 13          | 1-543286           | 1           | Grommet                   |             |                    |             |                            |

# Seat Assembly No. 144-2632




## Seat Assembly No. 144-2632 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 140-8012           | 1           | Seat Track Set     |
| 2           | 116-8911           | 1           | Knob-Adjuster      |
| 3           | 126-8559           | 1           | Bellows-Seat       |
| 4           | 145-3641           | 1           | Armrest Kit        |
| 5           | 145-3642           | 1           | Pads-Armrest       |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 126-8560           | 1           | Kit-Seat Belt      |
| 7           | 145-3643           | 1           | Cover-Back, Seat   |
| 8           | 145-3659           | 1           | Cover-Bottom, Seat |
| 9           | 82-2190            | 1           | Switch-Bail        |


# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|------------------------|
| 1           | 147-5046           | 1           | Motion Control ASM-RH | 20          | 139-6726           | 1           | Brake Lever ASM W/Grip |
| 2           | 147-2390           | 1           | RH Handle ASM         | 20:2        | 109-8054           | 2           | Bushing-Flange         |
| 2:2         | 109-5668           | 1           | Grip-Lever, Control   | 20:3        | 132-4749           | 1           | Grip-Lever             |
| 3           | 110-5052           | 4           | Screw-HHF             | 21          | 139-6743           | 1           | Pivot-Handle           |
| 4           | 147-5047           | 1           | Motion Control ASM-LH | 22          | 3234-29            | 1           | Screw-HHF              |
| 5           | 115-5099           | 2           | Bolt-Pivot            | 23          | 116-2670           | 2           | Screw-Shoulder         |
| 6           | 147-2391           | 1           | LH Handle ASM         | 24          | 144-6566           | 1           | Brake Link ASM         |
| 6:2         | 109-5668           | 1           | Grip-Lever, Control   | 24:2        | 116-4976           | 2           | Bushing-Sleeve         |
| 7           | 104-8301           | 2           | Nut-HF, NI            | 25          | 139-6745           | 1           | Plate-Switch           |
| 8           | 142-6851           | 2           | Damper                | 26          | 32144-70           | 2           | Screw-HWHTF            |
| 9           | 126-4424           | 4           | Screw-Shoulder        | 27          | 3230-23            | 2           | Bolt-CARR              |
| 10          | 112-3306           | 2           | Nut                   | 28          | 144-0353           | 2           | Brake Rod ASM          |
| 11          | 126-4299           | 2           | Screw-HSBH            | 28:1        | 140-4952           | 1           | Rod-Brake              |
| 12          | 37-8771            | 2           | Bolt-Shoulder, HF     | 28:2        | 139-6741           | 1           | Fitting-Rod            |
| 13          | 104-8300           | 6           | Nut-HF, NI            | 28:3        | 3256-3             | 1           | Washer-Flat            |
| 14          | 115-9625           | 1           | Decal-Brake, Parking  | 28:4        | 144-2645           | 1           | Spring-Compression     |
| 17          | 144-2658           | 1           | Brake ASM             | 28:5        | 104-8301           | 1           | Nut-HF, NI             |
| 18          | 126-5820           | 2           | Bearing-Spherical     | 29          | 3256-45            | 2           | Washer-Flat            |
| 19          | 139-6742           | 1           | Bracket-Brake         | 30          | 119-1415           | 4           | Pin-Cotter, Locking    |

# Left and Right Control Arm Assembly



## Left and Right Control Arm Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|------------------------|
| 1           | 104-8301           | 1           | Nut-HF, NI            | 7:2         | 126-8909           | 2           | Bushing                |
| 2           | 126-7296           | 1           | Washer-Friction       | 7:3         | 1-413152           | 2           | Bushing-Sleeve         |
| 3           | 147-2389           | 1           | Arm-Control           | 8           | 147-5048           | 1           | Spacer-Actuator        |
| 4           | 142-8478           | 1           | Spacer, Anti-Rotation | 9           | 126-5434           | 1           | Swivel                 |
| 5           | 119-8925           | 1           | Washer-Belleville     | 10          | 140-4949           | 1           | Link-Control           |
| 6           | 117-1198           | 1           | Bolt-Pivot            | 11          | 126-8195           | 1           | Spring-Return, Neutral |
| 7           | 145-5798           | 1           | ASM-Control Arm       | 12          | 104-8300           | 2           | Nut-HF, NI             |

# Caster Wheel Assembly




## Caster Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 2           | Front Caster W/ Fork ASM ● | 4           | 3256-68            | 2           | Washer-Flat        |
| 2           | 109-3678           | 4           | Bearing-Ball               | 5           | 100-1668           | 2           | Screw-HHF          |
| 3           | 145-3660           | 2           | Spacer-Bearing             | 6           | 144-0375           | 2           | Cap-Grease         |

● Not serviced separately

# Caster and Wheel Assembly




## Caster and Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 142-7827-01        | 1           | Fork-Caster              | 2:1:3       | 1-633585           | 2           | Bearing-Cone, Taper |
| 2           | 140-4896           | 1           | Semi Pneumatic ASM       | 2:1:4       | 103-3051           | 1           | Spacer-Nut          |
|             |                    |             | 13X6.50-6                | 2:1:5       | 103-0063           | 2           | Seal-Caster         |
| 2:1         |                    | 1           | Wheel And Bearings ASM ● | 2:2         | 126-5389           | 1           | Screw-HHF           |
| 2:1:2       | 126-7796           | 1           | Caster Axle ASM          | 2:3         | 99-5107            | 1           | Nut-HF Nylock       |
| 2:1:2:1     | 126-5220           | 1           | Axle-Caster              | 2:4         | 103-2768           | 2           | Guard-Seal          |
| 2:1:2:2     | 103-3051           | 1           | Spacer-Nut               |             |                    |             |                     |

● Not serviced separately

# Rear Wheel Assembly



## Rear Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 140-7958           | 2           | Wheel And Tire ASM |
| 1:1         | 140-7967           | 1           | Wheel              |
| 1:2         | 140-7973           | 1           | Tire               |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1:3         | 232-27             | 1           | Stem-Valve         |
| 2           | 242-50             | 8           | Nut-Lug            |

# Electrical Assembly



## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 1-603511           | 1           | Keys-Ignition (Spare Pair)   | 9           | 321-4              | 2           | Screw-HH           |
| 1           | 63-8360            | 1           | Key-Ignition                 | 10          | 3256-22            | 2           | Washer-Flat        |
| 2           | 139-6368           | 1           | Switch-Rocker,<br>On-None-On | 11          | 82-2190            | 2           | Switch-Bail        |
| 3           | 99-8445            | 1           | Screw-HWH                    | 12          | 104-8162           | 1           | Battery            |
| 4           | 110-6765           | 1           | Switch                       | 13          | 142-8697           | 1           | Strap, Bungee      |
| 5           | 116-5609           | 1           | Module ASM                   | 14          | 33094-00           | 1           | Washer-Plain       |
| 6           | 137-4100           | 1           | Switch-Ignition              | 15          | 33114-020          | 1           | Screw-HH           |
| 7           | 139-8078           | 1           | Harness-Wire                 | 25          | 140-7955           | 1           | Port-Power, USB    |
| 8           | 32128-33           | 2           | Nut-HF                       | 27          | 147-7852           | 1           | Bumper-Front       |
|             |                    |             |                              | 28          | 135-2015           | 2           | Screw-Shoulder     |


**Wire Harness Assembly No. 139-8078**



## Wire Harness Assembly No. 139-8078 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-------------------------|
| 11          | 116-0053           | 3           | Cap-Plug                | 16          | 32180-176          | 1           | Cover-Block, Fuse       |
| 12          | 103-3895           | 1           | Diode                   | 17          | 32180-177          | 1           | Clip-Mounting           |
| 13          | 121-8867           | 1           | Fuse-Mini Blade, 15 Amp | 18          | 126-8876           | 1           | Insulator-Battery       |
| 14          | 121-8868           | 1           | Fuse-Mini Blade, 20 Amp | 19          | 1-543393           | 1           | Insulator-Solenoid      |
| 15          | 126-3991           | 1           | Relay-Micro             | 24          | 121-8869           | 1           | Fuse-Mini Blade, 25 Amp |


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 139-5872           | 4           | Bearing-Flange                | 23          | 116-0886           | 1           | Spring-Extension    |
| 2           | 116-2887           | 4           | Gusset-Lift, Deck             | 24          | 92-7674            | 1           | Bolt-Shoulder       |
| 3           | 3230-22            | 8           | Screw-CARR                    | 25          | 126-5401           | 1           | Pin-HOC             |
| 4           | 104-8300           | 8           | Nut-HF, NI                    | 29          | 116-0780           | 1           | Screw-Shoulder, HHF |
| 5           | 139-8050-03        | 1           | Front Deck Lift Shaft ASM     | 30          | 99-5107            | 1           | Nut-HF Nylock       |
| 6           | 140-4975-03        | 1           | Shaft-Lift, Deck              | 31          | 140-4959           | 1           | Pedal-Foot Lift     |
| 7           | 126-4639-03        | 1           | Link-HOC                      | 32          | 3234-42            | 1           | Screw-HHF           |
| 8           | 126-9181           | 2           | Pin-Clevis                    | 42          | 132-4749           | 1           | Grip-Lever          |
| 9           | 138-8491           | 2           | Clip-Pin                      | 51          | 139-6699           | 1           | Decal-HOC           |
| 12          | 145-5702-03        | 4           | Link-Lift, Deck               | 52          | 104-7658           | 1           | Spacer              |
| 13          | 140-1179           | 1           | Deck Strut W/ Bushings<br>ASM | 53          | 9266934            | 1           | Screw               |
| 14          | 1-373034           | 2           | Washer                        | 60          | 2844               | 1           | Washer              |
| 15          | 109-6658           | 2           | Nut-Flange, NI                | 63          | 130-0742           | 8           | Bolt-Shoulder       |
| 16          | 3231-7             | 2           | Screw-CARR                    | 64          | 43-0940            | 8           | Spacer              |
| 20          | 145-8475-03        | 1           | Plate-Transport Lock          | 65          | 104-8301           | 8           | Nut-HF, NI          |

# Deck Strut Assembly No. 140-1179




## Deck Strut Assembly No. 140-1179 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            |
|-------------|--------------------|-------------|-------------------------------|
| 2           | 126-8360           | 4           | Bushing-Rubber,<br>Suspension |
| 3           | 108-6544           | 4           | Spacer                        |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 4           | 3231-7             | 2           | Screw-CARR         |
| 5           | 2844               | 2           | Washer             |
| 6           | 104-8301           | 2           | Nut-HF, NI         |

# Engine, Clutch and Muffler Assembly



## Engine, Clutch and Muffler Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-----------------------------|-------------|--------------------|-------------|---------------------------|
| 1           |                    | 1           | Engine-Kawasaki ■ ▲         | 11          | 144-2671           | 1           | Idler Arm ASM             |
| 1:1         | KW10761            | 1           | Filter-Oil Kaw              | 11:2        | 138-2573           | 2           | Bushing-Flange            |
| 1:2         | 142-6949           | 1           | Filter-Fuel                 | 12          | 140-4964           | 1           | Pulley-Idler, Flat        |
| 1:3         | 119-5945           | 1           | Element-Filter, Air (Inner) | 14          | 3231-42            | 1           | Screw-CARR                |
| 1:4         | 119-5944           | 1           | Element-Filter, Air (Outer) | 15          | 3231-29            | 1           | Screw-CARR                |
| 1:5         | 92-2153            | 2           | Plug-Spark                  | 16          | 139-6690           | 1           | Bushing, Idler Pivot      |
| 2           | 1-653313           | 2           | Gasket-Exhaust              | 17          | 3256-4             | 1           | Washer-Flat               |
| 3           | 139-6702           | 1           | Sheave, W/Hub               | 18          | 104-8301           | 2           | Nut-HF, NI                |
| 4           | 1-807259           | 1           | Key                         | 22          | 116-4924           | 1           | Engine Oil Drain Hose ASM |
| 5           | 140-1190           | 1           | Anchor-Clutch               | 22:1        | 353-508            | 1           | Plug-HH ●                 |
| 6           | 98-5975            | 4           | Washer-Belleville           | 22:1:1      | 237-42             | 1           | O-Ring                    |
| 7           | 109-6919           | 1           | Washer-Plain                | 23          | 139-1079           | 1           | Muffler                   |
| 8           | 1-603610           | 2           | Washer-Spring               | 24          | 1-653331           | 1           | Spring-Idler              |
| 9           | 109-9761           | 1           | Screw-HH                    | 25          | 116-1947           | 1           | Clutch                    |
| 10          | 323-7              | 4           | Screw-HH                    |             |                    |             |                           |

● Torque to 24-26 ft-lb

▲ Obtain parts from [www.kawpower.com](http://www.kawpower.com)

■ Not serviced separately


# Decal Assembly



## Decal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1           | 144-0438           | 1           | Decal - Pro          |
| 2           | 144-0439           | 1           | Decal - Pro          |
| 9           | 144-0405           | 1           | Decal-Panel, Control |


# Deck Assembly



## Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 147-4995           | 1           | Deck Decal ASM          | 20          | 109-6935           | 1           | Cover-Belt, RH            |
| 2           | 137-9780           | 3           | Spindle ASM             | 21          | 3230-3             | 1           | Screw-CARR                |
| 2:2         | 116-0720           | 2           | Bearing-Ball            | 22          | 104-8300           | 2           | Nut-HF, NI                |
| 2:3         | 138-6042           | 1           | Spacer-Bearing          | 23          | 126-4781-03        | 1           | Step-Deck                 |
| 3           | 104-8301           | 32          | Nut-HF, NI              | 24          | 144-2635           | 1           | Rubber Deflector ASM      |
| 4           | 137-9784           | 3           | Guard-Bottom            | 25          | 322-50             | 1           | Screw-HH                  |
| 5           | 138-6045           | 3           | Shaft-Spindle           | 26          | 105-4622           | 1           | Spacer                    |
| 6           | 140-1243           | 3           | Blade-16.50 High Flow   | 27          | 108-4052           | 1           | Spring-Torsion            |
| 7           | 137-9787           | 3           | Bushing-Hex             | 28          | 139-8061           | 2           | Bushing, Idler            |
| 8           | 109-9220           | 3           | Screw-Sems              | 29          | 132-9425           | 2           | Pulley-Idler, Flat        |
| 9           | 103-1330           | 3           | Guard-Bearing, Top      | 30          | 3231-7             | 2           | Screw-CARR                |
| 10          | 138-6065           | 3           | Sheave,Blade Drive 5.91 | 31          | 109-6658           | 2           | Nut-Flange, NI            |
| 11          | 103-2802           | 3           | Washer                  | 32          | 108-5388           | 1           | Screw-HH                  |
| 12          | 116-7306           | 3           | Nut-Hex                 | 33          | 98-5967            | 1           | Spacer-Wheel              |
| 13          | 3231-27            | 8           | Screw-CARR              | 34          | 147-4976-03        | 1           | Plate-Turbo Force [black] |
| 14          | 107-8541-01        | 1           | Baffle-Discharge        | 35          | 130-8451           | 2           | Rivet-Trifold             |
| 15          | 1-603299           | 3           | Roller-Scalp, Anti      | 36          | 109-6936           | 1           | Cover-Belt, LH            |
| 16          | 323-23             | 1           | Screw-HH                | 37          | 144-0358           | 1           | Belt-V                    |
| 17          | 133-2129           | 1           | Tube-Shafting           | 38          | 139-1087           | 1           | Idler Arm ASM             |
| 18          | 133-2128           | 1           | Tube-Spacer             | 39          | 116-6317           | 1           | Spring-Extension          |
| 19          | 109-6982           | 2           | Wireform-Cover          |             |                    |             |                           |

Deck Decal Assembly No. 147-4995




## Deck Decal Assembly No. 147-4995 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 1           |                    | 1           | Deck ASM W/Decals ● |
| 1:2         | 117-3848           | 2           | Decal-Danger        |
| 1:3         | 127-0326           | 1           | Decal-Scalp, Anti   |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 1:4         | 116-8283           | 1           | Decal-Torque, Bolt  |
| 1:5         | 109-6035           | 1           | Decal-Routing, Belt |

● Not serviced separately

# Deflector Assembly No. 144-2635




## Deflector Assembly No. 144-2635 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------|
| 1           | 3231-5             | 4           | Screw-CARR             |
| 2           | 106-3246-01        | 1           | Deflector              |
| 3           | 106-3248-03        | 1           | Strap-Discharge        |
| 4           | 161-3464           | 1           | Deflector-Deck, Rubber |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | 108-4059-01        | 1           | Plate-Hinge, Rear  |
| 6           | 106-3253-01        | 1           | Plate-Hinge, Front |
| 7           | 104-8301           | 4           | Nut-HF, NI         |

# Idler Arm Assembly No. 139-1087



## Idler Arm Assembly No. 139-1087 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1           | 139-1086           | 1           | Idler Arm ASM        |
| 2           | 138-2573           | 2           | Bushing-Flange       |
| 3           | 139-8060           | 1           | Bushing, Idler       |
| 4           | 132-9424           | 1           | Pulley-Idler, Flat   |
| 5           | 139-6690           | 1           | Bushing, Idler Pivot |
| 6           | 1-213069           | 3           | Washer               |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 7           | 109-6658           | 3           | Nut-Flange, NI       |
| 8           | 323-15             | 1           | Screw-HH             |
| 9           | 3231-5             | 1           | Screw-CARR           |
| 10          | 132-4729           | 1           | Anchor-Spring, Short |
| 11          | 136-9028           | 1           | Bolt-Shoulder, HWH   |
| 12          | 104-8301           | 1           | Nut-HF, NI           |

# Attachments and Accessories

## For 74000 — 48in Z Master 4000 Series Riding Mower

| Product Name                                                          | Model/Part |
|-----------------------------------------------------------------------|------------|
| HYPR-OIL 500 (quart) .....                                            | 114-4713   |
| HYPR-OIL 500 (gallon).....                                            | 114-4714   |
| HYPR-OIL 500-5 (5 gallon).....                                        | 114-4715   |
| Striper Kit.....                                                      | 126-7882   |
| Jack Kit .....                                                        | 127-6666   |
| Tweel-Turf Tire.....                                                  | 139-3649   |
| Recycler Kit .....                                                    | 139-6650   |
| Blade-16.50 High Flow .....                                           | 140-1243   |
| Blade-16.50 Medium Flow .....                                         | 140-4860   |
| Blade-16.50 Low Flow .....                                            | 140-4861   |
| Blade-16.50 Atomic .....                                              | 140-4862   |
| Blade-16.50 Recycler .....                                            | 140-4863   |
| 6 Pack-Blade, 16.5 High Flow.....                                     | 140-4887   |
| 6 Pack-Blade, 16.5 Med Flow .....                                     | 140-4888   |
| 6 Pack-Blade, 16.5 Low Flow .....                                     | 140-4889   |
| 6 Pack-Blade, 16.5 Atomic.....                                        | 140-4890   |
| 6 Pack-Blade, 16.5 Recycler.....                                      | 140-4891   |
| Base Light Kit.....                                                   | 144-0389   |
| Trimmer Mount .....                                                   | 144-2665   |
| Jack Mount Kit .....                                                  | 144-2676   |
| 48in Chute Gate Kit .....                                             | 144-2688   |
| Handle Extension Kit .....                                            | 145-3615   |
| Voodoo Trac Assembly 24x9.5-12 .....                                  | 147-5029   |
| Blade-16.50 High Flow .....                                           | 147-6250   |
| 6 Pack-Blade, 16.50 High Flow.....                                    | 147-6254   |
| 13x6.5n6 Caster Tweel Asm .....                                       | 147-6294   |
| Bucket Mount Kit, Z Master 2000 or 4000 Series Riding Mower .....     | 147-6345   |
| Universal Mount Kit, Z Master 2000 or 4000 Series Riding Mower .....  | 147-6346   |
| Kit-Baffle, Turbo Force 48 .....                                      | 147-7360   |
| Electric Deck Lift Kit .....                                          | 147-7867   |
| 2in Reciever Hitch Kit.....                                           | 161-2810   |
| Actuator Replacement Kit,412200557 Below .....                        | 161-3549   |
| Electric Deck Lift Actuator Replacement Kit, SN 412200557 Below ..... | 161-3550   |
| Fuel Pickup with Screen Kit .....                                     | 161-6806   |
| Spark Arrestor Screen .....                                           | 75-6880    |
| Bagger Kit, Z Master 2000 / 4000 .....                                | 78439      |
| Z 4000 48in Completion Kit.....                                       | 78464      |

**Notes:**



**Count on it.**