



Form No. 3469-540 Rev B

**Count on it.**

# Parts Catalog

## 53cm Heavy-Duty Recycler®/Rear Bagger

Lawn Mower

Model No. 22285—Serial No. 417000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Frame Assembly..... 4

Grass Bag Assembly ..... 6

Engine and Blade Assembly..... 8

Front Wheel and Height-of-Cut Assembly ..... 10


Transmission and Rear Wheel Assembly..... 12

Transmission Assembly No. 131-5350..... 14

Handle Assembly ..... 16

Attachments and Accessories ..... 18


# Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 136-5897           | 1           | Housing ASM        | 10          | 104-8300           | 2           | Nut-HF, NI         |
| 1:2         | 112-8760           | 1           | Decal-Danger       | 11          | 3230-3             | 2           | Screw-CARR         |
| 2           | 125-1002-01        | 1           | Floor-Chute        | 12          | 125-1047-03        | 2           | Guard-Side, Deck   |
| 3           | 3229-2             | 4           | Screw-CARR         | 13          | 125-8387           | 1           | Clamp-Cable        |
| 4           | 104-7201           | 4           | Nut-HF, NI         | 16          | 32115-15           | 1           | Nut-Push           |
| 5           | 125-5041           | 2           | Kicker             | 17          | 32144-86           | 1           | Screw-HWHTF        |
| 6           | 49-2040            | 8           | Screw-HWHTF        | 18          | 125-8435-03        | 1           | Guard-Toe, Front   |
| 7           | 125-5038           | 1           | Cover-Belt, Front  | 23          | 119-2368           | 1           | Decal-Recycler     |
| 8           | 125-5039           | 1           | Cover-Belt, Rear   | 24          | 125-8420           | 1           | Decal              |
| 9           | 140-3880-03        | 1           | Guard-Engine       |             |                    |             |                    |


Grass Bag Assembly



## Grass Bag Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 125-1017           | 1           | Rod-Door, Bag      | 7           | 125-1008           | 1           | Plug-Mulch                 |
| 2           | 125-8402           | 1           | Bag Door ASM       | 8           | 125-1007           | 1           | Shield-Trailing            |
| 2:2         | 116-7583           | 1           | Decal-Warning      | 9           | 125-8413           | 1           | Rod-Shield, Trailing       |
| 3           | 125-1019           | 1           | Spring-Torsion     | 10          | 133-8193-03        | 1           | Bracket-Mount, Handle (LH) |
| 4           | 1-513658           | 2           | Bumper             | 11          | 133-8194-03        | 1           | Bracket-Mount, Handle (RH) |
| 5           | 121-1399-03        | 1           | Frame-Bag          | 12          | 32144-70           | 4           | Screw-HWHTF                |
| 6           | 125-1030           | 1           | Bag-Grass          |             |                    |             |                            |

# Engine and Blade Assembly




## Engine and Blade Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|--------------------------------|
| 1           |                    | 1           | Engine-Kawasaki, Fj180V ● | 27          | 138-3225           | 1           | Disk                           |
|             |                    |             | ■                         | 28          | 130-6405-03        | 1           | Spacer-Driver, Blade           |
| 2           | 110-0520           | 1           | Decal                     | 29          | 107-7487           | 1           | Support-Blade                  |
| 3           | 125-1073           | 4           | Screw-HWH                 | 30          | 133-8183-03        | 1           | Blade-Recycling 21In (Bagging) |
| 5           | 104-7201           | 3           | Nut-HF, NI                | 31          | 125-1069-03        | 1           | Accelerator-Blade              |
| 6           | 130-2377           | 2           | Bushing-Flange            | 32          | 127-6852           | 2           | Nut-Flange, Lock               |
| 7           | 130-2375           | 1           | Plate-Anchor              | 33          | 117-3510           | 1           | Tank-Fuel                      |
| 8           | 3231-25            | 1           | Bolt-CARR                 | 33:1        | 117-7400           | 1           | Fitting-Plastic                |
| 10          | 42-3560            | 1           | Bolt-Shoulder             | 34          | 93-7198            | 1           | Cap-Gas                        |
| 11          | 125-8446           | 1           | Plate-Guide, BBC          | 35          | 109-0297           | 1           | Hose-Fuel                      |
| 12          | 110-1790           | 1           | Belt                      | 36          | 125-8381-03        | 1           | Bracket-Tank, Mounting         |
| 13          | 605256             | 1           | Spacer                    | 37          | 125-8382-03        | 1           | Bracket-Tank, Support          |
| 14          | 138-3217           | 1           | Retainer-Belt             | 38          | 46-8091            | 2           | Screw-HWH                      |
| 15          | 38-7820            | 3           | Bearing-Ball              | 39          | 125-8383           | 3           | Screw-HWH                      |
| 16          | 107-0758           | 1           | Spacer-Bearing            | 40          | 107-0588           | 1           | Hose-Fuel                      |
| 17          | 130-9699           | 1           | Bolt-Shoulder             | 41          | 2412-98            | 4           | Clamp-Hose                     |
| 18          | 125-1063           | 1           | Plate-Brake               | 42          | 1-603770           | 1           | Valve-Fuel                     |
| 19          | 125-5069           | 2           | Nut-Hex                   | 43          | 130-9654           | 1           | Wire-Control                   |
| 20          | 108-3792           | 1           | Spring-Tension, Brake     | 44          | 3229-30            | 1           | Screw-CARR                     |
| 21          | 117-5970           | 1           | Pulley                    | 45          | 130-6440-03        | 1           | Bracket-Mount, Throttle        |
| 22          | 3211-42            | 2           | Screw-HH                  | 46          | 130-9655           | 1           | Control-Throttle               |
| 23          | 126-8108           | 1           | Drum                      | 47          | 130-9656           | 1           | Decal-Throttle, Choke          |
| 24          | 108-9342           | 1           | Nut-Hex                   | 48          | 32115-15           | 3           | Nut-Push                       |
| 25          | 125-1006           | 1           | Cover                     | 49          | 125-8440           | 1           | Cup-Anti Scalp                 |
| 26          | 32144-86           | 3           | Screw-HWHTF               |             |                    |             |                                |

● Not serviced separately

■ Obtain parts from [www.kawpower.com](http://www.kawpower.com)


# Front Wheel and Height-of-Cut Assembly



## Front Wheel and Height-of-Cut Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 121-1439           | 2           | Plate-HOC, Front          | 11          | 121-1431-03        | 2           | Arm-Spring          |
| 2           | 49-2040            | 4           | Screw-HWHTF               | 12          | 104-2065           | 2           | Screw-HWH           |
| 3           | 136-5871           | 2           | Bushing-Axle, Front (HOC) | 13          | 130-6420           | 2           | Arm-Pivot, Front    |
| 4           | 130-6434           | 2           | Retainer-Bushing, Axle    | 14          | 99-5107            | 2           | Nut-HF Nylock       |
| 5           | 321-37             | 4           | Screw-HH                  | 15          | 323-13             | 2           | Screw-HH            |
| 6           | 104-7201           | 4           | Nut-HF, NI                | 16          | 74-1671            | 2           | Spacer-Cover, Wheel |
| 7           | 133-2644           | 2           | Axle-Front HOC            | 17          | 133-2639           | 2           | Wheel               |
| 8           | 104-8301           | 2           | Nut-HF, NI                | 17:2        | 133-2603           | 2           | Bearing-Ball        |
| 9           | 125-1093           | 2           | Knob-Lever, HOC           | 17:3        | 125-1077           | 1           | Spacer              |
| 10          | 131-5377           | 2           | Key-Arm, Spring           | 18          | 104-8300           | 2           | Nut-HF, NI          |

# Transmission and Rear Wheel Assembly




## Transmission and Rear Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 131-5350           | 1           | Transmission              | 16          | 121-1448-03        | 2           | Arm-Spring, Rear     |
| 2           | 125-5090-03        | 1           | Guide-Belt                | 17          | 136-5894           | 2           | Bearing Retainer ASM |
| 3           | 125-5040           | 1           | Lever-Shift               | 17:2        | 133-2606           | 2           | Bearing-Ball, Custom |
| 4           | 130-9681           | 1           | Cover-Shaft, Transmission | 18          | 133-2668           | 2           | Screw-HH             |
| 5           | 125-1011           | 1           | Belt-V                    | 19          | 133-2635           | 2           | Cover-Wheel          |
| 6           | 127-6848           | 2           | Cover-Bearing             | 20          | 32151-61           | 4           | Ring-Retaining       |
| 7           | 32151-10           | 2           | Ring-Retaining            | 21          | 131-5399           | 2           | Gear-Pinion, 15T     |
| 8           | 98-1452            | 2           | Washer-Thrust             | 22          | 74-1671            | 2           | Spacer-Cover, Wheel  |
| 9           | 130-6422           | 2           | Plate-HOC, Rear           | 23          | 133-2640           | 2           | 9-Inch Wheel ASM     |
| 10          | 49-2040            | 9           | Screw-HWHTF               | 23:1        |                    | 1           | Wheel ●              |
| 11          | 323-13             | 2           | Screw-HH                  | 23:1:2      | 133-2603           | 2           | Bearing-Ball         |
| 12          | 133-2641           | 2           | Arm-Pivot, Rear           | 23:1:3      | 125-1077           | 1           | Spacer               |
| 13          | 131-5377           | 2           | Key-Arm, Spring           | 24          | 104-8301           | 2           | Nut-HF, NI           |
| 14          | 125-1093           | 2           | Knob-Lever, HOC           | 25          | 104-7201           | 1           | Nut-HF, NI           |
| 15          | 104-2065           | 2           | Screw-HWH                 |             |                    |             |                      |

● Not serviced separately


# Transmission Assembly No. 131-5350



## Transmission Assembly No. 131-5350 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 130-2301           | 1           | Nut-Flange               | 21          | 130-2302           | 10          | Screw                       |
| 2           | 130-2326           | 2           | Flange-Pulley            | 22          | 130-2317           | 1           | Gear-Output, 32 Tooth       |
| 3           | 130-2336           | 1           | Case-Upper, Transmission | 23          | 133-2614           | 2           | Key                         |
| 4           | 130-2318           | 1           | Bearing-Ball             | 24          | 133-2612           | 1           | Shaft-Output, Long          |
| 5           | 130-2311           | 1           | Gear-Bevel, 53 Tooth     | 25          | 133-2617           | 1           | Spacer-Long                 |
| 6           | 130-2327           | 1           | Fork-Shift               | 26          | 133-2616           | 2           | Pin                         |
| 7           | 133-2611           | 1           | Shaft-Output, Short      | 27          | 133-2613           | 1           | Hub-Gear, Output            |
| 8           | 130-2322           | 1           | Spring-Retaining         | 28          | 130-2306           | 1           | Shaft-Shift                 |
| 9           | 130-9708           | 2           | Bearing-Ball             | 29          | 130-2304           | 1           | Ring-Retaining              |
| 10          | 130-2325           | 2           | Seal                     | 30          | 130-2319           | 1           | Bearing-Ball                |
| 11          | 130-2333           | 2           | Bushing-Shaft, Output    | 31          | 130-2314           | 1           | Gear-Intermediate, 14 Tooth |
| 12          | 133-2615           | 2           | Spring                   | 32          | 130-2313           | 1           | Gear-Intermediate, 15 Tooth |
| 13          | 130-2328           | 2           | Key-Shift                | 33          | 130-2312           | 1           | Gear-Intermediate, 17 Tooth |
| 14          | 130-2329           | 1           | Ring-Shift               | 34          | 130-2307           | 1           | Shaft-Intermediate          |
| 15          | 130-2315           | 1           | Gear-Output, 22 Tooth    | 35          | 130-2303           | 1           | Nut-Shaft, Input            |
| 16          | 130-2316           | 1           | Gear-Output, 25 Tooth    | 36          | 130-2310           | 1           | Gear-Bevel, 12 Tooth        |
| 17          | 130-2321           | 1           | Spring-Indexing, Shifter | 37          | 130-2324           | 2           | Seal                        |
| 18          | 130-2332           | 1           | Pin-Indexing, Shifter    | 38          | 130-2300           | 1           | Shaft-Input                 |
| 19          | 130-2331           | 1           | Lever-Indexing, Shifter  | 39          | 130-9708           | 2           | Bearing-Ball                |
| 20          | 130-2337           | 1           | Case-Lower, Transmission | 40          | 133-2618           | 1           | Spacer-Short                |

# Handle Assembly



## Handle Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 111-8990           | 1           | Clamp-Bar                  | 20          | 145-4022-03        | 1           | Handle-Upper           |
| 2           | 09688              | 3           | Washer-Nylon               | 21          | 134-5087-03        | 2           | Lower Handle           |
| 3           | 134-2660           | 1           | Anchor Plate Welded        | 22          | 104-8300           | 8           | Nut-HF, NI             |
| 4           | 134-1761           | 1           | Bush, Igus (8 X 9 X 8)     | 23          | 137-3009           | 8           | Washer-Cup             |
| 5           | 0201086            | 1           | Washer-Starlock            | 24          | 322-39             | 4           | Screw-HH               |
| 6           | 134-2284           | 1           | Lever-Bail Arm, Spring     | 25          | 3230-4             | 2           | Screw-CARR             |
| 7           | 111-8908           | 1           | Latch-Pin                  | 26          | 115-1794           | 2           | Screw-HHF              |
| 8           | 134-3208           | 1           | Starlock-Domed             | 27          | 144-6379           | 2           | Plug-Round Tube, 1 In. |
| 9           | 111-8906           | 1           | Lever-Bail, Spring         | 28          | 145-5850           | 1           | Cable-BBC              |
| 10          | 111-8903           | 1           | Lever-Catch                | 29          | 161-8211           | 1           | Cable-Traction         |
| 11          | 111-0718           | 1           | Fastener-Starlock, Push-On | 30          | 134-5187-03        | 2           | Guard-Cable, Handle    |
| 12          | 134-2027           | 1           | Clip-Tree                  | 32          | 108-0988           | 4           | Screw-CARR             |
| 13          | 09687              | 1           | Screw                      | 33          | 114-3778           | 4           | Nut-HF                 |
| 14          | 340182             | 1           | Pin-Pivot                  | 34          | 134-2608           | 1           | Arm-Bail               |
| 15          | 145-4027           | 1           | Button-Latch, BBC          | 35          | 144-0221           | 2           | Screw-CARR             |
| 16          | 111-9381-03        | 1           | Lever-Clutch, Gearbox      | 36          | 134-2662           | 1           | BBC Linkage Assembly   |
| 17          | 42-3560            | 1           | Bolt-Shoulder              | 37          | 94-2691            | 1           | Screw-HWH Taptite      |
| 18          | 133-8199           | 1           | Anchor-Cable               | 38          | 136-9075           | 2           | Washer-Curved          |
| 19          | 104-7201           | 2           | Nut-HF, NI                 | 39          | 131-0822           | 1           | Decal                  |

# Attachments and Accessories

## For 22285 — 53cm Heavy-Duty Recycler/Rear Bagger Lawn Mower

| Product Name            | Model/Part |
|-------------------------|------------|
| Rear Discharge Kit..... | 130-9734   |

## For 22285 — 53cm Heavy-Duty Recycler/Rear Bagger Lawn Mower

| Product Name            | Model/Part |
|-------------------------|------------|
| Rear Discharge Kit..... | 130-9734   |

**Notes:**



**Count on it.**