Form No. 3451-917 Rev B

TORO®

Count on it.

Parts Catalog

53cm Heavy-Duty 60V

Recycler®/Rear Bagger Lawn Mower

Model No. 22275T—Serial No. 411500000 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3451-917 B

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Housing Assembly 4
Grass Bag Assembly 6
Motor Module and Blade Assembly 8
Motor Module No. 140-4161 Lower Shroud Assembly 10
Motor Module No. 140-4161 Upper Shroud Assembly 12
Front Wheel and Height-of-Cut Assembly 14
Transmission and Rear Wheel Assembly 16
Handle Assembly 18
Attachments and Accessories 20

© 2026—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


Housing Assembly



Housing Assembly (continued)

Ref.	Part Number	Qty.	Description
1	136-5897	1	Housing ASM
1:2	112-8760	1	Decal-Danger
2	125-1002-01	1	Floor-Chute
3	3229-2	1	Screw-CARR
4	104-7201	1	Nut-HF, NI
5	125-5041	2	Kicker
6	49-2040	7	Screw-HWHTF
7	125-5038	1	Cover-Belt, Front
8	125-8380	1	Cover-Belt, Rear
9	140-3880-03	1	Guard-Engine
10	104-8300	2	Nut-HF, NI
11	3230-3	2	Screw-CARR
16	32115-15	1	Nut-Push
17	32144-86	1	Screw-HWHTF
18	125-8435-03	1	Guard-Toe, Front
23	119-2368	1	Decal-Recycler
24	125-8420	1	Decal


Grass Bag Assembly



Grass Bag Assembly (continued)

Ref.	Part Number	Qty.	Description
1	125-1017	1	Rod-Door, Bag
2	125-8402	1	Bag Door ASM
2:2	116-7583	1	Decal-Warning
3	125-1019	1	Spring-Torsion
4	1-513658	2	Bumper
5	121-1399-03	1	Frame-Bag
6	125-1030	1	Bag-Grass
7	125-1008	1	Plug-Mulch
8	125-1007	1	Shield-Trailing
9	125-8413	1	Rod-Shield, Trailing
10	133-8193-03	1	Bracket-Mount, Handle (LH)
11	133-8194-03	1	Bracket-Mount, Handle (RH)
12	32144-70	4	Screw-HWHTF


Motor Module and Blade Assembly



Motor Module and Blade Assembly (continued)

Ref.	Part Number	Qty.	Description
1	140-4161	1	Motor Module
2	95-1727	3	Screw-Taptite
3	125-8396	1	Pulley-Driver
4	125-1004	1	Driver-Blade
5	125-8370	1	Protector-Crankshaft
6	32144-70	3	Screw-HWHTF
7	133-8183-03	1	Blade-Recycling 21In (Bagging)
8	125-1069-03	1	Accelerator-Blade
9	125-2466	1	Bolt-Blade
10	125-1024	1	Cover-Belt
11	49-2040	1	Screw-HWHTF


Motor Module No. 140-4161 Lower Shroud Assembly



Motor Module No. 140-4161 Lower Shroud Assembly (continued)

Ref.	Part Number	Qty.	Description
1	139-6628	1	Base-Mount, Motor
2	140-4119	1	Motor-2Kw
3	131-9732	3	Insert-Mount, Motor
4	137-4795	3	Screw
5	115-7373	4	Nut-Lock
6	140-4118	1	Shroud-Lower
7	139-6632	1	Battery Reciever ASM
8	139-6633	1	Shroud-Motor
9	130-6658	6	Screw-Flange, Plastic
10	140-4162	1	Controller-Motor
11	139-6642	4	Screw
12	139-6635	1	Bracket-Foam
13	138-3273	1	Screw-Plastic, PPH
14	139-6636	1	Foam
15	133-1918	1	Bail Switch ASM
15:4	104-6478	1	Spring-Extension
16	139-6637	1	Harness-Wire


Motor Module No. 140-4161
Upper Shroud Assembly



Motor Module No. 140-4161
Upper Shroud Assembly (continued)

Ref.	Part Number	Qty.	Description
1	140-3886	1	Shroud-Upper
2	114-5896	2	Magnet
3	130-6658	8	Screw-Flange, Plastic
4	139-6639	1	Hood
5	139-6640	1	Spring-LH
6	139-6641	1	Spring-RH
7	95-4234	2	Screw-PPH
8	140-4126	1	Decal-Hood, Top
9	140-4127	1	Decal-Hood, Front


Front Wheel and Height-of-Cut Assembly



Front Wheel and Height-of-Cut Assembly (continued)

Ref.	Part Number	Qty.	Description
1	121-1439	2	Plate-HOC, Front
2	49-2040	4	Screw-HWHTF
3	136-5871	2	Bushing-Axle, Front (HOC)
4	130-6434	2	Retainer-Bushing, Axle
5	321-37	4	Screw-HH
6	104-7201	4	Nut-HF, NI
7	133-2644	2	Axle-Front HOC
8	104-8301	2	Nut-HF, NI
9	125-1093	2	Knob-Lever, HOC
10	131-5377	2	Key-Arm, Spring
11	121-1431-03	2	Arm-Spring
12	104-2065	2	Screw-HWH
13	130-6420	2	Arm-Pivot, Front
14	99-5107	2	Nut-HF Nylock
15	323-13	2	Screw-HH
16	74-1671	2	Spacer-Cover, Wheel
17	133-2639	2	Wheel
17:2	133-2603	2	Bearing-Ball
17:3	125-1077	1	Spacer
18	104-8300	2	Nut-HF, NI

Transmission and Rear Wheel Assembly




Transmission and Rear Wheel Assembly (continued)

Ref.	Part Number	Qty.	Description
1	140-4011	1	Transmission-HD
2	140-4012-03	1	Belt Guide ASM
3	27-0220	3	Screw-Special
4	130-9681	1	Cover-Shaft, Transmission
5	125-8395	1	Belt-V
6	127-6848	2	Cover-Bearing
7	32151-10	2	Ring-Retaining
8	98-1452	2	Washer-Thrust
9	130-6422	2	Plate-HOC, Rear
10	49-2040	6	Screw-HWHTF
11	323-13	2	Screw-HH
12	133-2641	2	Arm-Pivot, Rear
13	131-5377	2	Key-Arm, Spring
14	125-1093	2	Knob-Lever, HOC
15	104-2065	2	Screw-HWH
16	121-1448-03	2	Arm-Spring, Rear
17	136-5894	2	Bearing Retainer ASM
17:2	133-2606	2	Bearing-Ball, Custom
18	133-2668	2	Screw-HH
19	133-2635	2	Cover-Wheel
20	32151-61	4	Ring-Retaining
21	131-5399	2	Gear-Pinion, 15T
22	74-1671	2	Spacer-Cover, Wheel
23	133-2640	2	9-Inch Wheel ASM
23:1		1	Wheel ●
23:1:2	133-2603	2	Bearing-Ball
23:1:3	125-1077	1	Spacer
24	104-8301	2	Nut-HF, NI

● Not serviced separately

Handle Assembly



Handle Assembly (continued)

Ref.	Part Number	Qty.	Description
1	134-5087-03	2	Lower Handle
2	145-4022-03	1	Handle-Upper
3	3230-4	2	Screw-CARR
4	119-4041	8	Nut-HF
5	322-39	4	Screw-HH
6	137-3009	8	Washer-Cup
7	134-5187-03	1	Guard-Cable, Handle
8	108-0988	2	Screw-CARR
9	137-3016	2	Nut-HF
10	140-3891	1	Starter Switch ASM
10:3	140-4231	1	Starter Button Service ASM
12	140-4168-03	1	Guard-Housing, Switch
13	134-5188	2	Spacer
14	137-9142	1	Screw-CARR
15	136-7081	1	Screw-CARR
16	104-7201	3	Nut-HF, NI
17	161-8211	1	Cable-Traction
18	144-3180	1	Cable-Brake
19	340182	2	Pin-Pivot
20	09687	2	Screw
21	09688	2	Washer-Nylon
22	111-9662	1	OPC Lever - Engine
23	111-9381-03	1	Lever-Clutch, Gearbox
24	42-3560	1	Bolt-Shoulder
25	115-1794	2	Screw-HHF
26	94-2691	1	Screw-HWH Taptite
27	144-3175	1	Decal-Controls (60V Start)
28	144-6379	2	Plug-Round Tube, 1 In.
29	131-0822	1	Decal

Attachments and Accessories

For 22275T — 53cm Heavy-Duty 60V Recycler/Rear Bagger Lawn Mower

Product Name	Model/Part
Cup-Anti Scalp	125-8440
Deck Side Guard Kit	130-9701
Rear Discharge Kit	130-9734
21in Recycling Blade	144-3178-03
60v Battery Charger 5 Amp International	81805
60V 6.0 AH Battery CE	81860
60V 7.5 AH Battery CE	81875

Notes:

Notes:

Notes:



Count on it.