Form No. 3464-719 Rev D

TORO®

Count on it.

Parts Catalog

# 52in Z Master®

## Revolution® Series Riding Mower

**Model No. 18752—Serial No. 414889588 and Up**

Register at www.Toro.com.
Original Instructions (EN)

*3464-719* D

# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

**Understanding Reference Numbers**

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

**Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

**Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents


Main Frame Assembly . . . . . 4
Roll-Over Protection System Assembly No. 161-3495 . . . . . 6
Drive Assembly . . . . . 8
Guards Assembly . . . . . 10
Battery Assembly . . . . . 12
Battery Assembly No. 145-5385 . . . . . 14
Seat Mount Assembly . . . . . 16
Seat Assembly No. 145-8422 . . . . . 18
Motion Control and Parking Brake Assembly . . . . . 20
Right Motion Control Assembly No. 145-1325 . . . . . 22
Left Motion Control Assembly No. 145-1326 . . . . . 24
Front Caster Wheel Assembly . . . . . 26
Caster and Wheel Assembly . . . . . 28
Rear Wheel Assembly . . . . . 30
Electrical and Wire Harness Assembly . . . . . 32
Wire Harness Assembly No. 144-2673 . . . . . 34
Deck Lift Assembly . . . . . 36
Deck Strut Assembly No. 140-1179 . . . . . 38
Electrical Components Assembly . . . . . 40
Decal Assembly . . . . . 42
Deck Assembly . . . . . 44
Deck Decal Assembly No. 147-7826 . . . . . 46
Deflector Assembly No. 147-1642 . . . . . 48
Attachments and Accessories . . . . . 50

**© 2026—The Toro® Company**
**8111 Lyndale Avenue South**
**Bloomington, MN 55420**



**Contact us at www.Toro.com.**
**Printed in the USA.**
**All Rights Reserved**


# Main Frame Assembly



# Main Frame Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 145-1307-01 | 1 | Frame |
| 2 | 161-3495 | 1 | ROPS ASM |
| 3 | 145-3666 | 1 | Toeboard W/Decal |
| 3:2 | 145-3665 | 1 | Decal-Danger |
| 4 | 109-9233 | 2 | Bumper-Push-In, Rubber |
| 5 | 138-9753 | 6 | Screw |
| 6 | 138-6098 | 1 | Floor Pan ASM |
| 6:2 | 109-9233 | 2 | Bumper-Push-In, Rubber |
| 10 | 147-7856-01 | 1 | Plate-Skid |
| 11 | 140-4992 | 1 | Step |
| 12 | 117-2382 | 6 | Plug-Plastic |
| 13 | 140-4994-01 | 1 | Bracket-Light |
| 14 | 140-7950 | 1 | Floormat-Fixed Seat |
| 15 | 3230-22 | 2 | Screw-CARR |
| 16 | 117-2749 | 2 | Nut-Push |
| 17 | 144-6568 | 2 | Grommet-Rubber |
| 21 | 147-0290 | 1 | Decal-Light, Warning |

# Roll-Over Protection System Assembly
# No. 161-3495




# Roll-Over Protection System Assembly No. 161-3495 (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | | 1 | Upper ROPS ASM ● |
| 1:2 | 107-3069 | 1 | Decal-Warning |
| 2 | | 1 | ROPS-Lower ● |
| 3 | 119-4164 | 2 | Washer-Wave |
| 4 | 126-9209 | 2 | Bolt-Shoulder |
| 5 | 99-5107 | 6 | Nut-HF Nylock |
| 6 | 109-5337 | 2 | Bumper-ROPS |
| 7 | 109-9505 | 4 | Washer-Spring |
| 8 | 325-13 | 4 | Screw-HH |
| 9 | 161-4477 | 2 | ROPS Pin ASM |

● Not serviced separately


# Drive Assembly



# Drive Assembly (continued)

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 147-6261 | 1 | Motor/Gearbox ASM |
| 2 | 114-4681 | 8 | Screw-HHF |
| 3 | 109-6658 | 8 | Nut-Flange, NI |


# Guards Assembly



# Guards Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 144-6621-01 | 1 | Guard-Rear |
| 2 | 135-0505 | 4 | Bumper-Seat |
| 3 | 144-6608 | 1 | Plate-Rear, Upper |
| 4 | 147-4637 | 1 | LH Rear Guard ASM |
| 4:2 | 144-7008 | 1 | Decal-Service, Shut-Off |
| 5 | 147-1608-03 | 1 | Guard-Rear, RH |
| 6 | 144-6624-01 | 1 | Guard-Rear, LH |
| 7 | 145-5704-01 | 1 | Guard-Rear, Top |
| 8 | 144-6612-01 | 1 | Guard-Rear, RH |
| 10 | 138-9753 | 26 | Screw |
| 11 | 104-8300 | 14 | Nut-HF, NI |
| 12 | 145-1316 | 1 | RH Cover ASM |
| 12:2 | 161-3501 | 1 | Decal-Control Lever, RH |
| 13 | 145-1319 | 1 | LH Cover ASM |
| 13:2 | 161-3502 | 1 | Decal-Control Lever, LH |
| 14 | 87-6620 | 4 | Screw-Tph Thd Form |
| 15 | 140-7968 | 1 | Cup Holder |
| 16 | 140-7996-03 | 1 | Plate-Cover, LH Front |
| 17 | 140-7998-03 | 1 | Plate-Cover, RH Front |
| 18 | 130-8451 | 12 | Rivet-Trifold |
| 19 | 144-2666 | 1 | Side Pod, LH |
| 20 | 140-7980 | 1 | Side Pod, RH |
| 21 | 120-7950 | 12 | Screw-Torx |
| 22 | 140-8019 | 1 | Cupholder-RH |
| 23 | 145-1287-01 | 1 | Console-LH |
| 24 | 147-7810-01 | 1 | Console-RH |
| 25 | 144-2642 | 2 | Rod-Support, Pod |
| 26 | 3296-59 | 4 | Nut-Lock, NI |
| 27 | 3230-18 | 6 | Screw-CARR |
| 28 | 147-1627-03 | 1 | Plate-Cover, Component |
| 29 | 145-1253 | 1 | Cover-Rear |
| 30 | 112-3306 | 4 | Nut |
| 32 | 145-1254 | 1 | Plate-Rear, LH |
| 33 | 145-1255 | 1 | Plate-Rear, RH |
| 35 | 145-1978 | 1 | Decal-Logo, Silver |
| 37 | 144-6622 | 1 | Bumper-Rear |
| 38 | 135-2015 | 5 | Screw-Shoulder |
| 39 | 126-6267 | 4 | Screw-TTH |
| 40 | 144-6628 | 2 | Plate-Cover, Spring |
| 41 | 923786 | 4 | Rivet |
| 42 | 3230-22 | 2 | Screw-CARR |
| 43 | 145-1974 | 1 | Decal-Pod, LH |
| 44 | 145-1975 | 1 | Decal-Pod, RH |
| 45 | 147-7817 | 1 | Decal-Hypercell |
| 46 | 147-7781-01 | 1 | Plate-Cover, Electrical |

# Battery Assembly




# Battery Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 145-5385 | 10 | Battery ASM |
| 2 | 147-7809-03 | 2 | Plate-Retainer |
| 3 | 3230-23 | 4 | Bolt-CARR |
| 4 | 104-8300 | 4 | Nut-HF, NI |
| 5 | 147-7773-03 | 2 | Plate-Cover |
| 6 | 99-8445 | 4 | Screw-HWH |
| 8 | 140-9565 | 9 | Harness-Wire, Data Interface |
| 11 | 145-5783 | 20 | Screw-Sems |
| 13 | 122-2323 | 1 | Harness-Wire, Can Terminator |
| 14 | 147-1666 | 1 | Busbar-10, Bk |
| 15 | 147-1632 | 1 | Busbar-10, Rd |
| 16 | 1-807512 | 1 | Bolt-CARR |
| 17 | 104-7201 | 2 | Nut-HF, NI |
| 18 | 147-4560 | 2 | Cable-Battery, Rd ASM |
| 19 | 147-4570 | 1 | Cable-Battery, Bk ASM |
| 20 | 138-0689 | 1 | Screw-PH |
| 99 | 145-1070 | 9 | Charger-3300W ● |

● Not illustrated


# Battery Assembly No. 145-5385



# Battery Assembly No. 145-5385 (continued)

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 2 | 145-5338 | 1 | Decal-Warning, Battery |
| 14 | 32180-466 | 2 | Nut-Mounting, Jwpf Panel Lock |


# Seat Mount Assembly



# Seat Mount Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 147-7804-03 | 1 | Pan-Seat |
| 2 | 145-1311-03 | 1 | Badge Plate ASM |
| 3 | 147-4954-01 | 1 | Plate-Backer |
| 4 | 130-8451 | 2 | Rivet-Trifold |
| 5 | 99-8445 | 2 | Screw-HWH |
| 6 | 5-0652 | 4 | Spacer |
| 7 | 138-9753 | 4 | Screw |
| 8 | 145-8422 | 1 | Suspension Seat ASM |
| 9 | 104-8300 | 8 | Nut-HF, NI |
| 10 | 116-1297 | 2 | Screw-Shoulder |
| 11 | 3230-23 | 2 | Bolt-CARR |
| 12 | 117-2749 | 2 | Nut-Push |
| 14 | 145-7011 | 1 | Decal-Backer Plate |
| 16 | 147-7789-03 | 1 | Plate-Cover, Seat |


# Seat Assembly No. 145-8422



# Seat Assembly No. 145-8422 (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 140-8012 | 1 | Seat Track Set |
| 2 | 140-7118 | 1 | Knob-Weight Adjust ASM |
| 3 | 126-8559 | 1 | Bellows-Seat |
| 4 | 147-7925 | 1 | Arm Rest Kit |
| 5 | 147-7926 | 1 | Pads-Armrest W/ Hardware |
| 6 | 146-0595 | 1 | Seat Belt Kit |
| 7 | 147-7922 | 1 | Cover-Back, Seat |
| 8 | 147-7923 | 1 | Cover-Bottom, Seat |
| 9 | 145-3520 | 1 | Switch-Plunger, On-(On) |


# Motion Control and Parking Brake Assembly



# Motion Control and Parking Brake Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 145-1325 | 1 | RH Motion Control ASM |
| 2 | 147-2390 | 1 | RH Handle ASM |
| 2:2 | 109-5668 | 1 | Grip-Lever, Control |
| 3 | 3234-42 | 4 | Screw-HHF |
| 4 | 145-1326 | 1 | LH Motion Control ASM |
| 5 | 147-2391 | 1 | LH Handle ASM |
| 5:2 | 109-5668 | 1 | Grip-Lever, Control |
| 6 | 142-6851 | 2 | Damper |
| 7 | 126-4424 | 4 | Screw-Shoulder |
| 10 | 3218-3 | 2 | Nut-Jam |
| 11 | 138-7539 | 2 | Spring-Torsion |
| 12 | 138-9753 | 2 | Screw |
| 14 | 256-156 | 4 | Bushing-Flange |
| 15 | 140-5028 | 2 | Spacer-Sensor |
| 16 | 122-0917 | 2 | Sensor-Position |
| 17 | 3290-424 | 4 | Screw-SHH |
| 18 | 135-6342 | 4 | Nut-Hex Flange |
| 19 | 112-3306 | 2 | Nut |
| 20 | 126-4299 | 2 | Screw-HSBH |
| 21 | 147-7778-03 | 1 | Plate-Cover, Sensor LH |
| 22 | 147-7779-03 | 1 | Plate-Cover, Sensor RH |


# Right Motion Control Assembly No. 145-1325



# Right Motion Control Assembly No. 145-1325 (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 145-1323 | 1 | RH Ctrl Arm ASM |
| 2 | 126-7296 | 1 | Washer-Friction |
| 3 | 147-2389 | 1 | Arm-Control |
| 4 | 117-1240 | 1 | Washer |
| 5 | 119-8925 | 1 | Washer-Belleville |
| 6 | 117-1198 | 1 | Bolt-Pivot |
| 7 | 3256-24 | 1 | Washer-Plain |
| 8 | 32152-2 | 1 | Nut-Lock, Cone |


# Left Motion Control Assembly No. 145-1326



# Left Motion Control Assembly No. 145-1326 (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 145-1320 | 1 | LH Ctrl Arm ASM |
| 2 | 126-7296 | 1 | Washer-Friction |
| 3 | 147-2389 | 1 | Arm-Control |
| 4 | 117-1240 | 1 | Washer |
| 5 | 119-8925 | 1 | Washer-Belleville |
| 6 | 117-1198 | 1 | Bolt-Pivot |
| 7 | 3256-24 | 1 | Washer-Plain |
| 8 | 32152-2 | 1 | Nut-Lock, Cone |

# Front Caster Wheel Assembly




# Front Caster Wheel Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 109-3678 | 4 | Bearing-Ball |
| 2 | 145-3660 | 2 | Spacer-Bearing |
| 3 | 3256-68 | 2 | Washer-Flat |
| 4 | 144-0375 | 2 | Cap-Grease |
| 5 | 100-1668 | 2 | Screw-HHF |
| 6 | | 2 | Front Caster W/ Fork ASM ● |

● Not serviced separately

# Caster and Wheel Assembly





# Caster and Wheel Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 142-7827-01 | 1 | Fork-Caster |
| 2 | 140-4896 | 1 | Semi Pneumatic ASM 13X6.50-6 |
| 2:1 | | 1 | Wheel And Bearings ASM ● |
| 2:1:2 | 126-7796 | 1 | Caster Axle ASM |
| 2:1:2:1 | 126-5220 | 1 | Axle-Caster |
| 2:1:2:2 | 103-3051 | 1 | Spacer-Nut |
| 2:1:3 | 1-633585 | 2 | Bearing-Cone, Taper |
| 2:1:4 | 103-3051 | 1 | Spacer-Nut |
| 2:1:5 | 103-0063 | 2 | Seal-Caster |
| 2:2 | 126-5389 | 1 | Screw-HHF |
| 2:3 | 99-5107 | 1 | Nut-HF Nylock |
| 2:4 | 103-2768 | 2 | Guard-Seal |

● Not serviced separately

# Rear Wheel Assembly






# Rear Wheel Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 144-6632 | 2 | Wheel And Tire ASM |
| 1:1 | 145-1259 | 1 | Wheel |
| 1:2 | 140-7974 | 1 | Tire |
| 1:3 | 232-27 | 1 | Stem-Valve |
| 2 | 242-35 | 8 | Nut-Wheel |


# Electrical and Wire Harness Assembly



# Electrical and Wire Harness Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 145-3520 | 2 | Switch-Plunger, On-(On) |
| 2 | 139-8089 | 1 | Light - Flush Mount |
| 3 | 104-2065 | 2 | Screw-HWH |
| 4 | 140-7955 | 1 | Port-Power, USB |
| 5 | 139-6368 | 1 | Switch-Rocker, On-None-On |
| 6 | 92-8875 | 1 | Switch-Rocker |
| 7 | 140-4993 | 1 | Bumper-Front |
| 8 | 135-2015 | 2 | Screw-Shoulder |
| 9 | 139-7716 | 1 | Switch-Key, Spst |
| 10 | 101884 | 1 | Nut |
| 11 | 80-9330 | 1 | Audio Alarm ASM |
| 11:1 | 104-5107 | 1 | Nut-Plastic, Knurled |
| 12 | 122-1201 | 1 | Module-Display |
| 13 | 136-9678 | 4 | Cable Assy-Pushbutton |
| 14 | 144-2673 | 1 | Harness-Wire, Main |
| 15 | 3290-378 | 2 | Tie-Cable |
| 16 | 139-7720 | 1 | Ferrite, Snap-On |
| 17 | 122-0603 | 1 | Switch-Disconnect |
| 17:1 | 33006-00 | 1 | Nut-HF |
| 18 | 145-3597-03 | 1 | Bracket-Charger, Dual |
| 19 | 32105-9 | 1 | Screw-HH |
| 20 | 3296-9 | 1 | Nut-Hex |
| 21 | 138-9753 | 4 | Screw |
| 24 | 99-8445 | 1 | Screw-HWH |
| 25 | 63-8360 | 1 | Key-Ignition |
| 27 | 145-4800 | 1 | Harness-Wire, Charger Port |
| 29 | 139-8189 | 1 | Controller |
| 30 | 147-0250 | 1 | Harness-Wire |
| 31 | 33023-00 | 4 | Nut-Lock |
| 32 | 112-9356 | 4 | Screw-HSBH |
| 33 | 145-4807 | 1 | Harness-Wire, Deck |
| 34 | 147-0370 | 1 | Busbar-2, Switch |
| 35 | 161-3544 | 1 | Harness-Wire, Jumper |


# Wire Harness Assembly No. 144-2673



# Wire Harness Assembly No. 144-2673 (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 18 | 32180-282 | 1 | Conn, Res, 120 Ohm |
| 24 | 121-8861 | 2 | Fuse-Mini Blade, 2 Amp |
| 25 | 121-8864 | 3 | Fuse-Mini Blade, 5 Amp |
| 30 | 117-4724 | 1 | Fuse-Blade, 10A |
| 31 | 117-4725 | 1 | Fuse-Blade, 15A |
| 33 | 121-8865 | 1 | Fuse-Mini Blade, 7.5 Amp |


# Deck Lift Assembly



# Deck Lift Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 139-5872 | 4 | Bearing-Flange |
| 2 | 116-2887 | 4 | Gusset-Lift, Deck |
| 3 | 3230-22 | 8 | Screw-CARR |
| 4 | 104-8300 | 8 | Nut-HF, NI |
| 5 | 139-8050-03 | 1 | Front Deck Lift Shaft ASM |
| 6 | 145-1951-03 | 1 | Adj Deck Lift Shaft ASM |
| 7 | 126-4639-03 | 1 | Link-HOC |
| 8 | 126-9181 | 2 | Pin-Clevis |
| 9 | 138-8491 | 2 | Clip-Pin |
| 10 | 139-6699 | 1 | Decal-HOC |
| 11 | 126-8877 | 2 | Deck Chain ASM |
| 11:1 | 1-633447 | 1 | Chain-Lift, Deck |
| 11:2 | 130-0742 | 2 | Bolt-Shoulder |
| 11:3 | 104-8301 | 2 | Nut-HF, NI |
| 11:4 | 43-0940 | 2 | Spacer |
| 12 | 140-1179 | 1 | Deck Strut W/ Bushings ASM |
| 13 | 1-373034 | 2 | Washer |
| 14 | 109-6658 | 2 | Nut-Flange, NI |
| 15 | 3231-7 | 2 | Screw-CARR |
| 16 | 140-1249 | 1 | Plate-Transport Lock |
| 17 | 116-0886 | 1 | Spring-Extension |
| 18 | 92-7674 | 1 | Bolt-Shoulder |
| 19 | 126-5401 | 1 | Pin-HOC |
| 21 | 116-0780 | 1 | Screw-Shoulder, HHF |
| 22 | 99-5107 | 1 | Nut-HF Nylock |
| 23 | 140-4959 | 1 | Pedal-Foot Lift |
| 24 | 132-4749 | 1 | Grip-Lever |
| 25 | 104-7658 | 1 | Spacer |
| 26 | 9266934 | 1 | Screw |
| 27 | 2844 | 1 | Washer |
| 28 | 3234-42 | 1 | Screw-HHF |
| 31 | 104-8301 | 2 | Nut-HF, NI |
| 32 | 109-9066 | 2 | Yoke-Adjust, Deck |
| 33 | 116-0756 | 2 | Deck Lift Chain ASM |
| 33:1 | 1-633447 | 1 | Chain-Lift, Deck |
| 33:2 | 109-9065 | 1 | Screw-HH-Spcl |
| 33:3 | 32128-37 | 1 | Nut-HF |
| 34 | 114-8417 | 2 | Nut-HF, NI |
| 35 | 322-47 | 2 | Screw-HH |
| 36 | 3218-2 | 4 | Nut-Hex Jam |
| 37 | 130-0742 | 2 | Bolt-Shoulder |
| 38 | 43-0940 | 2 | Spacer |
| 40 | 145-1972 | 1 | Decal-Rake, LH |
| 41 | 145-1973 | 1 | Decal-Rake, RH |


# Deck Strut Assembly No. 140-1179



# Deck Strut Assembly No. 140-1179 (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 2 | 126-8360 | 4 | Bushing-Rubber, Suspension |
| 3 | 108-6544 | 4 | Spacer |
| 4 | 3231-7 | 2 | Screw-CARR |
| 5 | 2844 | 2 | Washer |
| 6 | 104-8301 | 2 | Nut-HF, NI |


# Electrical Components Assembly



# Electrical Components Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 147-1606-03 | 1 | Bracket-Chassis |
| 2 | 147-1611-03 | 1 | Plate-Controller, Deck |
| 3 | 147-1607-03 | 1 | Plate, Fuse-Mnt |
| 4 | 145-7270 | 3 | Inv/Ctrlr-48V |
| 5 | 138-8984 | 1 | Inv/Ctrlr-48V, Dual 94Arms |
| 7 | 110-8823 | 1 | Block-Junction |
| 8 | 145-3542 | 2 | Contactor-DC, 12V |
| 9 | 145-4958 | 2 | Holder-Fuse |
| 10 | 144-6975 | 1 | Converter DC-DC |
| 11 | 127-2770 | 1 | Controller |
| 12 | 3217-7 | 1 | Nut-Hex |
| 14 | 70-1480 | 3 | Relay |
| 15 | 32144-86 | 12 | Screw-HWHTF |
| 16 | 32144-44 | 12 | Screw-HWH, Thread Roll |
| 17 | 99-8445 | 15 | Screw-HWH |
| 18 | 105-6849 | 2 | Screw-Forming, Thread |
| 20 | 138-9753 | 4 | Screw |
| 22 | 104-8300 | 6 | Nut-HF, NI |
| 23 | 32144-70 | 2 | Screw-HWHTF |
| 25 | 145-5782 | 23 | Screw-Sems |
| 26 | 147-4567 | 1 | Cable-Battery, Bk ASM |
| 29 | 147-4564 | 1 | Cable-Battery, Rd ASM |
| 30 | 147-4563 | 1 | Cable-Battery, Rd ASM |
| 31 | 147-4561 | 1 | Cable-Battery, Rd ASM |
| 32 | 147-4562 | 1 | Cable-Battery, Rd ASM |
| 33 | 147-4563 | 1 | Cable-Battery, Rd ASM |
| 34 | 147-4565 | 1 | Cable-Battery, Rd ASM |
| 35 | 147-4568 | 1 | Cable-Battery, Bk ASM |
| 38 | 122-2561 | 2 | Fuse-200A |
| 43 | 147-1610-03 | 2 | Bracket-Cable |
| 44 | 145-6985 | 6 | Mount-Cable |
| 45 | 3234-29 | 2 | Screw-HHF |
| 46 | 115-7721 | 2 | Nut-Clip, U |
| 48 | 3230-23 | 6 | Bolt-CARR |
| 50 | 147-0238 | 2 | Cable-Battery, Rd ASM |
| 51 | 147-0239 | 2 | Cable-Battery, Bk ASM |


# Decal Assembly



# Decal Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 3 | 145-1946 | 1 | Decal-Panel, Control |


# Deck Assembly



# Deck Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 147-7826 | 1 | Deck ASM-52In |
| 2 | 147-1689 | 1 | Motor/Gen |
| 3 | 701243 | 18 | Screw-Thd Roll, HWH |
| 4 | 145-3439 | 3 | Retainer-Blade |
| 5 | 145-3499 | 3 | Screw-Shoulder, HWH |
| 6 | 125-1736 | 3 | Washer-Belleville |
| 7 | 323-23 | 2 | Screw-HH |
| 8 | 98-7912 | 1 | Tube-Spanner |
| 9 | 98-7913 | 1 | Tube-Spacer |
| 10 | 1-603299 | 4 | Roller-Scalp, Anti |
| 11 | 104-8301 | 13 | Nut-HF, NI |
| 12 | 147-1642 | 1 | Rubber Deflector ASM |
| 13 | 322-50 | 1 | Screw-HH |
| 14 | 105-4622 | 1 | Spacer |
| 15 | 104-8300 | 2 | Nut-HF, NI |
| 16 | 108-4052 | 1 | Spring-Torsion |
| 17 | 3230-3 | 1 | Screw-CARR |
| 18 | 126-4781-03 | 1 | Step-Deck |
| 19 | 108-5388 | 1 | Screw-HH |
| 20 | 98-5967 | 1 | Spacer-Wheel |
| 21 | 133-2129 | 1 | Tube-Shafting |
| 22 | 133-2128 | 1 | Tube-Spacer |
| 23 | 3231-21 | 3 | Screw-CARR |
| 25 | 115-7461-01 | 1 | Baffle |
| 26 | 145-3640-01 | 1 | Baffle |
| 28 | 94-7582 | 1 | Bolt-Shoulder |
| 30 | 3231-27 | 6 | Screw-CARR |
| 31 | 3231-25 | 1 | Bolt-CARR |
| 32 | 100-4852 | 1 | Washer-Hardened |
| 33 | 109-1092 | 1 | Knob |
| 34 | 107-8541-01 | 1 | Baffle-Discharge |
| 35 | 145-3504-03 | 3 | Blade-18.0In, Med Sail |

# Deck Decal Assembly No. 147-7826




# Deck Decal Assembly No. 147-7826 (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | | 1 | Deck ASM W/Decals 52 ● |
| 1:2 | 117-3848 | 2 | Decal-Danger |
| 1:3 | 127-0326 | 1 | Decal-Scalp, Anti |
| 1:4 | 147-0288 | 1 | Decal-Danger |
| 1:5 | 107-1618 | 1 | Decal |
| 1:6 | 137-8127 | 2 | Decal-No Spray |
| 1:7 | 145-8411 | 1 | Decal-Adjustable Baffle |

● Not serviced separately

# Deflector Assembly No. 147-1642



# Deflector Assembly No. 147-1642 (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 3231-4 | 4 | Screw-CARR |
| 2 | 106-3246-01 | 1 | Deflector |
| 3 | 106-3248-03 | 1 | Strap-Discharge |
| 4 | 139-8114 | 1 | Deflector-Deck, Rubber |
| 5 | 147-0386-01 | 1 | Plate-Hinge, Rear |
| 6 | 147-0387-01 | 1 | Plate-Hinge, Front |
| 7 | 104-8301 | 4 | Nut-HF, NI |

# Attachments and Accessories

## For 18752 — 52in Z Master Revolution Series Riding Mower

| Product Name | Model/Part |
|---|---|
| Anti-Scalp Kit (Trim Side) | 108-4140 |
| Jack Kit | 127-6666 |
| Recycler Kit | 139-6653 |
| Trimmer Mount | 144-2665 |
| Jack Mount Kit | 144-2676 |
| Hardtop Sun Canopy | 144-3719 |
| Blade-18.0in, Med Sail | 145-3504-03 |
| Blade-18.0in, Recycler | 145-3507-03 |
| Handle Extension Kit | 145-3615 |
| Blade-18.0in, High Sail | 147-0252-03 |
| Blade-18.0in, Atomic Sail | 147-0261-03 |
| Wiring Harness Adapter Kit | 147-1612 |
| HV Synthetic Electric Motor Drive Oil | 147-6275 |

## Notes:




**Count on it.**