



Form No. 3475-395 Rev C

Count on it.

Parts Catalog

GreensPro® 1700

Greens Roller

Model No. 44914—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Chassis Assembly 4

Steering Mechanism Assembly 6

Roller Assembly 8

Seat Assembly 10

Operator Platform Assembly 12

Drawbar Assembly 14

Lifting Mechanism Assembly 16

Hub and Bearing Assembly No. 117-5115 18

Tire and Wheel Assembly No 142-5511 20

Electrical and Battery Assembly 22

Battery Assembly 24


Battery Assembly No. 145-5385 26

Main Wire Harness Assembly No. 122-4193 28

Controller Assembly 30

Attachments and Accessories 32


Chassis Assembly



Chassis Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	163-8129	1	Main Frame ASM	13	163-8078-01	1	Panel-Cleanout, LH
1:2	93-4665	4	Bushing-Flange	14	163-8136	1	Rear Cover ASM
1:3	254-66	4	Cup-Bearing, Roller	14:2	137-8127	1	Decal-No Spray
1:4	161-7799	8	Nut-Clinch	15	163-8134	1	LH Cover ASM
1:5	133-8061	1	Decal-Warning	15:2	67-1300	1	Decal
1:6	120-0625	3	Decal-Warning	15:3	161-9149	1	Decal-Greenspro 1700
1:7	1-811010	2	Plug	16	163-8135	1	RH Cover ASM
2	33104-045	6	Screw-HHF	16:2	67-1300	1	Decal
3	161-9177-01	1	Tube-Support, Front	16:3	161-9149	1	Decal-Greenspro 1700
5	142-9904	10	Nut-U	16:4	144-7008	1	Decal-Service, Shut-Off
6	161-2278-01	1	Panel-Cleanout	17	163-8087-01	1	Footrest
7	134-3746	12	Screw-HHF	18	114-1926	2	Bumper-Rubber
8	161-9178-01	1	Tube-Support, Rear	19	119-4041	2	Nut-HF
9	130-8743	6	Grommet	20	74-5950	2	Latch-Swell
10	163-8133	1	Front Cover ASM	21	144-6766	1	Pin, Lock
10:2	144-6628	1	Plate-Cover, Spring	22	09438	2	Nut-Nyloc
10:3	3269-32	2	Rivet-Pop	23	104-7048	1	Cap-Housing
10:4	147-0289	1	Decal-Charging Port	24	104-7050	1	Tube-Manual
10:5	161-9152	1	Decal-Warning	25	134-3740	2	Screw-HHF
10:6	137-8127	1	Decal-No Spray	26	163-8066	2	Cap-End, Ec Profile
10:7	140-4590	1	Decal-Charger Input Lithium	27	163-8065	2	Seal-Shaft
11	33104-040	8	Screw-HHF	28	107-1865	2	R-Clamp
12	134-3762	14	Nut-Flange, NI				


Steering Mechanism Assembly



Steering Mechanism Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	163-8138	1	Roller Hanger ASM	6:2	60-0080	4	Bushing
1:2	60-0080	2	Bushing	7	147-3391	1	Actuator-Steering
2	3-6498	2	Washer-Thrust	8	110-4888	2	Washer-Spacer
3	254-65	4	Bearing-Roller, Cone	9	32120-93	2	Ring-Retaining
4	137-8171	2	Washer	10	161-2207	1	Pin-Clevis
5	137-7942	2	Nut-Castle	11	137-7943	2	Washer-Tang
6	163-8130	1	Outer Roller Lift Arm ASM	12	32151-36	1	Ring-Retaining

Roller Assembly




Roller Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-3756	4	Screw-HHF	19	240-14	4	Bumper-Rubber
2	163-8097	3	O-Ring	20	161-2227-01	1	Shell-Roller, Outer
3	163-8098	3	O-Ring	21	134-2299	3	Screw-HWH
4	161-2228-01	1	Shell-Roller, Center	22	161-2285-03	2	Roller-Outer
5	161-3266	3	Pin-Flag	23	161-9102-03	1	Stop-Tilt
6	164-2650	3	Washer-Flat	24	144-3901	1	End-Rod, Tie
7	134-3746	3	Screw-HHF	25	144-3902	1	End-Rod, Tie
8	134-3752	12	Screw-HHF	26	140-6135	2	Nut-Hex, Slotted
9	147-8361	3	Motor-Roller	27	161-7759-03	1	Rod-Steering
9:1		1	Motor/Gen-120V, 3Kw ■●	28	84-5300	1	Nut-Jam
9:1:1	163-8121	1	Kit-Motor, Service ●	29	110-5337	1	Nut-Jam
9:1:2	145-5057	1	Kit-Cover/Seal, Motor ●	30	119-6807	1	Decal-Warning
9:2		1	Gearbox, Plntry-12:1 Rdctn ●■	31	32180-030	6	Clip-Tie
9:2:1	161-9864	1	Kit-Seal ●	32	AU419-2624	1	Screw-Plow
9:2:2	164-2671	1	Kit-Gearbox ●	33	3217-7	1	Nut-Hex
9:3		1	Brake,Parking-Torquehub ●■	34	119-7568	4	Screw-HSBH
9:3:99	145-5058	1	Kit-Brake ●	35	09430	4	Nut-Nyloc
10	161-2232-03	3	Mount-Motor, Roller	36	3296-56	4	Nut-Lock, NI
11	163-8099	3	Coupler-Roller	37	161-2218-01	1	Roller Shell-Outer, RH
12	144-2269	12	Nut-Nylk,HF	38	163-8067	2	Sleeve-Spring, Short
13	161-2286-03	1	Roller-Center	39	163-8068	2	Sleeve-Spring, Long
14	147-6042	18	Screw-Tfh	40	108-5412	2	Spring-Extension
15	131-6367	6	Spacer	41	33115-130	2	Screw-HH
16	111-5744	3	Bearing ASM	42	33115-080	2	Screw-HH
16:1	111-5758	1	Bearing	43	33025-00	4	Nut-Lock, NI
17	134-3757	12	Screw-HHF	44	163-8093-03	1	Stop-Tilt, LH
18	134-3764	6	Nut-Flange, NI	45	3272-12	2	Pin-Cotter
				46	163-8149	2	Pad-Wear
				47	140-2149	2	Rivet-Push

● Not illustrated

■ Not serviced separately

Seat Assembly




Seat Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	161-9195	1	Seat Base ASM
1:2	147-0290	1	Decal-Light, Warning
2	161-9144	1	Seat
2:1	163-8079	1	Switch-Seat
2:2	132-3837	4	Screw-HHF ●
3	161-9124-01	1	Pivot-Console
5	322-5	4	Screw-HH
6	3256-57	4	Washer-Flat
7	3253-4	4	Washer-Lock
9	145-2598	2	Light-Work, LED

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
10	134-3740	2	Screw-HHF
11	09479	2	Washer-Plain
12	161-7700	2	Spacer
13	134-3761	2	Nut-Flange, NI
14	4-2390	2	Washer-Flat
15	134-3747	2	Screw-HHF
16	134-3746	4	Screw-HHF
17	134-3762	2	Nut-Flange, NI
18	32180-030	2	Clip-Tie

● Not illustrated


Operator Platform Assembly



Operator Platform Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	163-8057-01	1	Console-Control	16:2	122-2704	1	Nut-Face, M22 (Plastic)
2	94-2738	2	Screw-CARR	16:3	121-5162	1	Set-Key, Ignition
3	134-3762	2	Nut-Flange, NI	17	163-8137	1	Side Cover ASM
4	74-5950	2	Latch-Swell	17:2	163-8125	1	Decal-Service
5	161-7798	1	Pq Pistol Grip Joystick	18	161-8355	1	Cup Holder ASM
6	3256-51	4	Washer-Flat	19	3290-321	2	Screw-HWH
7	108-3153	4	Screw-HSBH	20	3296-2	2	Nut-Lock, NI
8	161-0497	1	Plate-Retaining	21	135-6374	9	Screw-HSBH
9	161-9163	1	Pad-Arm	22	163-8050	1	Cover-Console
10	3274-55	2	Screw-HSBH	23	120-9683	2	Washer-Plain
11	122-2152	1	Controller, Tdm-1601	24	107-0382	1	Powercord-AC, Europe
12	136-9678	3	Cable Assy-Pushbutton	24	107-0383	1	Powercord-AC, U.K.
13	122-3610	1	Switch-Rocker, On-Off-On	24	107-0384	1	Powercord-AC
14	122-3200	1	Relay	25	138-0719	1	Nut-HF
15	122-3611	1	Switch-Rocker, (On)-Off-(On)	26	117-2382	3	Plug-Plastic
16	122-2513	1	Switch-Ignition, Suns	27	161-9142	1	Decal-Console
16:1	121-5160	1	Nut-Hex	28	164-2661	1	Decal-Joystick
				29	3253-4	2	Washer-Lock


Drawbar Assembly



Drawbar Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	161-7738-01	1	Skid-Qtach	19	09690	1	Bolt
2	161-9105-01	1	Skid-Qtach, LH	20	09456	1	Nut
3	161-9106-01	1	Skid-Qtach, RH	21	161-7789	1	Pin-Clevis
4	134-3756	4	Screw-HHF	22	32120-93	6	Ring-Retaining
5	134-3763	9	Nut-Flange, NI	23	161-7794	2	Block-Wear
6	161-7741-01	1	Handle-Latch	24	33105-080	2	Screw-HHF
7	33125-030	3	Screw-CARR	25	161-7719	1	Latch ASM
8	161-7742	1	Rod-Latch Release	26	161-7747	1	Pin-Clevis
9	161-7797	1	Washer-Special	27	3-6498	4	Washer-Thrust
10	114-8187	1	Spring-Compression	28	161-7744	1	Spacer Tube
11	115-2750	1	Knob	29	111-7679	1	Washer-Plain
12	115-3592	1	Grip	30	33113-050	1	Screw-HH
13	163-8083	1	Pin-Quick W/Lnyd	31	134-3761	1	Nut-Flange, NI
14	161-7793	1	Drawbar ASM	32	161-7787-01	1	Step-Drawbar
14:2	256-113	2	Bushing-Flange	33	33105-070	4	Screw-HHF
14:3	161-9148	1	Decal-Hitch Release	34	161-3264	1	Clevis-Hitch
15	134-2623	1	Washer-Thrust	35	161-7796	1	Pin-Clevis
16	33116-110	1	Screw-HH	36	161-4477	1	ROPS Pin ASM
17	134-3764	5	Nut-Flange, NI	37	32120-47	1	Ring-Retaining, External
18	161-7783	2	Spacer				


Lifting Mechanism Assembly



Lifting Mechanism Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	161-0546	2	Support-Wheel	18	134-3757	12	Screw-HHF
2	117-5115	2	Hub And Bearing ASM	19	161-7764	1	Pin-Pivot
3	142-5511	2	Tire/Rim ASM	20	164-2651	4	Washer-Flat
4	117-8259	2	Washer-Spindle	21	164-2652	1	Rod-Lift
5	117-8260	2	Nut	22	328-25	2	Screw-HH
6	93-0307	2	Nut-Lock, Retainer	23	138-4082	2	Nut-HF
7	3272-18	2	Pin-Cotter	24	108-0015	4	Washer-Flat
8	AU103-16200	2	Ring-Retaining, External	25	32151-62	4	Ring-Retaining
9	161-7795	1	Qtach Hanger ASM	26	147-3392	1	Actuator-Lift
9:2	256-113	2	Bushing-Flange	26:1	302-5	1	Fitting-Grease
10	161-7760	1	Pin-Clevis	27	163-8142	1	Pin ASM
11	3-6498	2	Washer-Thrust	28	161-7758-03	1	Bracket-Lockout
12	32120-93	2	Ring-Retaining	29	164-2654	1	Bearing-Rod End, RH
13	134-2299	1	Screw-HWH	30	164-2655	1	Bearing-Rod End, LH
14	163-8077	1	Pin-Pivot	31	3220-17	1	Nut-Jam, LH
15	140-2149	4	Rivet-Push	32	3220-7	1	Nut-Jam
16	163-8082	4	Washer-Flat	33	134-3301	8	Washer, Lock M12
17	163-8107-03	1	Tube-Lift				

Hub and Bearing Assembly No. 117-5115




Hub and Bearing Assembly No. 117-5115 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	117-8251	1	Hub ASM
1:2	114-3918	4	Stud-Wheel
1:3	254-72	2	Bearing-Cup, Tapered
2	254-94	2	Bearing-Cone, Tapered

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	112-1690	1	Seal-Oil
4	241-119	1	Cap-Dust
5	139-2564	4	Nut-Lug


Tire and Wheel Assembly No 142-5511



Tire and Wheel Assembly No 142-5511 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-6214	1	Tire
2	142-6215	1	Rim-8X5.375, Centered
3	232-27	1	Stem-Valve

Electrical and Battery Assembly




Electrical and Battery Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	161-7777-03	1	Bracket-Mount, Charger
2	145-1177	1	Charger-Onboard
2:2	147-3234	1	DC Harness Service Kit
3	134-3761	4	Nut-Flange, NI
4	32180-030	1	Clip-Tie
7	122-4391	1	Harness-Wire, AC Charger
8	147-3230	1	Connector-lec
9	510-0015	2	Scr-Mch
10	134-3762	4	Nut-Flange, NI
11	122-3785	1	Harness-Wire, Jumper

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
12	33104-045	4	Screw-HHF
13	3296-52	2	Nut-Lock, NI
15	09735	4	Bolt Coach
16	134-3746	4	Screw-HHF
17	33123-016	4	Screw-CARR
18	122-4326	1	Converter DC-DC
20	161-9001	1	Gateway-Telematics
21	134-3740	4	Screw-HHF
22	09438	8	Nut-Nyloc


Battery Assembly



Battery Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	145-5385	2	Battery ASM	22	122-0603	1	Switch-Disconnect
2	147-3877	2	Bar-Bus, 400A	22:1	33006-00	1	Nut-HF
3	145-5783	4	Screw-Sems	23	3234-29	2	Screw-HHF
4	140-9565	1	Harness-Wire, Data Interface	24	119-4041	2	Nut-HF
5	122-2323	1	Harness-Wire, Can Terminator	25	161-6249	2	Holder-Fuse
6	163-8131	1	Battery Tray ASM	25:1	136-8682	8	Washer-Lock
6:2	161-7799	11	Nut-Clinch	25:2	3256-74	16	Washer-Flat
7	161-7773-03	2	Bracket-Hold, Battery	25:3	117-4059	8	Nut-Hex
8	134-3746	15	Screw-HHF	26	104-2628	4	Screw
9	134-3762	6	Nut-Flange, NI	27	122-4193	1	Harness-Wire, Main
11	161-7770-03	1	Bracket-Mount, Controller	28	32149-8	2	Nut-Keps
12	161-7771-03	1	Bracket-Mount, Controller	29	3253-4	2	Washer-Lock
13	161-7775-03	1	Hold-Battery	30	3220-2	2	Nut-Hex Jam
14	32180-030	5	Clip-Tie	33	122-2627	1	Fuse-70A
15	3290-378	1	Tie-Cable	35	122-2559	1	Fuse-100 Amp
16	33123-030	8	Screw-CARR	37	122-3402	1	Cable-Battery, Rd ASM
17	145-5782	4	Screw-Sems	38	122-3403	1	Cable-Battery, Rd ASM
18	122-1274	1	Contactor-DC, 48V	39	122-3404	1	Cable-Battery, Rd ASM
19	33123-016	2	Screw-CARR	40	122-3405	1	Cable-Battery, Rd ASM
20	134-3761	10	Nut-Flange, NI	41	122-3406	1	Cable-Battery, Rd ASM
21	163-8132	1	Service Switch Bracket ASM	42	122-3407	1	Cable-Battery, Bk ASM
21:2	161-7799	2	Nut-Clinch	43	122-3408	1	Cable-Battery, Bk ASM
				44	122-3427	1	Cable-Battery, Rd ASM


Battery Assembly No. 145-5385



Battery Assembly No. 145-5385 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1:2	145-5338	1	Decal-Warning, Battery
1:14	32180-466	2	Nut-Mounting, Jwpf Panel Lock


Main Wire Harness Assembly No. 122-4193



Main Wire Harness Assembly No. 122-4193 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
26	32180-662	1	Cap-Dust, For Dtm 12 Way	37	32180-567	3	Cover-Aptiv, Modified
29	32180-459	2	Backshell-Harnessflex, Dt6	39	117-4724	1	Fuse-Blade, 10A
32	32180-282	1	Conn, Res, 120 Ohm	40	121-8861	1	Fuse-Mini Blade, 2 Amp
35	32180-089	1	Cap-Plug, 3 Way	41	117-4725	2	Fuse-Blade, 15A
36	121-8866	1	Fuse-Mini Blade, 10 Amp				

Controller Assembly



Controller Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-8984	1	Inv/Ctrlr-48V, Dual 94Arms	5	HDW21408	9	Nut-Hex
2	145-7270	1	Inv/Ctrlr-48V	6	122-4247	1	Cable-Battery Rd ASM ASM
3	145-5782	9	Screw-Sems	7	122-4248	1	Cable-Battery Rd ASM ASM
4	1-303435	9	Washer-Spring	8	122-4249	1	Cable-Battery Rd ASM ASM

Attachments and Accessories

For 44914 — GreensPro 1700 Greens Roller

Product Name	Model/Part
Powercord-AC, Europe.....	107-0382
Powercord-AC, U.K.	107-0383
Powercord-AC	107-0384
HV Synthetic Electric Motor Drive Oil.....	147-6275
Roller Motor Oil Change Kit	164-2660
Battery Expansion Kit	44976

Notes:

Notes:

Notes:



Count on it.