Form Number 3351-950

Left Reel Backlapping Kit
Greensmaster® 3000 Series

Model No. 107-9527

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

©The Toro Company - 2004
All Rights Reserved



Left Reel Backlap Kit Assembly

Ref	Part No.	Qty.	Description
1	54-9510	1	Motor-Hyd, With By-Pass
2	54-9530	2	Fitting
2:1	237-42	1	O-Ring
3	353-384	1	Fitting-Straight
3:1	237-42	1	O-Ring
4	353-374	1	Elbow-90 DEG
4:1	237-42	1	O-Ring
5	92-9657	2	Coupling-Quick Disconnect
5:1	92-9658	1	Coupling-Nose
5:2	92-9659	1	Coupling-Quick, Body
6	70-9940	1	Hydraulic Hose ASM
6:1	237-42	1	O-Ring
6:2	237-22	1	O-Ring
7	70-9950	1	Hydraulic Hose ASM
7:1	237-42	1	O-Ring



Hydraulic Motor and By-Pass Assembly No. 54-9510

Ref	Part No.	Qty.	Description
1	353-891	1	Body
2	353-892	4	Screw
3	353-893	1	Pin-Drive
4	353-894	2	Pin-Dowel
5	353-895	1	Cover
5:1		1	Seat (Not Serviced Separately)
7	353-897	1	Washer-Seal
10	353-899	1	Cup-Seal
11	353-900	1	Plate-Mount, Flange
16	353-904	1	Shaft-Spline
17	353-905	4	Screw-Socket Head
18	353-906	1	Spring-Seal
19	353-907	3	Ring-Retaining
21	353-909	1	Element-Gerotor
22	353-910	2	Bearing-Needle
23	54-9520	1	Valve-By-Pass
23:1		1	Collar (Not Serviced Separately)
23:2	353-850	1	O-Ring
23:3	353-914	1	O-Ring
23:4		1	Body (Not Serviced Separately)
23:5		1	Seal (Not Serviced Separately)
23:6		1	Poppet (Not Serviced Separately)
23:7		1	Pin-Spring (Not Serviced Separately)

Ref	Part No.	Qty.	Description
26	353-911	2	Plug
26:1	237-156	1	O-Ring
27	353-912	2	Spring-Retainer, Ball
28	353-664	2	Ball
99	353-913	1	Seal Kit


TORO®