


TORO®

MODEL NO. 30144-6000001 & UP

PARTS CATALOG


44" CUTTING DECK WIDE AREA MOWER



CUTTING UNIT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3211-15	Screw — Cap Hex Head	2
2	54-2660	Grass Deflector	1
3	3296-5	Nut — Lock	2
4	40-6230	Spring — Torsion	2
5	32152-1	Nut — Lock	16
6	55-8320	Bracket — Pivot	1
7	3230-18	Bolt — Carriage	4
8	47-0094	Spindle Shaft	2
9	55-7690	Pulley — Spindle	2
10	27-1160	Belt — Deck Drive	1
11	54-3230	Cover — Bracket R.H.	1
12	3296-63	Nut — Lock	1
13	57-4140	Pulley	1
14	32128-13	Nut — Lock	2


Ref. No.	Part No.	Description	No. Used
15	52-4780	Rod — Belt	2
16	3230-2	Bolt — Carriage	2
17	54-3240	Cover Bracket	1
18	3296-42	Nut — Lock	4
19	323-10	Capscrew — Hex Head	1
20	3296-5	Nut — Lock	1
21	52-4580	Pulley	1
22	3256-24	Washer	1
23	54-2710	Idler Arm	1
24	51-3640	Sleeve — Idler Pivot	1
25	54-2730	Spring — Extension	1
26	322-6	Screw — Cap Hex Head	1
27	3218-2	Nut — Hex Jam	1
28	54-2900	Housing	1



CUTTING UNIT ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
29	43-8480	Decal — Danger	1
30	3211-8	Capscrew — Hex Head	1
31	20-9530	Washer	1
32	32128-21	Nut — Lock, Flange	1
33	3229-3	Bolt — Carriage	2
34	7-3522	Anti-Scalp Cup	3
35	54-0010	Blade	3
36	57-4130	Spindle — Shaft	1
37	47-0100	Spacer — Spindle	3
38	32120-11	Retaining Ring — Internal	3
39	251-318	Bearing	6
40	54-0160	Spindle Tube	3


Ref. No.	Part No.	Description	No. Used
41	55-8280	Support Ring	2
42	55-7680	Spacer — Bearing	3
43	42-6860	Decal — Height of Cut	1
44	3229-1	Bolt — Carriage	2
45	322-4	Screw — Cap Hex Head	11
46	42-6430	Decal — Warning	1
47	283-55	Pin — Clevis	4
48	3290-355	Pin — Hair	4
49	26-7970	Decal — Caution	1
50	3296-41	Locknut	5
51	302-5	Grease — Fitting	3



CUTTING UNIT DECK COVER'S

Ref. No.	Part No.	Description	No. Used
1	54-2250	Cover — Deck R.H.	1
2	43-5120	Decal — Toro	1
3	54-3190	Cover — Deck, Center	1
4	27-4571	Adjustment Handle	2

Ref. No.	Part No.	Description	No. Used
5	54-2220	Cover — Deck L.H.	1
6	46-8560	Screw — Self Tapping	5
7	29-0641	Jiffy Trim	5
8	54-2760	Decal — 44"	1



CARRIER FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32128-27	Nut — Lock	6
2	54-2800	Suspension Frame (Incl. Ref. #28)	1
3	3234-6	Screw — Flange Hex Hd.	6
4	3272-7	Pin — Cotter	2
5	51-3490	Shaft — Adjusting	2
6	3218-5	Nut — Hex Jam	4
7	51-3500	Washer	2
8	47-0960	Spring — Compression	2
9	51-3480	Sleeve — Tube	2
10	54-2700	Cushion — Rubber	2
11	328-9	Screw — Cap Hex Head	2
12	3253-4	Washer — Lock	8
13	3217-6	Nut — Hex	8
14	57-4250	Thrust Washer	4
15	54-8840	Bearing Retainer	4
16	54-8860	Spanner Bushing	2
17	54-8850	Roller Bearing	2

Ref. No.	Part No.	Description	No. Used
18	54-8880	Tube w/Valve	2
19	54-8900	Wheel Half — Male	2
20	54-8870	Tire	2
21	54-8910	Wheel Half — Female	2
22	54-8830	Hub — Centered	2
23	302-10	Grease Fitting	2
24	54-8890	Bolt — Wheel	8
25	32153-6	Locknut	2
26	40-0370	Castor Lock	2
27	3-6781	Washer — Thrust	8
28	28-9290	Bushing — Special	4
29	302-5	Grease Fitting	2
30	3290-384	Pin — Lynch	2
31	26-7980	Decal — Caution	1
*	12-1519	Castor Wheel Assembly (Incl. Ref. #12, 13 & 15-24) (Qty 2 per carton)	1

*Not Illustrated