Form Number 3352-103

Z587L Z Master®
With 60in TURBO FORCE Side Discharge Mower

Model No. 74251 - 250000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

©The Toro Company - 2004
All Rights Reserved

Register your product at www.Toro.com

Contents

Description	Page
Front Frame Assembly	3
Castor and Wheel Assembly	5
Main Frame Assembly	6
Brake and Wheel Hub Assembly	7
Steering Control Assembly	8
Hydraulic System Assembly	9
Seat and Roll-Over-Protection-System Assembly	11
Suspension Seat Assembly No. 106-9988	12
Roll-Over-Protection-System Assembly No. 108-1097	13
Deck Mounting Assembly	14
Drive Idler Assembly	15
Z-Stand Assembly	16
Engine and Clutch Assembly	17
Air Cleaner Assembly No. 95-5805	18
Cooling System Assembly	19
Hood Assembly	20
Cooling Mounting Frame Assembly	21
Fuel Tank Assembly	22
Electrical Components Assembly	23
60in Deck Assembly	24
Spindle Assembly No. 106-3217	26
Deck Decal Assembly No. 107-1624	27
Rubber Deflector Assembly No. 106-3249	28
Lever Assembly No. 106-3242	29
Cylinder/Crankcase Assembly Kawasaki FD750D-AS03	30
Piston/Crankshaft Assembly Kawasaki FD750D-AS03	31
Valve/Camshaft Assembly Kawasaki FD750D-AS03	32
Lubrication Equipment Assembly Kawasaki FD750D-AS03	33
Cooling Equipment Assembly Kawasaki FD750D-AS03	34
Electric Equipment Assembly Kawasaki FD750D-AS03	35
Control Equipment Assembly Kawasaki FD750D-AS03	36
Carburetor Assembly Kawasaki FD750D-AS03	37
Air Filter/Muffler Assembly Kawasaki FD750D-AS03	38
Fuel Tank/Fuel Valve Assembly Kawasaki FD750D-AS03	39
Starter Assembly Kawasaki FD750D-AS03	40
Attachments and Accessories List	41

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR	as required
ASM	assembly
CARR	carriage
DEG	degrees
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HHFTF	hex head flange thread forming
HJ	hex jam
HLH	hex lag head
HOC	height-of-cut
HS	hex
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming
HYD	hydraulic
INC	incorporated
LH	left hand
NI	nylon insert
PPH	phillips pan head
PTH	phillips truss head
PTO	power take off
RH	right hand
SFH	slotted fillister head
SHH	slotted hex head
SHWH	slotted hex washer head
SPH	slotted pan head
SQH	square head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	torx truss head
WH	wing head

Footnotes

❶ Not illustrated

❷ Not serviced separately


❸ Obtain Parts From Kawasaki



Front Frame Assembly


Ref	Part No.	Qty.	Description
1	106-8998	1	Frame ASM
1:2	107-1857	1	Decal-Brake, Parking
1:3	1-811010	2	Plug
1:4	302-19	5	Fitting-Grease
1:5	94-1291	2	Bushing
1:6	104-7759	1	Decal-Warning
1:7	103-1918	1	Bushing
3	106-9981	1	Front Floorpan ASM
3:2	106-7451	1	Decal
3:3	107-2112	1	Decal-Warning
4	103-1918	1	Bushing
5	103-2083-03	1	Lift Lever ASM
6	1-633295	1	Grip-Lever, Lift
7	103-2064-03	1	Arm-Lift, Deck
8	1-633325	1	Spring-Compression
9	3256-24	1	Washer-Flat
10	3296-39	9	Nut-Lock, NI
11	32151-103	5	Ring-Snap
12	1-633068	2	Arm-Lift, Deck
14	323-29	2	Screw-HH
15	1-633889-01	1	Plate-Lift, Deck
16	1-632899-01	1	Plate-Lift, Deck
17	1-633082	1	Bushing-Lever, Lift
18	1-633080	1	Bushing-Lever, Lift

Ref	Part No.	Qty.	Description
19	323-13	1	Screw-HH
20	106-9951	1	Hitch Pin ASM
22	323-9	2	Screw-HH
23	98-5975	12	Washer-Belleville
24	3290-357	15	Nut-HHF
25	323-6	1	Screw-HH
26	323-7	12	Screw-HH
27	3256-29	4	Washer-Flat
❷35		2	Front Frame Spring ASM
35:1	1-633096	1	Rod-Lift, Deck
35:2	1-633441	2	Swivel-Deck Mount, Rear
35:3	3217-11	4	Nut-Hex
35:4	3218-6	2	Nut-Jam
35:5	3256-7	2	Washer-Flat
35:6	1-633064	1	Spring-Support, Deck
36	107-1861	1	Decal-Height, Deck
37	107-1860	1	Decal-Height, Deck
38	3274-94	4	Screw-HSBH
40	106-8983-01	1	RH Deck Lift ASM
41	106-8984-01	1	LH Deck Lift ASM
42	1-523157	2	Washer-Spacer
43	32151-29	2	Ring-Retaining
44	3274-18	2	Screw-HSH
45	3218-2	2	Nut-Jam




Front Frame Assembly (continued)

Ref	Part No.	Qty.	Description
46	1-513658	2	Bumper



Castor and Wheel Assembly


Ref	Part No.	Qty.	Description
1	103-4882	2	Cap-Grease
2	3296-51	2	Nut-Lock, NI
3	1-633508	6	Washer-Bellville
4	254-94	4	Bearing-Cone, Tapered
5	254-72	4	Bearing-Cup, Tapered
7	1-543511	2	Seal-Grease
8	103-1474-01	2	Fork-Caster
11	1-644251	2	Caster Wheel ASM
11:1	1-633580	2	Seal-Bearing
11:2	1-633581	2	Spacer-Bearing
11:3	1-633585	2	Bearing-Cone, Taper
11:4	1-633959	1	Spacer-Caster, Front
❷11:5		1	Wheel And Tire ASM
11:5:1	1-523009	1	Tire
11:5:2	1-633987	1	Wheel
11:5:3	1-633584	2	Bearing-Cup
21	325-39	2	Screw-HH
22	3296-45	2	Nut-Lock, NI



Main Frame Assembly

Ref	Part No.	Qty.	Description
1	1-633964-03	1	Stop-Brake, Park
4	322-43	6	Screw-HH
5	323-6	2	Screw-HH
11	108-1095	1	Main Frame ASM
11:2	107-8076	1	Decal-Console, Top
12	1-633970	2	Wheel And Tire ASM
12:1	1-633993	1	Tire
12:2	1-633992	1	Wheel
12:3	232-27	1	Stem-Valve
13	107-1858	1	Floorpan
13:2	98-4387	1	Decal-Protection, Ear
13:3	107-1864	1	Decal-Location, Manual
15	242-50	8	Nut-Lug
21	3296-39	2	Nut-Lock, NI
24	1-513762	1	Clip-Loom
25	1-303335	1	Tie-Plastic
27	321-4	3	Screw-HH
28	32128-33	1	Nut-HF
44	3256-70	6	Washer-Flat
47	106-7498	1	Pocket
48	106-7488-03	1	Hinge-Floorpan, LH
49	106-7489-03	1	Hinge-Floorpan, RH
50	323-20	2	Screw-HH
51	3296-59	2	Nut-Lock, NI


Ref	Part No.	Qty.	Description
52	3296-42	4	Nut-Lock, NI
53	3256-63	2	Washer-Flat
54	3258-166	2	Screw-Prh
55	106-9989	1	Decal-Warning
56	106-7492	1	Decal-Danger
57	107-1865	2	R-Clamp
58	104-7050	1	Housing-Manual
59	104-7048	1	Cap-Housing



Brake and Wheel Hub Assembly

Ref	Part No.	Qty.	Description
1	1-513140	2	Bearing-Control
2	1-633454	2	Spring-Brake
3	103-4332	1	Brake Rod And Yoke ASM
3:1	1-633131	2	Yoke-Linkage, Brake
3:2	1-633477	1	Rod-Brake
3:3	3219-3	2	Nut-Hex
4	1-634500	1	Brake Lever ASM
4:2	1-633268	1	Grip-Lever, Brake
5	1-632217-03	1	Shaft-Brake
6	103-0352-03	2	Bracket-Brake
7	1-523157	2	Washer-Spacer
9	103-0355	2	Band-Brake
10	1-633380	4	Spacer-Wheel, Short
11	1-633382	4	Spacer-Wheel, Long
12	1-633102	2	Bearing-Flange, Side
13	103-4333	2	Brake Rod And Yoke ASM
13:1	1-633131	1	Yoke-Linkage, Brake
13:2	1-633477	1	Rod-Brake
13:3	3219-3	1	Nut-Hex
14	1-633144	2	Pin-Trunion
15	103-0590	2	Hub And Wheel ASM
15:1	103-0589	1	Wheel Hub ASM
15:2	1-633926	4	Stud-Wheel
18	323-4	4	Screw-HH


Ref	Part No.	Qty.	Description
19	103-2399	3	Pin-Spring, Clevis
20	325-17	8	Screw-HH
21	1481	2	Fitting-Grease
22	103-0131	8	Nut-Square
23	3219-3	4	Nut-Hex
24	3290-357	4	Nut-HHF
25	3253-7	8	Washer-Lock
26	3256-4	4	Washer-Flat
27	3272-10	1	Pin-Cotter
28	1-806800	2	Pin-Cotter
29	322-9	6	Screw-HH
30	103-0384	6	Spacer
31	103-0374	2	Retainer-Band, Brake
32	1-808285	1	Pin-Clevis
33	3272-10	1	Pin-Cotter



Steering Control Assembly

Ref	Part No.	Qty.	Description
1	1-303105	2	Yoke-Adjustable
2	98-5975	4	Washer-Belleville
3	103-4079	2	Damper-Control, Motion
5	1-603735	2	Bushing-Flanged
6	1-603737	2	Bolt-Return, Neutral
7	1-603807	2	Spring-Return, Neutral
8	1-403180	4	Screw-HH
❷9		1	Tracking Rod ASM
9:1	1-543017	1	Balljoint-RH
9:2	3219-2	3	Nut-Hex
9:3	103-3064	1	Link-Rod, Tracking
9:4	1-804524	1	Nut
9:5	1-633152	1	Balljoint-Thread, LH
❷10		1	Tracking Rod ASM
10:1	1-543017	1	Balljoint-RH
10:2	3219-2	1	Nut-Hex
10:3	103-3060	1	Knob-Tracking
10:4	1-804524	2	Nut
10:5	1-323245	2	Spring-Compression
10:6	1-633152	1	Balljoint-Thread, LH
10:7	103-3064	1	Link-Rod, Tracking
11	108-7238	1	LH Lever ASM
11:2	106-9987	1	Grip-Control, Motion
12	1-632208	2	Arm-Control, Pump


Ref	Part No.	Qty.	Description
13	103-4781	1	Control-Motion, LH
14	103-4782	1	Control-Motion, RH
16	1-633102	4	Bearing-Flange, Side
18	103-0407	2	Arm-Shaft, Control
20	322-6	4	Screw-HH
21	323-4	8	Screw-HH
22	323-6	4	Screw-HH
23	323-9	6	Screw-HH
24	1-803022	2	Screw-Set
25	3296-39	6	Nut-Lock, NI
26	3219-2	4	Nut-Hex
28	3220-2	2	Nut-Jam
29	3256-2	2	Washer-Flat
30	3256-3	4	Washer-Flat
32	3272-5	2	Pin-Cotter
33	1-808280	2	Pin-Clevis
34	32128-20	16	Nut-HF
35	3290-357	8	Nut-HHF
37	108-7237	1	RH Lever ASM
37:2	106-9987	1	Grip-Control, Motion



Hydraulic System Assembly


Ref	Part No.	Qty.	Description
1	103-3736	1	HYD Hose ASM
2	103-1947	1	HYD Reservoir ASM
❷2:1		1	Reservoir-HYD
2:1:1	103-1948	1	Cap-Reservoir, HYD
2:1:2	103-1949	1	Gasket-Cap
2:2	1-523552	1	Decal-Tank, HYD
3	104-7836	1	Head-Filter
4	103-3733	1	HYD Hose ASM
6	1-633750	1	Filter-HYD
6	1-633752	1	Filter-Hyd, Winter
7	103-1799	2	Elbow-90 DEG
7:1	237-42	1	O-Ring
10	1-603991	4	Fitting-Straight
10:1	237-80	1	O-Ring
10:2	1-603992	1	O-Ring
11	103-6988	2	Motor-Wheel
11:1	1-809036	1	Nut-HH
11:2	3257-42	1	Key-Woodruff
❶11:99	103-2748	1	Drive Link Kit
❶11:99	1-000139	1	Bearing Kit
❶11:99	1-000099	1	Seal Kit
12	1-603384	1	Bushing-Pivot, Idler
13	103-3330	1	Spring-Extension
14	103-1828	1	Adapter-Run, Tee

Ref	Part No.	Qty.	Description
14:1	237-42	1	O-Ring
16	103-1716	3	Clamp-Hose
17	103-1988	4	Clamp-Hose
18	103-1801	1	Adapter-Straight
18:1	237-42	1	O-Ring
19	103-1912	1	Adapter-Straight
19:1	237-42	1	O-Ring
20	103-1802	2	Fitting-Hyd, 90 DEG
20:1	1-603921	1	O-Ring
21	1-603990	4	Fitting-Straight
21:1	1-603920	1	O-Ring
21:2	1-603992	1	O-Ring
22	103-3737	1	HYD Hose ASM
23	103-3735	1	HYD Hose ASM
24	103-1826	1	HYD Hose ASM
25	103-1808	1	Hose-HYD
26	103-1807	1	Elbow-45 DEG
26:1	237-42	1	O-Ring
27	103-1806	1	HYD Hose ASM
28	103-6907	2	Sheave
29	1-633567	1	Sheave
30	103-7445	1	Belt-V
31	1-633167	1	Sheave-Idler
32	103-1827	1	HYD Hose ASM




Hydraulic System Assembly (continued)

Ref	Part No.	Qty.	Description
33	1-634277	1	Bearing Arm ASM
33:1	1-513034	2	Sleeve-Bearing
33:3	302-40	1	Fitting-Grease
34	321-6	2	Screw-HH
35	323-8	1	Screw-HH
36	323-9	1	Screw-HH
37	1-800805	1	Screw-HH
38	323-7	4	Screw-HH
39	1-803022	2	Screw-Set
40	30-1710	2	Screw
41	1-803050	2	Screw-Set
42	3256-22	2	Washer-Flat
43	3256-3	1	Washer-Flat
44	3256-4	1	Washer-Flat
45	13-2840	1	Key-Square
46	1-807272	2	Key
47	3290-357	8	Nut-HHF
48	32128-33	2	Nut-HF
49	1-805004	2	Washer-Lock
50	321-3	2	Screw-HH
51	103-7262	2	Pump-HYD




Seat and Roll-Over-Protection-System Assembly

Ref	Part No.	Qty.	Description
2	106-9988	1	Seat-Suspension
16	1-633293	1	Rod-Holdup, Seat
17	322-5	1	Screw-HH
18	323-39	2	Screw-HH
20	3296-29	3	Nut-Lock, NI
21	3296-39	3	Nut-Lock, NI
23	32128-20	4	Nut-HF
34	99-4693	1	Decal
78	108-1097	1	Rops ASM



Suspension Seat Assembly No. 106-9988


Ref	Part No.	Qty.	Description
1	107-1880	1	Seat Track Kit
2	107-1885	1	Weight Indicator Kit
3	107-1881	1	Knob Kit
4	107-1883	1	Bottom Cushion Kit
5	107-1886	1	Switch Kit
6	107-1887	1	Armrest Kit
7	107-1884	1	Shock Absorber Kit
8	107-1882	1	Back Cushion Kit
9	103-4469	1	Seatbelt Kit
9:2	3212-4	2	Screw-HH
9:3	3296-38	2	Nut-Lock NI



Roll-Over-Protection-System Assembly No. 108-1097


Ref	Part No.	Qty.	Description
❷1		1	Upper Tube ASM
1:2	107-2101	1	Decal-Rops
1:3	107-2102	1	Decal-Warning, Folding Rops
2	107-3154	2	Nut-Push
4	103-4553	2	Rops Fold Pin ASM
5	325-13	2	Screw-HH
6	32128-23	2	Nut-HF
13	106-0887	2	Knob
14	107-3124	2	Clip
16	107-3052-03	1	Seat Support Frame ASM
17	107-3058	1	Catch-Latch, Seat
18	322-3	2	Screw-HH
19	3296-29	2	Nut-Lock, NI
20	3296-39	1	Nut-Lock, NI
23	322-20	1	Screw-HH
24	107-0076	1	Spring-Torsion
25	107-0075	1	Bushing-Latch, Seat
26	62-9130	1	Grip-Handle
28	3256-24	1	Washer-Flat
29	107-3083	1	Latch ASM
34	103-4469	1	Seatbelt Kit
34:2	3212-4	2	Screw-HH
34:3	3296-38	2	Nut-Lock NI
❶❷54		1	Rops Bolt Bag

Ref	Part No.	Qty.	Description
54:3	323-6	8	Screw-HH
54:4	98-5975	8	Washer-Belleville
54:5	3290-357	8	Nut-HHF



Deck Mounting Assembly


Ref	Part No.	Qty.	Description
1	32128-37	16	Nut-HF
2	103-1898	8	Screw-HH
3	1-633447	4	Chain-Lift, Deck
4	302-19	4	Fitting-Grease
5	3217-11	2	Nut-Hex
6	3253-8	2	Washer-Lock
7	327-11	2	Screw-HH
8	1-633029	2	Balljoint-Spherical
9	3219-6	2	Nut-Hex
10	103-1072-01	2	Strut
11	1-632199-01	2	Pin-Strut
12	322-3	2	Screw-HH
13	3296-29	2	Nut-Lock, NI



Drive Idler Assembly


Ref	Part No.	Qty.	Description
1	98-5975	1	Washer-Belleville
6	103-2627	1	Bushing-Idler
7	1-603384	1	Bushing-Pivot, Idler
9	1-603496	1	Bushing-Idler
10	99-4638	1	Idler
11	1-603402	1	Spring-Extension
12	1-633166	1	Pulley-Idler
14	103-3147	1	Arm ASM
14:1	1-513034	2	Sleeve-Bearing
14:2	302-40	1	Fitting-Grease
15	323-12	2	Screw-HH
16	323-9	1	Screw-HH
17	323-13	1	Screw-HH
18	1-800805	1	Screw-HH
19	3296-39	3	Nut-Lock, NI
20	3256-24	3	Washer-Flat
21	3290-357	6	Nut-HHF
22	1-603401	1	Spacer-Fender
24	3256-4	3	Washer-Flat
26	106-3271	1	Travel Limiter ASM
26:1	106-3228-03	1	Plate-Limiter, Pulley
26:2	106-3229	1	Pad-Bumber
26:3	3269-24	2	Rivet
27	108-7204	1	Guide-Belt, LH

Ref	Part No.	Qty.	Description
28	108-7229	1	Guide-Belt, RH
29	3231-2	2	Screw-CARR



Z-Stand Assembly


Ref	Part No.	Qty.	Description
1	323-20	1	Screw-HH
2	100-6542-01	1	Bracket-Cradle
3	3296-39	2	Nut-Lock, NI
4	107-1874	1	Leg ASM
4:2	106-7464	1	Decal-Z Stand
5	283-55	1	Pin-Clevis
6	100-9692-01	1	Pivot Pin ASM
7	323-8	1	Screw-HH
8	100-9686-01	1	Bracket-Latch
9	3-6781	2	Washer-Thrust
10	283-71	1	Pin-Lynch
11	3290-355	1	Pin-Hair
12	100-6547	2	Cushion-Rubber
14	105-1647	1	Pin-Hitch, Cotterless
15	100-9385	1	Lanyard-Nylon
16	321-4	1	Screw-HH
17	3296-42	1	Nut-Lock, NI



Engine and Clutch Assembly


Ref	Part No.	Qty.	Description
2	103-2759	1	Muffler
5	52-4780	1	Rod-Belt
6	1-603610	2	Washer-Spring
7	1-303334	6	Washer-Spring
9	103-6589	1	Clutch
❷11		1	Engine-Kawasaki, Fd750d-As03
12	33013-00	4	Nut-Hex
13	1-805004	4	Washer-Lock
14	103-0152	1	Keeper-Clutch
15	95-5806	1	Bracket-Mounting
16	3256-3	4	Washer-Flat
17	95-5805	1	Air Cleaner ASM
18	1-643009	1	Clamp-Hose
20	1-643084	1	Hose-Inlet, Air
25	48-7570	1	Screw - HH
33	33115-025	5	Screw-HH
37	33115-020	2	Screw-HH
39	322-6	3	Screw-HH
42	3296-29	2	Nut-Lock, NI
46	103-3068	1	Valve-Drain, Oil
47	103-0114	1	Spacer-Clutch
48	103-1511	1	Arrestor-Spark
49	103-1512	1	Clamp-Muffler
50	3256-24	1	Washer-Flat

Ref	Part No.	Qty.	Description
51	98-5975	1	Washer-Belleville
52	1-643083	1	Hose-Aircleaner



Air Cleaner Assembly No. 95-5805


Ref	Part No.	Qty.	Description
2	108-3811	1	Filter-Air
3	94-3652	1	Cover ASM
4	87-9400	1	Valve-Vacuator
5	285-17	1	Plug-Pipe



Cooling System Assembly


Ref	Part No.	Qty.	Description
1	104-7843	1	Radiator Trim Plate ASM
1:2	65-2690	2	Decal-Surface, Hot
1:3	104-2449	1	Decal-Coolant
2	1-643161	1	Cap-Radiator
3	103-1046	1	Radiator,horiz Mount
4	322-1	12	Screw-HH
5	3256-23	14	Washer-Flat
6	100-4301	1	99-4644
6:2	1-643253	2	Decal-Fan, Radiator
7	1-803067	4	Screw
8	3256-16	8	Washer-Flat
9	1-804254	4	Nut
10	1-633831	1	Fan
11	1-633989	4	Clamp-Hose
12	103-0074	1	Hose, Radiator Inlet
13	103-0075	1	Hose, Radiator Outlet
14	1-643164	1	Cap-Tank, Overflow
15	1-643163	1	Tank-Overflow
16	1-643131	1	Hose
17	1-643259	1	Fitting-Elbow
18	1-513645	1	Bushing-Valve, Fuel
19	103-2603-03	1	Bracket-Bottle
20	321-2	2	Screw-HH
21	1-303287	3	Tie-Plastic

Ref	Part No.	Qty.	Description
22	1-643129	1	Hose
23	1-633851	1	Extension-Crankshaft
24	3255-8	3	Washer-Lock
25	33014-00	3	Nut-Hex
26	1-633869	1	Fan-Pump, Cooling
27	3256-22	3	Washer-Flat
28	1-809095	3	Screw-HSH
29	103-0098	1	Shroud,hydraulic Fan
30	3296-2	6	Nut-Lock
31	3256-14	12	Washer-Flat
32	3290-500	6	Screw-PPH
33	103-0895-03	1	Shield-LH
34	1-633794-03	1	Shield-RH
35	321-4	6	Screw-HH
36	32128-33	6	Nut-HF
37	103-3270	1	Decal



Hood Assembly


Ref	Part No.	Qty.	Description
1	1-633864-03	1	Screen-Radiator
2	1-803072	17	Rivet
3	3256-14	12	Washer-Flat
4	322-4	4	Screw-HH
5	104-5136	1	Hood
6	3256-23	10	Washer-Flat
7	1-303435	5	Washer-Spring
8	3296-29	4	Nut-Lock, NI
9	1-633885-03	2	Plate-Hinge, Hood
10	1-632986-03	2	Shackle-Hinge
11	32128-20	25	Nut-HF
12	322-3	16	Screw-HH
13	1-808285	2	Pin-Clevis
14	3256-24	6	Washer-Flat
15	1-806003	2	Pin-Hair
16	1-643106-03	1	Angle-Radiator, RH
17	1-643108-03	1	Angle-Radiator, Bottom
18	1-643107-03	1	Angle-Radiator, Top
19	1-643105-03	1	Angle-Radiator, LH
20	1-643187	2	Seal-Trim
21	1-643186	2	Seal-Trim
23	1-643188	2	Latch-Rubber
24	923786	4	Rivet-Pop
28	106-7456	1	Decal



Cooling Mounting Frame Assembly

Ref	Part No.	Qty.	Description
1	3256-24	6	Washer-Flat
2	1-803075	4	Screw-Head, Truss
4	3296-2	4	Nut-Lock
5	1-633878-03	1	Crossbar
6	322-4	4	Screw-HH
7	32128-20	12	Nut-HF
8	322-3	8	Screw-HH
9	3296-42	6	Nut-Lock, NI
10	32128-33	2	Nut-HF
11	1-523420	2	Bumper
12	321-9	2	Screw-HH
13	1-643339	1	Decal-Routing, Belt
14	103-0107-03	1	Brace-Radiator, LH
15	1-632985-03	1	Brace-Radiator, RH
16	103-2870-03	1	Deflector-Air
17	3269-3	4	Rivet-Pop
18	49-2040	2	Screw-Tapping
19	103-0110-03	1	Plenum-Intake, Air
20	1-644276	1	Shield ASM
20:1	1-633462	1	Decal-Important
20:2	1-634308	1	Shield/lift ASM
20:2:1	103-1308	1	Shield-Engine
20:2:2	1-633300-03	1	Lift-Shield
20:2:3	1-803035	3	Rivet-Pop


Ref	Part No.	Qty.	Description
20:3	103-5881	1	Decal-Devices, Rotating
21	321-4	4	Screw-HH
22	103-7452-03	1	Plate, Side Rad. Mount Hl
23	3256-2	6	Washer-Flat
24	923786	4	Rivet-Pop
25	322-5	9	Screw-HH
26	1-632873-03	1	Mount-Radiator, Rear
27	1-633886-03	1	Guard-Bumper
28	1-633897-03	2	Rib-Top
29	1-633898-03	2	Rib-Bottom
30	1-633877-03	2	Bar-Latch Hook
31	1-643189	2	Keeper-Latch, Rubber
32	3290-357	10	Nut-HHF
33	323-6	6	Screw-HH
34	3256-23	11	Washer-Flat
35	323-7	4	Screw-HH
36	103-7623-03	2	Strap,guard L/c
37	103-7453-03	1	Plate, Side Rad. Mount RH



Fuel Tank Assembly

Ref	Part No.	Qty.	Description
1	1-303077	17	Clamp
2	107-8078-03	1	Panel-Control, Lc
3	1-543526	1	Hose-Fuel
4	103-1335	1	Hose-Fuel
5	88-3980	2	Gas Cap ASM
5:3	88-4010	1	Gasket-Cap, Gas
8	80-7360	1	Hose-Fuel
9	1-633023	6	Stud
10	106-9980	1	LH Fuel Tank ASM
10:2	103-2605	1	Fitting-Fuel, Bulkhead
11	106-9979	1	RH Fuel Tank ASM
11:2	103-2605	1	Fitting-Fuel, Bulkhead
12	1-603770	1	Valve-Fuel
13	47-2965	1	Gas Hose
14	1-633349	6	Spring-Tank, Fuel
15	321-4	2	Screw-HH
16	322-3	2	Screw-HH
17	3296-47	6	Nut-Lock, NI
18	3256-2	2	Washer-Flat
19	1-805005	2	Washer-Lock
20	3256-23	8	Washer-Flat
21	106-9968	1	Decal-Panel, Control
23	1-803071	4	Screw
24	1-303435	4	Washer-Spring


Ref	Part No.	Qty.	Description
25	321-3	2	Screw-HH
26	1-805004	2	Washer-Lock
27	47-2965	2	Gas Hose
28	1-513762	1	Clip-Loom
29	32128-33	2	Nut-HF
31	99-5005	1	Fitting-Tee, Barbed
32	99-5000	2	Valve-Check, Fuel
33	99-7190	2	Hose-Fuel
44	107-8073	1	Throttle-Control
45	106-9962	1	Control-Choke, Push/pull
46	1-807513	2	Bolt-CARR
47	1-513592	1	Knob-Ball
48	3296-2	2	Nut-Lock
49	1-303335	4	Tie-Plastic



Electrical Components Assembly

Ref	Part No.	Qty.	Description
1	106-7496	1	Harness-Wire
2	1-816001	1	Fuse-Blade Type, 20 Amp
3	1-816003	1	Fuse-Blade Type, 30 Amp
4	1-643275	3	Relay
5	1-803071	2	Screw
6	3296-2	4	Nut-Lock
7	1-543393	1	Insulator-Solenoid
8	321-4	5	Screw-HH
9	1-633396	3	Clip-Loom
10	32128-33	5	Nut-HF
11	33014-00	1	Nut-Hex
12	3256-23	2	Washer-Flat
13	105-3646	1	Decal-Warning, Battery
14	33114-016	1	Screw-HH
16	1-643145	1	Tab
17	103-0283	1	Sender-Temperature
18	1-643153	1	Washer-Aluminum
19	1-523279	1	Wire-Battery, Positive
20	1-633307	1	Wire-Ground
21	1-543391	1	Insulator-Battery
22	1-303335	10	Tie-Plastic
23	3256-2	2	Washer-Flat
24	105-1692	1	Battery
24:1	104-4163	1	Decal-Battery


Ref	Part No.	Qty.	Description
24:2	104-4164	1	Decal-Battery
25	1-303287	2	Tie-Plastic
26	1-633652-03	1	Strap-Holddown
27	1-543792	2	Wingnut
28	1-633651	2	Bolt-Holddown
29	3290-500	8	Screw-PPH
31	1-633181	3	Plate-Tapped
33	1-633111	1	Switch
34	1-513762	1	Clip-Loom
35	1-633673	1	Switch-Delta
36	88-9830	1	Key Switch ASM
36:1	3254-5	1	Washer-Tooth
36:2	218-461	1	Nut-HH
37	1-513374	1	Meter-Hour
38	100-6186	1	Module-Delay, Seat
39	1-643115	1	Tie-Plastic
41	63-8360	2	Key-Ignition
43	1-643037	1	Gauge-Voltmeter
44	1-643021	1	Gauge-Temperature
48	1-513051	2	Switch-Open, Normally
49	103-1027	1	Decal-Relay
50	103-1227	1	Harness-Wiring, Seat



60in Deck Assembly


Ref	Part No.	Qty.	Description
1	105-8783	1	Belt
2	74-5950	4	Latch-Swell
3	105-8786-01	2	Cover-Belt
4	106-3220	1	Guide-Belt
5	105-8792-01	1	Plate-Skid
6	32144-70	4	Screw-HH
7	105-8787-01	4	Bracket-Cover
8	105-7699	8	Strip-Seal
9	106-7354-01	1	Plate-Roller, LH
10	106-7355-01	1	Plate-Roller, RH
11	3290-357	38	Nut-HHF
12	323-28	1	Screw-HH
13	92-1624	33	Screw
14	105-7734	3	Pulley
15	106-3217	3	Spindle ASM
16	105-7718-03	3	Blade-Hi Flow
17	323-23	4	Screw-HH
18	98-7913	4	Tube-Spacer
19	322-50	1	Screw-HH
20	98-5967	1	Spacer-Wheel
21	1-603299	6	Roller-Anti Scalp
22	3296-29	1	Nut-Lock, NI
23	107-1624	1	Deck ASM
24	105-7657-01	1	Baffle ASM

Ref	Part No.	Qty.	Description
25	105-7669-01	1	Baffle ASM
26	98-7912	4	Tube-Spanner
27	104-8554	1	Spring-Torsion
28	105-4622	1	Spacer
29	106-3249	1	Rubber Deflector ASM
30	105-7697	2	Washer-Plastic
31	106-3242	2	Lever ASM
32	323-12	2	Screw-HH
33	106-3214	2	Mount-Pulley
34	3256-24	4	Washer-Flat
35	1-633109	3	Idler-Flat
36	3231-1	10	Screw-CARR
37	99-3058	4	Washer
38	323-9	1	Screw-HH
39	1-603496	1	Bushing-Idler
40	105-7787-01	1	Plate-Idler
41	105-7788	2	Spacer
42	3231-4	2	Screw-CARR
43	3296-39	7	Nut-Lock, NI
44	98-5975	1	Washer-Belleville
45	103-0862	3	Screw-Cap
46	103-0865	3	Washer-Blade Bolt, Heavy
47	106-3216-01	1	Baffle-Discharge
48	112843	1	Washer




60in Deck Assembly (continued)

Ref	Part No.	Qty.	Description
49	108-7220	1	Guide-Belt
❶99	105-7777-03	3	Blade-Recycler, 20.5
❶99	105-7716-03	3	Blade-Lo Flow, 20.5
❶99	105-7715-03	3	Blade-Mid Flow, 20.5
❶99	105-8777-03	3	Blade-Atomic, 20.5




Spindle Assembly No. 106-3217

Ref	Part No.	Qty.	Description
1	10-8040	1	Key-Square
2	106-3277	1	Hub-Pulley
3	103-0865	1	Washer-Blade Bolt, Heavy
4	106-3204	2	Shield-Bearing
❷5		1	Spindle Bearing ASM
5:1	106-3211	1	Housing-Spindle
5:2	106-3207	1	Bearing ASM
5:2:1	27-0960	1	Bearing ASM
5:2:2	106-3206	1	Spacer-Set, Matched
5:3	253-133	2	Seal-Oil
5:4	302-5	1	Fitting-Grease
6	106-3218	2	Spacer-Seal
7	106-3233	1	Spindle Shaft ASM
8	3219-6	1	Nut-Hex




Deck Decal Assembly No. 107-1624

Ref	Part No.	Qty.	Description
2	54-9220	1	Decal-Danger
3	66-1340	1	Decal-Danger
4	98-5954	3	Decal-Missing, Cover
5	43-8480	1	Decal-Danger
6	68-8340	1	Decal-Torque
7	105-7797	1	Decal-Routing, Belt
8	105-7798	1	Decal-Anti Scalp
9	58-6520	3	Decal-Grease
10	107-1622	1	Decal-Adjustment, Baffle
11	107-1613	2	Decal-Grease
12	107-1619	1	Decal
13	107-1621	1	Decal-Service, Check
14	104-8569	1	Decal-Warning
15	107-3137	1	Plate-Turbo
16	3274-104	2	Screw-HSBH
17	1-303334	4	Washer-Spring
18	3296-29	2	Nut-Lock, NI




Rubber Deflector Assembly No. 106-3249

Ref	Part No.	Qty.	Description
1	3231-4	4	Screw-CARR
2	106-3246-01	1	Deflector
3	106-3248-03	1	Strap-Discharge
4	107-1617	1	Defelector-Rubber
5	106-3252-01	1	Plate-Hinge, Rear
6	106-3253-01	1	Plate-Hinge, Front
7	3296-39	4	Nut-Lock, NI



Lever Assembly No. 106-3242


Ref	Part No.	Qty.	Description
1	106-3239	1	Screw-Lock
2	106-3240	1	Cap-Lock
3	106-3241	1	Lever-Lock
4	3296-29	1	Nut-Lock, NI



Cylinder/Crankcase Assembly
Kawasaki FD750D-AS03


Ref	Part No.	Qty.	Description
❸11004	11004-2142	2	Gasket-Head
❸11008	11008-2145	1	Head-Comp-Cylinder
❸11008A	11008-2146	1	Head-Comp-Cylinder
❸11022	11022-2072	1	Case-Rocker
❸11022A	11022-2073	1	Case-Rocker
❸11060	11060-2466	1	Gasket, Breath
❸11060A	11060-2470	2	Gasket, Rocker, Case
❸13271	13271-2105	2	Plate
❸14091	14091-2064	1	Cover, Breath
❸16126	16126-2225	2	Valve, Breath
❸49015	49015-6232	1	Cover-Crankcase
❸49120	49120-6127	1	Crankcase-Comp
❸59071	59071-2079	1	Joint
❸92009	92009-2308	2	Screw
❸92043	92043-1037	6	Pin
❸92049	92049-2242	1	Seal-Oil
❸92049A	92049-2243	1	Seal-Oil
❸92093	92093-2086	1	Seal
❸92141	92141-2118	1	Bearing-Plane
❸92141A	92141-2119	1	Bearing-Plane
❸92151	92151-2158	4	Bolt
❸92151A	92151-2159	8	Bolt
❸92170	92170-2002	2	Clamp
❸92191	92191-2105	1	Tube

Ref	Part No.	Qty.	Description
❸130	130G0630	8	Bolt-Flanged
❸130A	130G0830	4	Bolt-Flanged
❸130B	130G0845	4	Bolt
❸130C	310G0860	4	Bolt-Flanged
❸172	172G0822	4	Bolt-Stud
❸670	670B2011	2	O-Ring




Piston/Crankshaft Assembly
Kawasaki FD750D-AS03

Ref	Part No.	Qty.	Description
❸13001	13001-2125	2	Piston-Engine
❸13002	13002-2069	2	Pin-Piston
❸13008	13008-6007	2	Ring-Set-Piston
❸13251	13251-2058	2	Rod ASM-Connecting
❸49119	49119-2198	1	Crankshaft ASM
❸59051	59051-2358	1	Gear-Spur, 33t
❸92036	92036-008	4	Ring-Snap
❸92151	92151-2150	4	Bolt
❸510	510A5100	1	Key-Woodruff




Valve/Camshaft Assembly
Kawasaki FD750D-AS03

Ref	Part No.	Qty.	Description
❸11051	11051-2092	2	Bracket
❸12004	12004-2113	2	Valve-Intake
❸12005	12005-2100	2	Valve-Exhaust
❸12009	12009-2060	4	Retainer-Valve Spring
❸12011	12011-2052	8	Collet
❸12016	12016-2063	4	Arm-Rocker
❸12032	12032-2060	4	Tappet
❸13116	13116-2074	4	Rod-Push
❸16007	16007-2052	4	Seat-Spring
❸49078	49078-2060	4	Spring-Engine Valve
❸49118	49118-2138	1	Camshaft
❸92049	92049-2100	4	Seal-Oil
❸92145	92145-2085	1	Spring
❸92151	92151-2134	4	Bolt
❸92152	92152-2066	4	Collar
❸92200	92200-2128	4	Washer
❸130	130G0814	4	Bolt-Flanged
❸311	311B0600	4	Nut-Hex



Lubrication Equipment Assembly
Kawasaki FD750D-AS03


Ref	Part No.	Qty.	Description
❸11009	11009-2566	2	Gasket,drain Plug
❸13107	13107-2281	1	Shaft, Oil Pump
❸13280	13280-2061	1	Holder, Oil Pump
❸14091	14091-2065	1	Cover, Oil Pump
❸16115	16115-2126	1	Cap-Oil Filler
❸16154	16154-1075	1	Rotor-Pump, Outer
❸16154A	16154-1076	1	Rotor-Pump, Inner
❸16154B	16154-1079	1	Rotor-Pump
❸32153	32153-2076-9H	1	Pipe, Oil Gauge
❸49065	49065-2071	1	Filter-Oil
❸49065A	49065-2082	1	Filter
❸52005	52005-2132	1	Gauge, Oil
❸59051	59051-2354	1	Gear-Spur, 33t
❸92042	92042-014	2	Pin
❸92055	92055-2086	1	O-Ring
❸92066	92066-2099	2	Plug,drain
❸92144	92144-2053	1	Spring
❸130	130G0616	3	Bolt
❸130A	130G0625	2	Bolt-Flanged
❸600	600A1300	1	Ball-Steel
❸670	670B2010	1	O-Ring
❸670A	670B2011	1	O-Ring
❸670B	670B3025	1	O-Ring



Cooling Equipment Assembly
Kawasaki FD750D-AS03

Ref	Part No.	Qty.	Description
❸11009	11009-3028	1	Gasket
❸11060	11060-2475	1	Gasket-Thermostat
❸13107	13107-2097	1	Shaft,impeller
❸16142	16142-2077	1	Cover-Pump
❸16160	16160-2127	1	Body-Upper
❸16160A	16160-6002	1	Body-Valve
❸39062	39062-2080	1	Hose-Cooling
❸39062A	39062-2083	1	Hose-Cooling
❸39062B	39062-2084	1	Hose-Cooling
❸49044	49044-2063	1	Pump-Water
❸49054	49054-2058	1	Thermostat
❸49063	49063-1054	1	Seal-Mechanical
❸59051	59051-2355	1	Gear-Spur, 25t
❸59256	59256-2069	1	Impeller
❸59336	59336-2078	1	Case-Pump
❸92037	92170-1284	2	Clamp
❸92043	92043-2237	1	Pin
❸92049	92049-2111	1	Seal-Oil
❸92171	92171-2056	4	Clamp
❸92200	92200-2134	1	Washer
❸92200A	92200-2135	1	Washer
❸130	130C0812	1	Bolt-Flanged
❸130A	130G0625	3	Bolt-Flanged
❸130B	130G0635	2	Bolt-Flanged


Ref	Part No.	Qty.	Description
❸130C	130G0830	2	Bolt-Flanged
❸130D	130G0845	1	Bolt
❸130E	130G0860	2	Bolt-Flanged
❸130F	130G0880	4	Bolt-Flanged
❸171	171G0818	3	Bolt-Stud
❸551	551A0314	1	Pin-Dowel
❸670	670B1507	1	O Ring



Electric Equipment Assembly
Kawasaki FD750D-AS03

Ref	Part No.	Qty.	Description
❸11009	11009-2766	1	Gasket
❸11052	11052-2058	1	Bracket
❸21066	21066-2079	1	Regulator-Voltage
❸21121	21121-2090	1	Coil-Ignition, No. 1
❸21121A	21121-2091	1	Coil-Ignition, No. 2
❸21193	21193-2177	1	Flywheel ASM
❸26004	26004-1093	1	Fuse ASM
❸26030	26030-2320	1	Harness
❸27010	27010-7001	1	Switch
❸59031	59031-2127	1	Coil-Charging
❸92009	92009-2273	4	Scerw
❸92037A	92037-2101	1	Clamp
❸92066	92066-2099	1	Plug,drain
❸92070	92070-2110	2	Plug-Spark, Bpr2es
❸92072	92072-1195	1	Band
❸92151	92151-2097	1	Bolt (12x30)
❸92170	92170-2060	4	Clamp
❸92171	92171-2060	1	Clamp
❸92200	92200-2119	1	Washer
❸130	130G0520	1	Bolt-Flanged
❸130A	130G0630	2	Bolt-Flanged
❸130B	130G0812	3	Bolt
❸130C	130G0816	2	Bolt-Flanged
❸214	214B0510	1	Screw-Pan


Ref	Part No.	Qty.	Description
❸510	510A5100	1	Key-Woodruff



Control Equipment Assembly
Kawasaki FD750D-AS03


Ref	Part No.	Qty.	Description
❸11051	11051-2113	1	Bracket
❸13168	13168-2466	1	Lever-Throttle
❸13168A	13168-2467	1	Lever-Choke
❸16169	16169-2142	1	Link-Choke
❸16171	16171-2091	1	Link
❸21187	21187-2073	1	Arm ASM
❸39003	39003-2091	1	Arm-Pivot
❸39129	39129-2099	1	Spring-Governor
❸42036	42036-2060	1	Sleeve
❸49110	49110-2094	1	Governor ASM
❸49113	49113-2170	1	Panel-Comp-Control
❸59226	59226-2328	1	Panel-Control
❸92002	92002-1902	1	Bolt
❸92002A	92002-2269	1	Bolt
❸92009	92009-2381	2	Screw
❸92015	92015-2051	2	Nut
❸92022	92002-2372	1	Washer
❸92027	92027-1461	1	Collar
❸92037	92037-2209	2	Clamp
❸92143	92143-2135	2	Collar, 6x13x2.3
❸92143A	92143-2148	1	Collar
❸92144	92144-2052	1	Spring
❸92145	92145-2058	1	Spring
❸92145A	92145-2095	1	Spring

Ref	Part No.	Qty.	Description
❸92150	92150-2182	2	Bolt (5x18)
❸92200	92200-2035	1	Washer
❸92200A	92200-2108	2	Washer
❸92200B	92200-2120	1	Washer
❸92200C	92200-2122	1	Washer
❸130	130B0630	2	Bolt-Flanged
❸130A	130G0614	2	Bolt
❸311	311B0600	2	Nut-Hex
❸312	312G0500	2	Nut-Hex
❸411	411b0600	1	Washer-Plain
❸482	482J7000	1	Circlip-Type E




Carburetor Assembly
Kawasaki FD750D-AS03


Ref	Part No.	Qty.	Description
❸11060	11060-2468	1	Gasket-Intake
❸11060A	11060-2469	1	Gasket-Intake
❸11060B	11060-2471	2	Gasket-Intake Pipe
❸11060C	11060-2473	1	Gasket-Carburetor
❸15003	15003-2776	1	Carburetor ASM
❸16060	16060-2194	1	Pipe-Intake
❸16073	16073-2206	1	Insulator
❸16146	16146-2227	1	Cover ASM
❸16183	16183-2006	1	Float ASM
❸16184	16184-2004	1	Float Chamber ASM
❸16185	16185-2036	1	Throttle Valve ASM
❸16186	16186-2036	1	Choke Valve ASM
❸23013	23013-2059	1	Screw ASM
❸23013A	23013-2060	1	Screw ASM
❸59076	59076-2065	1	Manifold-Intake
❸92037	92037-1610	1	Clamp
❸92063	92063-2400	2	Jet-Main
❸92064	92064-2113	2	Jet-Pilot
❸130	130G0825	8	Bolt
❸130A	130T06110	4	Bolt-Flanged
❸701	701Q061000	1	Tube-Pvc



Air Filter/Muffler Assembly
Kawasaki FD750D-AS03


Ref	Part No.	Qty.	Description
❸11051	11051-2088	1	Bracket
❸11060	11060-2467	2	Gasket-Muffler
❸11060A	11060-2474	2	Gasket-Air Filter
❸14073	14073-2075	1	Duct-Lower
❸14073A	14073-2076	1	Duct-Upper
❸16060	16060-2197	1	Pipe-Intake
❸92037	92037-1654	1	Clamp
❸92093	92093-2118	1	Seal
❸92170	92170-2075	1	Clamp
❸130	130G0620	3	Bolt-Flanged
❸317	317R0800	1	Nut-Hex, Small
❸461	461F0800	1	Washer-Spring





Fuel Tank/Fuel Valve Assembly
Kawasaki FD750D-AS03

Ref	Part No.	Qty.	Description
❸49019	49019-1055	1	Filter-Fuel
❸49040	49040-2065	1	Pump-Fuel, Kawasaki
❸59071	59071-2119	1	Joint
❸92170	92170-2042	2	Clamp
❸92190	92190-2095	1	Tube



Starter Assembly
Kawasaki FD750D-AS03

Ref	Part No.	Qty.	Description
❸11012	11012-2226	1	Cap
❸13081	13081-2108	1	Clutch ASM
❸13091	13091-2068	1	Brush Holder
❸13168	13168-2131	1	Lever
❸14024	14024-2205	1	Cover
❸16073	16073-2098	1	Insulator
❸16146	16146-2187	1	Cover ASM
❸16146A	16146-2225	1	Cover ASM
❸21039	21039-2059	4	Brush
❸21040	21040-2052	4	Brush Spring
❸21080	21080-2054	1	Armature
❸21163	21163-2120	1	Starter-Electric
❸27010	27010-2122	1	Switch
❸32085	32085-2097	1	Stopper
❸92002	92002-2277	2	Bolt
❸92015	92015-2146	2	Nut
❸92015A	92015-2147	1	Nut
❸92033	92033-2081	1	Ring-Snap
❸130	130G0835	2	Bolt-Flanged
❸317	317B0800	2	Nut
❸461	461F0800	2	Washer-Spring

Attachments and Accessories

For 74251 - Z587L Z Master, With 60in TURBO FORCE Side Discharge Mower

Product Name	Model/Part
Seat Belt Kit	100-4928
Blade-Mid Flow, 20.5	105-7715-03
Blade-Lo Flow, 20.5	105-7716-03
Blade-Hi Flow	105-7718-03
Blade-Recycler, 20.5	105-7777-03
Blade-Atomic, 20.5	105-8777-03
60in Recycler Kit	107-1611
Hitch Kit	99-8925

NOTES

NOTES


TORO®