Form Number 3352-377

Sonic Boom™ Kit,
Multi-Pro® 1200, 1250, 5600, 5700 and Workman® 200 Turf Sprayers

Model No. 41089 - 250000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

©The Toro Company - 2004
All Rights Reserved

Register your product at www.Toro.com

Contents

Description	Page	Description	Page
Multi Pro 1200 and 1250 Mounting Assembly	3	Workman 200 Mounting Assembly	5
Multi Pro 5600 and 5700 Mounting Assembly	4	Sensor Assembly	6

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR	as required	INC	incorporated
ASM	assembly	LH	left hand
CARR	carriage	NI	nylon insert
DEG	degrees	PPH	phillips pan head
FH	flat head	PTH	phillips truss head
GA	gauge	PTO	power take off
HF	hex flange	RH	right hand
HH	hex head	SFH	slotted fillister head
HHF	hex head flange	SHH	slotted hex head
HHFTF	hex head flange thread forming	SHWH	slotted hex washer head
HJ	hex jam	SPH	slotted pan head
HLH	hex lag head	SQH	square head
HOC	height-of-cut	SRH	slotted round head
HS	hex	STD	standard
HSBH	hex socket button head	TAP	self tapping
HSFH	hex socket flat head	TTH	torx truss head
HSH	hex socket head	WH	wing head
HWH	hex washer head		
HWHTF	hex washer head thread forming		
HYD	hydraulic		

Footnotes


❶ Not illustrated

❷ Not serviced separately




Multi Pro 1200 and 1250 Mounting Assembly

Ref	Part No.	Qty.	Description
1	100-8590	1	Switch-Rocker, Dpdt (On-off-on)
2	44-2210	1	Light-Indicator, Red
2:1	218-535	1	Nut-Hex
2:2	218-536	1	Washer-Lock
2:3	218-533	1	Lens
❷2:4		1	Bulb
3	94-8582	1	Decal
4	3217-26	2	Nut-Hex
5	94-8564-03	1	Plate-Mount, Ecu
6	3217-5	8	Nut-Hex
7	3253-3	8	Washer-Lock
8	3253-4	2	Washer-Lock
9	322-3	2	Screw-HH
10	70-1480	4	Relay
11	321-3	4	Screw-HH
12	92-5720	1	Controller-Electronic
12:8	93-8053	1	Decal
13	321-15	4	Screw-HH
15	3290-500	2	Screw-PPH
16	106-5215	1	Harness-Sonic Boom
17	218-578	3	Fuse-10 Amp
18	110928	1	Fuse-5 Amp
❶99	109103	1	Fuse-30 Amp
❶99	94-8604	1	Decal




Multi Pro 5600 and 5700 Mounting Assembly

Ref	Part No.	Qty.	Description
1	100-8590	1	Switch-Rocker, Dpdt (On-off-on)
2	44-2210	1	Light-Indicator, Red
2:1	218-535	1	Nut-Hex
2:2	218-536	1	Washer-Lock
2:3	218-533	1	Lens
❷2:4		1	Bulb
3	94-8582	1	Decal
4	3217-26	2	Nut-Hex
5	94-8564-03	1	Plate-Mount, Ecu
6	3217-5	8	Nut-Hex
7	3253-3	8	Washer-Lock
8	3253-4	2	Washer-Lock
9	322-3	2	Screw-HH
10	70-1480	4	Relay
11	321-3	4	Screw-HH
12	92-5720	1	Controller-Electronic
12:8	93-8053	1	Decal
13	321-15	4	Screw-HH
15	3290-500	2	Screw-PPH
16	106-5215	1	Harness-Sonic Boom
17	218-578	3	Fuse-10 Amp
18	110928	1	Fuse-5 Amp
❶99	109103	1	Fuse-30 Amp
❶99	94-8604	1	Decal



Workman 200 Mounting Assembly

Ref	Part No.	Qty.	Description
1	100-8590	1	Switch-Rocker, Dpdt (On-off-on)
4	3217-26	2	Nut-Hex
5	94-8564-03	1	Plate-Mount, Ecu
6	3217-5	8	Nut-Hex
7	3253-3	8	Washer-Lock
10	70-1480	4	Relay
11	321-3	4	Screw-HH
12	92-5720	1	Controller-Electronic
12:8	93-8053	1	Decal
13	321-15	4	Screw-HH
15	3290-500	2	Screw-PPH
16	106-5215	1	Harness-Sonic Boom
17	218-578	3	Fuse-10 Amp
18	110928	1	Fuse-5 Amp
19	2112-6	2	Clamp-Muffler
19:1	3218-2	2	Nut-Jam
20	106-1403	1	Light-Indicator
21	240-2	1	Grommet-Rubber
❶99	109103	1	Fuse-30 Amp
❶99	94-8604	1	Decal



Sensor Assembly

Ref	Part No.	Qty.	Description
1	94-8586	2	Conduit
2	3290-378	16	Tie-Cable
3	94-8576	2	Decal
4	32105-30	4	Screw-SHH
5	95-2241-03	1	RH Sensor Bracket ASM
6	95-2240-03	1	LH Sensor Bracket ASM
7	94-6869	2	Sensor-Sonic, Ultra
7:1	106-5232	1	Patch-Goretex
8	107-8753-03	2	Sensor Shield ASM
9	95-2247	2	Foam-Shield, Sensor
10	3253-17	4	Washer-Lock/sp
11	3217-26	4	Nut-Hex
12	92-0010	4	U-Bolt
13	3256-2	8	Washer-Flat
14	32146-17	8	Nut-Lock

NOTES


TORO®