



**Sonic Boom™ Kit,  
Multi-Pro® 1200, 1250, 5600,  
5700 and Workman® 200 Turf Sprayers**

Model No. 41089 - 250000001 and up.

## Parts Catalog

### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Description	Page	Description	Page
Multi Pro 1200 and 1250 Mounting Assembly	..... 3	Workman 200 Mounting Assembly	..... 5
Multi Pro 5600 and 5700 Mounting Assembly	..... 4	Sensor Assembly	..... 6

## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. ....	as required	INC. ....	incorporated
ASM. ....	assembly	LH. ....	left hand
CARR. ....	carriage	NI. ....	nylon insert
DEG. ....	degrees	PPH. ....	phillips pan head
FH. ....	flat head	PTH. ....	phillips truss head
GA. ....	gauge	PTO. ....	power take off
HF. ....	hex flange	RH. ....	right hand
HH. ....	hex head	SFH. ....	slotted fillister head
HHF. ....	hex head flange	SHH. ....	slotted hex head
HHFTF. ....	hex head flange thread forming	SHWH. ....	slotted hex washer head
HJ. ....	hex jam	SPH. ....	slotted pan head
HLH. ....	hex lag head	SQH. ....	square head
HOC. ....	height-of-cut	SRH. ....	slotted round head
HS. ....	hex	STD. ....	standard
HSBH. ....	hex socket button head	TAP. ....	self tapping
HSFH. ....	hex socket flat head	TTH. ....	torx truss head
HSH. ....	hex socket head	WH. ....	wing head
HWH. ....	hex washer head		
HWHTF. ....	hex washer head thread forming		
HYD. ....	hydraulic		


## Footnotes

❶ Not illustrated

❷ Not serviced separately







## Workman 200 Mounting Assembly

Ref	Part No.	Qty.	Description
1	100-8590	1	Switch-Rocker, Dpdt (On-off-on)
4	3217-26	2	Nut-Hex
5	94-8564-03	1	Plate-Mount, Ecu
6	3217-5	8	Nut-Hex
7	3253-3	8	Washer-Lock
10	70-1480	4	Relay
11	321-3	4	Screw-HH
12	92-5720	1	Controller-Electronic
12:8	93-8053	1	Decal
13	321-15	4	Screw-HH
15	3290-500	2	Screw-PPH
16	106-5215	1	Harness-Sonic Boom
17	218-578	3	Fuse-10 Amp
18	110928	1	Fuse-5 Amp
19	2112-6	2	Clamp-Muffler
19:1	3218-2	2	Nut-Jam
20	106-1403	1	Light-Indicator
21	240-2	1	Grommet-Rubber
❶99	109103	1	Fuse-30 Amp
❶99	94-8604	1	Decal




## NOTES

