



Mid-Size ProLine, T-Bar, Gear Drive, 15 HP with 48in Side Discharge Mower

Model No. 30197 - 250000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Engine and Fuel System Assembly	 3	Head / Valve / Breather Assembly Kohler CV15T 41624	 18
Transmission and Drive Assembly	 4	Ignition / Electrical Assembly Kohler CV15T 41624	 19
Axle and Wheel Assembly	 6	Blower Housing and Baffle Assembly Kohler CV15T 41624	 20
Upper Handle Assembly	 8	Starting System Assembly Kohler CV15T 41624	 21
Front Caster and Blade Brake Assembly	 9	Fuel System Assembly Kohler CV15T 41624	 22
Spindle and Blade Assembly	 11	Engine Control Assembly Kohler CV15T 41624	 23
Idler Pulley Assembly	 12	Air Intake / Filtration Assembly Kohler CV15T 41624	 24
Deck Assembly	 13	Exhaust Assembly Kohler CV15T 41624	 25
Deflector Assembly No. 107-4140	 14	Attachments and Accessories List	 26
Crankshaft Assembly Kohler CV15T 41624	 15		
Crankcase Assembly Kohler CV15T 41624	 16		
Oil Pan / Lubrication Assembly Kohler CV15T 41624	 17		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	INC. incorporated
CARR. carriage	LH. left hand
DEG. degrees	NI. nylon insert
FH. flat head	PPH. phillips pan head
GA. gauge	PTH. phillips truss head
HF. hex flange	PTO. power take off
HH. hex head	RH. right hand
HHE. hex head flange	SFH. slotted fillister head
HHFTF. hex head flange thread forming	SHH. slotted hex head
HJ. hex jam	SHWH. slotted hex washer head
HLH. hex lag head	SPH. slotted pan head
HOC. height-of-cut	SQH. square head
HS. hex	SRH. slotted round head
HSBH. hex socket button head	STD. standard
HSFH. hex socket flat head	TAP. self tapping
HSH. hex socket head	TTH. torx truss head
HWH. hex washer head	WH. wing head
HWHTF. hex washer head thread forming	


Footnotes

- | | |
|--|---------------------------|
| ❶ Not illustrated | ❷ Not serviced separately |
| ❸ Obtain Parts From Your Local Kohler Dealer | |



Engine and Fuel System Assembly


Ref	Part No.	Qty.	Description				
1	1-633023	2	Stud				
2	3256-23	4	Washer-Flat				
3	1-633349	2	Spring-Tank, Fuel				
4	3296-47	2	Nut-Lock, NI				
5	1-303077	6	Clamp				
6	1-303197	1	Filter-Fuel				
7	47-2983	1	Hose-Fuel				
9		1	Engine-Kohler, Cv15t-41624				
10	106-0699	1	Decal-Warning, Hot Surfaces				
11	3290-357	2	Nut-HHF				
12	323-13	1	Screw-HH				
13	33114-025	4	Screw-HH				
14	1-303334	4	Washer-Spring				
16	103-1965	1	Valve-Drain, Oil				
18	1-603776	1	Hose-Line, Fuel				
19	1-603770	1	Valve-Fuel				
20	1-603955	1	Hose-Fuel				
22	322-3	2	Screw-HH				
24	1-805005	2	Washer-Lock				
26	106-0730	1	Fuel Tank ASM				
26:2	103-2605	1	Fitting-Fuel, Bulkhead				
27	88-3980	1	Gas Cap ASM				
27:3	88-4010	1	Gasket-Cap, Gas				



Transmission and Drive Assembly


Ref	Part No.	Qty.	Description
1	103-2923-01	1	Frame-Deck, Rear
2	1-323252	2	Bearing-Shaft
3	1-323254	2	Flange-Output
4	1-803310	3	Screw-Set
5	103-6511	2	Sheave-Transmission
6	321-3	4	Screw-HH
7	103-4177	1	Key-Machine
8	3242-4	2	Screw-Set, SQH
9	3296-39	1	Nut-Lock, NI
10	3256-24	1	Washer-Flat
11	1-323285	1	Idler-Drive, Transmission
12	3256-5	2	Washer-Flat
13	322-3	4	Screw-HH
14	1-805005	4	Washer-Lock
15	1-633181	1	Plate-Tapped
16	1-513152	1	Switch-Closed, Normally
17	32151-62	2	Ring-Retaining
18	3257-5	3	Key-Woodruff
19	1-323502	2	Shaft-Transmission
20	51-4220	2	Guard-Coupler
21	1-323680	2	Coupler
22	1-323630	1	V-Belt
23	3245-41	2	Screw-HSH
24	1-323278	1	Sheave-Transmission

Ref	Part No.	Qty.	Description
25	302-19	2	Fitting-Grease
26	1-323500	1	Transmission
27	3230-1	2	Bolt-CARR
28	1-323387-03	1	Plate-Shift
29	98-3256	1	Decal-Speed, Ground
30	1-303020	1	Grip-Lever
31	98-3274-03	1	Lever-Shift
32	98-5975	1	Washer-Belleville
33	3296-6	1	Nut-Lock
35	1-323379	1	Washer
36	32128-20	2	Nut-HF
37	9264964	4	Screw-Hwh, Thread Cut
38	1-603403	1	Bolt-Shoulder
39	1-323389-03	2	Bracket-Plate, Shift
40	1-806003	1	Pin-Hair
41	1-303186	1	Bellcrank
42	3290-357	1	Nut-HHF
43	95-2814	1	Decal-Shut Off, Fuel
44	3290-500	2	Screw-PPH
45	1-543296	1	Grommet
46	3231-6	1	Screw-CARR
47	3296-42	4	Nut-Lock, NI
48	98-0776	1	Decal-Caution
49	103-1666	1	Sheave-Transmission



Transmission and Drive Assembly (continued)


Ref	Part No.	Qty.	Description
50	1-403160	1	Sheave
53	1-323318-01	2	Hitch-Sulky
54	323-6	4	Screw-HH
55	3290-357	4	Nut-HHF
56	1-603610	2	Washer-Spring
57	3212-6	1	Screw-HH
58	1-633453	1	Spacer-Clutch
59	1-373034	2	Washer



Axle and Wheel Assembly


Ref	Part No.	Qty.	Description
1	98-3273	2	Spring-Extension
2	323-10	2	Screw-HH
3	32151-47	2	Ring-Retaining
4	1-806003	4	Pin-Hair
5	3256-23	2	Washer-Flat
6	104-1321-03	1	RH Idler Arm ASM
②6:1		1	RH Idler Arm ASM
6:1:4	302-19	1	Fitting-Grease
7	104-1322-03	1	LH Idler Arm ASM
②7:1		1	LH Idler Arm ASM
7:1:4	302-19	1	Fitting-Grease
8	74-0521	2	Fitting-Rod
9	283-6	2	Pin-Clevis
10	1-323296	2	Rod-Brake
11	1-322125	2	Swivel-Brake
12	1-513959	2	Wingnut-Nylock
13	3290-357	14	Nut-HHF
14	323-16	4	Screw-HH
16	98-5131-01	2	Shield-Wheel, Drive
17	1-323694	4	Spacer-Shield
18	1-323634	2	Idler-Drive, Wheel
21	1-323307	4	Pin-Clevis
22	1-322209-03	2	Arm-Brake
23	32120-47	2	Ring-Retaining, External

Ref	Part No.	Qty.	Description
24	1-803051	4	Nut-Push
25	1-323595	2	Band-Brake
26	1-322212-03	1	Axle ASM
27	1-543436	8	Washer-Spacer
27	1-523157	6	Washer-Spacer
28	1-323261	2	Drum-Brake
29	1-323253	4	Sheave-Wheel, Drive
②30		2	Wheel And Tire ASM
30:1	1-323720	1	Tire-Turfmaster
30:2	1-323328	1	Wheel And Hub ASM
30:2:1	1-323329	2	Bearing-Flanged
②30:2:2		1	Rim ASM
②30:2:3		1	Fitting-Grease
②30:2:4		1	Stem-Valve
34	1-808519	2	Ring-Snap
35	1-323260	8	Spacer-Sheave, Wheel
36	322-6	8	Screw-HH
37	1-412358	2	Scraper
38	1-323631	2	V-Belt
39	3296-29	2	Nut-Lock, NI
40	2412-104	2	R-Clamp
41	98-3259	1	Shield-Trailing
42	322-3	2	Screw-HH
43	98-5975	4	Washer-Belleville




Axle and Wheel Assembly (continued)

Ref	Part No.	Qty.	Description
44	323-6	4	Screw-HH
45	1-373034	8	Washer



Upper Handle Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	98-3282	2	Rod-Control	25	98-3258	1	Harness-Wire
2	95-5522-03	1	Control Bar ASM	26	98-3279	1	Linkage-Drive, Blade
3	3296-2	5	Nut-Lock	27	98-3287-03	1	Lever-Engagement, Blade
4	82-2290	1	Decal	28	323-6	4	Screw-HH
5	32105-1	1	Screw-SHH	29	32104-76	2	Screw
6	82-7680-03	1	Bail ASM	30	1-304259	1	Panel-Control
7	82-2280	1	Decal	31	104-7050	1	Housing-Manual
8	3272-11	2	Pin-Cotter	32	32105-14	4	Screw-SHH
9	99-8501-03	1	Control-Pivot ASM	33	106-0709	1	Decal
10	218-595	1	Connector-Body	34	99-8509	1	Spacer
11	98-3261-03	1	Lever-Brake, Parking	35	1-303020	1	Grip-Lever
12	98-3266	1	Decal	36	323-10	1	Screw-HH
13	740275	1	Switch-Seat	37	98-4387	1	Decal-Protection, Ear
14	1-806003	3	Pin-Hair	41	104-7048	1	Cap-Housing
15	237-141	2	Grommet-Rubber				
16	98-3267-03	1	Upper Handle ASM				
17	283-55	2	Pin-Clevis				
18	1-323637	1	Cable-Throttle				
19	2412-120	2	R-Clamp				
20	95-5537	1	Decal-Engage, Deck				
21	1-303335	1	Tie-Plastic				
22	1-303160	1	Spring-Compression				
23	3256-24	2	Washer-Flat				
24	3296-39	5	Nut-Lock, NI				



Front Caster and Blade Brake Assembly


Ref	Part No.	Qty.	Description
3	1-513338	2	Washer-Flat
5	1-303314	8	Spacer-Caster
6	1-809020	2	Pin
7	1-322145-01	2	Fork
8	325-20	2	Screw-HH
9	1-513648	2	Wheel And Tire ASM
9:2	1-513808	1	Tire
9:3	1-513809	1	Bearing
9:4	1-513810	2	Bushing
10	1-513547	2	Spacer
11	3217-9	2	Nut-Hex
12	3253-7	2	Washer-Lock
15	323-4	8	Screw-HH
16	3290-357	8	Nut-HHF
17	3296-42	2	Nut-Lock, NI
18	302-19	1	Fitting-Grease
19	32128-20	3	Nut-HF
20	1-323071	1	Spring-Extension
21	322-6	1	Screw-HH
22	103-3600	1	Idler Arm ASM
22:2	1-323729	2	Sleeve-Bearing
24	1-303348	1	Eyebolt-Thread, LH
25	1-303434	1	Bushing-Engagement
26	1-603843	1	Pulley-Idler

Ref	Part No.	Qty.	Description
27	98-5975	1	Washer-Belleville
28	702809	1	Screw-Cap
29	1-808280	1	Pin-Clevis
30	1-303105	1	Yoke-Adjustable
31	1-806003	3	Pin-Hair
32	1-323303	1	Linkage-Arm
33	1-322235	1	Arm-Assist
34	1-303238	1	Eyebolt-Thread, RH
35	1-303236	1	Body-Turnbuckle
36	32151-103	1	Ring-Snap
37	3296-29	1	Nut-Lock, NI
38	3256-3	1	Washer-Flat
39	1-403179	1	Tube-Pivot
40	3256-23	1	Washer-Flat
41	32120-35	1	E-Ring
42	1-323714	1	Rod-Brake
43	321-4	2	Screw-HH
44	1-323747	1	Spring-Compression
45	1-323746	1	Spacer-Flanged
46	1-324372	1	Pad / Spring ASM
47	1-303334	1	Washer-Spring
48	322-10	1	Screw-HH
49	1-303352	1	Washer-Spindle
50	1-323748	1	Ring-Push On




Front Caster and Blade Brake Assembly (continued)

Ref	Part No.	Qty.	Description
51	1-302203	2	Support ASM
② 51:1		1	Support-Caster
51:1:1	302-52	1	Fitting-Grease
51:2	1-303514	2	Bearing-Flanged
52	3296-56	1	Nut-Lock, NI




Spindle and Blade Assembly

Ref	Part No.	Qty.	Description				
1	1-800861	3	Screw-Cap, HH				
2	1-513208	3	Washer-Spring				
3	103-2507	3	Blade-Lift, Low				
3	103-2527	3	Blade-Notched				
4	1-323539	12	Spacer-Drive, Blade				
5	1-323529	3	Tube-Spindle, Short				
6	1-807267	3	Key				
7	103-2535	3	Spacer-Guard, Bottom				
13	107-4065	3	Cutter Housing ASM				
13:1	103-7975	1	Housing-Spindle				
13:2	103-2477	2	Bearing-Ball				
13:3	103-2534	1	Spacer-Bearing				
13:4	32120-8	1	Ring-Snap				
14	3296-39	18	Nut-Lock, NI				
16	323-7	18	Screw-HH				
17	1-403183	3	Sheave				
18	1-803310	3	Screw-Set				
19	1-323339	3	Washer-Retainer, Sheave				
20	3219-6	3	Nut-Hex				
21	1-403171	1	Belt-Drive, Blade				
22	103-1330	3	Guard-Bearing, Top				




Idler Pulley Assembly

Ref	Part No.	Qty.	Description				
1	3290-357	3	Nut-HHF				
2	3256-24	2	Washer-Flat				
3	1-403186	1	Idler-Pulley, Flat				
4	1-403184	2	Bushing-Idler				
5	1-403188	1	Spacer				
6	98-5975	3	Washer-Belleville				
7	323-20	1	Screw-HH				
8	1-613098	1	Pulley-Idler				
9	323-13	2	Screw-HH				
10	322-2	2	Screw-HH				
11	32128-20	2	Nut-HF				




Deck Assembly

Ref	Part No.	Qty.	Description				
1	1-404246	1	Shield-Belt				
1:5	106-0712	1	Decal				
3	106-4161	5	Knob-Handle				
4	1-323417	5	Washer				
5	1-303536	3	Stud-Shield, Belt (Long)				
6	1-303537	2	Stud-Shield, Belt (Short)				
9	107-4215	1	Deck ASM				
9:1	1-402107-01	1	Baffle-Dogleg				
9:3	1-403005	1	Decal-Danger				
9:4	322-2	4	Screw-HH				
9:5	32128-20	4	Nut-HF				
9:6	66-1340	1	Decal-Danger				
9:7	93-1122	1	Decal-Danger				
9:8	98-5130	1	Decal-Torque, Bolt				
9:9	99-3943	1	Decal-Routing, Belt				
10	322-2	7	Screw-HH				
11	322-50	1	Screw-HH				
14	107-4140	1	Deflector ASM				
16	104-8554	1	Spring-Torsion				
17	105-4622	1	Spacer				
18	3296-29	1	Nut-Lock, NI				
20	323-8	6	Screw-HH				
21	98-5975	6	Washer-Belleville				
22	3290-357	6	Nut-HHF				




Deflector Assembly No. 107-4140

Ref	Part No.	Qty.	Description
1	3231-4	3	Screw-CARR
2	107-4138-01	1	Strap-Deflector, Top
3	107-4139-01	1	Strap-Discharge
4	107-4137	1	Deflector-Rubber
5	107-4164-01	1	Bracket-Mounting, Deflector
6	3296-39	3	Nut-Lock, NI




Crankshaft Assembly Kohler CV15T 41624

Ref	Part No.	Qty.	Description
❸1	12 014 30-S	1	Crankshaft (Includes 2)
❸2	12 139 01-S	1	Plug-Cup




Crankcase Assembly Kohler CV15T 41624

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	12 032 03-S	1	Seal-Oil, Front	12	12 108 09-S	1	Ring Set (.50)
2	2	1	Crankcase (Use: Short Block 12 522 18)	13	12 067 05-S	1	Rod-Connecting (Std.)
3	12 445 02-S	1	Strap-Lifting	13	12 067 06-S	1	Rod-Connecting (.25)
4	M-839025-S	1	Screw-Hex Flange, M8x1.25x25	14	12 380 01-S	1	Pin-Governor Regulating
5	24 380 13-S	4	Pin-Locating	15	12 043 05-S	1	Gear-Governor
6	12 755 49-S	1	Camshaft Kit (Includes 7,8)	16	M-631005-S	1	Washer-Plain (6 Mm)
7	12 089 37-S	1	Spring-Actuating	17	12 144 02-S	1	Shaft-Governor Gear
8	12 422 08-S	1	Shim-Camshaft, Blue	18	52 139 09-S	1	Plug-Cup
8	12 422 09-S	1	Shim-Camshaft, Red	19	12 755 64-S	1	Governor Cross Shaft Kit (Includes 23)
8	12 422 10-S	1	Shim-Camshaft, Yellow	20	X-25-102-S	1	Washer-Plain, 1/4in
8	12 422 11-S	1	Shim-Camshaft, Green	21	12 032 01-S	1	Seal-Cross Shaft, Governor
8	12 422 12-S	1	Shim-Camshaft, Gray	22	M-631015-S	1	Washer-Plain, 6mm
8	12 422 13-S	1	Shim-Camshaft, Black	23	12 154 05-S	1	Clip-Pin, Hitch
8	12 422 07-S	1	Shim-Camshaft, White				
9	12 144 27-S	1	Shaft-Balance				
10	12 874 07-S	1	Piston W/ring Set (Std.) (Includes 11,12)				
10	12 874 08-S	1	Piston W/ring Set (.25)				
10	12 874 09-S	1	Piston W/ring Set (.50)				
10	12 874 11-S	1	Piston W/ring Set (.08)				
11	12 018 02-S	2	Retainer-Pin, Piston				
12	12 108 07-S	1	Ring Set (Std. & .08)				
12	12 108 08-S	1	Ring Set (.25)				



Oil Pan / Lubrication Assembly
Kohler CV15T 41624


Ref	Part No.	Qty.	Description				
❶1	12 038 01-S	1	Dipstick ASM (Includes 2,3)				
❷2	25 755 13-S	1	Oil Fill Cap Kit (Includes 3)				
❸3	25 153 02-S	1	O-Ring				
❹4	12 153 02-S	1	O-Ring (Upper Oil Fill Tube)				
❺5	12 123 04-S	1	Tube-Fill, Oil				
❻6	M-545020-S	1	Screw-Hex Flange, M5x0.8x20				
❼7	12 153 01-S	1	O-Ring (Lower Oil Fill Tube)				
❽8	25 162 07-S	1	Screen-Pickup, Oil				
❾9	12 096 03-S	1	Cover-Screen, Oil Pickup				
❿10	M-545016-S	1	Screw-Hex Flange, M5x0.8x16				
⓫11	12 050 01-S	1	Filter-Oil				
⓬12	25 139 57-S	2	Plug-Sq. Hd. 3/8 N.p.t.f.				
⓭13	12 199 50-S	1	Oil Pan ASM (Includes 14,16-19)				
⓮14	25 462 09-S	1	Valve-Relief, Oil Pressure				
⓯15	25 139 52-S	1	Plug-Pipe, 1/8in				
⓰16	M-545016-S	3	Screw-Hex Flange, M5x0.8x16				
⓱17	12 096 34-S	1	Cover-Pump, Oil				
⓲18	12 153 06-S	1	O-Ring (Oil Pump Cover)				
⓳19	12 393 01-S	1	Oil Pump ASM				
⓴20	12 032 03-S	1	Seal-Oil, Front				
⓵21	24 086 16-S	11	Screw-Hex Flange, M8x1.25x45				
⓶22	24 086 17-S	1	Screw-Hex Flange, M8x1.25x45				



Head / Valve / Breather Assembly
Kohler CV15T 41624


Ref	Part No.	Qty.	Description
❶1	25 351 01-S	2	Lifter-Valve
❷2	12 411 04-S	2	Rod-Push
❸3	12 041 10-S	1	Gasket-Head, Cylinder
❹4	12 017 01-S	1	Valve-Intake (Std.)
❺5	12 016 01-S	1	Valve-Exhaust (Std.)
❻6	25 139 60-S	1	Plug-Pipe, 1/8in Allen Head
❼7	12 318 19-S	1	Head-Cylinder
❽8	12 146 22-S	2	Plate-Guide
❾9	25 186 01-S	2	Arm-Rocker
❿10	25 599 01-S	2	Pivot-Arm, Rocker
⓫11	25 072 12-S	2	Stud-Rocker
⓬12	25 100 29-S	2	Nut-Hex
⓭13	25 086 112-S	2	Screw-Set
⓮14	M-640034-S	2	Screw-Hf, M6x1.0x34
⓯15	66 032 05-S	2	Seal-Valve Stem
⓰16	12 089 34-S	2	Spring-Valve
⓱17	12 173 01-S	2	Cap-Spring, Valve
⓲18	12 755 03-S	2	Retainer Kit
⓳19	12 468 05-S	1	Washer-Plain, 13/32in
⓴20	12 112 13-S	1	Spacer-Head Bolt, Exhaust Port
⓵21	20 086 02-S	5	Screw-Hf, M10x1.5x81
⓶22	25 237 14-S	2	Clamp-Breather
⓷23	12 326 18-S	1	Hose-Breather
⓸24	M-645016-S	5	Screw-Hex Flange, M6x1.0x16

Ref	Part No.	Qty.	Description
❶25	12 096 47-S	1	Cover-Valve
❷26	M-545010-S	1	Screw-Hex Flange, M5x0.8x10
❸27	66 018 04-S	1	Retainer-Breather Reed
❹28	12 402 02-S	1	Reed-Breather
❶❸	12 017 02-S	1	Valve-Intake (.25)
❶❹	12 016 02-S	1	Valve-Exhaust (.25)




Ignition / Electrical Assembly
Kohler CV15T 41624

Ref	Part No.	Qty.	Description				
❶1	12 086 14-S	1	Screw-Hex Flange, M10x1.5x46				
❷2	12 468 03-S	1	Washer-Plain (3/8)				
❸3	M-545010-S	3	Screw-Hex Flange, M5x0.8x10				
❹4	12 109 07-S	1	Cup-Drive, Starter				
❺5	12 162 09-S	1	Screen-Grass				
❻6	25 086 47-S	4	Bolt-Shoulder, M6x1.0x16				
❼7	12 157 03-S	1	Fan				
❽8	X-42-15-S	1	Key				
❾9	12 025 56-S	1	Flywheel				
❿10	12 132 02-S	1	Spark Plug				
⓫11	X-728-1-S	1	Clip				
⓬12	M-545010-S	3	Screw-Hex Flange, M5x0.8x10				
⓭13	12 584 05-S	1	Module-Ignition				
⓮14	M-545020-S	2	Screw-Hex Flange, M5x0.8x20				
⓯❶❶	25 086 110-S	2	Screw-Tapping, Slotted				
⓰❶❶	12 518 07-S	1	Lead-White (18in, 18 Gauge, Fully Insulated Female Disconnect Terminals)				
⓱❶❶	12 454 03-S	1	Tie-Wire				



Blower Housing and Baffle Assembly
Kohler CV15T 41624


Ref	Part No.	Qty.	Description				
❶1	12 314 10-S	1	Guard-Screen, Grass				
❷2	M-545010-S	8	Screw-Hex Flange, M5x0.8x10				
❸3	M-550010-S	6	Screw-Hf, M5x0.8x10				
❹4	12 096 29-S	1	Cover-Starter				
❺5	12 027 53-S	1	Housing-Blower				
❻6	12 096 27-S	1	Cover (Rectifier-regulator)				
❼7	M-639016-S	2	Screw-Hf, M6x1.0x16				
❽8	12 063 10-S	1	Baffle-Side, Intake				
❾9	12 063 08-S	1	Baffle-Head, Cylinder				
❿10	M-561016-S	1	Screw-Hf, M5x0.8x16				
⓫11	12 313 03-S	1	Grommet-Spark Plug				
⓬12	12 063 19-S	1	Baffle (Cylinder)				
⓭13	12 146 07-S	1	Plate-Housing, Blower				
⓯❶	12 113 124-S	1	Decal-15hp				
⓯❷	25 113 39-S	1	Decal-Clear Lamination				



Starting System Assembly


Kohler CV15T 41624

Ref	Part No.	Qty.	Description				
❸1	M-550010-S	5	Screw-Hf, M5x0.8x10				
❸2	12 165 01-S	1	Retractable Starter ASM (Includes 3-9)				
❸3	12 081 01-S	1	Housing-Starter				
❸4	12 160 01-S	1	Rope-Starter				
❸5	25 166 01-S	1	Handle-Start, Recoil				
❸6	12 089 06-S	1	Spring And Keeper				
❸7	12 093 01-S	1	Pulley				
❸8	12 757 06-S	1	Dog Repair Kit (Includes 9)				
❸9	41 086 09-S	1	Screw-Pozidriv				
❶❸	12 113 07-S	1	Decal-Starting				



Fuel System Assembly
Kohler CV15T 41624


Ref	Part No.	Qty.	Description				
❸1	M-641060-S	2	Nut-Hex Flange, M6x1.0				
❸2	M-629116-S	2	Stud-M6x1.0x116				
❸3	12 853 140-S	1	Carburetor Kit (Includes 4, 5)				
❸4	12 041 02-S	1	Gasket-Base, Air Cleaner				
❸5	12 041 01-S	2	Gasket-Carburetor				
❸6	12 265 04-S	1	Deflector-Heat				
❶❸	12 757 02-S	1	Float Kit				
❶❸	12 757 03-S	1	Carburetor Repair Kit				
❶❸	12 757 08-S	1	Choke Repair Kit				
❶❸	12 757 36-S	1	Throttle Shaft Bearing Kit				
❶❸	12 757 37-S	1	Bowl Replacement Kit				
❶❸	12 755 92-S	1	High Altitude Kit				



Engine Control Assembly


Kohler CV15T 41624

Ref	Part No.	Qty.	Description				
❶1	12 079 07-S	1	Linkage-Choke				
❷2	12 237 01-S	1	Clamp-Cable				
❸3	M-664020-S	2	Screw-Lobed Socket, M6x1.0x20				
❹4	M-545016-S	2	Screw-Hex Flange, M5x0.8x16				
❺5	12 536 06-S	1	Speed Control ASM (Includes 6-10)				
❻6	12 089 23-S	1	Spring-Return, Choke				
❼7	12 089 11-S	2	Spring-Control, Speed				
❽8	12 086 39-S	1	Screw-Pan Head (W/loctite)				
❾9	M-443020-S	1	Screw-Pan Head, M4x0.7x20				
❿10	25 452 14-S	1	Terminal-Switch, Kill				
⓫11	12 089 19-S	1	Spring-Governor				
⓬12	12 755 83-S	1	Governor Lever Kit (Includes 13-15)				
⓭13	12 100 07-S	1	Nut-Hf, M6x1.0				
⓮14	52 211 04-S	1	Screw-Hf, M6x1.0x25				
⓯15	12 090 28-S	1	Lever-Governor				
⓰16	12 079 01-S	1	Linkage-Throttle				
⓱17	25 158 08-S	1	Bushing-Linkage Retaining				
⓲18	25 158 11-S	1	Bushing-Linkage Retaining				



Air Intake / Filtration Assembly
Kohler CV15T 41624

Ref	Part No.	Qty.	Description				
❸1	12 743 04-S	1	Air Cleaner Kit (Includes 2-12)				
❸2	20 341 01-S	1	Knob-Cover				
❸3	12 096 44-S	1	Cover-Cleaner, Air				
❸4	12 083 12-S	1	Precleaner				
❸5	12 083 10-S	1	Element-Cleaner, Air (Includes 6-8)				
❸6	12 743 12-S	1	Seal Kit (Includes 7, 8)				
❸7	12 100 08-S	1	Nut-Wing				
❸8	12 032 11-S	1	Seal				
❸9	12 094 14-S	1	Base-Cleaner, Air (Includes 10, 11)				
❸10	12 072 04-S	1	Stud-Plate, Mounting				
❸11	12 086 01-S	2	Screw				
❸12	12 041 02-S	1	Gasket-Base, Air Cleaner				
❶❸	12 113 04-S	1	Decal-Cleaner, Air				



Exhaust Assembly
Kohler CV15T 41624

Ref	Part No.	Qty.	Description				
❶1	12 068 44-S	1	Muffler				
❷2	25 072 04-S	2	Stud, M8x1.25x33				
❸3	12 041 03-S	1	Gasket-Manifold, Exhaust				
❹4	X-25-78-S	1	Washer-Plain, 1/4in				
❺5	M-545016-S	1	Screw-Hex Flange, M5x0.8x16				
❻6	M-841080-S	2	Nut-Hex Flange, M8x1.25				
❼7	M-645016-S	2	Screw-Hex Flange, M6x1.0x16				
❽8	M-645025-S	2	Screw-Hex Flange, M6x1.0x25				
❾9	12 126 71-S	1	Bracket-Muffler				
❶❶	12 112 20-S	2	Spacer				
❶❷	12 522 18	1	Block-Short				
❶❸	12 755 93-S	1	Gasket Set				

Attachments and Accessories

For 30197 - Mid-Size ProLine T-Bar Gear, 15 HP with 48in Side Discharge Mow

Product Name	Model/Part
Atomic Blade and Decal Assembly	104-8595
Weight Kit	107-4100
Sulky	30109
48in Recycler Kit	30143
Soft Bag (3 bushel)	30198

NOTES

