



Mid-Size ProLine, T-Bar, Gear Drive 15 HP with 36in Side Discharge Mower

Model No. 30317 - 250000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Engine Installation Assembly	 3	Oil Pan/Lubrication Assembly Kohler CV15T-41629	 19
Fuel Tank Assembly	 4	Head/Valve/Breather Assembly Kohler CV15T-41629	 20
Lower Control Assembly	 5	Ignition/Electrical Assembly Kohler CV15T-41629	 21
Transmission Drive Assembly	 6	Blower Housing and Baffle Assembly Kohler CV15T-41629	 22
Wheel Drive and Brake Assembly	 7	Starting System Assembly Kohler CV15T-41629	 23
Upper Handle Assembly	 8	Fuel System Assembly Kohler CV15T-41629	 24
Control Panel Assembly	 9	Engine Control Assembly Kohler CV15T-41629	 25
Carrier Frame Assembly	 10	Air Intake/Filtration Assembly Kohler CV15T-41629	 26
Spindle, Pulley and Belt Assembly	 11	Exhaust Assembly Kohler CV15T-41629	 27
Spindle Assembly No. 106-0785	 12	Attachments and Accessories List	 28
Outer Spindle Assembly 106-0787	 13		
Deck Assembly	 14		
Deflector Assembly No. 107-4194	 15		
Drive Belt and Tensioner Assembly	 16		
Crankshaft Assembly Kohler CV15T-41629	 17		
Crankcase Assembly Kohler CV15T-41629	 18		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	INC. incorporated
CARR. carriage	LH. left hand
DEG. degrees	NI. nylon insert
FH. flat head	PPH. phillips pan head
GA. gauge	PTH. phillips truss head
HF. hex flange	PTO. power take off
HH. hex head	RH. right hand
HHE. hex head flange	SFH. slotted fillister head
HHFTF. hex head flange thread forming	SHH. slotted hex head
HJ. hex jam	SHWH. slotted hex washer head
HLH. hex lag head	SPH. slotted pan head
HOC. height-of-cut	SQH. square head
HS. hex	SRH. slotted round head
HSBH. hex socket button head	STD. standard
HSFH. hex socket flat head	TAP. self tapping
HSH. hex socket head	TTH. torx truss head
HWH. hex washer head	WH. wing head
HWHTF. hex washer head thread forming	


Footnotes

- | | |
|--|---------------------------|
| ❶ Not illustrated | ❷ Not serviced separately |
| ❸ Obtain Parts From Your Local Kohler Dealer | |




Engine Installation Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	92-6877	1	Valve-Drain, Oil	26	105-2635	1	Clutch / Brake
2	1-603610	2	Washer-Spring	27	107-4112	1	Pulley-Drive
3	106-0699	1	Decal-Warning, Hot Surfaces	28	608006	1	Key-Square
24		1	Engine-Kohler, Cv15t-41629	29	94-5847-01	1	Cover-Pulley
5	32144-19	1	Screw-SHWH	30	56-6360	1	Filter-Fuel
6	2412-87	1	Clamp-Cable	31	2412-134	1	R-Clamp
7	2412-98	2	Clamp	32	12-3270	1	Screw
8	47-2982	1	Hose-Fuel	99	103-1964	1	Hose-Drain, Oil
9	104-8136	1	Harness-Wire				
10	33104-025	1	Screw-HHF				
11	3255-8	1	Washer-Lock				
12	32128-20	2	Nut-HF				
13	237-124	1	Grommet				
14	104-6373	1	Tube-Retainer				
15	1-613235	4	Washer				
16	1-633630	2	Grommet-Brake				
17	1-633545	2	Spacer				
18	1-633543-03	1	Strap-Clutch, Brake				
19	322-11	1	Screw-HH				
20	3256-23	5	Washer-Flat				
21	33114-025	4	Screw-HH				
23	322-7	1	Screw-HH				
24	3212-9	1	Screw-HH				
25	107-4136	1	Washer				



Fuel Tank Assembly


Ref	Part No.	Qty.	Description				
1	88-3980	1	Gas Cap ASM				
1:3	88-4010	1	Gasket-Cap, Gas				
2	106-0730	1	Fuel Tank ASM				
2:2	103-2605	1	Fitting-Fuel, Bulkhead				
3	104-8121	2	Stud-Threaded				
6	3256-23	4	Washer-Flat				
7	1-633349	2	Spring-Tank, Fuel				
8	3296-47	2	Nut-Lock, NI				
9	106-0546-01	1	Gear Frame ASM				
10	2412-98	4	Clamp				
11	47-2982	1	Hose-Fuel				
12	1-603770	1	Valve-Fuel				
14	47-2966	1	Hose-Fuel				
15	322-4	2	Screw-HH				
16	3253-4	2	Washer-Lock				
17	95-2814	1	Decal-Shut Off, Fuel				
18	98-0776	1	Decal-Caution				



Transmission Drive Assembly

Ref	Part No.	Qty.	Description
1	47-1970	1	Grip
2	98-3274-03	1	Lever-Shift
3	3296-6	2	Nut-Lock
4	98-5975	1	Washer-Belleville
5	1-323379	1	Washer
6	1-323500	1	Transmission
7	302-5	2	Fitting-Grease
8	1-323680	2	Coupler
9	51-4220	2	Guard-Coupler
10	1-323254	2	Flange-Output
11	321-4	4	Screw-HH
12	3257-5	3	Key-Woodruff
13	3245-9	2	Screw-Set
14	32151-62	2	Ring-Retaining
15	105-2698	2	Pulley-Transmission
16	104-1102	2	Shaft-Output
17	1-323252	2	Bearing-Shaft
18	95-1529	1	Rod-Shield
19	95-1526	1	Shield-Trailing
20	105-5646	1	Pulley-Driven
21	3245-1	1	Screw-Set, HSH
22	32120-64	1	Ring-Snap, External
23	105-5668	1	V-Belt
24	68-2190	1	Spring


Ref	Part No.	Qty.	Description
25	27-6230	1	Bolt-Wheel
26	323-9	1	Screw-HH
27	16-7509	1	Lever-Idler
27:1	256-155	2	Bushing-Flange
28	62-4540	1	Pulley
29	3296-39	1	Nut-Lock, NI
30	322-2	4	Screw-HH
31	3253-4	4	Washer-Lock
32	3296-42	4	Nut-Lock, NI
33	1-323389-03	2	Bracket-Plate, Shift
34	9264964	4	Screw-Hwh, Thd Cut
35	32128-20	2	Nut-HF
36	1-323387-03	1	Plate-Shift
37	3230-1	2	Bolt-CARR
38	98-3256	1	Decal-Speed, Ground



Wheel Drive and Brake Assembly


Ref	Part No.	Qty.	Description
1	32151-72	4	Ring-Retaining
2	32151-56	2	Ring-Retaining, External
3	106-8792	2	Plate-Link, Brake
4	106-8779-01	2	Brake Arm ASM
6	3290-307	2	Pin-Hair
7	51-4580	2	Rod-Brake
8	32151-40	2	Ring-Retaining
9	106-8773	2	Brake Link ASM
10	51-4290	2	V-Belt
12	3296-29	8	Nut-Lock, NI
13	254-94	4	Bearing-Cone, Tapered
14	1-523157	2	Washer-Spacer
15	1-809082	2	Nut-SHH
16	106-0892	2	Wheel And Tire ASM
16:1	104-6322	1	Tire
16:2	106-0893	1	Wheel
16:3	232-27	1	Stem-Valve
17	242-50	8	Nut-Lug
18	241-119	2	Cap-Dust
19	1-413333	2	Hub/wheel ASM
19:2	254-72	2	Bearing-Cup, Tapered
19:3	302-19	1	Fitting-Grease
19:4	1-633926	4	Stud-Wheel
20	106-5544	2	Pulley-Wheel

Ref	Part No.	Qty.	Description
22	1-323262	2	Band-Brake
23	322-5	8	Screw-HH
24	1-543511	2	Seal-Grease
25	104-1197	2	Spacer-Wheel
26	104-1196-01	1	Axle ASM
27	1-806800	2	Pin-Cotter
28	32128-21	6	Nut-HF
29	3234-11	6	Screw-HHF




Upper Handle Assembly

Ref	Part No.	Qty.	Description				
1	105-4677	2	Rod-Control				
2	3272-4	2	Pin-Cotter				
3	237-141	2	Grommet-Rubber				
4	82-2290	1	Decal				
5	82-7680-03	1	Bail ASM				
6	82-7690-03	1	Bar-Control				
7	82-2280	1	Decal				
8	106-5477-03	1	Control Pivot ASM				
9	3272-11	2	Pin-Cotter				
10	105-3158-03	1	Upper Handle ASM				
11	283-55	2	Pin-Clevis				
12	3290-378	1	Tie-Cable				
13	32128-21	4	Nut-HF				
14	3234-11	4	Screw-HHF				
15	98-4387	1	Decal-Protection, Ear				
16	32105-1	1	Screw-SHH				
17	51-4850-03	1	Lever-Brake, Parking				
18	52-2010	1	Decal-Lever, Parking				
19	3296-2	1	Nut-Lock				
20	218-595	1	Connector-Body				
21	82-2190	1	Switch-Bail				




Control Panel Assembly

Ref	Part No.	Qty.	Description				
1	105-0884	1	Decal-Danger				
2	63-8360	1	Key-Ignition				
3	107-4102	1	Cable-Throttle				
4	32104-76	4	Screw				
5	32105-14	4	Screw-SHH				
6	3296-42	1	Nut-Lock, NI				
7	104-8141	1	Module-Delay				
8	93-1187-03	1	Panel-Bottom				
9	321-2	1	Screw-HH				
12	3296-2	4	Nut-Lock				
13	29-5560	1	Switch-On/off				
13:1	218-461	1	Nut-HH				
13:2	3254-5	1	Washer-Tooth				
14	2412-120	2	R-Clamp				
15	104-7050	1	Housing-Manual				
16	104-8140	1	Switch-PTO				
17	104-8177-03	1	Panel-Control				
18	106-5499	1	Decal-Control Panel				
19	104-7048	1	Cap-Housing				




Carrier Frame Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	106-0706	1	Carrier Frame ASM	19:3	83-4740	1	Bearing
1:2	32148-9	3	Insert-Nut	19:4	62-5580	2	Bearing-Outside
1:3	94-1291	4	Bushing	19:5	100-6452	1	Tire-Tubeless
1:4	302-5	2	Fitting-Grease	20	100-6453	2	Bushing-Spanner
2	105-3165-01	1	Cover-Frame, Carrier	21	325-19	2	Screw-HH
3	106-0719	1	Decal	22	283-71	2	Pin-Lynch
4	240-3	1	Grommet-Rubber	23	3-6781	8	Washer-Thrust
5	106-0565	3	Washer-Rubber	24	106-5512	1	Decal-Service, Hydro Pistol Grip
6	106-0887	3	Knob	24	106-5510	1	Decal-Service, Gear Pistol Grip
7	12-3270	2	Screw	24	106-5506	1	Decal-Service, Gear Tbar
8	106-5473-01	1	Shield-Heat	24	106-5504	1	Decal-Service, Hydro Tbar
9	3290-199	2	Nut-Speed				
10	104-1105	4	Spacer-Support, Deck				
11	1-513336	2	Bushing-Deck				
12	321-5	2	Screw-HH				
13	3256-22	2	Washer-Flat				
14	32120-33	2	Ring-Retaining				
15	105-0842	4	Spacer				
16	106-0635	2	Decal-HOC				
17	105-3159-01	2	Castor Fork ASM				
18	32153-5	2	Nut-Lock, Side				
19	100-6451	2	Castor Wheel ASM				
19:1	232-27	1	Stem-Valve				
19:2	302-11	1	Fitting-Lube, 45 DEG				




Spindle, Pulley and Belt Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	106-0615	1	36in Deck ASM	16	51-3641	1	Sleeve-Pivot, Idler
1:2	32148-9	2	Insert-Nut	17	3211-5	1	Screw-HH
1:3	104-8185	1	Decal	18	51-3660	1	Pulley-Idler
1:4	68-8340	1	Decal-Torque	19	105-0889	1	Idler Arm ASM
1:5	43-8480	1	Decal-Danger	20	3296-5	1	Nut-Lock
1:6	106-5532	1	Decal-Scalp, Anti	21	105-2673	1	Spring-Extension
1:7	67-5360	1	Decal-Danger				
1:8	93-1122	1	Decal-Danger				
1:9	106-0703	1	Decal				
1:10	66-1340	1	Decal-Danger				
2	51-3530	1	V-Belt-Drive, Deck				
3	1-633166	1	Pulley-Idler				
4	98-5975	1	Washer-Belleville				
5	3256-24	2	Washer-Flat				
6	323-6	1	Screw-HH				
7	3231-22	11	Screw-CARR				
8	106-0785	1	Spindle Housing ASM				
9	32128-21	12	Nut-HF				
10	56-2390-03	2	Blade-Sail, Extra High				
11	92-9820	2	Stiffener-Blade				
12	3256-6	2	Washer-Flat				
13	44-2200	2	Screw-Blade				
14	106-0787	1	Spindle Housing ASM				
15	323-12	1	Screw-HH				




Spindle Assembly No. 106-0785

Ref	Part No.	Qty.	Description				
1	3219-7	1	Nut-Hex				
2	7-4150	1	Washer				
3	104-1117	1	Pulley And Hub ASM				
4	106-0873	1	Shield-Bearing				
5	104-6325	2	Bearing				
6	106-0819	1	Housing-Spindle				
7	106-0795	1	Spacer-Bearing				
8	106-0781	1	Shaft-Spindle				




Outer Spindle Assembly 106-0787

Ref	Part No.	Qty.	Description				
1	3219-7	1	Nut-Hex				
2	7-4150	1	Washer				
3	104-1118	1	Pulley And Hub ASM				
4	106-0873	1	Shield-Bearing				
5	104-6325	2	Bearing				
6	106-0819	1	Housing-Spindle				
7	106-0795	1	Spacer-Bearing				
8	106-0782	1	Shaft-Spindle				




Deck Assembly

Ref	Part No.	Qty.	Description				
1	107-4194	1	Deflector ASM				
2	105-4622	1	Spacer				
3	104-8554	1	Spring-Torsion				
4	3296-29	2	Nut-Lock, NI				
5	106-0565	2	Washer-Rubber				
6	106-0887	2	Knob				
7	106-5475-01	1	Cover ASM				
8	106-0684	2	Front Pin ASM				
9	3220-3	2	Nut-Jam				
10	1-613204	2	Balljoint				
11	104-1156	2	Spacer				
12	3296-39	4	Nut-Lock, NI				
13	106-3365	2	Rear Pin ASM				
14	3290-256	6	Pin-Hair				
15	323-10	2	Screw-HH				
16	323-8	2	Screw-HH				
17	3256-23	2	Washer-Flat				
18	98-5967	1	Spacer-Wheel				
19	1-603299	2	Roller-Anti Scalp				
20	322-50	2	Screw-HH				
23	32128-20	2	Nut-HF				
24	322-1	2	Screw-HH				




Deflector Assembly No. 107-4194

Ref	Part No.	Qty.	Description				
1	3231-4	4	Screw-CARR				
2	106-3246-01	1	Deflector				
3	106-3248-03	1	Strap-Discharge				
4	108-5029	1	Deflector-Rubber				
5	107-4197-01	1	Bracket-Hinge, Rear				
6	107-4196-01	1	Bracket-Hinge, Front				
7	3296-39	4	Nut-Lock, NI				




Drive Belt and Tensioner Assembly

Ref	Part No.	Qty.	Description				
1	106-5492	1	Belt-Drive, PTO				
2	3296-39	1	Nut-Lock, NI				
4	52-2860	3	Washer				
5	104-6377	1	Tube-Idler				
6	106-0734	1	Idler Arm ASM				
6:1	1-513034	2	Sleeve-Bearing				
6:2	302-5	1	Fitting-Grease				
7	323-42	1	Screw-HH				
8	323-6	1	Screw-HH				
9	98-5975	1	Washer-Belleville				
10	3256-24	1	Washer-Flat				
11	1-413099	1	Pulley-Idler				
12	105-8443	1	Spring-Extension				




Crankshaft Assembly Kohler CV15T-41629

Ref	Part No.	Qty.	Description
③1	12 014 30-S	1	Crankshaft (Includes 2)
③2	12 139 01-S	1	Plug-Cup




Crankcase Assembly Kohler CV15T-41629

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
❶1	12 032 03-S	1	Seal-Oil, Front	❶13	12 108 07-S	1	Ring Set (Std. & .08)
❶2		1	Crankcase (Use: Short Block 12 522 18)	❶	12 108 08-S	1	Ring Set (.25)
❶3	12 445 02-S	1	Strap-Lifting	❶	12 108 09-S	1	Ring Set (.50)
❶4	M-839025-S	1	Screw-Hex Flange, M8x1.25x25	❶14	12 380 01-S	1	Pin-Governor Regulating
❶5	24 380 13-S	4	Pin-Locating	❶15	12 043 05-S	1	Gear-Governor
❶6	12 067 05-S	1	Rod-Connecting (Std.)	❶16	M-631005-S	1	Washer-Plain (6 Mm)
❶	12 067 06-S	1	Rod-Connecting (.25)	❶17	12 144 02-S	1	Shaft-Governor Gear
❶7	12 755 49-S	1	Kit, Camshaft (Includes 8,9)	❶18	52 139 09-S	1	Plug-Cup
❶8	12 089 31-S	1	Spring-Actuating	❶19	12 755 64-S	1	Kit, Governor Cross Shaft W/clip (Includes 23)
❶9	12 422 08-S	1	Shim-Camshaft, Blue	❶20	X-25-102-S	1	Washer-Plain, 1/4in
❶	12 422 09-S	1	Shim-Camshaft, Red	❶21	12 032 01-S	1	Seal-Cross Shaft, Governor
❶	12 422 10-S	1	Shim-Camshaft, Yellow	❶22	M-631015-S	1	Washer-Plain, 6mm
❶	12 422 11-S	1	Shim-Camshaft, Green	❶23	12 154 05-S	1	Clip-Pin, Hitch
❶	12 422 12-S	1	Shim-Camshaft, Gray				
❶	12 422 13-S	1	Shim-Camshaft, Black				
❶	12 422 07-S	1	Shim-Camshaft, White				
❶10	12 144 27-S	1	Shaft-Balance				
❶11	12 874 07-S	1	Piston W/ring Set (Std) (Includes 12,13)				
❶	12 874 11-S	1	Piston W/ring Set (.08)				
❶	12 874 08-S	1	Piston W/ring Set (.25)				
❶	12 874 09-S	1	Piston W/ring Set (.50)				
❶12	12 018 02-S	2	Retainer-Pin, Piston				



Oil Pan/Lubrication Assembly
Kohler CV15T-41629


Ref	Part No.	Qty.	Description				
❶1	12 038 01-S	1	Dipstick ASM (Includes 2,3)				
❷2	25 755 13-S	1	Kit, Oil Fill Cap (Includes 3)				
❸3	25 153 02-S	1	O-Ring				
❹4	12 153 02-S	1	O-Ring (Upper Oil Fill Tube)				
❺5	12 123 04-S	1	Tube-Fill, Oil				
❻6	M-545020-S	1	Screw-Hex Flange, M5x0.8x20				
❼7	12 153 01-S	1	O-Ring (Lower Oil Fill Tube)				
❽8	25 162 07-S	1	Screen-Pickup, Oil				
❾9	12 096 03-S	1	Cover-Screen, Oil Pickup				
❿10	M-545016-S	1	Screw-Hex Flange, M5x0.8x16				
⓫11	12 050 01-S	1	Filter-Oil				
⓬12	12 199 50-S	1	Pan Asm, Oil (Includes 13, 16-19)				
⓭13	25 462 09-S	1	Valve-Relief, Oil Pressure				
⓮14	25 139 57-S	2	Plug-Sq. Hd. 3/8 N.p.t.f.				
⓯15	25 139 52-S	1	Plug-Pipe, 1/8in				
⓰16	25 139 62-S	1	Plug, Pipe 3/8in Hex Ctsk				
⓱17	M-545016-S	3	Screw-Hex Flange, M5x0.8x16				
⓲18	12 096 34-S	1	Cover-Pump, Oil				
⓳19	12 153 06-S	1	O-Ring (Oil Pump Cover)				
⓴20	12 393 01-S	1	Oil Pump ASM				
⓵21	12 032 03-S	1	Seal-Oil, Front				
⓶22	24 086 16-S	10	Screw-Hex Flange, M8x1.25x45				
⓷23	24 086 17-S	1	Screw-Hex Flange, M8x1.25x45				



Head/Valve/Breather Assembly Kohler CV15T-41629


Ref	Part No.	Qty.	Description
❶	25 351 01-S	2	Lifter-Valve
❷	12 411 04-S	2	Rod-Push
❸	12 041 10-S	1	Gasket-Head, Cylinder
❹	12 017 01-S	1	Valve-Intake (Std.)
❺	12 016 01-S	1	Valve-Exhaust (Std.)
❻	25 139 60-S	1	Plug-Pipe, 1/8in Allen Head
❼	12 318 19-S	1	Head-Cylinder
❽	12 146 22-S	2	Plate-Guide
❾	25 072 12-S	2	Stud-Rocker
❿	25 186 01-S	2	Arm-Rocker
⓫	12 599 03-S	2	Pivot-Arm, Rocker
⓬	25 100 29-S	2	Nut-Hex
⓭	25 086 112-S	2	Screw-Set
⓮	66 032 05-S	2	Seal-Valve Stem
⓯	12 089 34-S	2	Spring-Valve
⓰	12 173 01-S	2	Cap-Spring, Valve
⓱	12 755 03-S	2	Retainer Kit
⓲	12 468 05-S	1	Washer-Plain, 13/32in
⓳	12 112 13-S	1	Spacer-Head Bolt, Exhaust Port
⓴	20 086 02-S	5	Screw-Hf, M10x1.5x81
⓵	25 237 14-S	1	Clamp-Breather
⓶	12 326 18-S	1	Hose-Breather
⓷	M-645016-S	3	Screw-Hex Flange, M6x1.0x16
⓸	12 096 47-S	1	Cover-Valve

Ref	Part No.	Qty.	Description
❷❹	M-545010-S	1	Screw-Hex Flange, M5x0.8x10
❷❺	66 018 04-S	1	Retainer-Breather Reed
❷❻	12 402 02-S	1	Reed-Breather
❶❶	12 017 02-S	1	Valve-Intake (.25)
❶❷	12 016 02-S	1	Valve-Exhaust (.25)
❶❸	12 041 01-S	1	Gasket-Carburetor
❶❹	12 041 02-S	1	Gasket-Base, Air Cleaner
❶❺	12 041 03-S	1	Gasket-Manifold, Exhaust




Ignition/Electrical Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
❶1	12 086 14-S	1	Screw-Hex Flange, M10x1.5x46			1	Terminal)
❶2	12 468 03-S	1	Washer-Plain (3/8)	❶❸	25 518 05-S	1	Lead-Black, Rectifier To Connector (5in, 14 Gauge, Uninsulated Push On Tab Terminals)
❶3	24 162 03-S	1	Screen-Grass			1	Terminals)
❶4	25 086 47-S	4	Bolt-Shoulder, M6x1.0x16	❶❹	24 518 12-S	1	Lead-Black (5in, 12 Gauge, Insulated Grip Barrel Eyelet Terminals)
❶5	12 157 03-S	1	Fan			1	Barrel Eyelet Terminal)
❶6	X-42-15-S	1	Key	❶❺	25 452 01-S	1	Terminal
❶7	12 025 56-S	1	Flywheel				
❶8	12 403 01-S	1	Rectifier-Regulator				
❶9	M-639016-S	2	Screw-Hf, M6x1.0x16				
❶10	236602-S	1	Connector (3 Contact)				
❶11	41 155 03-S	1	Connector-contact, Two				
❶12	M-548025-S	2	Screw-Hex. Cap, M5x0.8x25				
❶13	237878-S	1	Kit, Stator (Includes 25 452 01-S)				
❶14	12 132 02-S	1	Spark Plug				
❶15	X-728-1-S	2	Clip				
❶16	M-545010-S	2	Screw-Hex Flange, M5x0.8x10				
❶17	12 584 05-S	1	Module-Ignition				
❶18	M-545020-S	2	Screw-Hex Flange, M5x0.8x20				
❶❸	X-22-11-S	1	Washer-Lock, 1/4in				
❶❹	12 518 01-S	1	Lead, White, Ground To Kill (19in, 18 Gauge, Fully Insulated Push On Tab And Uninsulated Push On Tab Terminals)				
❶		1	Female Terminal And Uninsulated Female				




Blower Housing and Baffle Assembly Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
③1	M-545010-S	9	Screw-Hex Flange, M5x0.8x10				
③2	12 146 07-S	1	Plate-Housing, Blower				
③3	M-550010-S	6	Screw-Hf, M5x0.8x10				
③4	12 096 29-S	1	Cover-Starter				
③5	12 027 68-S	1	Housing, Blower				
③6	12 063 10-S	1	Baffle-Side, Intake				
③7	12 313 03-S	1	Grommet-Spark Plug				
③8	12 063 08-S	1	Baffle-Head, Cylinder				
③9	12 063 19-S	1	Baffle (Cylinder)				
③	12 113 124-S	1	Decal-15hp				
③	25 113 39-S	1	Decal-Clear Lamination				




Starting System Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❸1	M-550010-S	5	Screw-Hf, M5x0.8x10				
❸2	12 165 01-S	1	Starter, Retractable (Includes 3-9)				
❸3	12 081 01-S	1	Housing-Starter				
❸4	25 166 01-S	1	Handle-Start, Recoil				
❸5	12 160 01-S	1	Rope-Starter				
❸6	12 089 06-S	1	Spring And Keeper				
❸7	12 093 01-S	1	Pulley				
❸8	12 757 06-S	1	Dog Repair Kit				
❸9	41 086 09-S	1	Screw-Pozidriv				
❸10	15 109 01-S	1	Cup, Drive				
❶❸	12 113 07-S	1	Decal-Starting				




Fuel System Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❸1	M-641060-S	2	Nut-Hex Flange, M6x1.0				
❸2	M-629116-S	2	Stud-M6x1.0x116				
❸3	12 853 140-S	1	Kit, Carburetor W/gaskets (Includes 4,5 [qty 1])				
❸4	12 041 02-S	1	Gasket-Base, Air Cleaner				
❸5	12 041 01-S	2	Gasket-Carburetor				
❸6	12 265 04-S	1	Deflector-Heat				
❸7	47 154 01-S	1	Clip-Cable				
❶❸	12 757 02-S	1	Float Kit				
❶❸	12 757 03-S	1	Carburetor Repair Kit				
❶❸	12 757 08-S	1	Choke Repair Kit				
❶❸	12 757 36-S	1	Throttle Shaft Bearing Kit				
❶❸	12 757 37-S	1	Bowl Replacement Kit				
❶❸	12 755 92-S	1	High Altitude Kit				




Engine Control Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❶	M-664020-S	2	Screw-Lobed Socket, M6x1.0x20				
❷	M-545016-S	1	Screw-Hex Flange, M5x0.8x16				
❸	12 237 01-S	1	Clamp-Cable				
❹	12 536 01-S	1	Control, Speed ASM (Includes 5-7)				
❺	12 086 39-S	1	Screw-Pan Head (W/loctite)				
❻	12 089 11-S	1	Spring-Control, Speed				
❼	12 089 23-S	1	Spring-Return, Choke				
❽	12 089 19-S	1	Spring-Governor				
❾	12 755 83-S	1	Kit, Governor Lever (Includes 10-12)				
❿	12 100 07-S	1	Nut-Hf, M6x1.0				
⓫	52 211 04-S	1	Screw-Hf, M6x1.0x25				
⓬	12 090 28-S	1	Lever-Governor				
⓭	25 158 08-S	1	Bushing-Linkage Retaining				
⓮	12 079 01-S	1	Linkage-Throttle				
⓯	25 158 11-S	1	Bushing-Linkage Retaining				
⓰	12 079 07-S	1	Linkage-Choke				



Air Intake/Filtration Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
1	12 743 04-S	1	Kit, Air Cleaner (Includes 2-11)				
2	20 341 01-S	1	Knob-Cover				
3	12 096 44-S	1	Cover-Cleaner, Air				
4	12 083 12-S	1	Precleaner				
5	12 083 10-S	1	Element, Air Cleaner (Includes 6)				
6	12 100 01-S	1	Nut-Wing				
7	12 032 11-S	1	Seal				
8	12 072 04-S	1	Stud-Plate, Mounting				
9	12 086 01-S	2	Screw				
10	12 094 14-S	1	Base-Cleaner, Air				
11	12 041 02-S	1	Gasket-Base, Air Cleaner				
12	12 113 04-S	1	Decal-Cleaner, Air				



Exhaust Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❶	12 068 44-S	1	Muffler				
❷	M-645016-S	2	Screw-Hex Flange, M6x1.0x16				
❸	X-25-78-S	2	Washer-Plain, 1/4in				
❹	12 126 71-S	1	Bracket-Muffler				
❺	12 112 20-S	2	Spacer				
❻	M-645025-S	2	Screw-Hex Flange, M6x1.0x25				
❼	25 072 04-S	2	Stud, M8x1.25x33				
❽	12 041 03-S	1	Gasket-Manifold, Exhaust				
❾	M-841080-S	2	Nut-Hex Flange, M8x1.25				
❿	M-545016-S	1	Screw-Hex Flange, M5x0.8x16				
⓫	12 522 18	1	Block-Short				
⓬	12 755 93-S	1	Gasket Set				

Attachments and Accessories

For 30317 - Mid-Size ProLine T-Bar Gear, 15 HP with 36in Side Discharge Mow

Product Name	Model/Part
Blade-Atomic	104-1301
Electric Starter Kit	104-8580
Soft Bag (3 Bushel)	30104
Steel Grass Catcher	30107
Tru Trak Sulky	30110
Blade	56-2390-03

NOTES

NOTES

NOTES

