Form Number 3352-640

34cm Electric Recycler® Mower

Model No. 21060 - 240000001 and up.
Model No. 21061 - 240000001 and up.
Model No. 21062 - 240000001 and up.

Parts Catalog

Ordering Replacement Parts
To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers
Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers
Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity
In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

©The Toro Company - 2004
All Rights Reserved

Register your product at www.Toro.com

Contents

Description	Page	Description	Page
Motor and Blade Assembly	 3	Bag and Recycling Assembly	 5
Chassis Assembly	 4	Handle Assembly	 6


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
CARR. . . . . carriage
DEG. . . . . degrees
FH. . . . . flat head
GA. . . . . gauge
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HS. . . . . hex
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
INC. . . . . incorporated
LH. . . . . left hand
NI. . . . . nylon insert
PPH. . . . . phillips pan head
PTH. . . . . phillips truss head
PTO. . . . . power take off
RH. . . . . right hand
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head
WH. . . . . wing head


Footnotes

❶ Not illustrated




Motor and Blade Assembly

Ref	Part No.	Qty.	Description
1	95-6742	1	Motor
❶1	95-6867	1	Motor-1050 W-Gb
2	95-6732	5	Screw
3	95-6548	1	Fan
4	95-6748	1	Adapter-Motor
5	95-6624	1	Baffle-Motor
6	95-6632	1	Capacitor
7	95-6584	1	Clip-Capacitor
8	95-6598	1	Screw-Mount
9	95-6620	1	U-Clip
10	95-6893	1	Shroud-Motor (Incl. Ref. # 16)
11	95-6582	1	Blade
12	95-6767	1	Retainer-Blade
13	95-6743	1	Screw-Blade
14	95-6619	2	Nut-Snap On, Shround
15	95-6623	2	Screw
16	95-6906	1	Plate-Logo
17	95-6532	2	Screw
18	95-6692	1	Release-Cable




Chassis Assembly

Ref	Part No.	Qty.	Description
1	95-6795	1	Housing
2	95-6735	1	Axle-Rear
3	95-6734	1	Axle-Front
4	95-6665	3	Wheel ASM
5	95-6543	3	Cover-Wheel
6	95-6716	1	Cover-Wheel
7	95-6544	4	Clamp-Spring, Wheel
8	95-6888	1	Cover-Knob
9	95-6562	1	Knob-HOC
10	95-6506	1	Latch-HOC
11	95-6564	1	Spring-HOC
12	95-6719	1	Rod-HOC (Incl. Ref. # 15)
13	95-6741	1	Spacer
14	95-6565	1	Nut-Push
15	95-6709	1	Decal-HOC
16	95-6702	2	Nut-Push
17	95-6505	1	Spring-Balance, HOC
18	95-6700	1	Plate-Axle, Front
19	95-6699	1	Plate-Axle, Rear
20	95-6560	5	Screw
21	95-6835	1	Decal-Recycler, 34cm
22	95-6666	1	Smartwheel ASM



Bag and Recycling Assembly

Ref	Part No.	Qty.	Description
1	95-6712	1	Rear Door ASM (Incl. Ref. # 13)
2	95-6842	1	Spring-Door, Rear
3	95-6508	1	Handle
4	95-6732	3	Screw
5	95-6578	1	Plug-Recycler
6	95-6577	1	Kicker-Middle
7	95-6765	1	Kicker-Front
8	95-6560	3	Screw
9	95-6553	1	Frame-Bag
10	95-6551	1	Bag
11	95-6555	1	Ramp-Bag
13	95-6572	1	Decal-Safety



Handle Assembly

Ref	Part No.	Qty.	Description
1	95-6515	1	Handle-Lower
2	95-6517	1	Handle-Upper (Incl. Ref. # 17)
3	95-6718	2	Bolt And Screw Set-Handle
4	95-6713	2	Handle Adjusting Knob ASM (Incl. Ref. # 9)
5	95-6885	2	Disc-Handle, Adjusting
6	95-6568	2	Disc-Handle, Holding
7	95-6703	2	Bold
8	95-6740	2	Nut
9	95-6569	2	Nut-M8
10	95-6605	1	Switch ASM
10	95-6631	1	Switch Asm, Ch
10	95-6907	1	Switch Asm, Gb
11	95-6598	2	Screw-Mount
12	95-6596	1	Mount-Bail
13	95-6598	1	Screw-Mount
14	95-6535	1	Rod
15	95-6529	1	Bail
16	95-6602	1	Clamp-Bail
17	95-6810	2	Cap-Handle
18	95-6597	1	Cable-Holder

NOTES


TORO®