



## 13in Trim and Edge Electric Trimmer

Model No. 51358 - 250000001 and up.

### Parts Catalog

#### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers


Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

#### Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.



## Handle Assembly

| Ref | Part No. | Qty. | Description           |
|-----|----------|------|-----------------------|
| 5   | 107-3348 | 1    | Collar-Handle, Assist |
| 6   | 107-3346 | 1    | Handle-Assist, Right  |
| 7   | 107-3347 | 1    | Handle-Assist, Left   |
| 7   | 108-6438 | 1    | Assist Handle ASM     |
| 8   | 94-4496  | 1    | Screw-PPH             |
| 9   | 108-6405 | 1    | Screw-Carriage        |
| 10  | 108-6402 | 1    | Knob-Handle           |



## Spool and Shield Assembly

| Ref  | Part No. | Qty. | Description                     |  |  |  |  |
|------|----------|------|---------------------------------|--|--|--|--|
| 2    | 105-9422 | 1    | Cap-Drum                        |  |  |  |  |
| 4    | 73-8490  | 1    | .065 Spool ASM                  |  |  |  |  |
| 4:1  | 73-8190  | 1    | Spool-Large (Not Illustrated)   |  |  |  |  |
| 4:2  | 88003    | 1    | Line-Filiment (Not Illustrated) |  |  |  |  |
| 5    | 105-9423 | 1    | Spring-Extension                |  |  |  |  |
| 6    | 107-3344 | 1    | Eyelet-Guide                    |  |  |  |  |
| 11   | 106-9839 | 1    | Shield ASM (Not Illustrated)    |  |  |  |  |
| 11:1 | 105-9425 | 1    | Shield-12In                     |  |  |  |  |
| 11:2 | 106-6467 | 1    | Blade-Cutoff                    |  |  |  |  |
| 11:3 | 105-9437 | 1    | Screw-Pan Hd                    |  |  |  |  |

