



## 48in Vacuum Bagger 5xi Garden Tractors

Model No. 79310 - 260000001 and up.

### Parts Catalog

#### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

#### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


## Contents

| Description              | Page    | Description                      | Page    |
|--------------------------|---------|----------------------------------|---------|
| Drive Component Assembly | ..... 3 | Deck Assembly                    | ..... 6 |
| Blower Housing Assembly  | ..... 4 | Bag and Frame Assembly           | ..... 7 |
| Top Bag Assembly         | ..... 5 | Attachments and Accessories List | ..... 8 |

## Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

|                                            |                                              |
|--------------------------------------------|----------------------------------------------|
| AR. .... as required                       | INC. .... incorporated                       |
| ASM. .... assembly                         | LH. .... left hand                           |
| BBC. .... blade brake clutch               | NI. .... nylon insert                        |
| CARR. .... carriage                        | NPTF. .... national pipe thread fine         |
| DEG. .... degrees                          | PFH. .... phillips flat head                 |
| EXT. .... external                         | PPH. .... phillips pan head                  |
| FH. .... flat head                         | PPHTF. .... phillips pan head thread forming |
| GA. .... gauge                             | PRH. .... phillips round head                |
| HF. .... hex flange                        | PTH. .... phillips truss head                |
| HH. .... hex head                          | PTO. .... power-take-off                     |
| HHF. .... hex head flange                  | RH. .... right hand                          |
| HHFTF. .... hex head flange thread forming | ROPS. .... roll-over-protection-system       |
| HJ. .... hex jam                           | SFH. .... slotted fillister head             |
| HLH. .... hex lag head                     | SHH. .... slotted hex head                   |
| HOC. .... height-of-cut                    | SHWH. .... slotted hex washer head           |
| HSBH. .... hex socket button head          | SPH. .... slotted pan head                   |
| HSFH. .... hex socket flat head            | SQH. .... square head                        |
| HSH. .... hex socket head                  | SRH. .... slotted round head                 |
| HWH. .... hex washer head                  | STD. .... standard                           |
| HWHTF. .... hex washer head thread forming | TAP. .... self tapping                       |
| HYD. .... hydraulic                        | TTH. .... torx truss head                    |



## Drive Component Assembly


| Ref | Part No.   | Qty. | Description              |  |  |  |  |
|-----|------------|------|--------------------------|--|--|--|--|
| 1   | 79-7110    | 1    | Spring-Compression       |  |  |  |  |
| 2   | 79-2020    | 1    | Spring-Rod               |  |  |  |  |
| 3   | 79-1970    | 1    | Idler Arm ASM            |  |  |  |  |
| 4   | 3296-39    | 2    | Nut-Lock, NI             |  |  |  |  |
| 5   | 92-7099    | 1    | Pulley-Idler             |  |  |  |  |
| 6   | 3256-4     | 4    | Washer-Flat              |  |  |  |  |
| 7   | 107213     | 1    | Spacer                   |  |  |  |  |
| 8   | 3256-24    | 1    | Washer-Flat              |  |  |  |  |
| 9   | 323-10     | 1    | Screw-HH                 |  |  |  |  |
| 10  | 323-9      | 1    | Screw-HH                 |  |  |  |  |
| 11  | 93-1622    | 1    | Pulley-Idler             |  |  |  |  |
| 12  | 79-7490    | 1    | V-Belt                   |  |  |  |  |
| 13  | 79-7280-03 | 1    | Support-Shield, Belt     |  |  |  |  |
| 14  | 100284     | 2    | Bushing                  |  |  |  |  |
| 15  | 3256-26    | 1    | Washer-Flat              |  |  |  |  |
| 16  | 3272-7     | 1    | Pin-Cotter               |  |  |  |  |
| 17  | 79-7440    | 1    | Bracket-Support, Housing |  |  |  |  |
| 18  | 32128-20   | 4    | Nut-HF                   |  |  |  |  |
| 19  | 3256-3     | 1    | Washer-Flat              |  |  |  |  |
| 20  | 3230-1     | 3    | Bolt-CARR                |  |  |  |  |
| 21  | 3230-16    | 1    | Screw-CARR               |  |  |  |  |
| 22  | 3256-23    | 1    | Washer-Flat              |  |  |  |  |
| 23  | 3272-10    | 1    | Pin-Cotter               |  |  |  |  |
| 24  | 79-1380-03 | 1    | Blower Mounting ASM      |  |  |  |  |



Blower Housing Assembly

| Ref | Part No.   | Qty. | Description          |
|-----|------------|------|----------------------|
| 1   | 32128-20   | 6    | Nut-HF               |
| 3   | 3217-26    | 2    | Nut-Hex              |
| 4   | 3256-14    | 2    | Washer-Flat          |
| 5   | 32105-13   | 1    | Screw-SHH            |
| 6   | 79-7230-03 | 1    | Latch-Blower         |
| 7   | 79-7390    | 1    | Spring-Extension     |
| 8   | 3296-42    | 1    | Nut-Lock, NI         |
| 9   | 3290-479   | 1    | Fastener-Panel       |
| 10  | 82-5690    | 1    | Retainer-Duct        |
| 11  | 22-9741    | 1    | Spacer-Interlock     |
| 12  | 3220-6     | 2    | Nut-Jam              |
| 13  | 3253-8     | 2    | Washer-Lock          |
| 14  | 251-341    | 4    | Flange               |
| 15  | 251-288    | 2    | Bearing-Ball         |
| 16  | 3230-16    | 6    | Screw-CARR           |
| 17  | 79-6890    | 1    | Housing-Vac, Blower  |
| 18  | 3229-11    | 6    | Screw-CARR           |
| 19  | 79-4300-03 | 1    | Impeller ASM         |
| 20  | 79-7170-03 | 1    | Cover-Blower, Bottom |
| 21  | 3256-22    | 7    | Washer-Flat          |
| 22  | 3296-56    | 6    | Nut-Lock, NI         |
| 23  | 321-4      | 1    | Screw-HH             |
| 24  | 3257-40    | 1    | Key-Hi Pro           |
| 25  | 79-1470    | 1    | Shaft-Blower         |


| Ref | Part No. | Qty. | Description   |
|-----|----------|------|---------------|
| 26  | 7038     | 1    | Spacer        |
| 27  | 79-1460  | 1    | Pulley-Blower |



## Top Bag Assembly



| Ref  | Part No.   | Qty. | Description       |
|------|------------|------|-------------------|
| 1    | 115880     | 2    | Grip              |
| 2    | 115481-03  | 2    | Latch-Bagger, Top |
| 3    | 114439     | 24   | Rivet-Pop         |
| 4    | 9202704    | 4    | Washer            |
| 5    | 92-1734    | 1    | Top-Bagger        |
| 6    | 321-4      | 4    | Screw-HH          |
| 7    | 3296-42    | 4    | Nut-Lock, NI      |
| 8    | 2412-91    | 2    | Clamp             |
| 10   | 88-9570    | 1    | Stiffener ASM     |
| 10:2 | 93-7320    | 1    | Decal-Caution     |
| 11   | 3296-39    | 2    | Nut-Lock, NI      |
| 12   | 114966     | 1    | Clamp-Seal        |
| 13   | 117239     | 1    | Seal-Chute        |
| 14   | 92-1736-03 | 1    | Support-Screen    |
| 15   | 114969     | 1    | Feeler-Fill, Bag  |
| 16   | 3218-1     | 1    | Nut-Jam           |
| 17   | 32144-8    | 1    | Screw-HH          |
| 18   | 3256-49    | 1    | Washer-Flat       |
| 19   | 233-68     | 1    | Knob              |
| 20   | 100-6152   | 1    | Chute-Discharge   |
| 21   | 118320     | 1    | Handle-Tapered    |
| 22   | 114960     | 1    | Pin-Spring        |
| 23   | 114962     | 2    | Spring-Extension  |
| 24   | 9790944    | 2    | Spacer            |

| Ref | Part No.  | Qty. | Description    |
|-----|-----------|------|----------------|
| 25  | 114967    | 1    | Screen-Bagger  |
| 26  | 114955-03 | 1    | Frame ASM      |
| 27  | 323-6     | 2    | Screw-HH       |
| 28  | 114961-03 | 1    | Hinge-Bag, Top |
| 30  | 116347    | 1    | Decal          |



Deck Assembly

| Ref | Part No.   | Qty. | Description             |  |  |  |  |
|-----|------------|------|-------------------------|--|--|--|--|
| 1   | 86-9300    | 1    | Shield-Belt             |  |  |  |  |
| 2   | 321-3      | 2    | Screw-HH                |  |  |  |  |
| 3   | 92-7108    | 1    | Decal-Danger            |  |  |  |  |
| 4   | 98-5096    | 1    | Shield ASM              |  |  |  |  |
| 4:2 | 92-7108    | 1    | Decal-Danger            |  |  |  |  |
| 5   | 3234-26    | 3    | Screw                   |  |  |  |  |
| 6   | 94-7589-03 | 1    | Adapter-Shield          |  |  |  |  |
| 7   | 79-7130    | 1    | Pulley                  |  |  |  |  |
| 8   | 322-3      | 1    | Screw-HH                |  |  |  |  |
| 9   | 32128-20   | 1    | Nut-HF                  |  |  |  |  |
| 10  | 79-7000-03 | 1    | Pivot Bracket ASM       |  |  |  |  |
| 11  | 9266714    | 2    | Screw-HWH               |  |  |  |  |
| 12  | 88-1870    | 2    | Bracket-Support, Shield |  |  |  |  |
| 13  | 3296-42    | 2    | Nut-Lock, NI            |  |  |  |  |
| 14  | 79-0470    | 4    | Rivet-Pop               |  |  |  |  |
| 15  | 3256-56    | 5    | Washer-Flat             |  |  |  |  |
| 16  | 3296-39    | 4    | Nut-Lock, NI            |  |  |  |  |
| 17  | 98-3096    | 1    | Weight                  |  |  |  |  |
| 18  | 323-4      | 2    | Screw-HH                |  |  |  |  |
| 19  | 323-45     | 2    | Screw-HH                |  |  |  |  |



## Bag and Frame Assembly

|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|  |  |  |  |

**Attachments and Accessories**

**For 79310 - 48in Vacuum Bagger, 5xi Garden Tractors**

| Product Name          | Model/Part |
|-----------------------|------------|
| Blower Assembly ..... | 104-2486   |



## NOTES

## NOTES

## NOTES

