Form Number 3353-492 Rev A

44in Vac-Bagger
TimeCutter™ ZX Riding Mowers

Model No. 79163 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2005
All Rights Reserved

Register your product at www.Toro.com


Contents

Description	Page
Drive Assembly	3
Blower Housing Assembly	4
Blower Housing Assembly No. 108-9502	5
Top Bag Assembly	6
44 Inch Deck Assembly	7
Bag and Frame Assembly	8
Front Counter Weight Assembly	9

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR	as required
ASM	assembly
BBC	blade brake clutch
CARR	carriage
DEG	degrees
EXT	external
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HHFTF	hex head flange thread forming
HJ	hex jam
HLH	hex lag head
HOC	height-of-cut
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming
HYD	hydraulic
INC	incorporated
LH	left hand
NI	nylon insert
NPTF	national pipe thread fine
PFH	phillips flat head
PPH	phillips pan head
PPHTF	phillips pan head thread forming
PRH	phillips round head
PTH	phillips truss head
PTO	power-take-off
RH	right hand
ROPS	roll-over-protection-system
SFH	slotted fillister head
SHH	slotted hex head
SHWH	slotted hex washer head
SPH	slotted pan head
SQH	square head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	torx truss head



Drive Assembly


Ref	Part No.	Qty.	Description
1	323-10	2	Screw-HH
2	3256-24	1	Washer-Flat
3	107213	1	Spacer
4	79-2020	1	Spring-Rod
5	3256-4	4	Washer-Flat
6	92-7099	1	Pulley-Idler
7	79-1970	1	Idler Arm ASM
8	3296-39	2	Nut-Lock, NI
9	100284	2	Bushing
10	79-7110	1	Spring-Compression
11	3272-7	1	Pin-Cotter
12	3256-26	1	Washer-Flat
13	3230-16	4	Screw-CARR
14	79-7280-03	1	Support-Shield, Belt
15	93-8007	1	Belt-V
16	93-1622	1	Pulley-Idler
17	3296-29	1	Nut-Lock, NI
18	98-3499	2	Washer-Flat
19	79-7390	1	Spring-Extension
20	93-8012-03	1	Latch-Blower
21	93-8013	1	Bushing
22	32128-20	4	Nut-HF
23	93-8016-03	1	Mounting-Blower
24	3272-10	1	Pin-Cotter

Ref	Part No.	Qty.	Description
25	3256-23	1	Washer-Flat
26	3230-2	1	Bolt-CARR
27	79-7440	1	Bracket-Support, Housing
28	3256-3	1	Washer-Flat




Blower Housing Assembly

Ref	Part No.	Qty.	Description
1	3220-6	2	Nut-Jam
2	3253-8	2	Washer-Lock
3	79-1460	1	Pulley-Blower
4	32128-20	6	Nut-HF
5	251-341	4	Flange
6	251-288	2	Bearing-Ball
7	7038	1	Spacer
8	79-1470	1	Shaft-Blower
9	3257-40	1	Key-Hi Pro
10	79-4300-03	1	Impeller ASM
11	79-7170-03	1	Cover-Blower, Bottom
12	3229-11	6	Screw-CARR
13	3296-56	6	Nut-Lock, NI
14	3256-22	6	Washer-Flat
15	108-9502	1	Blower Housing ASM
16	3230-16	6	Screw-CARR



Blower Housing Assembly No. 108-9502


Ref	Part No.	Qty.	Description
3	107-9104	4	Rivet-Pop
4	22-9741	1	Spacer-Interlock
5	82-5690	1	Retainer-Duct
6	3290-479	1	Fastener-Panel



Top Bag Assembly


Ref	Part No.	Qty.	Description
1	3296-39	2	Nut-Lock, NI
2	114955-03	1	Frame ASM
3	114962	2	Spring-Extension
4	114961-03	1	Hinge-Bag, Top
5	321-4	2	Screw-HH
6	323-6	2	Screw-HH
7	114960	1	Pin-Spring
8	9790944	2	Spacer
9	321-4	2	Screw-HH
10	88-9570	1	Stiffener ASM
10:2	93-7320	1	Decal-Caution
11	3296-42	4	Nut-Lock, NI
12	114439	24	Rivet-Pop
13	114967	1	Screen-Bagger
14	9202704	4	Washer
15	92-1736-03	1	Support-Screen
16	115481-03	2	Latch-Bagger, Top
17	115880	2	Grip
18	114969	1	Feeler-Fill, Bag
19	2412-91	2	Clamp
20	3218-1	1	Nut-Jam
21	118320	1	Handle-Tapered
22	114966	1	Clamp-Seal
23	117239	1	Seal-Chute

Ref	Part No.	Qty.	Description
24	92-6752	1	Top-Bagger
25	233-68	1	Knob
26	108-9571	1	Chute-Discharge
27	3256-49	1	Washer-Flat
28	32144-8	1	Screw-HH
29	93-7329	1	Decal




44 Inch Deck Assembly

Ref	Part No.	Qty.	Description
1	3296-29	10	Nut-Lock, NI
2	3256-23	6	Washer-Flat
3	93-9344-03	1	Bracket-Pivot
4	93-8020-03	1	Pivot-Bracket
5	93-8023	1	Tube-Spacer
6	93-8009	1	Tube-Latch
7	110-6851	1	Belt Shield ASM
8	19-4050	2	Knob
9	46-8560	1	Screw-HHF
10	110-6514-03	1	Belt Cover ASM
11	93-8008	1	Pulley
12	3296-42	2	Nut-Lock, NI
13	100-4189-03	1	RH Bagging Ring ASM
14	321-4	2	Screw-HH
15	55-4940-03	3	Blade-Lift, High
16	100-4188-03	1	Baffle-Rear
17	3230-16	4	Screw-CARR
18	3230-8	1	Screw-CARR
19	100-4184	1	Screw-CARR
20	104-8003-01	1	Link-HOC, Adjusting



Bag and Frame Assembly

Ref	Part No.	Qty.	Description
1	93-1623	2	Bag-Depth
2	114972-03	2	Frame-Bag
3	3230-1	4	Bolt-CARR
4	114973-03	2	Hanger-Bag
5	114974-03	2	Clamp
6	3296-29	4	Nut-Lock, NI
7	104-3692-03	1	Bagger Bracket ASM
8	3296-42	8	Nut-Lock, NI
9	104-8006-03	2	Plate-Bagger
10	3256-22	12	Washer-Flat
11	321-6	4	Screw-HH
12	105-1940-03	2	Gusset-Bagger
13	321-10	4	Screw-HH
14	322-10	4	Screw-HH
15	105-1941	4	Spacer
16	9335064	1	Pin-Cotter, Hair
17	110-1884-03	1	Deflector
18	32104-76	1	Screw



Front Counter Weight Assembly

Ref	Part No.	Qty.	Description
1	104-8029	1	Weight-Bagger
2	67-7320	1	Decal
3	3234-18	4	Screw-HHF

NOTES

NOTES


TORO®