Form Number 3353-530 Rev C

Rinse Kit
Multi-Pro® 1200 and 1250 Turf Sprayers

Model No. 106-4842

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2005
All Rights Reserved

Register your product at www.Toro.com

Contents

Description	Page	Description	Page
Rinse Kit	 3	Tank Rinse Hose Assembly	 5
Suction Hose Assembly	 4	Rinse Hose Nozzle Assembly	 6


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . Blade Brake Clutch
CARR. . . . . carriage
DEG. . . . . degrees
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
INC. . . . . incorporated
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power take off
RH. . . . . right hand
ROPS. . . . . roll over protection system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head

Footnotes


❶ Not serviced separately



Rinse Kit


Ref	Part No.	Qty.	Description
4	107-8798	1	Valve-Pressure, Rinse Nozzle
4:1	107-8787	1	Nipple ASM
4:1:1	100-8637	1	O-Ring
5	107-8786	1	Valve-Pressure, Rinse Tank
5:1	107-8787	1	Nipple ASM
5:1:1	100-8637	1	O-Ring
6	107-8784	1	Decal-Rinse/Main Valve
7	107-8785	1	Decal-Nozzle/Boom Valve
9	106-4896	1	Fitting-Bulkhead
9:1	100-6710	1	Gasket-Bulkhead
10	100-6713	1	Nut-Bulkhead
❶11		1	Suction Hose ASM
13	100-6653	1	O-Ring
14	104-8797	1	Hosebarb
15	99-0766	1	Nut
16	106-4938	2	Reducer ASM
16:1	100-8637	1	O-Ring
17	106-4889	1	Upper Tank Drain Bulkhead ASM
17:1	100-6643	1	O-Ring
17:2	99-0758	1	Nut
17:3	100-6658	1	Gasket
17:4	106-1240	1	Bulkhead
17:5	106-1241	1	Nut-Special
❶18		1	Tank Rinse Hose ASM

Ref	Part No.	Qty.	Description
❶19		1	Rinse Hose Nozzle ASM
20	107-8793	2	Thread
21	107-8794	1	Tube-Rinse
22	107-8795	1	1/2In Bsp Fitting ASM
22:1	100-6645	1	O-Ring
23	99-0850	1	Nut
24	100-6653	1	O-Ring
25	99-0768	1	Elbow-60 DEG
26	107-8796	1	Rinse Ball ASM
26:1	107-8795	1	1/2In Bsp Fitting ASM
26:1:1	100-6645	1	O-Ring
26:2	99-0850	1	Nut
26:3	107-8797	1	Ball-Rinse
27	100-8635	4	Fork
28	100-6708	3	Fork
29	3290-379	3	Tie-Cable
30	2412-129	1	Clamp-Hose




Suction Hose Assembly

Ref	Part No.	Qty.	Description
1	106-4952	1	Hosebarb-90 DEG
1:1	100-6989	1	O-Ring
2	106-4936	1	Hosebarb
2:1	100-8637	1	O-Ring
3	41327	2	Clamp-Hose
4	108-3372	1	Hose-Suction



Tank Rinse Hose Assembly

Ref	Part No.	Qty.	Description
1	106-4945	2	Elbow
1:1	100-6712	1	O-Ring
2	107-8792	2	Hose-Suction
❶3		1	Check Valve ASM
3:1	100-7050	1	Bulkhead
3:2	106-4932	2	Hosebarb-Straight
3:2:1	100-8637	1	O-Ring
3:3	107-2867	1	Seat Drain ASM
3:3:2	107-2866	1	O-Ring
3:4	107-2869	1	Holder-Plunger
3:5	108-3658	1	Spring-Compression
3:6	107-2870	1	Drain Plunger ASM
3:6:2	107-2872	1	O-Ring
3:7	100-8635	2	Fork
4	2412-3	4	Clamp-Hose



Rinse Hose Nozzle Assembly

Ref	Part No.	Qty.	Description
1	106-4937	1	Hosebarb ASM
1:1	100-6712	1	O-Ring
2	107-8799	1	Hose-Pressure
3	2412-129	1	Clamp-Hose

NOTES


TORO®