



Brake and Tail Light Kit

Workman[®] 1100/2100 and Twister[®] Utility Vehicle

Model No. 104-6697

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers


Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.



Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.



(UNDER DASH)



(MOUNT WITH EXISTING HARDWARE)



(BRAKE PEDAL)

Brake and Tail Light Assembly

Ref	Part No.	Qty.	Description
1	104-6662	2	Stop And Tail Lamp ASM
1:1	32144-93	4	Screw-PPHTF
1:2	87-6300	2	Lens-Light, Tail
1:3	87-6310	2	Gasket-Light, Tail
2	104-6669	1	Harness-Light, Tail
3	95-8900	1	Switch
4	3290-378	4	Tie-Cable
5	2412-89	4	Clamp
6	46-8091	3	Screw-HWH
7	104-6833	1	Bracket-Brake
8	104-6958	1	Adapter
9	32105-13	2	Screw-SHH
10	104-6961	2	Reflector-Hexagon, Red
11	104-6962	2	Reflector-Amber
12	32144-89	4	Screw-Forming, Thread
13	104-6960	1	Harness-Dash
15	104-6959	1	Timer-Interval, 120 Second
16	32149-7	2	Nut-Keps
17	104-6995	1	Screw-Hscs
18	321-13	1	Screw-HH
19	3296-42	4	Nut-Lock, NI
20	32105-9	2	Screw
21	3296-9	2	Nut-Lock
23	99-7430	1	Relay

Ref	Part No.	Qty.	Description
24	218-578	1	Fuse-10 Amp
25	218-456	1	Flasher
26	2412-104	1	R-Clamp
27	3250-32	3	Screw-PPH
29	3253-7	1	Washer-Lock