


TORO®


MODEL NO. 04455 - 80001 & UP

**PARTS
CATALOG****GROOMING REEL KIT — GREENSMATER 3000****ROLLER EXTENSION ASSEMBLY**

Ref. No.	Part No.	Description	No. Used
1	3230-3	Bolt — Carriage	2
2	3296-47	Nut — Lock	4
3	32108-20	Screw — Machine Flat Head	2
4	10-5040	Knob — Height Adjustment	2
5	65-9490	Bracket — HOC	2
6	322-4	Screw — Cap Hex Hd.	2
7	32117-4	Nut — Pallet	2
8	2411-7	Stud — Ball	2

Ref. No.	Part No.	Description	No. Used
9	65-9500	Screw — Roller Adjustment	2
10	3253-3	Washer — Lock	2
11	321-4	Screw — Cap Hex Hd.	2
12	65-9530	Roller Extension W.A. — L.H.	1
*	65-9460	Roller Extension W.A. — R.H.	1
13	3253-4	Washer — Lock	4
14	322-2	Screw — Cap Hex Hd.	4
*	65-9620	Bar — Gauge	1

* Not Illustrated




FRAME ASSEMBLY — R.H.

Ref. No.	Part No.	Description	No. Used
1	32128-36	Nut — Flange	2
2	65-9970	Stud	2
3	65-9350	Adapter	1
4	65-9230	Plate — Side	1
5	65-9860	Bearing	1
6	65-9730	Nut — Splined	1
7	65-9960	Screw — Pivot	1
8	3296-60	Nut — Lock	2
9	65-9410	Spacer (76 Blade Reel)	79
9	65-9410	Spacer (26 Blade Reel)	4
*	65-9430	Spacer (26 Blade Reel)	25
10	65-9400	Blade (76 Blade Reel)	76
10	65-9400	Blade (26 Blade Reel)	26

Ref. No.	Part No.	Description	No. Used
11	65-9390	Shaft	1
12	32152-2	Nut — Lock	2
13	65-9820	Spacer	2
15	3289-21	Screw — Flat Hd. Hex Socket	3
16	251-327	Bearing — Ball	2
17	65-9300	Spacer	1
18	65-9220	Housing — Bearing	1
19	302-5	Fitting — Grease	1
20	3296-62	Nut	1
21	65-9360	Nut — Special	3
*	65-9440	Groomer Reel Assy. (26 Blade Reel) (Set of 3)	1

* Not Illustrated




FRAME ASSEMBLY — L.H.

Ref. No.	Part No.	Description	No. Used
1	65-9940	Spring	1
2	65-9930	Cap	1
3	32121-61	Roll Pin	4
4	284-3	Plug — Expansion	2
5		Driver	2
6		Spring	2
7	65-9560	Adjustment Knob Assembly (Incl. Ref. #4-6)	2
8	2410-68	Cover — Pin	2
9	32121-15	Roll Pin	2
10	65-9540	Cap Assembly	2
11	65-9830	Ramp	2
12	65-9840	Block — Mounting	2
13	3290-271	Rivet — Pop	2
14	65-9950	Plate — Caution	1
15	65-9810	Spring	2
16	3296-49	Nut — Lock	2
17	3256-24	Washer — Flat (L.H. Side)	1
17	65-9850	Washer (R.H. Side)	1
18	65-9860	Bearing	1
19	65-9820	Spacer	2
20	65-9330	Spacer	1
21	251-328	Bearing	2
22	65-9740	Screw — Pivot	1
23	3217-7	Nut — Hex	1

Ref. No.	Part No.	Description	No. Used
24	65-9350	Adapter	1
25		Clutch Assembly	1
26	3289-19	Screw — Flat Hd. Socket	2
27	3253-12	Washer — Lock	3
28	3274-13	Screw — Soc. Hd. Cap	2
29	3274-81	Screw — Soc. Hd. Cap	1
30	65-9710	Cover — Belt	1
31	65-9890	Bolt — Carriage	1
32	65-9340	Screw — Shoulder	1
33	65-9320	Idler — Pulley	1
34	65-9980	Spacer — Idler Pulley	1
35	65-9700	Belt	1
36	65-9290	Pulley — Driven	1
37	3274-8	Screw — Cap Hex Socket	1
38	3253-3	Washer — Lock	1
39	65-9310	Block — Idler	1
40	251-327	Bearing	2
41	65-9270	Housing — Belt Drive	1
42	32120-18	Ring — Retaining	1
43	302-5	Fitting — Grease	1
44	65-9300	Spacer — Pulley, Driven	1
45	32152-2	Nut — Lock	2
*	65-9560	Knob — Adjustment Assembly (Incl. Ref. #4-7)	2
*	65-9540	Cap Assembly (Incl. Ref. #8-10)	2

* Not Illustrated



CLUTCH ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	65-9990	Stud	1
2	65-9900	Seal — Felt	1
3	65-9610	Adapter	1
4	252-110	Bearing — Needle	1
5	65-9660	Pin — Clutch	1
6	65-9670	Spring — Compression	1
7	65-9630	Pulley — Driver	1
8	251-327	Bearing — Roller	1

Ref. No.	Part No.	Description	No. Used
9	3290-480	Washer — Belleville	2
10	65-9640	Disc — Release, Clutch	1
11	65-9650	Screw — Special	1
12	256-300	Bushing — Flange	1
13	32110-13	Screw — Set	2
14	65-9680	Knob — Clutch	1
15	3256-24	Washer — Flat	1
16	3296-17	Nut — Lock	1