



ProLine Walk-Behind Mower Fixed Deck, Pistol Grip, Gear Drive with 32in Cutting Unit

Model No. 30682 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Engine and Fuel Tank Assembly	 3	Cooling Equipment Assembly Kawasaki Model FH430V-AS25	 20
Transmission Drive Assembly	 4	Electric Equipment Assembly Kawasaki Model FH430V-AS25	 21
Drive Wheel and Brake Assembly	 6	Control Equipment Assembly Kawasaki Model FH430V-AS25	 22
Handle and Control Assembly	 8	Carburetor Assembly Kawasaki Model FH430V-AS25	 23
Control Panel Decal Assembly No. 110-6906	 10	Air Filter and Muffler Assembly Kawasaki Model FH430V-AS25	 24
Deck and Shield Assembly	 11	Fuel Tank and Fuel Valve Assembly Kawasaki Model FH430V-AS25	 25
Deflector Assembly No. 107-4140	 12	Starter Assembly Kawasaki Model FH430V-AS25	 26
Idler Arm and Caster Wheel Assembly	 13	Label Assembly Kawasaki Model FH430V-AS25	 27
Spindle and Blade Assembly	 15	Attachments and Accessories List	 28
Cylinder and Crankcase Assembly Kawasaki Model FH430V-AS25	 16		
Piston and Crankshaft Assembly Kawasaki Model FH430V-AS25	 17		
Valve and Camshaft Assembly Kawasaki Model FH430V-AS25	 18		
Lubrication Equipment Assembly Kawasaki Model FH430V-AS25	 19		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR. as required	INC. incorporated
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HF. hex flange	PTH. phillips truss head
HH. hex head	PTO. power-take-off
HHF. hex head flange	RH. right hand
HHFTF. hex head flange thread forming	ROPS. roll-over-protection-system
HJ. hex jam	SFH. slotted fillister head
HLH. hex lag head	SHH. slotted hex head
HOC. height-of-cut	SHWH. slotted hex washer head
HSBH. hex socket button head	SPH. slotted pan head
HSFH. hex socket flat head	SQH. square head
HSH. hex socket head	SRH. slotted round head
HWH. hex washer head	STD. standard
HWHTF. hex washer head thread forming	TAP. self tapping
HYD. hydraulic	TTH. torx truss head

Footnotes

- | | |
|----------------------|--|
| ❶ Not illustrated | ❷ Not serviced separately |
| ❸ Optional Equipment | ❹ Obtain from your local Kawasaki dealer |




Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	1-633023	2	Stud	23	1-805004	1	Washer-Lock
2	3256-23	4	Washer-Flat	24	100-6467	1	Muffler
3	1-633349	2	Spring-Tank, Fuel	25	103-5465	1	Clamp-Muffler
4	3296-47	2	Nut-Lock, NI	26	98-5975	2	Washer-Belleville
5	1-303077	4	Clamp	27	32128-21	1	Nut-HF
246		1	Engine-Kawasaki, FH430V-As25	28	1-413510	1	Clip-Loom
7	106-0699	1	Decal-Warning, Hot Surfaces	29	33114-016	1	Screw-HH
8	3290-357	1	Nut-HHF, Whiz	30	323-8	8	Screw-HH
9	323-14	1	Screw-HH	31	98-5975	8	Washer-Belleville
10	322-7	4	Screw-HH	32	3290-357	8	Nut-HHF, Whiz
11	1-303334	4	Washer-Spring	33	1-303335	1	Tie-Plastic
12	103-1966	1	Adapter	99	103-1964	1	Hose-Drain, Oil
13	92-6877	1	Valve-Drain, Oil				
14	32128-20	4	Nut-HF				
15	109-0293	1	Hose-Fuel				
16	1-603770	1	Valve-Fuel				
17	109-0306	1	Hose-Fuel				
18	322-3	2	Screw-HH				
19	1-805005	2	Washer-Lock				
20	106-0730	1	Fuel Tank ASM				
20:2	103-2605	1	Fitting-Fuel, Bulkhead				
21	88-3980	1	Gas Cap ASM				
21:3	88-4010	1	Gasket-Cap, Gas				
22	33113-016	1	Screw-HH				



Transmission Drive Assembly


Ref	Part No.	Qty.	Description
1	103-9897-01	1	Deck-Engine
2	1-323252	2	Bearing-Shaft
3	1-323254	2	Flange-Output
4	1-803310	2	Screw-Set
5	103-6512	2	Sheave-Transmission
6	321-3	6	Screw-HH
7	103-4177	1	Key-Machine
9	3296-39	1	Nut-Lock, NI
10	3256-24	1	Washer-Flat
11	1-323285	1	Idler-Drive, Transmission
12	3256-5	2	Washer-Flat
13	322-3	4	Screw-HH
14	1-805005	4	Washer-Lock
15	1-633181	1	Plate-Tapped
16	1-513051	1	Switch-Open, Normally
17	32151-62	2	Ring-Retaining
18	3257-5	3	Key-Woodruff
19	1-323502	2	Shaft-Transmission
20	51-4220	2	Guard-Coupler
21	1-323680	2	Coupler
22	1-323630	1	V-Belt
23	3245-41	2	Screw-HSH
24	1-323278	1	Sheave-Transmission
25	302-19	2	Fitting-Grease

Ref	Part No.	Qty.	Description
26	1-323500	1	Transmission
27	3230-1	2	Bolt-CARR
28	1-323387-03	1	Plate-Shift
29	105-4104	1	Decal-Speed, Ground
30	1-303020	1	Grip-Lever
31	98-3274-03	1	Lever-Shift
32	98-5975	1	Washer-Belleville
33	3296-6	1	Nut-Lock
35	1-323379	1	Washer
36	32128-20	2	Nut-HF
37	9264964	4	Screw-HWH, Thread Cut
38	1-603403	1	Bolt-Shoulder
39	1-323389-03	2	Bracket-Plate, Shift
40	1-806003	3	Pin-Hair
41	1-303186	1	Bellcrank
42	32128-21	1	Nut-HF
43	95-2814	1	Decal-Shut Off, Fuel
44	3290-500	2	Screw-PPH
45	1-543296	1	Grommet
46	3231-6	1	Screw-CARR
47	3296-42	4	Nut-Lock, NI
48	98-0776	1	Decal-Caution
49	103-1666	1	Sheave-Transmission
50	103-1667	1	Sheave



Transmission Drive Assembly (continued)


Ref	Part No.	Qty.	Description				
56	1-603610	2	Washer-Spring				
57	3212-6	1	Screw-HH				
58	1-633453	1	Spacer-Clutch				
59	1-373034	2	Washer				
62	32128-33	2	Nut-HF				
64	103-1797-01	1	Bracket-Cable, Choke				
65	103-1796	1	Cable-Choke				
66	1-303282	1	Switch-Start, Neutral				
67	1-323303	1	Linkage-Arm				
68	1-323745	1	Belt-Blade, Drive				
69	1-808280	1	Pin-Clevis				
70	1-303105	1	Yoke-Adjustable				
71	3219-2	1	Nut-Hex				
73	321-4	1	Screw-HH				
74	1-323430	1	Module-Interlock				
75	1-323229	1	Clip-Loom				
76	3256-22	1	Washer-Flat				
77	3296-42	1	Nut-Lock, NI				
78	1-303335	3	Tie-Plastic				



Drive Wheel and Brake Assembly


Ref	Part No.	Qty.	Description
2	99-8664	2	Screw-HH
3	32151-47	6	Ring-Retaining
4	1-806003	2	Pin-Hair
5	1-323245	2	Spring-Compression
6	103-1864	2	Swivel-Lever, Drive
7	322-6	2	Screw-HH
9	3256-23	4	Washer-Flat
10	1-323548	2	Linkage-Brake
11	1-322125	2	Swivel-Brake
12	1-513959	2	Wingnut-Nylock
13	3290-357	10	Nut-HHF, Whiz
14	323-39	4	Screw-HH
18	1-323352	2	Idler-Wheel, Drive
19	302-19	2	Fitting-Grease
21	1-323307	2	Pin-Clevis
22	103-1611-03	2	Arm-Brake
23	32120-47	2	Ring-Retaining, External
24	1-803051	2	Nut-Push
25	1-323262	2	Band-Brake
26	1-322141-03	1	Axle
27	1-523157	6	Washer-Spacer
27	1-543436	8	Washer-Spacer
28	1-323261	2	Drum-Brake
29	1-323349	2	Sheave-Wheel, Drive

Ref	Part No.	Qty.	Description
34	1-808519	2	Ring-Snap
36	322-5	8	Screw-HH
38	1-323744	2	Belt-Drive, Wheel
39	3296-29	4	Nut-Lock, NI
40	2412-104	2	R-Clamp
41	98-3259	1	Shield-Trailing
42	322-3	2	Screw-HH
43	98-5975	4	Washer-Belleville
44	323-6	4	Screw-HH
45	1-373034	8	Washer
46	1-805005	8	Washer-Lock
47		2	Wheel And Tire ASM
47:1	1-323361	1	Tire
47:2	1-323360	1	Wheel And Hub ASM
47:2:1	1-323329	2	Bearing-Flanged
47:2:2		1	Rim ASM
47:2:3		1	Fitting-Grease
47:2:4		1	Valve Stem And Cap
50	32128-20	4	Nut-HF
52	3296-39	4	Nut-Lock, NI
53	1-323287-01	2	Shield-Wheel, Drive
55	1-603402	2	Spring-Extension
56	1-323283	4	Spacer-Shield
57	103-1615-03	1	Arm-Idler, LH



Drive Wheel and Brake Assembly (continued)


Ref	Part No.	Qty.	Description
58	103-1616-03	1	Arm-Idler, RH



Handle and Control Assembly


Ref	Part No.	Qty.	Description
1	1-808286	2	Pin-Clevis
2	1-323359	2	Linkage-Wheel, Drive
4	1-303365	2	Bushing-Nylon
5	106-2717-03	1	Rod-Control, Operator Presence
6	106-5486	1	RH Opc Lever ASM
7	104-9838	2	Grip-Foam
8	321-18	2	Screw-HH
9	1-303435	6	Washer-Spring
10	1-323549	2	Spacer
11	3296-42	2	Nut-Lock, NI
12	3290-500	2	Screw-PPH
13	1-513051	1	Switch-Open, Normally
14	1-806003	3	Pin-Hair
15	1-633181	1	Plate-Tapped
16	110-6906	1	Gear Handle ASM
17	1-303363	1	Spring-Extension
18	1-633696	1	Throttle Cable ASM
19	2412-120	2	R-Clamp
20	1-303287	2	Tie-Plastic
22	1-303160	1	Spring-Compression
23	3256-4	2	Washer-Flat
24	3296-39	1	Nut-Lock, NI
26	1-323298	1	Linkage-Blade, Upper
27	1-322157	1	Lever ASM

Ref	Part No.	Qty.	Description
27:1	1-303020	1	Grip-Lever
28	3234-11	4	Screw-HHF
29	32104-76	2	Screw
30	32128-21	4	Nut-HF
31	104-7050	1	Housing-Manual
32	3296-2	2	Nut-Lock
34	1-513592	1	Knob-Ball
36	1-803001	2	Nut
38	1-807513	2	Bolt-CARR
39	106-5485	1	LH Opc Lever ASM
48	1-324280	1	RH Thumb Latch ASM
48:1	1-303019	1	Grip-Latch
49	1-324279	1	LH Thumb Latch ASM
49:1	1-303019	1	Grip-Latch
50	1-806340	2	Pin-Roll
51	1-808250	2	Pin-Lever, Drive
52	103-1610	1	Harness-Wiring
53	1-303088	1	Clip-Cable
54	1-302006	2	Drive Lever ASM
54:1	1-303021	1	Grip-Lever, Drive
55	29-5560	1	Switch-On / Off
55:1	218-461	1	Nut-HH
55:2	3254-5	1	Washer-Tooth
56	63-8360	1	Key-Ignition




Deck and Shield Assembly

Ref	Part No.	Qty.	Description				
1	1-324407	1	Shield ASM				
2	106-0710	1	Decal				
3	106-4161	4	Knob-Handle				
4	1-323417	4	Washer				
5	1-303536	2	Stud-Shield, Belt (Long)				
6	1-303537	2	Stud-Shield, Belt (Short)				
9	110-6901	1	32 Inch Deck ASM				
9:1		1	Deck				
9:1:2	98-3296	1	Decal-Routing, Belt				
9:1:3	98-5954	2	Decal-Missing, Cover				
9:1:4	98-5130	1	Decal-Torque, Bolt				
9:1:5	43-8480	1	Decal-Danger				
9:1:6	66-1340	1	Decal-Danger				
9:1:7	104-8569	1	Decal-Warning				
10	322-2	7	Screw-HH				
11	322-50	1	Screw-HH				
12	32128-20	11	Nut-HF				
13	1-302189-01	1	Baffle-Dogleg				
14	107-4140	1	Deflector ASM				
16	104-8554	1	Spring-Torsion				
17	105-4622	1	Spacer				
18	3296-29	1	Nut-Lock, NI				



Deflector Assembly No. 107-4140


Ref	Part No.	Qty.	Description
1	3231-4	3	Screw-CARR
2	107-4138-01	1	Strap-Deflector, Top
3	107-4139-01	1	Strap-Discharge
4	107-4137	1	Deflector-Rubber
5	107-4164-01	1	Bracket-Mounting, Deflector
6	3296-39	3	Nut-Lock, NI



Idler Arm and Caster Wheel Assembly


Ref	Part No.	Qty.	Description
3	1-513338	2	Washer-Flat
5	1-303314	8	Spacer-Caster
6	1-809020	2	Pin
7	1-322145-01	2	Fork
8	325-20	2	Screw-HH
9	1-513648	2	Wheel And Tire ASM
9:1		1	Rim
9:2	1-513808	1	Tire
9:3	1-513809	1	Bearing
9:4	1-513810	2	Bushing
10	1-513547	2	Spacer
11	3217-9	2	Nut-Hex
12	3253-7	2	Washer-Lock
15	323-6	8	Screw-HH
16	3290-357	8	Nut-HHF, Whiz
17	3296-42	2	Nut-Lock, NI
18	302-19	1	Fitting-Grease
19	32128-20	3	Nut-HF
20	1-323071	1	Spring-Extension
21	322-6	1	Screw-HH
22	103-3600	1	Idler Arm ASM
22:2	1-323729	2	Sleeve-Bearing
24	1-303348	1	Eyebolt-Thread, LH
25	1-303434	1	Bushing-Engagement

Ref	Part No.	Qty.	Description
26	1-603843	1	Pulley-Idler
27	98-5975	1	Washer-Belleville
28	702809	1	Screw-Cap
31	1-806003	1	Pin-Hair
33	1-322235	1	Arm-Assist
34	1-303238	1	Eyebolt-Thread, RH
35	1-303236	1	Body-Turnbuckle
36	32151-103	1	Ring-Snap
37	3296-29	1	Nut-Lock, NI
38	3256-3	1	Washer-Flat
39	1-403179	1	Tube-Pivot
40	3256-23	1	Washer-Flat
41	32120-35	1	E-Ring
42	1-323718	1	Rod-Brake
43	321-4	2	Screw-HH
44	1-323747	1	Spring-Compression
45	1-323746	1	Spacer-Flanged
46	1-324372	1	Pad / Spring ASM
47	1-303334	1	Washer-Spring
48	322-10	1	Screw-HH
49	1-303352	1	Washer-Spindle
50	1-323748	1	Ring-Push On
51	1-302203	2	Support ASM
51:1	302-52	1	Fitting-Grease




Idler Arm and Caster Wheel Assembly (continued)

Ref	Part No.	Qty.	Description
51:2	1-303514	2	Bearing-Flanged
52	3296-56	1	Nut-Lock, NI
53	3256-24	8	Washer-Flat




Spindle and Blade Assembly

Ref	Part No.	Qty.	Description				
1	1-800861	2	Screw-Cap, HH				
2	1-513208	2	Washer-Spring				
3	103-2507	2	Blade-Lift, Low				
3	103-2527	2	Blade-Notched				
4	1-323539	8	Spacer-Drive, Blade				
5	1-323529	2	Tube-Spindle, Short				
6	1-807267	2	Key				
8	103-2535	2	Spacer-Guard, Bottom				
13	107-4065	2	Cutter Housing ASM				
13:1		1	Housing-Cutter				
13:1:1	103-7975	1	Housing-Spindle				
13:1:2	103-2477	2	Bearing-Ball				
13:1:3	103-2534	1	Spacer-Bearing				
13:1:4	32120-8	1	Ring-Snap				
14	32128-20	8	Nut-HF				
15	1-303334	8	Washer-Spring				
16	322-6	8	Screw-HH				
17	1-403183	2	Sheave				
18	1-803310	2	Screw-Set				
19	1-323339	2	Washer-Retainer, Sheave				
20	3219-6	2	Nut-Hex				
22	103-1330	2	Guard-Bearing, Top				




Cylinder and Crankcase Assembly Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
④11004	11004-7008	1	Gasket-Head	④172	172G0818	1	Bolt-Stud
④11008	11008-7011	1	Head-Comp-Cylinder, No.2				
④11008A	11008-7017	1	Head-Comp-Cylinder, No.1				
④11008B	11008-7021	1	Head-Comp-Cylinder, No. 2				
④11008C	11008-7022	1	Head-Comp-Cylinder, No. 1				
④11022	11022-7003	1	Case-Rocker				
④11060	11060-7001	1	Gasket-Case, Rocker				
④11061	11061-7007	1	Gasket-Cover, Crankcase				
④11061A	11061-7008	1	Gasket-Breather				
④14091	14091-7007	1	Cover				
④49015	49015-7032	1	Cover-Crankcase				
④49120	49120-7015	1	Crankcase-Comp				
④59071	59071-2079	1	Joint				
④92043	92043-7001	1	Pin				
④92049	92049-7001	1	Seal-Oil, Rvc2 (6X11X10.2)				
④92049A	92049-7005	1	Seal-Oil, So (8X14X5 Hs)				
④92049B	92049-7015	1	Seal-Oil, Sd (35X62X8 L Hs)				
④92049C	92049-7016	1	Seal-Oil, Sd (35X48X8 R Hs)				
④92049D	92049-7019	1	Seal-Oil, So (8X14X5 Hs)				
④92139	92139-7002	1	Bushing				
④130	130B0612	1	Bolt-Flanged				
④130A	130B0640	1	Bolt-Flanged				
④130B	130T0850	1	Bolt-Flanged				
④130C	130T0875	1	Bolt-Flanged				




Piston and Crankshaft Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
④13001	13001-7009	1	Piston-Engine				
④13002	13002-7001	1	Pin-Piston				
④13008	13008-7001	1	Ring Set-Piston				
④13025	13025-7003	1	Ring Set-Piston (L,0.50)				
④13029	13029-7005	1	Piston-Engine (L,0.50)				
④13031	13031-7033	1	Crankshaft-Comp				
④13251	13251-7007	1	Connecting Rod ASM				
④13251A	13251-7008	1	Connecting Rod ASM (U/S=0.50)				
④92033	92033-7005	1	Ring-Snap				
④130	130G0630	1	Bolt-Flanged				




Valve and Camshaft Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
④12004	12004-7003	1	Valve-Intake				
④12005	12005-7003	1	Valve-Exhaust				
④12009	12009-7001	1	Retainer-Spring, Valve				
④12011	12011-2056	1	Collet				
④12016	12016-7001	1	Arm-Rocker				
④12032	12032-7001	1	Tappet				
④13070	13070-7001	1	Guide				
④13070A	13070-7004	1	Guide				
④13116	13116-2057	1	Rod-Push				
④13271	13271-7007	1	Plate				
④13271A	13271-7021	1	Plate-Governor				
④42036	42036-7009	1	Sleeve				
④49078	49078-7001	1	Spring-Valve, Engine				
④49118	49118-7009	1	Camshaft-Comp				
④92009	92009-2341	1	Screw				
④92015	92015-2253	1	Nut				
④92033	92033-7001	1	Ring-Snap				
④92140	92140-7002	1	Ball				
④92145	92145-7001	1	Spring				
④92153	92153-7019	1	Bolt				
④92200	92200-7001	1	Washer				




Lubrication Equipment Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
④13107	13107-7009	1	Shaft				
④13271	13271-7017	1	Plate				
④14075	14075-7009	1	Cap ASM				
④16154	16154-2053	1	Rotor-Pump (In)				
④16154A	16154-2054	1	Rotor-Pump (Out)				
④49065	49065-2078	1	Filter-Oil				
④49065A	49065-7004	1	Filter-Oil				
④59051	59051-7011	1	Gear-Spur				
④59231	59231-7003	1	Filler				
④92043	92043-7003	1	Pin				
④92066	92066-7003	1	Plug				
④92140	92140-7003	1	Ball				
④92145	92145-7002	1	Spring				
④130	130B0612	1	Bolt-Flanged				
④670	670D2016	1	O-Ring (16Mm)				




Cooling Equipment Assembly Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
④13270	13270-7007	1	Plate				
④14037	14037-7021-9H	1	Screen				
④14091	14091-7009	1	Cover				
④49089	49089-7044	1	Shroud-Engine				
④49089A	49089-7045	1	Shroud-Engine				
④59041	59041-7010	1	Fan				
④59066	59066-7023	1	Housing-Fan				
④92004	92004-7007	1	Stud				
④92153	92153-7007	1	Bolt				
④92153A	92153-7008	1	Bolt				
④130	130B0612	1	Bolt-Flanged				
④130A	130B0616	1	Bolt-Flanged				
④130B	130B0816	1	Bolt-Flanged				
④311	311F0600	1	Nut-Hex				




Electric Equipment Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
④21171	21171-7013	1	Ignition Coil ASM				
④21171A	21171-7014	1	Ignition Coil ASM				
④21194	21194-7013	1	Flywheel-Comp				
④26030	26030-7001	1	Harness				
④92004	92004-7008	1	Stud				
④92009	92009-2308	1	Screw				
④92066	92066-7002	1	Plug				
④92066A	92066-7005	1	Plug				
④92070	92070-7003	1	Plug-Spark (Rcj8Y, Solid)				
④92151	92151-2097	1	Bolt (12X30)				
④92200	92200-7002	1	Washer				
④130	130B0620	1	Bolt-Flanged				
④311	311F0600	1	Nut-Hex				
④510	510A5100	1	Key-Woodruff				



Control Equipment Assembly
Kawasaki Model FH430V-AS25


Ref	Part No.	Qty.	Description				
④13107	13107-7010	1	Shaft				
④13271	13271-7018	1	Plate				
④16169	16169-7012	1	Link-Choke				
④16171	16171-7007	1	Link				
④39129	39129-7003	1	Spring-Governor				
④49103	49103-7004	1	Arm-Governor				
④49113	49113-7024	1	Panel-Control				
④92009	92009-7007	1	Screw (4X35)				
④92145	92145-7003	1	Spring				
④92145A	92145-7005	1	Spring				
④92150	92150-2182	1	Bolt (5X18)				
④92153	92153-7005	1	Bolt (6X35)				
④92170	92170-7001	1	Clamp				
④130	130B0612	1	Bolt-Flanged				
④214	214B0408	1	Screw-Pan				
④311	311B0600	1	Nut-Hex				
④411	411b0600	1	Washer-Plain				



Carburetor Assembly Kawasaki Model FH430V-AS25


Ref	Part No.	Qty.	Description
④11061	11061-7004	1	Gasket-Insulator
④11061A	11061-7009	1	Gasket-Chamber
④11061B	11061-7010	1	Gasket-Screw
④11061C	11061-7018	1	Gasket-Cleaner, Air
④13107	13107-7018	1	Shaft
④15003	15003-7061	1	Carburetor-ASM
④16014	16014-7002	1	Screw-Pilot
④16020	16020-7003	1	Chamber-Float
④16025	16025-7006	1	Valve-Throttle
④16030	16030-7003	1	Valve-Float
④16031	16031-7002	1	Float
④16041	16041-7016	1	Shaft-Choke, Carburetor
④16041A	16041-7018	1	Shaft-Throttle, Carburetor
④16186	16186-7002	1	Choke Valve ASM
④39076	39076-7001	1	Limiter
④49121	49121-7001	1	Nozzle-Main
④59076	59076-7005	1	Manifold-Intake
④92009	92009-2083	1	Screw
④92009A	92009-2349	1	Screw
④92055	92055-2174	1	O-Ring
④92055A	92055-7007	1	O-Ring (Id=31)
④92063	92063-7026	1	Jet-Main, #88
④92063A	92063-7028	1	Jet-Main, #85
④92063B	92063-7029	1	Jet-Main, #82

Ref	Part No.	Qty.	Description
④92081	92081-2234	1	Spring
④92093	92093-2100	1	Seal
④92093A	92093-7003	1	Seal
④92145	92145-7015	1	Spring
④92153	92153-7009	1	Bolt
④92172	92172-7002	1	Screw
④92200	92200-7014	1	Washer




Air Filter and Muffler Assembly Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
④11011	11011-7035	1	Case-Filter, Air	④220	220B0614	1	Screw-Pan (Cross)
④11013	11013-7025	1	Element-Airfilter	④233	233B0416	1	Screw
④11013A	11013-7031	1	Element-Airfilter	④311	311B0400	1	Nut-Hex
④11051	11051-7005-9H	1	Bracket	④317	317R0800	1	Nut-Hex
④11053	11053-7022	1	Bracket	④461	461F0800	1	Washer-Spring
④11060	11060-7021	1	Gasket-Muffler	④670	670B2010	1	O-Ring (10Mm)
④13271	13271-7022	1	Plate				
④16060	16060-7016	1	Pipe-Intake				
④18088	18088-7001	1	Pipe-Exhaust				
④32154	32154-7006	1	Pipe				
④49070	49070-7015	1	Muffler				
④92015	92015-1193	1	Nut				
④92026	92026-7001	1	Spacer (6.2X7.9X5)				
④92055	92055-7015	1	Ring-O				
④92072	92072-7008	1	Band				
④92170	92170-7002	1	Clamp				
④92192	92192-7010	1	Tube				
④92200	92200-2070	1	Washer				
④92210	92210-7004	1	Nut				
④92210A	92210-7019	1	Nut				
④130	130B0610	1	Bolt-Flanged				
④130A	130B0612	1	Bolt-Flanged				
④130B	130B0816	1	Bolt-Flanged				






Fuel Tank and Fuel Valve Assembly Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
④23062	23062-7004-9H	1	Bracket				
④49019	49019-7001	1	Filter-Fuel				
④49040	49040-7001	1	Pump-Fuel				
④92170	92170-2088	1	Clamp				
④92191	92191-7002	1	Tube				
④92191A	92191-7003	1	Tube (6.35X12.7X160)				
④92191B	92191-7004	1	Tube				
④130	130B0620	1	Bolt-Flanged				



Starter Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
④13165	13165-7001	1	Pawl-Starter, Recoil				
④13271	13271-7003-9H	1	Plate				
④14020	14020-7001	1	Retainer				
④32099	32099-7002	1	Case-Recoil, Starter				
④46075	46075-7001	1	Grip-Recoil, Starter				
④49080	49080-7001	1	Pulley-Starting				
④49088	49088-7013	1	Starter-Recoil				
④59101	59101-7001	1	Reel-Recoil				
④59106	59106-7001	1	Rope				
④92145	92145-7006	1	Spring				
④92145A	92145-7007	1	Spring				
④92145B	92145-7008	1	Spring				
④92151	92151-7008	1	Bolt				
④92200	92200-7004	1	Washer				
④92200A	92200-7005	1	Washer				
④92210	92210-0003	1	Nut				
④130	130B0608	1	Bolt-Flanged				



Label Assembly

Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
④56033	56033-7001	1	Label-Manual
④56070	56070-7001	1	Label-Warning
④56080	56080-2077	1	Label-Brand
④56080A	56080-7024	1	Label-Brand

Attachments and Accessories

For 30682 - ProLine Walk-Behind Mower, Fixed Deck, Pistol Grip, Gear Drive with 32in Cutting Unit

Product Name	Model/Part
Atomic Blade and Decal Assembly	104-8595
Blade-16.25 Inch (6 Pack)	108-1119
Blade-Atomic, 16.25 Inch (6 Pack)	110-0407
32 Inch Recycler Kit	110-4915
Soft Bag (3 Bushel)	30198

NOTES

NOTES

NOTES

