Form Number 3354-105 Rev A

Commercial Walk-Behind Mower

Fixed Deck, T-Bar, Gear Drive with 40in TURBO FORCE® Cutting Unit

Model No. 30696 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2005
All Rights Reserved

Register your product at www.Toro.com

Contents

Description	Page
Engine and Fuel Tank Assembly	3
Transmission Drive Assembly	4
Drive Wheel and Brake Assembly	6
Handle and Control Assembly	7
Deck Assembly	8
Deck Decal Assembly No. 110-4908	9
Deflector Assembly No.110-0790	10
Sheave, Spindle and Blade Assembly	11
Idler Assembly	12
Caster Assembly	13
Cylinder and Crankcase Assembly Kawasaki Model FH430V-AS25	14
Piston and Crankshaft Assembly Kawasaki Model FH430V-AS25	15
Valve and Camshaft Assembly Kawasaki Model FH430V-AS25	16
Lubrication Equipment Assembly Kawasaki Model FH430V-AS25	17
Cooling Equipment Assembly Kawasaki Model FH430V-AS25	18
Electric Equipment Assembly Kawasaki Model FH430V-AS25	19
Control Equipment Assembly Kawasaki Model FH430V-AS25	20
Carburetor Assembly Kawasaki Model FH430V-AS25	21
Air Filter and Muffler Assembly Kawasaki Model FH430V-AS25	22
Fuel Tank and Fuel Valve Assembly Kawasaki Model FH430V-AS25	23
Starter Assembly Kawasaki Model FH430V-AS25	24
Label Assembly Kawasaki Model FH430V-AS25	25
Attachments and Accessories List	26

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR	as required
ASM	assembly
BBC	blade brake clutch
CARR	carriage
DEG	degrees
EXT	external
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HHFTF	hex head flange thread forming
HJ	hex jam
HLH	hex lag head
HOC	height-of-cut
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming
HYD	hydraulic
INC	incorporated
LH	left hand
NI	nylon insert
NPTF	national pipe thread fine
PFH	phillips flat head
PPH	phillips pan head
PPHTF	phillips pan head thread forming
PRH	phillips round head
PTH	phillips truss head
PTO	power-take-off
RH	right hand
ROPS	roll-over-protection-system
SFH	slotted fillister head
SHH	slotted hex head
SHWH	slotted hex washer head
SPH	slotted pan head
SQH	square head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	torx truss head

Footnotes

❶ Not serviced separately


❷ Obtain from your local Kawasaki dealer



Engine and Fuel Tank Assembly

Ref	Part No.	Qty.	Description
1	1-633023	2	Stud
2	3256-23	4	Washer-Flat
3	1-633349	2	Spring-Tank, Fuel
4	3296-47	2	Nut-Lock, NI
5	1-303077	4	Clamp
❶❷9		1	Engine-Kawasaki, FH430V-As25
10	106-0699	1	Decal-Warning, Hot Surfaces
11	32128-21	1	Nut-HF
12	323-14	1	Screw-HH
13	322-7	3	Screw-HH
14	1-303334	3	Washer-Spring
15	103-1966	1	Adapter
16	92-6877	1	Valve-Drain, Oil
17	5-0652	2	Spacer
18	109-0293	1	Hose-Fuel
19	1-603770	1	Valve-Fuel
20	109-0306	1	Hose-Fuel
21	3296-39	1	Nut-Lock, NI
22	322-3	2	Screw-HH
24	1-805005	2	Washer-Lock
26	106-0730	1	Fuel Tank ASM
26:2	103-2605	1	Fitting-Fuel, Bulkhead
27	88-3980	1	Gas Cap ASM
27:3	88-4010	1	Gasket-Cap, Gas


Ref	Part No.	Qty.	Description
28	32128-20	5	Nut-HF
30	322-9	1	Screw-HH
31	3254-2	1	Washer-Lock, Internal
32	100-6467	1	Muffler
33	103-5465	1	Clamp-Muffler
34	323-8	8	Screw-HH
35	98-5975	8	Washer-Belleville
36	3290-357	8	Nut-HHF, Whiz
99	103-1964	1	Hose-Drain, Oil



Transmission Drive Assembly


Ref	Part No.	Qty.	Description
1	103-9897-01	1	Deck-Engine
2	1-323252	2	Bearing-Shaft
3	1-323254	2	Flange-Output
4	1-803310	2	Screw-Set
5	103-6511	2	Sheave-Transmission
6	321-3	6	Screw-HH
7	103-4177	1	Key-Machine
9	3296-39	1	Nut-Lock, NI
10	3256-24	1	Washer-Flat
11	1-323285	1	Idler-Drive, Transmission
12	3256-5	2	Washer-Flat
13	322-3	4	Screw-HH
14	1-805005	4	Washer-Lock
15	1-633181	1	Plate-Tapped
16	1-513152	1	Switch-Closed, Normally
17	32151-62	2	Ring-Retaining
18	3257-5	3	Key-Woodruff
19	1-323502	2	Shaft-Transmission
20	51-4220	2	Guard-Coupler
21	1-323680	2	Coupler
22	1-323630	1	V-Belt
23	3245-41	2	Screw-HSH
24	1-323278	1	Sheave-Transmission
25	302-19	2	Fitting-Grease

Ref	Part No.	Qty.	Description
26	1-323500	1	Transmission
27	3230-1	2	Bolt-CARR
28	1-323387-03	1	Plate-Shift
29	98-3256	1	Decal-Speed, Ground
30	1-303020	1	Grip-Lever
31	98-3274-03	1	Lever-Shift
32	98-5975	1	Washer-Belleville
33	3296-6	1	Nut-Lock
35	1-323379	1	Washer
36	32128-20	2	Nut-HF
37	9264964	4	Screw-HWH, Thread Cut
38	1-603403	1	Bolt-Shoulder
39	1-323389-03	2	Bracket-Plate, Shift
40	1-806003	3	Pin-Hair
41	1-303186	1	Bellcrank
42	3290-357	1	Nut-HHF, Whiz
43	95-2814	1	Decal-Shut Off, Fuel
44	3290-500	2	Screw-PPH
45	1-543296	1	Grommet
46	3231-6	1	Screw-CARR
47	3296-42	4	Nut-Lock, NI
48	98-0776	1	Decal-Caution
49	103-1666	1	Sheave-Transmission
50	110-0504	1	Pulley Assembly



Transmission Drive Assembly (continued)


Ref	Part No.	Qty.	Description
56	1-603610	2	Washer-Spring
57	3212-6	1	Screw-HH
58	1-633453	1	Spacer-Clutch
59	1-373034	2	Washer
62	32128-33	2	Nut-HF
64	103-1797-01	1	Bracket-Cable, Choke
65	103-1796	1	Cable-Choke
67	1-323303	1	Linkage-Arm
68	110-0749	1	Belt-V
69	1-808280	1	Pin-Clevis
70	1-303105	1	Yoke-Adjustable
71	3219-2	1	Nut-Hex
72	1-303335	2	Tie-Plastic



Drive Wheel and Brake Assembly

Ref	Part No.	Qty.	Description
1	98-3273	2	Spring-Extension
2	323-10	2	Screw-HH
3	32151-47	2	Ring-Retaining
4	1-806003	4	Pin-Hair
5	3256-23	2	Washer-Flat
6	104-1321-03	1	RH Idler Arm ASM
7	104-1322-03	1	LH Idler Arm ASM
8	74-0521	2	Fitting-Rod
9	283-6	2	Pin-Clevis
10	1-323296	2	Rod-Brake
11	1-322125	2	Swivel-Brake
12	1-513959	2	Wingnut-Nylock
13	3290-357	10	Nut-HHF, Whiz
14	323-16	4	Screw-HH
16	98-5131-01	2	Shield-Wheel, Drive
17	1-323694	4	Spacer-Shield
18	1-323634	2	Idler-Drive, Wheel
19	302-19	2	Fitting-Grease
21	1-323307	4	Pin-Clevis
22	1-322209-03	2	Arm-Brake
23	32120-47	2	Ring-Retaining, External
24	1-803051	4	Nut-Push
25	1-323595	2	Band-Brake
26	1-322212-03	1	Axle ASM


Ref	Part No.	Qty.	Description
27	1-523157	6	Washer-Spacer
27	1-543436	8	Washer-Spacer
28	1-323261	2	Drum-Brake
29	1-323253	4	Sheave-Wheel, Drive
30	1-323719	2	Wheel And Tire ASM
30:1	1-323720	1	Tire-Turfmaster
30:2	1-323328	1	Wheel And Hub ASM
30:2:1	1-323329	2	Bearing-Flanged
34	1-808519	2	Ring-Snap
35	1-323260	8	Spacer-Sheave, Wheel
36	322-6	8	Screw-HH
38	1-323631	2	V-Belt
39	3296-29	2	Nut-Lock, NI
40	2412-104	2	R-Clamp
41	98-3259	1	Shield-Trailing
42	322-3	2	Screw-HH
43	98-5975	4	Washer-Belleville
44	323-6	4	Screw-HH
46	1-805005	8	Washer-Lock



Handle and Control Assembly

Ref	Part No.	Qty.	Description
1	98-3282	2	Rod-Control
2	95-5522-03	1	Control Bar ASM
3	3296-2	5	Nut-Lock
4	82-2290	1	Decal
5	32105-1	1	Screw-SHH
6	82-7680-03	1	Bail ASM
7	82-2280	1	Decal
8	3272-11	2	Pin-Cotter
9	99-8501-03	1	Control-Pivot
10	218-595	1	Connector-Body
11	98-3261-03	1	Lever-Brake, Parking
12	98-3266	1	Decal
13	740275	1	Switch-Seat
14	1-806003	3	Pin-Hair
15	237-141	2	Grommet-Rubber
16	98-3267-03	1	Upper Handle ASM
17	283-55	2	Pin-Clevis
18	100-6450	1	Control-Throttle
19	2412-120	2	R-Clamp
20	95-5537	1	Decal-Engage, Deck
21	1-303335	1	Tie-Plastic
22	1-303160	1	Spring-Compression
23	3256-24	2	Washer-Flat
24	3296-39	1	Nut-Lock, NI


Ref	Part No.	Qty.	Description
25	106-0678	1	Harness-Wire
26	98-3279	1	Linkage-Drive, Blade
27	98-3287-03	1	Lever-Engagement, Blade
28	3234-11	4	Screw-HHF
29	32104-76	2	Screw
30	110-6905	1	Control Panel ASM
30:2	110-6916	1	Decal-Control Panel
30:3	105-0884	1	Decal-Danger
31	104-7050	1	Housing-Manual
32	32105-14	4	Screw-SHH
33	32128-21	4	Nut-HF
34	99-8509	1	Spacer
35	1-303020	1	Grip-Lever
36	323-10	1	Screw-HH
37	98-4387	1	Decal-Protection, Ear
39	29-5560	1	Switch-On / Off
39:1	218-461	1	Nut-HH
39:2	3254-5	1	Washer-Tooth
40	63-8360	1	Key-Ignition
41	104-7048	1	Cap-Housing



Deck Assembly


Ref	Part No.	Qty.	Description
1	110-4908	1	Deck ASM
2	110-0795-01	1	Baffle, Adjust
3	108-7273-01	1	Baffle-Discharge
4	108-7282-01	1	Plate-Skid
5	110-0790	1	Deflector ASM
6	110-2034-01	1	Cover-Deck
7	92-1624	5	Screw
8	3290-357	12	Nut-HHF, Whiz
9	322-50	1	Screw-HH
10	105-4622	1	Spacer
11	104-8554	1	Spring-Torsion
12	107-1664	1	Lever ASM
12:1	106-3239	1	Screw-Lock
12:2	107-1644	1	Cap-Lock
12:3	106-3241	1	Lever-Lock
12:4	3296-29	1	Nut-Lock, NI
13	3296-29	1	Nut-Lock, NI
14	106-4161	5	Knob-Handle
15	1-323417	5	Washer
16	1-303536	3	Stud-Shield, Belt (Long)
17	1-303537	2	Stud-Shield, Belt (Short)
18	3231-1	4	Screw-CARR
19	32128-20	5	Nut-HF
20	110-6919	1	Decal

Ref	Part No.	Qty.	Description
21	110-6910-01	1	Baffle ASM
22	323-4	3	Screw-HH




Deck Decal Assembly No. 110-4908

Ref	Part No.	Qty.	Description
2	99-3943	1	Decal-Routing, Belt
3	43-8480	1	Decal-Danger
4	98-5130	1	Decal-Torque, Bolt
5	104-8569	1	Decal-Warning
6	98-5954	2	Decal-Missing, Cover
7	110-2067	1	Decal-Setting, Baffle
8	66-1340	1	Decal-Danger
9	110-2068	1	Decal-Adjustment, Baffle



Deflector Assembly No.110-0790


Ref	Part No.	Qty.	Description
1	3231-4	4	Screw-CARR
2	110-0792-01	1	Deflector
3	110-0793-03	1	Strap-Discharge
4	110-0791	1	Deflector-Rubber
5	107-4164-01	1	Bracket-Mounting, Deflector
6	3296-39	4	Nut-Lock, NI



Sheave, Spindle and Blade Assembly

Ref	Part No.	Qty.	Description
1	108-6697	3	Spindle Housing ASM
1:1	110-2118	2	Bearing
1:2	110-2116	1	Spacer-Bearing
1:3	108-6694	1	Housing-Spindle
1:4	32120-8	1	Ring-Snap
2	92-1624	18	Screw
3	3290-357	18	Nut-HHF, Whiz
4	110-4888	3	Washer-Spacer
5	103-2535	3	Spacer-Guard, Bottom
6	1-807267	3	Key
7	1-323529	3	Tube-Spindle, Short
8	1-323539	12	Spacer-Drive, Blade
9	108-4081-03	3	Blade-Rotary, 14 Inch High Sail
10	1-513208	3	Washer-Spring
11	1-800861	3	Screw-Cap, HH
12	103-1330	3	Guard-Bearing, Top
13	1-403183	3	Sheave
14	1-323339	3	Washer-Retainer, Sheave
15	3219-6	3	Nut-Hex
16	1-803310	3	Screw-Set
17	1-403184	2	Bushing-Idler
18	1-403186	1	Idler-Pulley, Flat
19	1-613098	1	Pulley-Idler
20	5-0652	2	Spacer


Ref	Part No.	Qty.	Description
21	98-5975	3	Washer-Belleville
22	1-403188	1	Spacer
23	323-15	1	Screw-HH
24	323-14	2	Screw-HH
25	322-2	1	Screw-HH
26	32128-20	1	Nut-HF
27	3296-39	3	Nut-Lock, NI



Idler Assembly


Ref	Part No.	Qty.	Description
1	1-324372	1	Pad/Spring ASM
2	321-4	2	Screw-HH
3	3296-42	2	Nut-Lock, NI
4	322-10	1	Screw-HH
5	1-403179	1	Tube, Pivot
6	32120-35	1	E-Ring
7	3256-23	1	Washer-Flat
8	1-322235	1	Arm-Assist
9	3256-3	1	Washer-Flat
10	3296-29	1	Nut-Lock, NI
11	1-303238	1	Eyebolt-Thread, RH
12	32128-20	3	Nut-HF
13	1-303236	1	Body-Turnbuckle
14	1-303348	1	Eyebolt-Thread, LH
15	702809	1	Screw-Cap
16	98-5975	1	Washer-Belleville
17	1-603843	1	Pulley-Idler
18	1-303434	1	Bushing-Engagement
19	103-3600	1	Idler Arm ASM
19:2	1-323729	2	Sleeve-Bearing
20	32151-103	1	Ring-Snap
21	322-6	1	Screw-HH
22	1-303352	1	Washer-Spindle
23	1-806003	3	Pin-Hair

Ref	Part No.	Qty.	Description
24	110-2051	1	Rod-Brake
25	1-323748	1	Ring-Push On
26	1-323747	1	Spring-Compression
27	1-323746	1	Spacer-Flanged
28	3296-56	1	Nut-Lock, NI
29	1-323071	1	Spring-Extension
30	1-303334	1	Washer-Spring
31	302-19	2	Fitting-Grease



Caster Assembly


Ref	Part No.	Qty.	Description
1	1-513648	2	Wheel And Tire ASM
❶1:1		1	Rim
1:2	1-513808	1	Tire
1:3	1-513809	1	Bearing
1:4	1-513810	2	Bushing
2	1-513547	2	Spacer
3	325-20	2	Screw-HH
4	1-322145-01	2	Fork
5	3217-9	2	Nut-Hex
6	3253-7	2	Washer-Lock
7	1-303314	8	Spacer-Caster
8	110-2130	2	Support ASM
8:2	1-303514	2	Bearing-Flanged
8:3	302-52	1	Fitting-Grease
9	1-513338	2	Washer-Flat
10	1-809020	2	Pin
11	323-4	8	Screw-HH
12	3290-357	8	Nut-HHF, Whiz



Cylinder and Crankcase Assembly
Kawasaki Model FH430V-AS25


Ref	Part No.	Qty.	Description
❷11004	11004-7008	1	Gasket-Head
❷11008	11008-7011	1	Head-Comp-Cylinder, No.2
❷11008A	11008-7017	1	Head-Comp-Cylinder, No.1
❷11008B	11008-7021	1	Head-Comp-Cylinder, No. 2
❷11008C	11008-7022	1	Head-Comp-Cylinder, No. 1
❷11022	11022-7003	1	Case-Rocker
❷11060	11060-7001	1	Gasket-Case, Rocker
❷11061	11061-7007	1	Gasket-Cover, Crankcase
❷11061A	11061-7008	1	Gasket-Breather
❷14091	14091-7007	1	Cover
❷49015	49015-7032	1	Cover-Crankcase
❷49120	49120-7015	1	Crankcase-Comp
❷59071	59071-2079	1	Joint
❷92043	92043-7001	1	Pin
❷92049	92049-7001	1	Seal-Oil, Rvc2 (6X11X10.2)
❷92049A	92049-7005	1	Seal-Oil, So (8X14X5 Hs)
❷92049B	92049-7015	1	Seal-Oil, Sd (35X62X8 L Hs)
❷92049C	92049-7016	1	Seal-Oil, Sd (35X48X8 R Hs)
❷92049D	92049-7019	1	Seal-Oil, So (8X14X5 Hs)
❷92139	92139-7002	1	Bushing
❷130	130B0612	1	Bolt-Flanged
❷130A	130B0640	1	Bolt-Flanged
❷130B	130T0850	1	Bolt-Flanged
❷130C	130T0875	1	Bolt-Flanged

Ref	Part No.	Qty.	Description
❷172	172G0818	1	Bolt-Stud




Piston and Crankshaft Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
❷13001	13001-7009	1	Piston-Engine
❷13002	13002-7001	1	Pin-Piston
❷13008	13008-7001	1	Ring Set-Piston
❷13025	13025-7003	1	Ring Set-Piston (L,0.50)
❷13029	13029-7005	1	Piston-Engine (L,0.50)
❷13031	13031-7033	1	Crankshaft-Comp
❷13251	13251-7007	1	Connecting Rod ASM
❷13251A	13251-7008	1	Connecting Rod ASM (U/S=0.50)
❷92033	92033-7005	1	Ring-Snap
❷130	130G0630	1	Bolt-Flanged




Valve and Camshaft Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
❷12004	12004-7003	1	Valve-Intake
❷12005	12005-7003	1	Valve-Exhaust
❷12009	12009-7001	1	Retainer-Spring, Valve
❷12011	12011-2056	1	Collet
❷12016	12016-7001	1	Arm-Rocker
❷12032	12032-7001	1	Tappet
❷13070	13070-7001	1	Guide
❷13070A	13070-7004	1	Guide
❷13116	13116-2057	1	Rod-Push
❷13271	13271-7007	1	Plate
❷13271A	13271-7021	1	Plate-Governor
❷42036	42036-7009	1	Sleeve
❷49078	49078-7001	1	Spring-Valve, Engine
❷49118	49118-7009	1	Camshaft-Comp
❷92009	92009-2341	1	Screw
❷92015	92015-2253	1	Nut
❷92033	92033-7001	1	Ring-Snap
❷92140	92140-7002	1	Ball
❷92145	92145-7001	1	Spring
❷92153	92153-7019	1	Bolt
❷92200	92200-7001	1	Washer




Lubrication Equipment Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
❷13107	13107-7009	1	Shaft
❷13271	13271-7017	1	Plate
❷14075	14075-7009	1	Cap ASM
❷16154	16154-2053	1	Rotor-Pump (In)
❷16154A	16154-2054	1	Rotor-Pump (Out)
❷49065	49065-2078	1	Filter-Oil
❷49065A	49065-7004	1	Filter-Oil
❷59051	59051-7011	1	Gear-Spur
❷59231	59231-7003	1	Filler
❷92043	92043-7003	1	Pin
❷92066	92066-7003	1	Plug
❷92140	92140-7003	1	Ball
❷92145	92145-7002	1	Spring
❷130	130B0612	1	Bolt-Flanged
❷670	670D2016	1	O-Ring (16Mm)




Cooling Equipment Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
❷13270	13270-7007	1	Plate
❷14037	14037-7021-9H	1	Screen
❷14091	14091-7009	1	Cover
❷49089	49089-7044	1	Shroud-Engine
❷49089A	49089-7045	1	Shroud-Engine
❷59041	59041-7010	1	Fan
❷59066	59066-7023	1	Housing-Fan
❷92004	92004-7007	1	Stud
❷92153	92153-7007	1	Bolt
❷92153A	92153-7008	1	Bolt
❷130	130B0612	1	Bolt-Flanged
❷130A	130B0616	1	Bolt-Flanged
❷130B	130B0816	1	Bolt-Flanged
❷311	311F0600	1	Nut-Hex




Electric Equipment Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
❷21171	21171-7013	1	Ignition Coil ASM
❷21171A	21171-7014	1	Ignition Coil ASM
❷21194	21194-7013	1	Flywheel-Comp
❷26030	26030-7001	1	Harness
❷92004	92004-7008	1	Stud
❷92009	92009-2308	1	Screw
❷92066	92066-7002	1	Plug
❷92066A	92066-7005	1	Plug
❷92070	92070-7003	1	Plug-Spark (Rcj8Y, Solid)
❷92151	92151-2097	1	Bolt (12X30)
❷92200	92200-7002	1	Washer
❷130	130B0620	1	Bolt-Flanged
❷311	311F0600	1	Nut-Hex
❷510	510A5100	1	Key-Woodruff



Control Equipment Assembly
Kawasaki Model FH430V-AS25


Ref	Part No.	Qty.	Description
❷13107	13107-7010	1	Shaft
❷13271	13271-7018	1	Plate
❷16169	16169-7012	1	Link-Choke
❷16171	16171-7007	1	Link
❷39129	39129-7003	1	Spring-Governor
❷49103	49103-7004	1	Arm-Governor
❷49113	49113-7024	1	Panel-Control
❷92009	92009-7007	1	Screw (4X35)
❷92145	92145-7003	1	Spring
❷92145A	92145-7005	1	Spring
❷92150	92150-2182	1	Bolt (5X18)
❷92153	92153-7005	1	Bolt (6X35)
❷92170	92170-7001	1	Clamp
❷130	130B0612	1	Bolt-Flanged
❷214	214B0408	1	Screw-Pan
❷311	311B0600	1	Nut-Hex
❷411	411b0600	1	Washer-Plain



Carburetor Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
❷11061	11061-7004	1	Gasket-Insulator
❷11061A	11061-7009	1	Gasket-Chamber
❷11061B	11061-7010	1	Gasket-Screw
❷11061C	11061-7018	1	Gasket-Cleaner, Air
❷13107	13107-7018	1	Shaft
❷15003	15003-7061	1	Carburetor-ASM
❷16014	16014-7002	1	Screw-Pilot
❷16020	16020-7003	1	Chamber-Float
❷16025	16025-7006	1	Valve-Throttle
❷16030	16030-7003	1	Valve-Float
❷16031	16031-7002	1	Float
❷16041	16041-7016	1	Shaft-Choke, Carburetor
❷16041A	16041-7018	1	Shaft-Throttle, Carburetor
❷16186	16186-7002	1	Choke Valve ASM
❷39076	39076-7001	1	Limiter
❷49121	49121-7001	1	Nozzle-Main
❷59076	59076-7005	1	Manifold-Intake
❷92009	92009-2083	1	Screw
❷92009A	92009-2349	1	Screw
❷92055	92055-2174	1	O-Ring
❷92055A	92055-7007	1	O-Ring (Id=31)
❷92063	92063-7026	1	Jet-Main, #88
❷92063A	92063-7028	1	Jet-Main, #85
❷92063B	92063-7029	1	Jet-Main, #82


Ref	Part No.	Qty.	Description
❷92081	92081-2234	1	Spring
❷92093	92093-2100	1	Seal
❷92093A	92093-7003	1	Seal
❷92145	92145-7015	1	Spring
❷92153	92153-7009	1	Bolt
❷92172	92172-7002	1	Screw
❷92200	92200-7014	1	Washer



Air Filter and Muffler Assembly
Kawasaki Model FH430V-AS25


Ref	Part No.	Qty.	Description
❷11011	11011-7035	1	Case-Filter, Air
❷11013	11013-7025	1	Element-Airfilter
❷11013A	11013-7031	1	Element-Airfilter
❷11051	11051-7005-9H	1	Bracket
❷11053	11053-7022	1	Bracket
❷11060	11060-7021	1	Gasket-Muffler
❷13271	13271-7022	1	Plate
❷16060	16060-7016	1	Pipe-Intake
❷18088	18088-7001	1	Pipe-Exhaust
❷32154	32154-7006	1	Pipe
❷49070	49070-7015	1	Muffler
❷92015	92015-1193	1	Nut
❷92026	92026-7001	1	Spacer (6.2X7.9X5)
❷92055	92055-7015	1	Ring-O
❷92072	92072-7008	1	Band
❷92170	92170-7002	1	Clamp
❷92192	92192-7010	1	Tube
❷92200	92200-2070	1	Washer
❷92210	92210-7004	1	Nut
❷92210A	92210-7019	1	Nut
❷130	130B0610	1	Bolt-Flanged
❷130A	130B0612	1	Bolt-Flanged
❷130B	130B0816	1	Bolt-Flanged

Ref	Part No.	Qty.	Description
❷220	220B0614	1	Screw-Pan (Cross)
❷233	233B0416	1	Screw
❷311	311B0400	1	Nut-Hex
❷317	317R0800	1	Nut-Hex
❷461	461F0800	1	Washer-Spring
❷670	670B2010	1	O-Ring (10Mm)




Fuel Tank and Fuel Valve Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
❷23062	23062-7004-9H	1	Bracket
❷49019	49019-7001	1	Filter-Fuel
❷49040	49040-7001	1	Pump-Fuel
❷92170	92170-2088	1	Clamp
❷92191	92191-7002	1	Tube
❷92191A	92191-7003	1	Tube (6.35X12.7X160)
❷92191B	92191-7004	1	Tube
❷130	130B0620	1	Bolt-Flanged



Starter Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
❷13165	13165-7001	1	Pawl-Starter, Recoil
❷13271	13271-7003-9H	1	Plate
❷14020	14020-7001	1	Retainer
❷32099	32099-7002	1	Case-Recoil, Starter
❷46075	46075-7001	1	Grip-Recoil, Starter
❷49080	49080-7001	1	Pulley-Starting
❷49088	49088-7013	1	Starter-Recoil
❷59101	59101-7001	1	Reel-Recoil
❷59106	59106-7001	1	Rope
❷92145	92145-7006	1	Spring
❷92145A	92145-7007	1	Spring
❷92145B	92145-7008	1	Spring
❷92151	92151-7008	1	Bolt
❷92200	92200-7004	1	Washer
❷92200A	92200-7005	1	Washer
❷92210	92210-0003	1	Nut
❷130	130B0608	1	Bolt-Flanged



56033



56070

56080



56080A



Label Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
❷56033	56033-7001	1	Label-Manual
❷56070	56070-7001	1	Label-Warning
❷56080	56080-2077	1	Label-Brand
❷56080A	56080-7024	1	Label-Brand

Attachments and Accessories

For 30696 - Commercial Walk-Behind Mower, Fixed Deck T-Bar Gear with 40in TURBO FORCE Cutting Unit

Product Name	Model/Part
Blade-Rotary, 14 Inch Recycling	108-4089-03
Blade-Rotary Mid Flow	108-4110-03
Blade-Rotary, 14 Inch Low Flow	108-4111-03
Blade-Rotary, 14 Inch Atomic	108-4112-03
40 Inch Bagger Enhancement Kit	110-2025
40 Inch Recycler Kit	110-2070
Weight Kit	110-2085
Plate Kit	110-6902
Soft Bag (3 Bushel)	30104
Sulky	30109

NOTES


TORO®