



48in Vac-Bagger TimeCutter™ Z Riding Mowers

Model No. 79166 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Description	Page	Description	Page
Blower Drive Assembly	 3	Bagger Hood and Hinge Assembly	 6
Blower Housing and Extension Assembly	 4	Blower Deck Mounting Assembly	 7
Blower Housing Assembly No. 108-9565	 5	Bag Frame and Mount Assembly	 8
		Bagger Weight Assembly	 9

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. as required	INC. incorporated
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HF. hex flange	PTH. phillips truss head
HH. hex head	PTO. power-take-off
HHF. hex head flange	RH. right hand
HHFTF. hex head flange thread forming	ROPS. roll-over-protection-system
HJ. hex jam	SFH. slotted fillister head
HLH. hex lag head	SHH. slotted hex head
HOC. height-of-cut	SHWH. slotted hex washer head
HSBH. hex socket button head	SPH. slotted pan head
HSFH. hex socket flat head	SQH. square head
HSH. hex socket head	SRH. slotted round head
HWH. hex washer head	STD. standard
HWHTF. hex washer head thread forming	TAP. self tapping
HYD. hydraulic	TTH. torx truss head




Blower Housing and Extension Assembly

Ref	Part No.	Qty.	Description				
1	3220-6	2	Nut-Jam				
2	3253-8	2	Washer-Lock				
3	79-1460	1	Pulley-Blower				
4	32128-20	6	Nut-HF				
5	251-341	4	Flange				
6	251-288	2	Bearing-Ball				
7	7038	1	Spacer				
8	3257-40	1	Key-Hi Pro				
9	79-1470	1	Shaft-Blower				
10	79-4300-03	1	Impeller ASM				
11	79-7170-03	1	Cover-Blower, Bottom				
12	3229-11	6	Screw-CARR				
13	3296-56	6	Nut-Lock, NI				
14	3256-22	7	Washer-Flat				
15	3296-42	1	Nut-Lock, NI				
16	3256-14	2	Washer-Flat				
17	3217-26	2	Nut-Hex				
18	32105-13	1	Screw-SHH				
19	79-7390	1	Spring-Extension				
20	79-7230-03	1	Latch-Blower				
21	321-4	1	Screw-HH				
22	108-9565	1	Blower Housing ASM				
23	3230-16	6	Screw-CARR				




Blower Housing Assembly No. 108-9565

Ref	Part No.	Qty.	Description				
3	107-9104	4	Rivet-Pop				
4	22-9741	1	Spacer-Interlock				
5	82-5690	1	Retainer-Duct				
6	3290-479	1	Fastener-Panel				




Bagger Hood and Hinge Assembly

Ref	Part No.	Qty.	Description				
1	32144-8	1	Screw-HH				
2	3256-49	1	Washer-Flat				
3	233-68	1	Knob				
4	108-9554	1	Chute-Discharge				
5	105-9100	1	Top-Bagger				
6	117239	1	Seal-Chute				
7	114966	1	Clamp-Seal				
8	92-1736-03	1	Support-Screen				
9	115481-03	2	Latch-Bagger, Top				
10	115880	2	Grip				
11	114439	24	Rivet-Pop				
12	9202704	10	Washer				
13	114967	1	Screen-Bagger				
14	3296-42	2	Nut-Lock, NI				
15	88-9570	1	Stiffener ASM				
15:2	93-7320	1	Decal-Caution				
16	323-6	2	Screw-HH				
17	3296-39	2	Nut-Lock, NI				
18	114955-03	1	Frame ASM				
19	114962	2	Spring-Extension				
20	9790944	2	Spacer				
21	114960	1	Pin-Spring				
22	321-4	2	Screw-HH				
23	114961-03	1	Hinge-Bag, Top				



Bag Frame and Mount Assembly

Ref	Part No.	Qty.	Description				
1	105-6980	2	Bag				
2	114972-03	2	Frame-Bag				
3	3230-1	4	Bolt-CARR				
4	114973-03	2	Hanger-Bag				
5	114974-03	2	Clamp				
6	3296-29	4	Nut-Lock, NI				
7	323-6	4	Screw-HH				
8	3256-24	4	Washer-Flat				
9	3296-39	4	Nut-Lock, NI				
10	110-1860-03	1	Bagger Support ASM				



Bagger Weight Assembly

Ref	Part No.	Qty.	Description
1	105-6972-03	1	Weight-Bagger
2	323-11	2	Screw-HH
3	3256-24	4	Washer-Flat
4	3296-39	2	Nut-Lock, NI

NOTES

NOTES

