Form Number 3354-176 Rev A

NEW HOLLAND

MZ48GC Grass Collector

MZ Series Riding Mowers

Model No. 717318006 - T06ZP0001 and up.

Model No. 99166 - T06ZP0001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© CNH America LLC - 2005
All Rights Reserved


Contents

Description	Page	Description	Page
Blower Drive Assembly	 3	Blower Deck Mounting Assembly	 6
Blower Housing and Extension Assembly	 4	Bag Frame and Mount Assembly	 7
Bagger Hood and Hinge Assembly	 5	Bagger Weight Assembly	 8

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . blade brake clutch
CARR. . . . . carriage
DEG. . . . . degrees
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
INC. . . . . incorporated
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PFH. . . . . phillips flat head
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power-take-off
RH. . . . . right hand
ROPS. . . . . roll-over-protection-system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head



Blower Drive Assembly


Ref	Part No.	Qty.	Description
1	323-9	1	Screw-HH
2	93-1622	1	Pulley-Idler
3	3256-4	4	Washer-Flat
4	79-7280-03	1	Support-Shield, Belt
5	3230-16	1	Screw-CARR
6	3296-39	2	Nut-Lock, NI
7	100284	2	Bushing
8	3256-26	1	Washer-Flat
9	3272-7	1	Pin-Cotter
10	79-7440	1	Bracket-Support, Housing
11	3256-3	1	Washer-Flat
12	32128-20	4	Nut-HF
13	3230-1	3	Bolt-CARR
14	3272-10	1	Pin-Cotter
15	3256-23	1	Washer-Flat
16	79-1380-03	1	Blower Mounting ASM
17	79-7110	1	Spring-Compression
18	79-2020	1	Spring-Rod
19	323-10	1	Screw-HH
20	3256-24	1	Washer-Flat
21	107213	1	Spacer
22	92-7099	1	Pulley-Idler
23	79-1970	1	Idler Arm ASM
24	79-7490	1	V-Belt



Blower Housing and Extension Assembly


Ref	Part No.	Qty.	Description
1	3220-6	2	Nut-Jam
2	3253-8	2	Washer-Lock
3	79-1460	1	Pulley-Blower
4	32128-20	6	Nut-HF
5	251-341	4	Flange
6	251-288	2	Bearing-Ball
7	7038	1	Spacer
8	3257-40	1	Key-Hi Pro
9	79-1470	1	Shaft-Blower
10	79-4300-03	1	Impeller ASM
11	79-7170-03	1	Cover-Blower, Bottom
12	3229-11	6	Screw-CARR
13	3296-56	6	Nut-Lock, NI
14	3256-22	7	Washer-Flat
15	3296-42	1	Nut-Lock, NI
16	3256-14	2	Washer-Flat
17	3217-26	2	Nut-Hex
18	32105-13	1	Screw-SHH
19	79-7390	1	Spring-Extension
20	79-7230-03	1	Latch-Blower
21	321-4	1	Screw-HH
22	108-9565	1	Blower Housing ASM
22:4	22-9741	1	Spacer-Interlock
22:5	82-5690	1	Retainer-Duct

Ref	Part No.	Qty.	Description
22:6	3290-479	1	Fastener-Panel
23	3230-16	6	Screw-CARR




Bagger Hood and Hinge Assembly

Ref	Part No.	Qty.	Description
1	32144-8	1	Screw-HH
2	3256-49	1	Washer-Flat
3	233-68	1	Knob
4	108-9554	1	Chute-Discharge
5	105-9100	1	Top-Bagger
6	117239	1	Seal-Chute
7	114966	1	Clamp-Seal
8	92-1736-03	1	Support-Screen
9	115481-03	2	Latch-Bagger, Top
10	115880	2	Grip
11	114439	24	Rivet-Pop
12	9202704	10	Washer
13	114967	1	Screen-Bagger
14	3296-42	2	Nut-Lock, NI
15	88-9570	1	Stiffener ASM
15:2	93-7320	1	Decal-Caution
16	323-6	2	Screw-HH
17	3296-39	2	Nut-Lock, NI
18	114955-03	1	Frame ASM
19	114962	2	Spring-Extension
20	9790944	2	Spacer
21	114960	1	Pin-Spring
22	321-4	2	Screw-HH
23	114961-03	1	Hinge-Bag, Top




Blower Deck Mounting Assembly

Ref	Part No.	Qty.	Description
1	110-6505	1	Belt Shield ASM
2	321-3	2	Screw-HH
3	110-6503	1	Cover ASM
3:2	110-1868	1	Decal-Danger, Shield
4	3234-26	3	Screw
5	110-6502	1	Pulley
6	3256-3	1	Washer-Flat
7	3296-29	2	Nut-Lock, NI
8	93-9910-03	2	Link-Adjusting, HOC
9	322-3	1	Screw-HH
10	106-8279-03	1	Adapter-Shield
11	79-7000-03	1	Pivot Bracket ASM
12	32128-20	1	Nut-HF
13	3230-1	2	Bolt-CARR
14	108-8563-03	1	Baffle
15	9266714	2	Screw-HWH
16	3296-42	2	Nut-Lock, NI
17	3256-24	1	Washer-Flat
18	9152366	1	Nut-HJ



Bag Frame and Mount Assembly

Ref	Part No.	Qty.	Description
1	105-6980	2	Bag
2	114972-03	2	Frame-Bag
3	3230-1	4	Bolt-CARR
4	114973-03	2	Hanger-Bag
5	114974-03	2	Clamp
6	3296-29	4	Nut-Lock, NI
7	323-6	4	Screw-HH
8	3256-24	4	Washer-Flat
9	3296-39	4	Nut-Lock, NI
10	110-1860-03	1	Bagger Support ASM



Bagger Weight Assembly

Ref	Part No.	Qty.	Description
1	105-6972-03	1	Weight-Bagger
2	323-11	2	Screw-HH
3	3256-24	4	Washer-Flat
4	3296-39	2	Nut-Lock, NI

NOTES

NOTES

NOTES


NEW HOLLAND