Form Number 3354-264 Rev A

Finish Grader
Sand Pro® 3040 and 5040

Model No. 08754 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2006
All Rights Reserved

Register your product at www.Toro.com


Contents

Description	Page	Description	Page
Adapter Assembly	 3	Box Assembly	 5
Link Assembly No. 110-8105	 4	Attachments and Accessories List	 6

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . blade brake clutch
CARR. . . . . carriage
DEG. . . . . degrees
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
INC. . . . . incorporated
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PFH. . . . . phillips flat head
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power-take-off
RH. . . . . right hand
ROPS. . . . . roll-over-protection-system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head




Adapter Assembly

Ref	Part No.	Qty.	Description
1	112-1432	1	Adapter ASM
1:2	106-5517	1	Decal-Surface, Hot
2	3272-11	1	Pin-Cotter
3	3256-26	2	Washer-Flat
4	3296-44	1	Nut-Lock, NI
5	283-83	1	Pin-Clevis
6	110-8154	1	Latch ASM
7	323-11	1	Screw-HH
8	110-8116	3	Spacer-Link
9	110-8105	1	Link ASM
10	323-10	1	Screw-HH
11	112-0040-03	1	Handle ASM
12	99-7984	1	Knob-Soft Grip, Push-On
13	3296-25	1	Nut-Lock, NI
14	92-2651	1	Washer
15	112-0038	1	Spacer



Link Assembly No. 110-8105

Ref	Part No.	Qty.	Description
1	110-8111-01	1	Yoke ASM
2	110-8110	1	Spacer
3	110-8114	1	Washer
4	66-7230	1	Spring-Compression
5	3256-3	3	Washer-Flat
6	3211-12	1	Screw-HH
7	3220-3	2	Nut-Hex, Jam
8	92-7008	2	End-Rod, Female
9	110-8108	1	Rod-Link
10	32128-12	1	Nut-Lock, Flange



Box Assembly

Ref	Part No.	Qty.	Description
1	108-2928-01	1	Box ASM
2	3230-2	4	Bolt-CARR
3	3290-355	2	Pin-Hair
4	104-8300	4	Nut-Flange, NI
5	110-1376	2	Pivot Pin ASM
6	323-13	15	Screw-HH
7	110-0259-03	15	Tine-Scarifier
8	104-8301	27	Nut-Flange, NI
9	283-60	2	Pin-Clevis
10	3231-25	4	Screw-CARR
11	23-2790-01	1	Blade-Scraper
12	110-1395-03	1	Tool Bar ASM
14	23-2770	2	Rod-Actuating
15	23-2740	2	Pin-Actuating
16	108-2288-01	2	Support-Spring
17	20-9420-01	2	Comp Spring
18	112-1400	2	Pivot ASM
18:2	95-3577	2	Bushing
19	3256-7	2	Washer-Flat
20	3296-53	2	Nut-Lock, NI
21	62-7400	1	Decal
22	323-6	8	Screw-HH
23	3256-24	12	Washer-Flat

Attachments and Accessories

For 08754 - Finish Grader, Sand/Infield Pro 3040 and 5040 Traction Unit

Product Name	Model/Part
Tine-Weeder	110-0260-03
Carbide Tine ASM	110-0266-03

NOTES


TORO®