Form Number 3354-437 Rev A

Mid-Size ProLine

T-Bar, Gear Drive
13 HP with 32in Side Discharge Mower

Model No. 30316 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2005
All Rights Reserved

Register your product at www.Toro.com

Contents

Description	Page
Fuel Tank and Idler Bracket Assembly	3
Transmission and Idler Pulley Assembly	4
Brake, Wheel Pulley and Wheel Assembly	5
Handle and Control Panel Assembly	6
Engine Assembly	7
Carrier Assembly	8
Deck Assembly	9
Spindle and Blade Assembly	10
Decal and Mulcher Cover Assembly	11
Crankshaft Assembly Kohler CV13T 21540	12
Crankcase Assembly Kohler CV13T 21540	13
Oil Pan and Lubrication Assembly Kohler CV13T 21540	14
Head, Valve and Breather Assembly Kohler CV13T 21540	15
Ignition and Electrical Assembly Kohler CV13T 21540	16
Blower Housing and Baffle Assembly Kohler CV13T 21540	17
Starting System Assembly Kohler CV13T 21540	18
Fuel System Assembly Kohler CV13T 21540	19
Engine Control Assembly Kohler CV13T 21540	20
Air Intake and Filtration Assembly Kohler CV13T 21540	21
Exhaust Assembly Kohler CV13T 21540	22

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR	as required
ASM	assembly
BBC	blade brake clutch
CARR	carriage
DEG	degrees
EXT	external
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HHFTF	hex head flange thread forming
HJ	hex jam
HLH	hex lag head
HOC	height-of-cut
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming
HYD	hydraulic
INC	incorporated
LH	left hand
NI	nylon insert
NPTF	national pipe thread fine
PFH	phillips flat head
PPH	phillips pan head
PPHTF	phillips pan head thread forming
PRH	phillips round head
PTH	phillips truss head
PTO	power-take-off
RH	right hand
ROPS	roll-over-protection-system
SFH	slotted fillister head
SHH	slotted hex head
SHWH	slotted hex washer head
SPH	slotted pan head
SQH	square head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	torx truss head

Footnotes

❶ Not illustrated

❷ Not serviced separately


❸ Obtain from your local Kohler dealer



Fuel Tank and Idler Bracket Assembly

Ref	Part No.	Qty.	Description
1	88-3980	1	Gas Cap ASM
1:3	88-4010	1	Gasket-Cap, Gas
2	106-0730	1	Fuel Tank ASM
2:2	103-2605	1	Fitting-Fuel, Bulkhead
5	3296-39	8	Nut-Lock, NI
6	74-0040	4	Spacer-Pivot, Idler
7	51-4370	1	Spring-Torsion, RH
8	51-4380	1	Spring-Torsion, LH
9	32103-25	2	Nut-Wing
10	3256-23	10	Washer-Flat
11	52-2890	2	Bushing-Nylon
12	3290-307	4	Pin-Hair
13	74-0230-01	1	Bracket-Idler, RH
14	74-0220-01	1	Bracket-Idler, LH
15	74-0521	2	Fitting-Rod
16	283-6	2	Pin-Clevis
17	67-6370-01	1	Bracket-Support, RH
18	67-6380-01	1	Bracket-Support, LH
19	323-16	2	Screw-HH
20	323-6	6	Screw-HH
21	3296-23	2	Nut-Lock, NI
22	95-2800	2	Pulley-Idler
23	95-2801	2	Spacer-Pulley
24	51-4450	2	Screw-Leveler


Ref	Part No.	Qty.	Description
25	68-9690	2	Fitting-Rod
26	237-124	1	Grommet
29	105-4670-01	1	Frame ASM
30	322-4	4	Screw-HH
31	3253-4	2	Washer-Lock
33	95-2814	1	Decal-Shut Off, Fuel
34	106-0649-01	1	Frame-Upper
36	98-0776	1	Decal-Caution
37	104-8121	2	Stud-Threaded
38	1-633349	2	Spring-Tank, Fuel
39	3296-47	2	Nut-Lock, NI



Transmission and Idler Pulley Assembly

Ref	Part No.	Qty.	Description
1	98-3274-03	1	Lever-Shift
2	47-1970	1	Grip
3	3296-42	4	Nut-Lock, NI
4	32120-64	1	Ring-Snap, External
5	1-323252	2	Bearing-Shaft
6	321-4	4	Screw-HH
7	104-1102	2	Shaft-Output
9	3257-5	3	Key-Woodruff
10	3245-3	2	Screw-Set, Hs
11	105-2698	2	Pulley-Transmission
12	51-4220	2	Guard-Coupler
13	1-323680	2	Coupler
14	302-5	2	Fitting-Grease
15	3245-1	1	Screw-Set, HSH
16	51-4190	1	Pulley-Driven
17	26-9671	1	V-Belt
18	323-9	1	Screw-HH
19	51-4810	1	Pulley-Idler
20	3256-24	1	Washer-Flat
21	32128-21	1	Nut-HF
22	322-2	4	Screw-HH
23	3253-4	4	Washer-Lock
24	1-323500	1	Transmission
25	3296-6	1	Nut-Lock


Ref	Part No.	Qty.	Description
26	98-5975	1	Washer-Belleville
27	1-323379	1	Washer
28	32151-62	2	Ring-Retaining
29	3256-24	1	Washer-Flat
30	1-323254	2	Flange-Output
31	95-1526	1	Shield-Trailing
32	95-1529	1	Rod-Shield
33	104-8102-01	1	Plate-Gate, Shift
34	98-3256	1	Decal-Speed, Ground



Brake, Wheel Pulley and Wheel Assembly

Ref	Part No.	Qty.	Description
1	51-4580	2	Rod-Brake
2	3290-307	2	Pin-Hair
3	67-6400-01	1	Arm-Brake, RH
4	67-6420-01	1	Arm-Brake, LH
5	32151-40	2	Ring-Retaining
6	32151-56	2	Ring-Retaining, External
7	51-4660-01	2	Plate-Link, Brake
8	51-4650-01	2	Link-Brake
9	93-1163	2	Wheel And Tire ASM
9:1	231-94	1	Tire-Front
9:2	93-1181	1	Wheel ASM
9:3	92-1746	2	Bearing-Ball
9:4	302-57	1	Fitting-Grease
9:5	232-27	1	Stem-Valve
10	10-8110	8	Washer-Thrust
11	32151-91	2	Ring-Retaining
12	51-4291	2	V-Belt
13	51-4170	8	Spacer-Pulley
14	51-4160-03	4	Pulley-Wheel
15	51-4180-03	2	Drum-Brake
16	3253-4	8	Washer-Lock
17	51-4700	2	Band-Brake
18	322-7	8	Screw-HH
19	51-4230	2	Washer-Wheel


Ref	Part No.	Qty.	Description
20	32151-72	4	Ring-Retaining



Handle and Control Panel Assembly

Ref	Part No.	Qty.	Description
1	82-7690-03	1	Bar-Control
2	82-2290	1	Decal
3	3296-2	5	Nut-Lock
4	82-7680-03	1	Bail ASM
5	32105-1	1	Screw-SHH
6	106-5477-03	1	Control Pivot ASM
7	82-2280	1	Decal
8	3272-11	2	Pin-Cotter
9	105-3158-03	1	Upper Handle ASM
11	104-8140	1	Switch-PTO
12	63-8360	2	Key-Ignition
14	3296-42	1	Nut-Lock, NI
16	93-1187-03	1	Panel-Bottom
17	104-8141	1	Module-Delay
18	321-2	1	Screw-HH
19	283-55	2	Pin-Clevis
21	74-0630	1	Control-Throttle
23	29-5560	1	Switch-On / Off
23:1	218-461	1	Nut-HH
23:2	3254-5	1	Washer-Tooth
24	3290-378	2	Tie-Cable
25	104-8136	1	Harness-Wire
26	2412-120	2	R-Clamp
27	32104-76	4	Screw


Ref	Part No.	Qty.	Description
28	104-8177-03	1	Panel-Control
29	104-7050	1	Housing-Manual
30	32128-21	4	Nut-HF
31	3234-11	4	Screw-HHF
32	32105-14	4	Screw-SHH
33	106-5499	1	Decal-Control Panel
34	105-0884	1	Decal-Danger
35	82-7632	2	Rod-Control
36	218-595	1	Connector-Body
37	51-4850-03	1	Lever-Brake, Parking
38	52-2010	1	Decal-Lever, Parking
39	82-2190	1	Switch-Bail
40	3290-307	2	Pin-Hair
41	237-141	2	Grommet-Rubber
42	98-4387	1	Decal-Protection, Ear
43	104-7048	1	Cap-Housing



Engine Assembly

Ref	Part No.	Qty.	Description
❷❸1		1	Engine-Kohler, Cv13T-Ps-21540
2	32144-19	1	Screw-SHWH
3	2412-87	1	Clamp-Cable
4	56-6360	1	Filter-Fuel
5	2412-98	5	Clamp
6	110-4894	1	Hose-Fuel
7	2412-108	1	Clamp-Worm
8	12-3270	1	Screw
9	3255-7	1	Washer-Lock / EXT
10	3256-23	5	Washer-Flat
11	3253-4	2	Washer-Lock
12	33114-025	4	Screw-HH
13	1-633543-03	1	Strap-Clutch, Brake
14	74-0930-01	1	Guard-Pulley
15	3212-9	1	Screw-HH
16	107-4136	1	Washer
17	105-2635	1	Clutch / Brake
18	608006	1	Key-Square
19	107-4112	1	Pulley-Drive
20	322-7	1	Screw-HH
21	93-7034	2	Nut-Muffler
22	93-7032	1	Gasket-Exhaust
24	1-613235	4	Washer
25	95-5517	1	Muffler


Ref	Part No.	Qty.	Description
26	74-0950	2	Elbow-Street, 90 DEG
27	289-20	1	Nipple-Pipe
28	288-4	1	Cap-Pipe
29	106-0699	1	Decal-Warning, Hot Surfaces
30	109-0678	1	Hose-Fuel
31	1-603770	1	Valve-Fuel
32	3255-8	1	Washer-Lock
33	1-633545	2	Spacer
34	1-633630	2	Grommet-Brake
35	32128-20	2	Nut-HF
36	322-11	1	Screw-HH
37	104-6373	1	Tube-Retainer
38	1-603610	2	Washer-Spring
39	33104-025	1	Screw-HHF



Carrier Assembly


Ref	Part No.	Qty.	Description
1	74-0080	1	Carrier Frame ASM
2	94-1291	4	Bushing
3	74-0330	4	Pad-Rubber
4	3269-24	16	Rivet
5	32151-91	2	Ring-Retaining
6	3-6781	4	Washer-Thrust
7	93-1166	2	Spacer-Castor
8	325-18	2	Screw-HH
9	67-6220	2	Spanner
10	93-1164-01	2	Fork-Caster ASM
11	32153-5	2	Nut-Lock, Side
12	63-8400	2	Caster Wheel ASM
12:1	62-5580	2	Bearing-Outside
12:2	63-8580	1	Bearing-Roller
12:3	302-40	1	Fitting-Grease
13	67-6570	4	Spacer-Wheel
14	302-5	2	Fitting-Grease
15	256-156	2	Bushing-Flange
16	74-0290	2	Spring
17	41-8440	2	Washer
18	3218-5	4	Nut-Jam
19	74-0310	2	Shaft-Adjusting
20	3296-45	2	Nut-Lock, NI
21	3234-6	6	Screw-HHF

Ref	Part No.	Qty.	Description
22	32128-23	6	Nut-HF




Deck Assembly

Ref	Part No.	Qty.	Description
❷1		1	Deck ASM
❷2		1	Spindle ASM
5	32153-2	1	Nut-Lock, Side
6	28-8010	1	Spring
7	44-5930	1	Deflector ASM
7:2	54-9220	1	Decal-Danger
8	28-7350	1	Post-Pivot
9	67-6180	1	Strip-Magnetic
10	3234-29	2	Screw-HHF
11	67-6160-01	1	Cover
12	104-8587	1	Knob
13	3256-24	1	Washer-Flat
14	32151-72	1	Ring-Retaining
15	74-0570	1	Guide-Belt
16	3290-355	4	Pin-Hair
17	67-6140	2	Rod-Support
18	3296-29	24	Nut-Lock, NI
19	322-4	24	Screw-HH
20	92-5419-03	4	Ring-Recycler
21	3290-496	2	Nut-Retainer
22	80-2630-03	4	Kicker
23	67-6920	1	V-Belt




Spindle and Blade Assembly

Ref	Part No.	Qty.	Description
1	104-6325	2	Bearing
2	32146-20	1	Nut-Jam
3	3253-23	1	Washer-Lock/Sp
4	51-4060	1	Screw-Blade
5	67-6060	1	Housing-Spindle
6	67-6070	1	Spacer-Bearing
7	67-6080	1	Spacer
8	92-6313	1	Cup-Anti Scalp
9	106-0776	1	Washer-Pinion
10	74-0580	1	Pulley ASM
11	80-4430-03	1	Blade-Recycler
12	82-4750-03	1	Blade Spacer
13	105-4607-03	1	Spindle Shaft ASM




Decal and Mulcher Cover Assembly

Ref	Part No.	Qty.	Description
1	66-1340	1	Decal-Danger
2	67-5360	1	Decal-Danger
3	105-2625	1	Decal-STD, Safety
4	68-8340	1	Decal-Torque
5	93-1159	1	Decal-HOC
6	106-0719	1	Decal
7	67-6170	1	Decal
8	54-0910	1	Decal-Hot
9	66-6380	1	Decal-Danger
10	92-5422	1	Mulcher Cover ASM
10:1	28-8070	1	Lanyard
10:2	28-8130	1	Pin-Locking, Chute
10:3	3256-49	1	Washer-Flat
10:4	3290-282	1	Rivet-Pop
11	322-11	1	Screw-HH
12	3256-23	2	Washer-Flat
13	3296-29	1	Nut-Lock, NI



Crankshaft Assembly
Kohler CV13T 21540


Ref	Part No.	Qty.	Description
❸1	12 014 30-S	1	Crankshaft (Incl. Ref. #2)
❸2	12 139 01-S	1	Plug-Cup



Crankcase Assembly
Kohler CV13T 21540


Ref	Part No.	Qty.	Description
❸1	12 032 03-S	1	Seal-Oil
❷❸2		1	Crankcase (Use: Short Block 12 522 33)
❸3	12 445 02-S	1	Strap-Lifting
❸4	M-839025-S	1	Screw-HF (M8X1.25X25)
❸5	24 380 13-S	4	Pin-Locating
❸6	12 755 49-S	1	Camshaft Kit (Incl. Ref. #7 And 8)
❸7	12 089 37-S	1	Spring-Actuating
❸8	12 422 08-S	1	Shim-Camshaft, Blue
❸8	12 422 09-S	1	Shim-Camshaft, Red
❸8	12 422 10-S	1	Shim-Camshaft, Yellow
❸8	12 422 11-S	1	Shim-Camshaft, Green
❸8	12 422 12-S	1	Shim-Camshaft, Gray
❸8	12 422 13-S	1	Shim-Camshaft, Black
❸8	12 422 07-S	1	Shim-Camshaft, White
❸9	12 144 27-S	1	Shaft-Balance
❸10	12 874 01-S	1	Piston W/Ring Set (STD) (Incl. Ref. #11 And 12)
❸10	12 874 10-S	1	Piston W/Ring Set (.08)
❸10	12 874 02-S	1	Piston W/Ring Set (.25)
❸10	12 874 03-S	1	Piston W/Ring Set (.50)
❸11	12 018 02-S	2	Retainer-Pin, Piston
❸12	12 108 01-S	1	Ring Set (STD And .08)
❸12	12 108 02-S	1	Ring Set (.25)

Ref	Part No.	Qty.	Description
❸12	12 108 03-S	1	Ring Set (.50)
❸13	12 067 05-S	1	Rod-Connecting (STD)
❸13	12 067 06-S	1	Rod-Connecting (.25)
❸14	12 380 01-S	1	Pin-Regulating, Governor
❸15	12 043 05-S	1	Gear-Governor
❸16	M-631005-S	1	Washer-Plain (6Mm)
❸17	12 144 02-S	1	Shaft-Gear, Governor
❸18	52 139 09-S	1	Plug-Cup
❸19	12 755 64-S	1	Governor Cross Shaft Kit (Includes 20)
❸20	12 154 05-S	1	Clip-Pin, Hitch
❸21	X-25-102-S	1	Washer-Plain (1/4In)
❸22	12 032 01-S	1	Seal-Cross Shaft, Governor
❸23	M-631015-S	1	Washer-Plain (6Mm)



Oil Pan and Lubrication Assembly
Kohler CV13T 21540


Ref	Part No.	Qty.	Description
❸1	12 038 01-S	1	Dipstick ASM (Incl. Ref. #2 And 3)
❸2	25 755 13-S	1	Oil Fill Cap ASM (Incl. Ref. #3)
❸3	25 153 02-S	1	O-Ring (Dipstick)
❸4	12 153 02-S	1	O-Ring (Upper Oil Fill Tube)
❸5	12 123 04-S	1	Tube-Fill, Oil
❸6	M-545020-S	1	Screw-HF (M5X0.8X20)
❸7	12 153 01-S	1	O-Ring (Lower Oil Fill Tube)
❸8	25 162 07-S	1	Screen-Pickup, Oil
❸9	12 096 03-S	1	Cover-Screen, Oil Pickup
❸10	M-545016-S	1	Screw-HF (M5X0.8X16)
❸11	12 050 01-S	1	Filter-Oil
❸12	12 199 50-S	1	Oil Pan ASM (Incl. Ref. #13, 16-19)
❸13	25 462 09-S	1	Valve-Relief, Oil Pressure
❸14	25 139 57-S	2	Plug-SQH (3/8In NPTF)
❸15	25 139 52-S	1	Plug-Pipe (1/8In)
❸16	M-545016-S	3	Screw-HF (M5X0.8X16)
❸17	12 096 34-S	1	Cover-Pump, Oil
❸18	12 153 06-S	1	O-Ring (Oil Pump Cover)
❸19	12 393 01-S	1	Oil Pump ASM
❸20	12 032 03-S	1	Seal-Oil (PTO End)
❸21	24 086 16-S	10	Screw-HF (M8X1.25X45)
❸22	24 086 17-S	1	Screw-HF (M8X1.25X45)



Head, Valve and Breather Assembly
Kohler CV13T 21540

Ref	Part No.	Qty.	Description
❸1	25 351 01-S	2	Lifter-Valve
❸2	12 755 81-S	1	Cylinder Head Kit (Incl. Ref. #3-18, Carburetor Gasket 12 041 01-S (2), Air Cleaner Base Gasket 12 041 02-S, Exhaust Manifold Gasket 12 041 03-S)
❸3	12 411 04-S	2	Rod-Push
❸4	12 041 08-S	1	Gasket-Head, Cylinder
❸5	12 017 01-S	1	Valve-Intake (STD)
❸6	12 016 01-S	1	Valve-Exhaust (STD)
❸7	12 318 19-S	1	Head-Cylinder
❸8	12 146 22-S	2	Plate-Guide
❸9	25 072 12-S	2	Stud-Rocker
❸10	25 186 01-S	2	Arm-Rocker
❸11	24 599 01-S	2	Pivot-Arm, Rocker
❸12	25 100 29-S	2	Nut-Hex
❸13	25 086 112-S	2	Screw-Set
❸14	66 032 05-S	2	Seal-Stem, Valve
❸15	12 089 34-S	2	Spring-Valve
❸16	12 173 01-S	2	Cap-Spring, Valve
❸17	12 755 03-S	2	Retainer Kit
❸18	12 468 05-S	1	Washer-Plain (13/32In)
❸19	12 112 13-S	1	Spacer-Head Bolt (Exhaust Port)
❸20	20 086 02-S	5	Screw-HF (M10X1.5X81)
❸21	12 326 18-S	1	Hose-Breather


Ref	Part No.	Qty.	Description
❸22	25 237 14-S	1	Clamp
❸23	M-645016-S	3	Screw-HF (M6X1.0X16)
❸24	12 096 47-S	1	Cover-Valve
❸25	M-545010-S	1	Screw-HF (M5X0.8X10)
❸26	66 018 04-S	1	Retainer-Reed, Breather
❸27	12 402 02-S	1	Reed-Breather
❶❸	12 017 02-S	1	Valve-Intake (.25)
❶❸	12 016 02-S	1	Valve-Exhaust (.25)
❶❸	12 041 01-S	1	Gasket-Carburetor
❶❸	12 041 02-S	1	Gasket-Cleaner, Air
❶❸	12 041 03-S	1	Gasket-Manifold, Exhaust



Ignition and Electrical Assembly
Kohler CV13T 21540


Ref	Part No.	Qty.	Description
❸1	12 086 14-S	1	Screw-HF (M10X1.5X46)
❸2	12 468 03-S	1	Washer-Plain (3/8In)
❸3	24 162 03-S	1	Screen-Grass
❸4	25 086 47-S	4	Bolt-Shoulder (M6X1.0X16)
❸5	12 157 03-S	1	Fan
❸6	X-42-15-S	1	Key
❸7	12 025 53-S	1	Flywheel
❸8	12 403 01-S	1	Rectifier-Regulator
❸9	M-639016-S	2	Screw-HF (M6X1.0X16)
❸10	236602-S	1	Connector
❸11	41 155 03-S	1	Connector
❸12	M-548025-S	2	Screw (M5X0.8X25)
❸13	237878-S	1	Stator Kit (Includes 25 452 01-S)
❸14	12 132 02-S	1	Spark Plug
❸15	X-728-1-S	2	Clip
❸16	M-545010-S	2	Screw-HF (M5X0.8X10)
❸17	12 584 05-S	1	Module-Ignition
❸18	M-545020-S	2	Screw-HF (M5X0.8X20)
❶❸	X-25-5-S	1	Washer-Steel
❶❸	12 126 96-S	1	Bracket-Strap, Ground
❶❸	12 518 01-S	1	Lead-White (19In - 18 Gauge-Fully Insulated Female Terminal And Uninsulated Female Terminal)


Ref	Part No.	Qty.	Description
❶❸	25 518 05-S	1	Lead-Red (20In - 18 Gauge-Uninsulated Female Terminals)
❶❸	25 452 01-S	2	Terminal



Blower Housing and Baffle Assembly
Kohler CV13T 21540


Ref	Part No.	Qty.	Description
❸1	M-545010-S	8	Screw-HF (M5X0.8X10)
❸2	12 146 07-S	1	Plate-Housing, Blower
❸3	M-550010-S	6	Screw-HF (M5X0.8X10)
❸4	12 096 29-S	1	Cover-Starter
❸5	12 027 68-S	1	Housing-Blower
❸6	12 063 10-S	1	Baffle-Side, Intake
❸7	M-561016-S	1	Screw
❸8	12 313 03-S	1	Grommet-Spark Plug
❸9	12 063 08-S	1	Baffle-Head, Cylinder
❸10	12 063 19-S	1	Baffle-Cylinder
❶❸	12 113 124-S	1	Decal-15Hp
❶❸	25 113 39-S	1	Decal-Lamination, Clear






Starting System Assembly
Kohler CV13T 21540

Ref	Part No.	Qty.	Description
❸1	M-550010-S	5	Screw-HF (M5X0.8X10)
❸2	12 165 01-S	1	Retractable Starter ASM (Incl. Ref. #3 And 9)
❸3	12 081 01-S	1	Housing-Starter
❸4	25 166 01-S	1	Handle-Start, Recoil
❸5	12 160 01-S	1	Rope-Starter
❸6	12 089 06-S	1	Spring And Keeper
❸7	12 093 01-S	1	Pulley
❸8	12 757 06-S	1	Dog Repair Kit
❸9	41 086 09-S	1	Screw-Pozi Driv
❸10	15 109 01-S	1	Cup-Drive
❶❸	12 113 07-S	1	Decal-Starting




Fuel System Assembly
Kohler CV13T 21540

Ref	Part No.	Qty.	Description
❸1	M-641060-S	2	Nut-HF
❸2	M-629116-S	2	Stud (M6X1.0X116)
❸3	12 853 140-S	1	Carburetor Kit (Incl. Ref. #4, 5 [qty 1])
❸4	12 041 02-S	1	Gasket-Cleaner, Air
❸5	12 041 01-S	2	Gasket-Carburetor
❸6	12 265 04-S	1	Deflector-Heat
❸7	47 154 01-S	1	Clip-Cable
❶❸	12 757 02-S	1	Float Kit
❶❸	12 757 03-S	1	Carburetor Repair Kit
❶❸	12 757 08-S	1	Choke Repair Kit
❶❸	12 757 36-S	1	Throttle Shaft Bearing Kit
❶❸	12 757 37-S	1	Bowl Replacement Kit
❶❸	12 755 92-S	1	High Altitude Kit




Engine Control Assembly
Kohler CV13T 21540

Ref	Part No.	Qty.	Description
❸1	M-664020-S	2	Screw-Socket, Lobed (M6X1.0X20)
❸2	M-545016-S	1	Screw-HF (M5X0.8X16)
❸3	12 237 01-S	1	Clamp-Cable
❸4	12 536 01-S	1	Speed Control ASM (Incl. Ref. #5-7)
❸5	12 086 39-S	1	Screw-Pan Head (W/Loctite)
❸6	12 089 11-S	1	Spring-Control, Speed
❸7	12 089 23-S	1	Spring-Return, Choke
❸8	12 089 19-S	1	Spring-Governor
❸9	12 755 83-S	1	Governor Lever Kit (Incl. Ref. #10-12)
❸10	12 100 07-S	1	Nut-HF
❸11	52 211 04-S	1	Screw
❸12	12 090 28-S	1	Lever-Governor
❸13	25 158 08-S	1	Bushing-Retaining, Linkage
❸14	12 079 01-S	1	Linkage-Throttle
❸15	25 158 11-S	1	Bushing-Linkage
❸16	12 079 07-S	1	Linkage-Choke



Air Intake and Filtration Assembly
Kohler CV13T 21540

Ref	Part No.	Qty.	Description
❸1	12 743 04-S	1	Air Cleaner Kit (Incl. Ref. #2-11)
❸2	25 341 04-S	1	Knob-Cover
❸3	12 096 44-S	1	Cover-Cleaner, Air
❸4	12 083 12-S	1	Element-Precleaner
❸5	12 083 10-S	1	Element-Cleaner, Air (Incl. Ref. #6)
❸6	12 100 01-S	1	Nut-Wing
❸7	12 032 11-S	1	Seal
❸8	12 072 04-S	1	Stud
❸9	12 086 01-S	2	Screw
❸10	12 094 14-S	1	Base-Cleaner, Air
❸11	12 041 02-S	1	Gasket-Cleaner, Air
❶❸	12 113 04-S	1	Decal-Cleaner, Air



Exhaust Assembly
Kohler CV13T 21540

Ref	Part No.	Qty.	Description
❸1	12 068 35-S	1	Muffler
❸2	25 072 04-S	2	Stud (M8X1.25X33)
❸3	12 755 30-S	1	Bracket-Kit (Incl. Ref. #4-9)
❸4	M-650012-S	2	Screw-HF (M6X1.0X12)
❸5	X-25-52-S	2	Washer
❸6	12 041 03-S	1	Gasket-Manifold, Exhaust
❸7	12 126 55-S	1	Bracket-Muffler
❸8	12 468 01-S	1	Washer
❸9	12 086 13-S	1	Screw-HF (M8X1.25X 50)
❸10	M-841080-S	1	Nut-HF (M8X1.25)
❸11	12 126 87-S	1	Bracket-Strap, Lifting
❸12	M-645020-S	2	Screw-HF (M6X1.0X20)
❶❸	12 522 33	1	Shortblock
❶❸	12 755 93-S	1	Gasket Set

NOTES


TORO®