



Mid-Size ProLine T-Bar, Gear Drive, 15 HP with 44in Side Discharge Mower

Model No. 30318 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Engine Installation Assembly	 3	Oil Pan / Lubrication Assembly Kohler CV15T-41629	 19
Fuel Tank Assembly	 4	Head / Valve / Breather Assembly Kohler CV15T-41629	 20
Lower Control Assembly	 5	Ignition / Electrical Assembly Kohler CV15T-41629	 21
Transmission Drive Assembly	 6	Blower Housing and Baffle Assembly Kohler CV15T-41629	 22
Wheel Drive and Brake Assembly	 7	Starting System Assembly Kohler CV15T-41629	 23
Upper Handle Assembly	 8	Fuel System Assembly Kohler CV15T-41629	 24
Control Panel Assembly	 9	Engine Control Assembly Kohler CV15T-41629	 25
Carrier Frame Assembly	 10	Air Intake / Filtration Assembly Kohler CV15T-41629	 26
Spindle, Pulley and Belt Assembly	 11	Exhaust Assembly Kohler CV15T-41629	 27
Spindle Assembly No. 106-0786	 12	Attachments and Accessories List	 28
Spindle Assembly No. 106-0784	 13		
Belt Cover, Deflector and Roller Assembly	 14		
Deflector Assembly No. 107-4194	 15		
Drive Belt and Tensioner Assembly	 16		
Crankshaft Assembly Kohler CV15T-41629	 17		
Crankcase Assembly Kohler CV15T-41629	 18		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	INC. incorporated
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HF. hex flange	PTH. phillips truss head
HH. hex head	PTO. power-take-off
HHF. hex head flange	RH. right hand
HHFTF. hex head flange thread forming	ROPS. roll-over-protection-system
HJ. hex jam	SFH. slotted fillister head
HLH. hex lag head	SHH. slotted hex head
HOC. height-of-cut	SHWH. slotted hex washer head
HSBH. hex socket button head	SPH. slotted pan head
HSFH. hex socket flat head	SQH. square head
HSH. hex socket head	SRH. slotted round head
HWH. hex washer head	STD. standard
HWHTF. hex washer head thread forming	TAP. self tapping
HYD. hydraulic	TTH. torx truss head

Footnotes


- ❶ Not illustrated
- ❷ Not serviced separately
- ❸ Obtain from your local Kohler dealer



Engine Installation Assembly


Ref	Part No.	Qty.	Description
1	92-6877	1	Valve-Drain, Oil
2	1-603610	2	Washer-Spring
3	106-0699	1	Decal-Warning, Hot Surfaces
4	106-0699	1	Engine-Kohler, Cv15T-41629
5	32144-19	1	Screw-SHWH
6	2412-87	1	Clamp-Cable
7	2412-98	2	Clamp
8	110-4894	1	Hose-Fuel
9	104-8136	1	Harness-Wire
10	33104-025	1	Screw-HHF
11	3255-8	1	Washer-Lock
12	32128-20	2	Nut-HF
13	237-124	1	Grommet
14	104-6373	1	Tube-Retainer
15	1-613235	4	Washer
16	1-633630	2	Grommet-Brake
17	1-633545	2	Spacer
18	1-633543-03	1	Strap-Clutch, Brake
19	322-11	1	Screw-HH
20	3256-23	5	Washer-Flat
21	33114-025	4	Screw-HH
23	322-7	1	Screw-HH
24	3212-9	1	Screw-HH
25	107-4136	1	Washer

Ref	Part No.	Qty.	Description
26	105-2635	1	Clutch / Brake
27	107-4112	1	Pulley-Drive
28	608006	1	Key-Square
29	94-5847-01	1	Cover-Pulley
30	56-6360	1	Filter-Fuel
31	2412-134	1	R-Clamp
32	12-3270	1	Screw
99	103-1964	1	Hose-Drain, Oil




Fuel Tank Assembly

Ref	Part No.	Qty.	Description				
1	88-3980	1	Gas Cap ASM				
1:3	88-4010	1	Gasket-Cap, Gas				
2	106-0730	1	Fuel Tank ASM				
2:2	103-2605	1	Fitting-Fuel, Bulkhead				
3	104-8121	2	Stud-Threaded				
6	3256-23	4	Washer-Flat				
7	1-633349	2	Spring-Tank, Fuel				
8	3296-47	2	Nut-Lock, NI				
9	106-0546-01	1	Gear Frame ASM				
10	2412-98	4	Clamp				
11	110-4894	1	Hose-Fuel				
12	1-603770	1	Valve-Fuel				
14	109-0678	1	Hose-Fuel				
15	322-4	2	Screw-HH				
16	3253-4	2	Washer-Lock				
17	95-2814	1	Decal-Shut Off, Fuel				
18	98-0776	1	Decal-Caution				



Lower Control Assembly


Ref	Part No.	Qty.	Description				
1	32103-25	2	Nut-Wing				
2	3256-23	6	Washer-Flat				
3	3290-307	4	Pin-Hair				
4	52-2890	2	Bushing-Nylon				
5	74-0521	2	Fitting-Rod				
6	283-6	2	Pin-Clevis				
7	74-0040	4	Spacer-Pivot, Idler				
8	67-6380-01	1	Bracket-Support, LH				
9	67-6370-01	1	Bracket-Support, RH				
10	323-16	2	Screw-HH				
11	323-6	4	Screw-HH				
12	3296-23	2	Nut-Lock, NI				
13	95-2800	2	Pulley-Idler				
14	95-2801	2	Spacer-Pulley				
15	74-0220-01	1	Bracket-Idler, LH				
16	74-0230-01	1	Bracket-Idler, RH				
17	51-4450	2	Screw-Leveler				
18	68-9690	2	Fitting-Rod				
19	51-4380	1	Spring-Torsion, LH				
20	51-4370	1	Spring-Torsion, RH				
21	3296-39	6	Nut-Lock, NI				
31	3234-32	6	Screw-HHF				
32	32128-23	6	Nut-HF				



Transmission Drive Assembly

Ref	Part No.	Qty.	Description
1	47-1970	1	Grip
2	98-3274-03	1	Lever-Shift
3	3296-6	2	Nut-Lock
4	98-5975	1	Washer-Belleville
5	1-323379	1	Washer
6	1-323500	1	Transmission
7	302-5	2	Fitting-Grease
8	1-323680	2	Coupler
9	51-4220	2	Guard-Coupler
10	1-323254	2	Flange-Output
11	321-4	4	Screw-HH
12	3257-5	3	Key-Woodruff
13	3245-9	2	Screw-Set
14	32151-62	2	Ring-Retaining
15	105-2698	2	Pulley-Transmission
16	104-1102	2	Shaft-Output
17	1-323252	2	Bearing-Shaft
18	95-1529	1	Rod-Shield
19	95-1526	1	Shield-Trailing
20	105-5646	1	Pulley-Driven
21	3245-1	1	Screw-Set, HSH
22	32120-64	1	Ring-Snap, External
23	105-5668	1	V-Belt
24	68-2190	1	Spring


Ref	Part No.	Qty.	Description
25	27-6230	1	Bolt-Wheel
26	323-9	1	Screw-HH
27	16-7509	1	Lever-Idler
27:1	256-155	2	Bushing-Flange
28	62-4540	1	Pulley
29	3296-39	1	Nut-Lock, NI
30	322-2	4	Screw-HH
31	3253-4	4	Washer-Lock
32	3296-42	4	Nut-Lock, NI
33	1-323389-03	2	Bracket-Plate, Shift
34	9264964	4	Screw-HWH, Thread Cut
35	32128-20	2	Nut-HF
36	1-323387-03	1	Plate-Shift
37	3230-1	2	Bolt-CARR
38	98-3256	1	Decal-Speed, Ground



Wheel Drive and Brake Assembly


Ref	Part No.	Qty.	Description
1	32151-72	4	Ring-Retaining
2	32151-56	2	Ring-Retaining, External
3	106-8792	2	Plate-Link, Brake
4	106-8779-01	2	Brake Arm ASM
6	3290-307	2	Pin-Hair
7	51-4580	2	Rod-Brake
8	32151-40	2	Ring-Retaining
9	106-8773	2	Brake Link ASM
10	51-4290	2	V-Belt
12	3296-29	8	Nut-Lock, NI
13	254-94	4	Bearing-Cone, Tapered
14	1-523157	2	Washer-Spacer, 14 GA
15	1-809082	2	Nut-SHH
16	106-0892	2	Wheel And Tire ASM
16:1	104-6322	1	Tire
16:2	106-0893	1	Wheel
16:3	232-27	1	Stem-Valve
17	242-50	8	Nut-Lug
18	241-119	2	Cap-Dust
19	1-413333	2	Hub/Wheel ASM
19:2	254-72	2	Bearing-Cup, Tapered
19:3	302-19	1	Fitting-Grease
19:4	1-633926	4	Stud-Wheel
20	106-5544	2	Pulley-Wheel

Ref	Part No.	Qty.	Description
22	1-323262	2	Band-Brake
23	322-5	8	Screw-HH
24	1-543511	2	Seal-Grease
25	104-1197	2	Spacer-Wheel
26	104-1196-01	1	Axle ASM
27	1-806800	2	Pin-Cotter
28	32128-21	6	Nut-HF
29	3234-11	6	Screw-HHF




Upper Handle Assembly

Ref	Part No.	Qty.	Description				
1	105-4677	2	Rod-Control				
2	3272-4	2	Pin-Cotter				
3	237-141	2	Grommet-Rubber				
4	82-2290	1	Decal				
5	82-7680-03	1	Bail ASM				
6	82-7690-03	1	Bar-Control				
7	82-2280	1	Decal				
8	106-5477-03	1	Control Pivot ASM				
9	3272-11	2	Pin-Cotter				
10	105-3158-03	1	Upper Handle ASM				
11	283-55	2	Pin-Clevis				
12	3290-378	1	Tie-Cable				
13	32128-21	4	Nut-HF				
14	3234-11	4	Screw-HHF				
15	98-4387	1	Decal-Protection, Ear				
16	32105-1	1	Screw-SHH				
17	51-4850-03	1	Lever-Brake, Parking				
18	52-2010	1	Decal-Lever, Parking				
19	3296-2	1	Nut-Lock				
20	218-595	1	Connector-Body				
21	82-2190	1	Switch-Bail				




Control Panel Assembly

Ref	Part No.	Qty.	Description				
1	105-0884	1	Decal-Danger				
2	63-8360	1	Key-Ignition				
3	74-0630	1	Control-Throttle				
4	32104-76	4	Screw				
5	32105-14	4	Screw-SHH				
6	3296-42	1	Nut-Lock, NI				
7	104-8141	1	Module-Delay				
8	93-1187-03	1	Panel-Bottom				
9	321-2	1	Screw-HH				
12	3296-2	4	Nut-Lock				
13	29-5560	1	Switch-On / Off				
13:1	218-461	1	Nut-HH				
13:2	3254-5	1	Washer-Tooth				
14	2412-120	2	R-Clamp				
15	104-7050	1	Housing-Manual				
16	104-8140	1	Switch-PTO				
17	104-8177-03	1	Panel-Control				
18	106-5499	1	Decal-Control Panel				
19	104-7048	1	Cap-Housing				



Carrier Frame Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	106-0707	1	Carrier Frame ASM	19:3	83-4740	1	Bearing
1:2	32148-9	3	Insert-Nut	19:4	62-5580	2	Bearing-Outside
1:3	94-1291	4	Bushing	19:5	100-6452	1	Tire-Tubeless
1:4	302-5	2	Fitting-Grease	20	100-6453	2	Bushing-Spanner
2	106-0537-01	1	Cover	21	325-19	2	Screw-HH
3	106-0719	1	Decal	22	283-71	2	Pin-Lynch
4	240-3	1	Grommet-Rubber	23	3-6781	8	Washer-Thrust
5	106-0565	3	Washer-Rubber	24	106-5503	1	Decal-Service, Hydro (Tbar)
6	106-0887	3	Knob	24	106-5505	1	Decal-Service, Gear (Tbar)
7	12-3270	2	Screw	24	106-5511	1	Decal-Service, Gear (Pistol Grip)
8	105-9389-01	1	Shield-Heat	24	106-5513	1	Decal-Service, Hydro (Pistol Grip)
9	3290-199	2	Nut-Speed				
10	104-1105	4	Spacer-Support, Deck				
11	1-513336	2	Bushing-Deck				
12	321-5	2	Screw-HH				
13	3256-22	2	Washer-Flat				
14	32120-33	2	Ring-Retaining				
15	1-323539	4	Spacer-Drive, Blade				
16	106-0635	2	Decal-HOC				
17	105-3159-01	2	Castor Fork ASM				
18	32153-5	2	Nut-Lock, Side				
19	100-6451	2	Caster Wheel ASM				
19:1	232-27	1	Stem-Valve				
19:2	302-11	1	Fitting-Lube, 45 DEG				



Spindle, Pulley and Belt Assembly


Ref	Part No.	Qty.	Description
1	107-4212	1	Deck ASM
1:2	32148-10	2	Insert-Threaded
1:3	106-5532	1	Decal-Anti Scalp
1:4	66-1340	1	Decal-Danger
1:5	106-0704	1	Decal
1:6	93-1122	1	Decal-Danger
1:7	104-8186	1	Decal-Routing, Belt
1:8	67-5360	3	Decal-Danger
1:9	68-8340	1	Decal-Torque
1:10	43-8480	1	Decal-Danger
2	27-1160	1	V-Belt
3	106-5488	1	Guide-Belt
4	3256-24	3	Washer-Flat
5	32128-13	2	Nut-HF
6	52-4780	2	Rod-Belt
7	32128-10	1	Nut-Lock, HHF
8	322-6	1	Screw-HH
9	3218-2	1	Nut-Jam
10	322-4	11	Screw-HH
11	302-19	1	Fitting-Grease
12	32128-19	1	Nut-HF
13	323-4	1	Screw-HH
14	98-5975	1	Washer-Belleville
15	65-5940	1	Pulley-Idler

Ref	Part No.	Qty.	Description
16	54-2730	1	Spring-Extension
17	104-8110	1	Idler Arm ASM
18	104-8113	1	Tube-Idler
19	52-2860	1	Washer
20	106-0786	2	Spindle Housing ASM
21	32152-1	12	Nut-Lock, Cone
22	54-0010-03	3	Blade
23	51-4060	3	Screw-Blade
24	3253-8	3	Washer-Lock
25	3256-27	3	Washer-Flat
26	3230-2	2	Bolt-CARR
27	20-9530	1	Washer-End
28	323-13	1	Screw-HH
29	3229-4	1	Screw-CARR
30	106-0784	1	Spindle Housing ASM
31	100-3258-03	1	Plate-Blowout, LH
32	12-3270	9	Screw
33	100-3257-03	1	Plate-Blowout, RH
34	1-503033	1	Washer-Retainer, Pulley




Spindle Assembly No. 106-0786

Ref	Part No.	Qty.	Description
1	3219-7	1	Nut-Hex
2	7-4150	1	Washer
3	104-1181	1	Pulley ASM
4	106-0873	1	Shield-Bearing
5	104-6325	2	Bearing
6	106-0818	1	Housing-Spindle
7	106-0794	1	Spacer-Bearing
8	106-0780	1	Shaft-Spindle




Spindle Assembly No. 106-0784

Ref	Part No.	Qty.	Description				
1	3219-7	1	Nut-Hex				
2	7-4150	1	Washer				
3	104-1116	1	Pulley And Hub ASM				
4	106-0873	1	Shield-Bearing				
5	104-6325	2	Bearing				
6	106-0818	1	Housing-Spindle				
7	106-0794	1	Spacer-Bearing				
8	106-0779	1	Shaft-Spindle				




Belt Cover, Deflector and Roller Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	107-4194	1	Deflector ASM	25	98-5967	1	Spacer-Wheel
2	105-4622	1	Spacer	26	322-50	2	Screw-HH
3	104-8554	1	Spring-Torsion				
4	3296-29	3	Nut-Lock, NI				
5	106-3363-01	1	Cover-Belt, RH				
6	106-3362-01	1	Cover-Belt, LH				
7	106-0565	2	Washer-Rubber				
8	106-0887	2	Knob				
9	106-0684	2	Front Pin ASM				
10	3220-3	2	Nut-Hex, Jam				
11	3296-39	4	Nut-Lock, NI				
12	1-613204	2	Balljoint				
13	104-1156	2	Spacer				
14	323-8	2	Screw-HH				
15	106-3365	2	Rear Pin ASM				
16	3290-256	6	Pin-Hair				
17	323-10	2	Screw-HH				
18	32128-20	4	Nut-HF				
19	322-1	4	Screw-HH				
20	3230-30	1	Screw-CARR				
21	106-0563	1	Spacer-Wheel				
22	106-0545	1	Bushing-Roller				
23	1-603299	3	Roller-Scalp, Anti				
24	3256-23	3	Washer-Flat				




Deflector Assembly No. 107-4194

Ref	Part No.	Qty.	Description
1	3231-4	4	Screw-CARR
2	106-3246-01	1	Deflector
3	106-3248-03	1	Strap-Discharge
4	108-5029	1	Deflector-Rubber
5	107-4197-01	1	Bracket-Hinge, Rear
6	107-4196-01	1	Bracket-Hinge, Front
7	3296-39	4	Nut-Lock, NI




Drive Belt and Tensioner Assembly

Ref	Part No.	Qty.	Description				
1	104-8120	1	V-Belt, PTO				
2	3296-39	1	Nut-Lock, NI				
4	52-2860	3	Washer				
5	104-6377	1	Tube-Idler				
6	106-0734	1	Idler Arm ASM				
6:1	1-513034	2	Sleeve-Bearing				
6:2	302-5	1	Fitting-Grease				
7	323-42	1	Screw-HH				
8	323-6	1	Screw-HH				
9	98-5975	1	Washer-Belleville				
10	3256-24	1	Washer-Flat				
11	1-413099	1	Pulley-Idler				
12	105-8443	1	Spring-Extension				



Crankshaft Assembly Kohler CV15T-41629


Ref	Part No.	Qty.	Description
❸1	12 014 30-S	1	Crankshaft (Includes 2)
❸2	12 139 01-S	1	Plug-Cup



Crankcase Assembly Kohler CV15T-41629


Ref	Part No.	Qty.	Description
❶	12 032 03-S	1	Seal-Oil
❷		1	Crankcase (Use: Short Block 12 522 18)
❸	12 445 02-S	1	Strap-Lifting
❹	M-839025-S	1	Screw-HF (M8X1.25X25)
❺	24 380 13-S	4	Pin-Locating
❻	12 067 05-S	1	Rod-Connecting (STD)
❼	12 067 06-S	1	Rod-Connecting (.25)
❽	12 755 49-S	1	Camshaft Kit (Includes 8,9)
❾	12 089 31-S	1	Spring-Actuating
❿	12 422 08-S	1	Shim-Camshaft, Blue
⓫	12 422 09-S	1	Shim-Camshaft, Red
⓬	12 422 10-S	1	Shim-Camshaft, Yellow
⓭	12 422 11-S	1	Shim-Camshaft, Green
⓮	12 422 12-S	1	Shim-Camshaft, Gray
⓯	12 422 13-S	1	Shim-Camshaft, Black
⓰	12 422 07-S	1	Shim-Camshaft, White
❶❶	12 144 27-S	1	Shaft-Balance
❶❷	12 874 07-S	1	Piston W/Ring Set (STD) (Includes 12-13)
⓯	12 874 11-S	1	Piston W/Ring Set (.08)
⓯	12 874 08-S	1	Piston W/Ring Set (.25)
⓯	12 874 09-S	1	Piston W/Ring Set (.50)
❶❸	12 018 02-S	2	Retainer-Pin, Piston

Ref	Part No.	Qty.	Description
❶❸	12 108 07-S	1	Ring Set (STD. And .08)
⓯	12 108 08-S	1	Ring Set (.25)
⓯	12 108 09-S	1	Ring Set (.50)
❶❹	12 380 01-S	1	Pin-Regulating, Governor
❶❺	12 043 05-S	1	Gear-Governor
❶❻	M-631005-S	1	Washer-Plain (6Mm)
❶❼	12 144 02-S	1	Shaft-Gear, Governor
❶❽	52 139 09-S	1	Plug-Cup
❶❾	12 755 64-S	1	Governor Cross Shaft Kit (Includes 23)
❶❶	X-25-102-S	1	Washer-Plain
❶❷	12 032 01-S	1	Seal-Cross Shaft, Governor
❶❸	M-631015-S	1	Washer-Plain
❶❹	12 154 05-S	1	Clip-Pin, Hitch



Oil Pan / Lubrication Assembly Kohler CV15T-41629


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
❶1	12 038 01-S	1	Dipstick ASM (Includes 2-3)	❶23	24 086 17-S	1	Screw-HF (M8X1.25X45)
❶2	25 755 13-S	1	Oil Fill Cap ASM (Includes 3)				
❶3	25 153 02-S	1	O-Ring				
❶4	12 153 02-S	1	O-Ring (Upper Oil Fill Tube)				
❶5	12 123 04-S	1	Tube-Fill, Oil				
❶6	M-545020-S	1	Screw-Flange, Hex (M5X0.8X20)				
❶7	12 153 01-S	1	O-Ring				
❶8	25 162 07-S	1	Screen-Pickup, Oil				
❶9	12 096 03-S	1	Cover-Screen, Oil Pickup				
❶10	M-545016-S	1	Screw-Flange, Hex (Thread Forming, M5X0.8X16)				
❶11	12 050 01-S	1	Filter-Oil				
❶12	12 199 50-S	1	Oil Pan ASM (Includes 13, 17-19)				
❶13	25 462 09-S	1	Valve-Relief, Oil Pressure				
❶14	25 139 57-S	2	Plug-Square Head, Pipe (3/8)				
❶15	25 139 52-S	1	Plug-Pipe (1/8In)				
❶16	25 139 62-S	1	Plug, Pipe 3/8In Hex Ctsk				
❶17	M-545016-S	3	Screw-Flange, Hex (Thread Forming, M5X0.8X16)				
❶18	12 096 34-S	1	Cover-Pump, Oil				
❶19	12 153 06-S	1	O-Ring (Oil Pump Cover)				
❶20	12 393 01-S	1	Oil Pump ASM				
❶21	12 032 03-S	1	Seal-Oil				
❶22	24 086 16-S	10	Screw-HF (M8X1.25X45)				



Head / Valve / Breather Assembly
Kohler CV15T-41629


Ref	Part No.	Qty.	Description
❶1	25 351 01-S	2	Lifter-Valve
❷2	12 411 04-S	2	Rod-Push
❸3	12 041 10-S	1	Gasket-Head, Cylinder
❹4	12 017 01-S	1	Valve-Intake (STD)
❺5	12 016 01-S	1	Valve-Exhaust (STD)
❻6	25 139 60-S	1	Plug-Pipe
❼7	12 318 19-S	1	Head-Cylinder
❽8	12 146 22-S	2	Plate-Guide
❾9	25 072 12-S	2	Stud-Rocker
❿10	25 186 01-S	2	Arm-Rocker
⓫11	12 599 03-S	2	Pivot-Arm, Rocker
⓬12	25 100 29-S	2	Nut-Hex
⓭13	25 086 112-S	2	Screw-Set
⓮14	66 032 05-S	2	Seal-Stem, Valve
⓯15	12 089 34-S	2	Spring-Valve
⓰16	12 173 01-S	2	Cap-Spring, Valve
⓱17	12 755 03-S	2	Retainer Kit
⓲18	12 468 05-S	1	Washer-Flat (1/2)
⓳19	12 112 13-S	1	Spacer-Head Bolt (Exhaust Port)
⓴20	20 086 02-S	5	Screw-Flange, Hex (M10X1.5X37)
⓵21	25 237 14-S	1	Clamp-Hose
⓶22	12 326 18-S	1	Hose-Breather
⓷23	M-645016-S	3	Screw-HF (M6X1.0X16)
⓸24	12 096 47-S	1	Cover-Valve

Ref	Part No.	Qty.	Description
❶25	M-545010-S	1	Screw-HF (M5X0.8X10)
❶26	66 018 04-S	1	Retainer-Reed, Breather
❶27	12 402 02-S	1	Reed-Breather
❶❶	12 017 02-S	1	Valve-Intake (.25)
❶❶	12 016 02-S	1	Valve-Exhaust (.25)
❶❶	12 041 01-S	1	Gasket-Carburetor
❶❶	12 041 02-S	1	Gasket-Base, Air Cleaner
❶❶	12 041 03-S	1	Gasket-Manifold, Exhaust




Ignition / Electrical Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❶1	12 086 14-S	1	Screw-Flange, Hex (M10X1.5X46)				
❷2	12 468 03-S	1	Washer-Flat				
❸3	24 162 03-S	1	Screen-Grass				
❹4	25 086 47-S	4	Bolt-Shoulder (M6X1.0X16)				
❺5	12 157 03-S	1	Fan				
❻6	X-42-15-S	1	Key-Woodruff				
❼7	12 025 56-S	1	Flywheel				
❽8	12 403 01-S	1	Rectifier-Regulator				
❾9	M-639016-S	2	Screw-HF (M6X1.0X16)				
❿10	236602-S	1	Connector-Body (3 Contact)				
❿11	41 155 03-S	1	Connector				
❿12	M-548025-S	2	Screw (M5X0.8X25)				
❿13	237878-S	1	Stator Kit (Includes 25 452 01-S)				
❿14	12 132 02-S	1	Plug-Spark				
❿15	X-728-1-S	2	Clip				
❿16	M-545010-S	2	Screw-HF (M5X0.8X10)				
❿17	12 584 05-S	1	Module-Ignition				
❿18	M-545020-S	2	Screw-Flange, Hex (M5X0.8X20)				
❶❸	X-22-11-S	1	Washer-Lock, Internal Tooth (1/4)				
❶❹	12 518 01-S	1	Lead				
❶❺	25 518 05-S	1	Lead				
❶❻	24 518 12-S	1	Lead-Black				
❶❼	25 452 01-S	1	Terminal				



Blower Housing and Baffle Assembly
Kohler CV15T-41629


Ref	Part No.	Qty.	Description				
❶	M-545010-S	9	Screw-HF (M5X0.8X10)				
❷	12 146 07-S	1	Plate-Housing, Blower				
❸	M-550010-S	6	Screw-HF (M5X0.8X10)				
❹	12 096 29-S	1	Cover-Starter				
❺	12 027 68-S	1	Housing-Blower				
❻	12 063 10-S	1	Baffle-Side, Intake				
❼	12 313 03-S	1	Grommet-Spark Plug				
❽	12 063 08-S	1	Baffle-Head, Cylinder				
❾	12 063 19-S	1	Baffle (Cylinder)				
❿	12 113 124-S	1	Decal-15Hp				
⓫	25 113 39-S	1	Decal-Lamination, Clear				



Starting System Assembly


Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
1	M-550010-S	5	Screw-HF (M5X0.8X10)				
2	12 165 01-S	1	Retractable Starter ASM (Includes 3-9)				
3	12 081 01-S	1	Housing-Starter				
4	25 166 01-S	1	Handle-Start, Recoil				
5	12 160 01-S	1	Rope-Starter				
6	12 089 06-S	1	Spring And Keeper				
7	12 093 01-S	1	Pulley				
8	12 757 06-S	1	Dog Repair Kit				
9	41 086 09-S	1	Screw-Pozi Driv				
10	15 109 01-S	1	Cup-Drive				
11	12 113 07-S	1	Decal-Starting				




Fuel System Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❶1	M-641060-S	2	Nut-Flange, Hex (M6X1.0)				
❷2	M-629116-S	2	Stud (M6X1.0X116)				
❸3	12 853 140-S	1	Carburetor Kit (Includes 4-5)				
❹4	12 041 02-S	1	Gasket-Base, Air Cleaner				
❺5	12 041 01-S	2	Gasket-Carburetor				
❻6	12 265 04-S	1	Deflector-Heat				
❼7	47 154 01-S	1	Clip-Cable				
❶❸	12 757 02-S	1	Float Kit				
❶❸	12 757 03-S	1	Carburetor Repair Kit				
❶❸	12 757 08-S	1	Choke Repair Kit				
❶❸	12 757 36-S	1	Throttle Shaft Bearing Kit				
❶❸	12 757 37-S	1	Bowl Replacement Kit				
❶❸	12 755 92-S	1	High Altitude Kit				




Engine Control Assembly Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❸1	M-664020-S	2	Screw-Socket, 6 Lobed (Thread Forming, M6X1.0X20)				
❸2	M-545016-S	1	Screw-Flange, Hex (Thread Forming, M5X0.8X16)				
❸3	12 237 01-S	1	Clamp-Cable				
❸4	12 536 01-S	1	Speed Control ASM (Includes 5-7)				
❸5	12 086 39-S	1	Screw-Pan Head (W/Loctite)				
❸6	12 089 11-S	1	Spring-Control, Speed				
❸7	12 089 23-S	1	Spring-Return, Choke				
❸8	12 089 19-S	1	Spring-Governor				
❸9	12 755 83-S	1	Governor Lever Kit (Includes 10-12)				
❸10	12 100 07-S	1	Nut-Flange, Hex (1/4-20)				
❸11	52 211 04-S	1	Bolt-Square Neck, Round Head (1/4-20X1)				
❸12	12 090 28-S	1	Lever-Governor				
❸13	25 158 08-S	1	Bushing-Retaining, Linkage				
❸14	12 079 01-S	1	Linkage-Throttle				
❸15	25 158 11-S	1	Bushing-Linkage, Throttle				
❸16	12 079 07-S	1	Linkage-Choke				



Air Intake / Filtration Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❸1	12 743 04-S	1	Air Cleaner Kit (Includes 2-11)				
❸2	20 341 01-S	1	Knob-Cover				
❸3	12 096 44-S	1	Cover-Cleaner, Air				
❸4	12 083 12-S	1	Element-Precleaner				
❸5	12 083 10-S	1	Element-Cleaner, Air (Includes 6-7)				
❸6	12 100 01-S	1	Nut-Wing				
❸7	12 032 11-S	1	Seal				
❸8	12 072 04-S	1	Stud				
❸9	12 086 01-S	2	Screw				
❸10	12 094 14-S	1	Base-Cleaner, Air				
❸11	12 041 02-S	1	Gasket-Base, Air Cleaner				
❶❸	12 113 04-S	1	Decal-Cleaner, Air				



Exhaust Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❶1	12 068 44-S	1	Muffler				
❷2	M-645016-S	2	Screw-HF (M6X1.0X16)				
❸3	X-25-78-S	2	Washer-Plain (1/4In)				
❹4	12 126 71-S	1	Bracket-Muffler				
❺5	12 112 20-S	2	Spacer				
❻6	M-645025-S	2	Screw-HF (M6X1.0X25)				
❼7	25 072 04-S	2	Stud-Exhaust				
❽8	12 041 03-S	1	Gasket-Manifold, Exhaust				
❾9	M-841080-S	2	Nut-HF (M8X1.25)				
❶❶	M-545016-S	1	Screw-Flange, Hex (Thread Forming, M5X0.8X16)				
❶❷	12 522 18	1	Block-Short				
❶❸	12 755 93-S	1	Gasket Set				

Attachments and Accessories

For 30318 - Mid-Size ProLine T-Bar Gear, 15 HP with 44in Side Discharge Mower

Product Name	Model/Part
Atomic Blade	104-1300
Electric Starter Kit	104-8580
Striping Kit	106-3370
Weight Kit	106-5491
Blade-Atomic, 15.5 Inch (6 Pack)	108-1116
Extra High Lift Blade 15.5 Inch (6 Pack)	108-1125
Soft Bag (3 Bushel)	30104
Steel Grass Catcher	30107
Tru Trak Sulky	30110
High Lift Blade	55-4940-03
Recycler Kit	59220
Recycler Blade	92-7952-03
44 Inch Mulching Kit	99-8525

NOTES

NOTES

NOTES

