



## Commercial Side-Discharge Lawnmower

Model No. 22243 - 260000001 and up.

### Parts Catalog

---

#### **Ordering Replacement Parts**

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### **Understanding Reference Numbers**

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### **Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

#### **Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Description	Page	Description	Page
Housing Assembly	..... 3	Air Cleaner Assembly Briggs and Stratton 12W802-1701-B1	..... 12
Gear Case Assembly No. 92-7869	..... 4	Governor Assembly Briggs and Stratton 12W802-1701-B1	..... 13
Gear Case and Wheel Assembly	..... 5	Muffler and Fuel Tank Assembly Briggs and Stratton 12W802-1701-B1	..... 14
Engine, Blade and Fuel Tank Assembly	..... 6	Blower Housing Assembly Briggs and Stratton 12W802-1701-B1	..... 15
Handle Assembly	..... 7	Starter Assembly Briggs and Stratton 12W802- 1701-B1	..... 16
Cylinder Assembly Briggs and Stratton 12W802-1701-B1	..... 8	358 Engine Gasket Set Assembly Briggs and Stratton 12W802-1701-B1	..... 17
Crankshaft Assembly Briggs and Stratton 12W802-1701-B1	..... 9	121 Carburetor Overhaul Kit and 977 Carburetor Gasket Set Briggs and Stratton 12W802-1701-B1	..... 18
Crankcase Assembly Briggs and Stratton 12W802-1701-B1	..... 10		
Carburetor Assembly Briggs and Stratton 12W802-1701-B1	..... 11		


## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. .... as required	INC. .... incorporated
ASM. .... assembly	LH. .... left hand
BBC. .... blade brake clutch	NI. .... nylon insert
CARR. .... carriage	NPTF. .... national pipe thread fine
DEG. .... degrees	PFH. .... phillips flat head
EXT. .... external	PPH. .... phillips pan head
FH. .... flat head	PPHTF. .... phillips pan head thread forming
GA. .... gauge	PRH. .... phillips round head
HF. .... hex flange	PTH. .... phillips truss head
HH. .... hex head	PTO. .... power-take-off
HHF. .... hex head flange	RH. .... right hand
HHFTF. .... hex head flange thread forming	ROPS. .... roll-over-protection-system
HJ. .... hex jam	SFH. .... slotted fillister head
HLH. .... hex lag head	SHH. .... slotted hex head
HOC. .... height-of-cut	SHWH. .... slotted hex washer head
HSBH. .... hex socket button head	SPH. .... slotted pan head
HSFH. .... hex socket flat head	SQH. .... square head
HSH. .... hex socket head	SRH. .... slotted round head
HWH. .... hex washer head	STD. .... standard
HWHTF. .... hex washer head thread forming	TAP. .... self tapping
HYD. .... hydraulic	TTH. .... torx truss head

## Footnotes


- ❶ Not serviced separately
- ❷ Obtain from your local Briggs & Stratton dealer
- ❸ Included in Carburetor Overhaul Kit (Ref. No. 121)
- ❹ Included in Engine Gasket Set (Ref. No. 358)
- ❺ Included in Carburetor Gasket Set (Ref. No. 977)



## Housing Assembly

Ref	Part No.	Qty.	Description
1	92-7869	1	Gear Case ASM
2	46-5551	2	Spacer
3	92-7699-03	1	Bracket-Actuator
4	32144-110	2	Screw-HWH
5	32144-112	2	Screw-HWH
6	98-4493	1	Cover-Drive
7	108-9333	1	Housing ASM
8	603773	2	Nut
9	95-7052	1	Plate-Opening, Chute
10	43-8480	1	Decal-Danger
11	608175	1	Bar-Toe
12	46-6811	2	Screw-HWH
13	92-1008	4	Knob-Lever, Height Adjustment
14	92-7736	1	Shield-Trailing
15	93-7250	1	Decal-Warning
16	92-1006	2	Front Spring Arm ASM
17	3296-39	2	Nut-Lock, NI
18	40-1940	4	Washer
19	95-7403-03	2	Bracket-Height Adjustment, Wheel
20	3290-413	2	Washer-Belleville
21	92-9673	2	Bolt-Shoulder
22	98-8332	1	Knob
23	603567	2	Bolt
24	614677	2	Screw-Sems


Ref	Part No.	Qty.	Description
25	94-1610	3	Nut-Clip
26	108-9397	1	Decal
27	684159	2	Wheel And Tire ASM
28	92-4856	2	Bolt-Shoulder



## Gear Case Assembly No. 92-7869

Ref	Part No.	Qty.	Description
1	60-8770	1	Bushing-Output
2	76-0760	2	Key-Shift
3	65-5250	1	Clip-Spring
4	76-0770	1	Collar-Shift
5	60-8750	2	Bushing
6	36-4791	2	Washer-Thrust
7	104-7668	1	Gear-15T Spur, 37T Bevel
8	55-3780	1	Pinion-20T
9	55-3800	1	Pinion-25T
10	60-8800	1	Shaft-Intermediate
11	60-8850	1	Bushing
12	65-4770	1	Shaft-Output
13	3285-19	1	Pin-Groove
14	60-8790	1	Sleeve-Gear
15	55-3810	1	Gear-39T
16	55-3790	1	Gear-44T
17	55-3770	1	Gear-49T
18	76-0780	1	Sleeve-Key, Shift
19	36-4780	1	Washer
20	100-1048	1	Bearing-Ball
21	3256-24	1	Washer-Flat
22	3296-5	1	Nut-Lock
23	92-5790	1	Pinion
24	100-1176	2	Pulley-Half


Ref	Part No.	Qty.	Description
25	92-5791	1	Spacer
26	60-8810	1	Retainer-Fork, Shift
27	29-9570	1	Bushing-Yoke
28	60-8870	1	Yoke-Shift
29	60-8710	1	Case-Gear, Upper
30	60-8730-03	1	Cover-Case, Gear
31	49-2040	6	Screw-HWHTF



## Gear Case and Wheel Assembly

Ref	Part No.	Qty.	Description
1	92-1057	2	Bolt-Shoulder
2	95-1714	2	Wheel And Gear ASM
2:3		1	8 Inch Wheel ASM
2:3:1	27-6250	2	Bushing
3	65-2720	4	Klipring-Locking
4	65-4740	4	Washer-Thrust, Keyed
5	66-6050	1	Key-Rocking, LH
6	66-6040	1	Key-Rocking, RH
7	65-4710	2	Ring-Friction
8	92-7746	2	Rear Height Adjustment Arm ASM
8:2	70-9760	1	Bushing
8:3	47-2900	1	Bushing
8:4	302-56	1	Fitting-Grease
9	32144-70	1	Screw-HWHTF
10	60-8821	1	Lever-Shift
11	3272-10	1	Pin-Cotter
12	82-8780	1	Clamp-Cable
13	24-7920	1	Cover-Shaft, Drive
14	303259	1	Washer
15	605255	1	Washer
16	92-1043	1	V-Belt
17	92-6535	2	Ring-Isolator
18	32144-85	2	Screw-HWH
19	92-6540	1	LH Rear Spring Arm ASM


Ref	Part No.	Qty.	Description
20	92-6539	1	RH Rear Spring Arm ASM
21	603773	2	Nut
22	65-4730	2	Washer-Arm, Pivot
23	65-4760	2	Washer-Clutch
24	65-4750	2	Gear-Pinion
25	65-4720	2	Spring-Compression
26	94-1609	2	Cover-Wheel
27	614426	2	Washer-Stepped



## Engine, Blade and Fuel Tank Assembly


Ref	Part No.	Qty.	Description
1	105-8579	1	Bolt-Blade
2	92-8626	1	Spacer-Blade
3	100-2899	1	Plate And Collar ASM
4	92-4877	3	Push Nut
5	92-1648	3	Screw-Mount, Engine
6	104-0214	1	Screw-Set
10	98-4497	1	Tank-Fuel
11	609830	2	Spring
12	92-1701	1	Stop-Rope
13	108-9334	1	Decal-Recoil
15		1	Engine-Briggs And Stratton, 12W8021701B1
16	108-9381	1	Gas Cap ASM
17	95-1878	1	Pulley
18	108-9376-03	1	Shield-Grass
19	108-7470	1	Guard-Muffler
20	612543	1	Blade
20	612543-03	1	Blade-20.88 Inch
22	98-4459-03	1	Tank Bracket ASM
23	3296-29	4	Nut-Lock, NI
24	104-7577-03	1	Shield-Muffler
25	32144-1	3	Screw-Taptite
26	32152-2	2	Nut-Lock, Cone
27	110-1824	1	Gas-Line

Ref	Part No.	Qty.	Description
28	2412-98	2	Clamp



## Handle Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	3230-29	2	Screw-CARR	27	3296-29	2	Nut-Lock, NI
2	100-2890-05	1	Handle-Lower	28	3256-23	2	Washer-Flat
3	614249	3	Strap-Tie	29	92-7899-03	1	Bracket-Cable, Traction
4	609739	2	Washer-Curved				
5	322-9	2	Screw-HH				
6	3296-29	2	Nut-Lock, NI				
7	92-9665	4	Screw-Thread Cut				
8	92-1094	1	Bracket-Stop, Bail				
9	3296-73	3	Nut-Lock, NI				
10	108-9390	1	Cable-Traction				
11	107-0757	1	Stop-Pivot				
12	92-1001-03	1	Bail-Control				
13	321-4	1	Screw-HH				
14	613050	1	Bolt				
15	108-9336	1	Decal-Control Panel				
16	108-9391	1	Cable-Ground Speed				
17	108-7519-03	1	Panel-Control				
18	92-1093	1	Bail-Engine Control				
19	108-9337	1	Decal-Panel, Front				
21	100-6368	1	Brake Cable ASM				
22	86-9671	1	Guide-Rope				
24	92-2928	1	Bracket-Anchor, Cable				
25	3296-56	1	Nut-Lock, NI				
26	100-2892-05	1	Handle-Upper				



## Cylinder Assembly Briggs and Stratton 12W802-1701-B1

Ref	Part No.	Qty.	Description
1	697324	1	Cylinder ASM
2	399269	1	Bushing/Seal Kit
3	299819	1	Seal-Oil
4	691160	1	Head-Cylinder
5	692249	1	Gasket-Head, Cylinder
6	695250	1	Breather ASM
7	696125	1	Gasket-Breather
8	691125	1	Screw
9	691781	1	Tube-Breather
10	690912	1	Screw
11	497465	1	Manifold-Intake
12	272199	1	Gasket-Intake
13	691650	1	Screw
14	690450	1	Shield-Cylinder
15	690345	1	Screw
16	697451	1	Plug-Spark
17	89838	1	Wrench-Plug, Spark
18	690272	1	Washer
19	697734	1	Cover-Passage, Breather
20	691879	1	Gasket-Passage, Breather
21	690340	1	Retainer-Shaft, Governor
22	698801	1	Crank-Governor
23	66538	1	Boot-Plug, Spark
24	690345	1	Screw

Ref	Part No.	Qty.	Description
25	690959	1	Pin-Locating
26	691155	1	Seat-Valve (Intake)
27	690380	1	Seat-Valve (Exhaust)
28	262001	1	Bushing-Guide (Exhaust)
29	63709	1	Bushing-Guide (Intake)
30	494256	1	Label Kit
31	275177	1	Manual-Owner's



## Crankshaft Assembly Briggs and Stratton 12W802-1701-B1

Ref	Part No.	Qty.	Description
●16	694079	1	Crankshaft
●24	222698	1	Key
●25	791096	1	Piston ASM
●25	691325	1	Spline-Starter
●26	791098	1	Ring Set
●26	691324	1	Cover-Cleaner, Air
●27	691866	1	Lock-Pin, Piston
●28	499423	1	Pin-Piston (STD)
●28	298908	1	Pin-Piston (.005In Undersize)
●29	499424	1	Rod-Connecting
●32	691664	1	Screw
●32A	695759	1	Screw
●33	262651	1	Valve-Exhaust
●34	262652	1	Valve-Intake
●35	691270	1	Spring-Valve
●36	691270	1	Spring-Valve
●40	692194	1	Retainer-Valve
●45	690548	1	Tappet-Valve
●741	790345	1	Gear-Timing
●868	697338	1	Seal-Valve


--	--	--	--











## Muffler and Fuel Tank Assembly Briggs and Stratton 12W802-1701-B1

Ref	Part No.	Qty.	Description
●81	691740	1	Lock-Screw, Muffler
●187	691050	1	Line-Fuel (Cut To Required Length)
●240	298090	1	Filter
●300	692038	1	Muffler
●601	95162	1	Clamp-Hose
●613	691340	1	Screw









## NOTES

